

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
80C2,80E	X		1664M18G01	Link, Assy Grbx	72-65-10	GE
Boeing	X		332A1200-3	Duct	71-00-04	Boeing
Boeing	X		332A1311-30	Duct	71-00-04	Boeing
Boeing	X		332A1320-1	Duct	71-00-04	Boeing
CF34 8C	X		4118T08G01	Support	72-56-05	GE
CF34 8C, 8E	X		4126T73P02	Seal	72-33-09	GE
CF34-10E	X	X	1846M43G03	Clevis	71-20-04	GE
CF34-10E	X	X	1846M43G04	Clevis	71-20-04	GE
CF34-10E	X		1846M47P01	Bolt	71-20-09	GE
CF34-10E	X	X	1846M55P01	Sleeve, Engine Mount	71-20-13	GE
CF34-10E	X		1846M63P01	Bolt, Shoulder Hex Hd	LMM 71-20-00	GE
CF34-10E	X		1846M64P01	Bolt	71-20-09	GE
CF34-10E	X		1846M66P01	Bolt	LMM 71-20-09	GE
CF34-10E	X	X	1846M67P01	Bolt	71-20-00	GE
CF34-10E	X	X	1865M53P04	Retainer, Blade HPT	72-52-05	GE
CF34-10E	X	X	1865M57P02	Damper Sleeve, HPT Frt Shaft	72-52-06	GE
CF34-10E	X	X	1865M61P03	Ring, Retainer	72-52-10	GE
CF34-10E	X	X	1865M85P02	Sleeve, Damper	72-52-07	GE
CF34-10E	X		1999M77G02	Shaft, Actuator	72-31-05	GE
CF34-10E	X		1999M78P01	Nut	72-31-05	GE
CF34-10E	X	X	2028M41P01	Disk, Stg 3	72-33-05	GE
CF34-10E	X	X	2028M59G01	Support	72-31-05	GE
CF34-10E	X	X	2028M64G01	Link	72-31-06	GE
CF34-10E	X	X	2028M65G01	Link, Connecting Stg 1	72-31-06	GE
CF34-10E	X	X	2028M67G01	Link, Connecting Stg 3	72-31-06	GE
CF34-10E	X	X	2028M70G02	Ring	72-31-06	GE
CF34-10E	X		2028M71G01	Ring	72-31-06	GE
CF34-10E	X	X	2028M72G01	Ring	72-31-06	GE
CF34-10E	X	X	2028M73G01	Ring	72-31-06	GE
CF34-10E	X		2028M74P01	Assy, Linkage	72-31-05	GE
CF34-10E	X		2028M74P03	Clevis	72-31-05	GE
CF34-10E	X		2029M31P01	Tube/Hose, Drain	LMM 72-09-00	GE
CF34-10E	X		2029M43P01	Tube And Hose, Head End VSV Actuator Fuel	LMM 72-09-04	GE
CF34-10E	X		2030M30G01	Tube	LMM 72-09-00	GE
CF34-10E	X		2030M30G01	Tube	LMM 72-09-00	GE
CF34-10E	X		2031M19G01	Seal	72-31-03	GE
CF34-10E	X		2031M19G02	Seal	72-31-03	GE
CF34-10E	X	X	2031M29G01	Mount, Actuator	72-32-12	GE
CF34-10E	X	X	2032M56G02	Mount, Actuator	72-31-12	GE
CF34-10E	X		2035M23G01	Tube	LMM 72-09-00	GE
CF34-10E	X		2043M42P02	Accelerometer	LMM 77-00-00	GE
CF34-10E	X		2044M56P04	Bracket	72-23-13	GE
CF34-10E	X	X	2044M58P01	Scoop, Oil Radial	72-61-14	GE
CF34-10E	X		2044M69P02	Seal, No.3 Bearing Air Oil Rotating	72-61-04	GE
CF34-10E	X	X	2044M75P01	Nut	72-61-06	GE
CF34-10E	X	X	2044M85G01	Bracket	72-09-01	GE
CF34-10E	X		2050M13P04	Turnbuckle Body	72-31-05	GE
CF34-10E	X	X	2050M16G01	Support Actuator	72-31-05	GE
CF34-10E	X	X	2050M38P02	Shim	72-21-10	GE
CF34-10E	X		2050M76G01	Link	72-31-05	GE
CF34-10E	X	X	2050M76G02	Link	72-31-05	GE
CF34-10E	X	X	2050M76G03	Link	72-31-05	GE
CF34-10E	X	X	2052M36G01	Bracket	72-09-01	GE
CF34-10E	X		2052M90G01	Bracket	72-09-01	GE
CF34-10E	X		2053M12P01	Tube, Air	72-09-00	GE
CF34-10E	X		2053M19G01	Bracket	72-09-01	GE
CF34-10E	X	X	2053M28P01	Joint, Flexible Wye	72-09-01	GE
CF34-10E	X	X	2053M29G01	Tube	72-09-04	GE
CF34-10E	X		2054M23P01	Tube And Hose, Rod End VSV Actuator Fuel	LMM 72-09-00	GE
CF34-10E	X		2054M36G01	Tube	LMM 72-09-00	GE
CF34-10E	X		2054M42P01	Tube/Hose, Oil AGB to TGB	LMM 72-09-00	GE
CF34-10E	X		2054M44P01	Hose, Tube Oil	72-09-00	GE
CF34-10E	X	X	2054M85G01	Tube, Air	70-09-00	GE
CF34-10E	X		2058M16G01	Tube, Fuel, Burn Flow	72-09-04	GE
CF34-10E	X		2058M49G01	Manifold, Fuel TBV	72-09-04	GE
CF34-10E	X		2058M54P01	Tube Hose	LMM 72-09-00	GE
CF34-10E	X		2058M69G01	Bracket	72-09-01	GE
CF34-10E	X		2058M90G01	Manifold	LMM 72-09-00	GE
CF34-10E	X		2059M27G01	Tube	72-09-04	GE
CF34-10E	X		2059M47G01	Bracket, Support	72-09-01	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF34-10E	X		2059M49G01	Bracket, Support	72-09-01	GE
CF34-10E	X		2059M51G01	Bracket	72-09-01	GE
CF34-10E	X	X	2070M12G01	Segment, Fan Flowpath	72-23-07	GE
CF34-10E	X	X	2070M13G01	Flowpath	72-23-07	GE
CF34-10E	X	X	2070M14G01	Segment, Fan Flowpath	72-23-07	GE
CF34-10E	X	X	2070M15G01	Segment, Fan Flowpath	72-23-07	GE
CF34-10E	X	X	2070M16G01	Segment, Fan Flowpath	72-23-07	GE
CF34-10E	X	X	2070M23G01	Ring	72-23-14	GE
CF34-10E	X		2070M31G01	Bellcrank	72-23-14	GE
CF34-10E	X	X	2070M53G01	Shield, Heat	72-53-11	GE
CF34-10E	X	X	2070M57G01	Support, Nozzle	72-51-04	GE
CF34-10E	X	X	2070M58P01	Retainer, External Pressure Seal	72-51-05	GE
CF34-10E	X		2070M59P01	Support, Fairing	72-23-23	GE
CF34-10E	X	X	2072M42P01	Clevis, By-pass Valve	72-23-14	GE
CF34-10E	X	X	2072M54P01	Adapter, Igniter	72-41-06	GE
CF34-10E	X		2072M54P02	Adapter, Igniter	72-41-06	GE
CF34-10E	X	X	2072M56P02	Strut	72-23-23	GE
CF34-10E	X	X	2072M60G01	Plug	72-53-08	GE
CF34-10E	X	X	2072M61G01	Guide, Fan Speed Sensor	72-23-12	GE
CF34-10E	X	X	2072M68G01	Bracket, Fairing-Upper	72-09-01	GE
CF34-10E	x		2072M72G03	Seal, Extension Ring	72-23-22	GE
CF34-10E	X	X	2072M79G01	Segment, Fan Flowpath	72-23-07	GE
CF34-10E	X	X	2072M80G01	Segment, Fan Flowpath	72-23-07	GE
CF34-10E	X	X	2072M81G01	Flowpath	72-23-07	GE
CF34-10E	X	X	2072M82G01	Segment, Fan Flowpath	72-23-07	GE
CF34-10E	X	X	2072M83G01	Segment, Fan Flowpath	72-23-07	GE
CF34-10E	X	X	2072M84G01	Segment, Fan Flowpath	72-23-07	GE
CF34-10E	X	X	2072M85G01	Segment, Fan Flowpath	72-23-07	GE
CF34-10E	X		2072M87P01	Stop	72-32-01	GE
CF34-10E	x		2072M93P01	Strut	72-23-23	GE
CF34-10E	X	X	2072M93P02	Strut	72-23-23	GE
CF34-10E	X	X	2072M95G03	Support	72-53-07	GE
CF34-10E	X		2093M29P02	Bolt, Tension	71-20-09	GE
CF34-10E	X		2098M11G01	Bracket	72-09-01	GE
CF34-10E	X		2098M19P01	Joint, Low Flexible	LMM 72-09-00	GE
CF34-10E	X		2098M31P01	Joint	LMM 73-00-00	GE
CF34-10E	X		2098M46P01	Tube	LMM 72-09-00	GE
CF34-10E	X	X	2116M66P04	Ring, Retaining	72-52-13	GE
CF34-10E	X	X	2131M72G01	Scoop	72-23-26	GE
CF34-10E	X	X	2134M11G02	Link	71-20-06	GE
CF34-10E	X		2134M17P01	Bolt	71-20-09	GE
CF34-10E	X		2134M18P01	Bolt	71-20-09	GE
CF34-10E	X		2134M19P01	Bolt	71-20-09	GE
CF34-10E	X		2134M20P01	Bolt	71-20-09	GE
CF34-10E	X		2134M21P01	Bolt	71-20-09	GE
CF34-10E	X		2134M27P02	Bolt	71-20-09	GE
CF34-10E	X		2134M61G02	Yoke Thrust, Engine	71-20-07	GE
CF34-10E	X		2134M78G01	Link, Fixed VBV Actuator	72-23-14	GE
CF34-10E	X		2170M31G01	Tube	LMM 72-09-00	GE
CF34-10E	X		2170M82G01	Tube	LMM 72-09-00	GE
CF34-10E	X		2170M86G01	Tube, Oil Supply Sump	LMM 72-09-00	GE
CF34-10E	X		2176M20G01	Tube	LMM 72-09-00	GE
CF34-10E	X	X	2176M61G01	Bracket	72-09-01	GE
CF34-10E	X		2177M28G01	Bracket	72-09-01	GE
CF34-10E	X		2177M64G01	Tube, Air PS3	LMM 72-09-00	GE
CF34-10E	X		2191M33P01	Tube, Hose Fuel Fmi To Servo	72-09-04	GE
CF34-10E	X	X	2191M41G01	Bracket, Support	72-09-01	GE
CF34-10E	X		2191M49P01	Tube	LMM 72-09-00	GE
CF34-10E	X	X	2226M31P01	Sleeve	72-59-04	GE
CF34-10E	X		2226M32G03	Tube	LMM 72-09-00	GE
CF34-10E	X	X	2226M34P01	Panel	72-59-07	GE
CF34-10E	X		2226M34P02	Panel	72-59-07	GE
CF34-10E	X		2226M39G01	Plug	72-57-13	GE
CF34-10E	X	X	2226M39G02	Plug	72-57-13	GE
CF34-10E	X	X	2226M46P01	Retainer	72-57-23	GE
CF34-10E	X		2226M56P01	Support Ring	72-55-11	GE
CF34-10E	X	X	2226M60P01	Nut	72-55-09	GE
CF34-10E	X		2226M64G01	Retainer, A/O Stg 1 Blade	72-00-57	GE
CF34-10E	X	X	2226M77G01	Tube	72-09-00	GE
CF34-10E	X		2226M84P02	Sleeve	72-59-09	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF34-10E	X		2226M85P05	Damper, Ring No. 5	72-09-02	GE
CF34-10E	X		2226M86G02	Oiljet, A/O No. 5 Bearing	72-09-03	GE
CF34-10E	X	X	2226M86G03	OILJET A/O No. 5 bearing	72-09-03	GE
CF34-10E	X	X	2226M87G01	Duct	72-57-14	GE
CF34-10E	X	X	2226M88G01	Duct	72-57-14	GE
CF34-10E	X	X	2226M95P01	Housing, Air Seal	72-57-18	GE
CF34-10E	X		2226M98P01	Nut	72-55-18	GE
CF34-10E	x		2226M99P01	Nut	72-55-04	GE
CF34-10E	X		2227M12P01	Ring	72-55-13	GE
CF34-10E	X	X	2227M13P01	Plate, Lock Nut	72-55-18	GE
CF34-10E	X		2227M28G01	Bracket	72-57-21	GE
CF34-10E	x		2227M34G02	Oiljet, A/O No. 4 bearing	72-09-03	GE
CF34-10E	X		2227M39P01	Bracket	72-57-17	GE
CF34-10E	X	X	2227M39P02	Bracket	72-57-17	GE
CF34-10E	X		2227M40P01	Bracket	72-57-17	GE
CF34-10E	x		2227M45P02	Ring, Lock	72-55-18	GE
CF34-10E	x		2227M48P01	Nut, Lock	72-55-16	GE
CF34-10E	x		2227M59P01	Bracket	72-09-01	GE
CF34-10E	X		2227M71G01	Tube, A/O Stay	72-59-14	GE
CF34-10E	X	X	2227M85P01	Bracket	72-57-16	GE
CF34-10E	X		2228M16P01	Bracket	72-09-01	GE
CF34-10E	X	X	2228M21P02	Seal, Oil Rotating Fwd	72-55-12	GE
CF34-10E	X		2229M14G02	Tube	LMM 72-09-00	GE
CF34-10E	X		2230M32P01	Nut	72-61-11	GE
CF34-10E	X		2230M34P01	Nut	72-23-25	GE
CF34-10E	X	X	2232M70P01	Shaft, TGB Horizontal Drive	72-62-04	GE
CF34-10E	X		2278M19G01	Bracket	72-09-01	GE
CF34-10E	X		2278M61G01	Bracket	72-09-01	GE
CF34-10E	X		2278M63G01	Bracket	72-09-01	GE
CF34-10E	X		2278M64G01	Bracket	72-09-01	GE
CF34-10E	X		2278M65G01	Bracket	72-09-01	GE
CF34-10E	x		2284M29G01	Bracket	72-09-01	GE
CF34-10E	x		2284M35G01	Tube	72-09-00	GE
CF34-10E	X		2284M37P01	Tube	LMM 72-09-00	GE
CF34-10E	X		2284M48G01	Tube	LMM 72-09-00	GE
CF34-10E	X		2284M76P01	Tube	LMM 72-09-00	GE
CF34-10E	X		2284M77G01	Tube	LMM 72-09-00	GE
CF34-10E	x		2284M83G01	Tube, LPT Cooling	72-09-00	GE
CF34-10E	X		2284M85G01	Support	72-09-01	GE
CF34-10E	X	X	2284M87P01	Bracket	72-09-01	GE
CF34-10E	X	X	2284M89G01	Bracket	72-09-01	GE
CF34-10E	X		2284M92G01	Bracket	72-09-01	GE
CF34-10E	X	X	2284M93G01	Bracket, Support	72-09-01	GE
CF34-10E	X	X	2290M17G01	Bracket	72-09-01	GE
CF34-10E	X		2290M30G01	Bracket	72-09-01	GE
CF34-10E	X		2290M33G01	Bracket	72-09-01	GE
CF34-10E	X		2290M46G01	Bracket	72-09-01	GE
CF34-10E	X		2290M53G01	Bracket	72-09-01	GE
CF34-10E	X		2290M56P01	Tube, Hose Oil Scavenge Aft Sump	LMM 72-09-00	GE
CF34-10E	X		2290M60G01	Bracket	72-09-01	GE
CF34-10E	X		2290M88G01	Bracket	72-09-01	GE
CF34-10E	X		2290M89G01	Bracket	72-09-01	GE
CF34-10E	X		2290M97G01	Tube	LMM 72-09-00	GE
CF34-10E	X		2291M27G01	Bracket, Support	72-09-01	GE
CF34-10E	X		2291M44G01	Tube	LMM 72-09-00	GE
CF34-10E	X		2291M48G01	Bracket	72-09-01	GE
CF34-10E	X		2291M68G01	Seal, Fire	72-09-01	GE
CF34-10E	X	X	2291M69G01	Bracket	72-09-01	GE
CF34-10E	X	X	2291M70G01	Bracket	72-09-01	GE
CF34-10E	X		2291M91G01	Tube, Air	LMM 72-09-00	GE
CF34-10E	X		2298M26G01	Tube	LMM 72-09-00	GE
CF34-10E	X		2298M87G01	Bracket	72-09-01	GE
CF34-10E	X		2298M88G01	Bracket	72-09-01	GE
CF34-10E	X		2298M95G01	Fuel, Manifold	LMM 72-09-00	GE
CF34-10E	X		2299M14G01	Manifold	LMM 72-09-00	GE
CF34-10E	X		2299M43P01	Tube/Hose, Oil Tank	LMM 72-09-00	GE
CF34-10E	X	X	2299M55G01	Bracket	72-09-01	GE
CF34-10E	X		2299M79G01	Tube	LMM 72-09-00	GE
CF34-10E	X		2359M23G01	Bracket	72-09-01	GE
CF34-10E	x		2359M40G01	Bracket	72-09-01	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF34-10E	X		2359M46G01	Bracket, Support	72-09-01	GE
CF34-10E	X	X	2359M47G01	Bracket, Valve	72-09-01	GE
CF34-10E	X		2359M95G01	Bracket	72-09-01	GE
CF34-10E	X	X	2367M71G01	Bracket	72-09-01	GE
CF34-10E	X		2367M72G01	Bracket, Support	72-09-01	GE
CF34-10E	X	X	2367M84G01	BRACKET	72-09-01	GE
CF34-10E	X	X	2367M90G01	Bracket	72-09-01	GE
CF34-10E	X		2367M91G01	Bracket, Tube Scavenge	72-09-01	GE
CF34-10E	X		2367M92G01	Tube, Air	LMM 72-09-00	GE
CF34-10E	X	X	2367M94G01	Bracket, Support	72-09-01	GE
CF34-10E	X	X	2367M95G01	Bracket	72-09-01	GE
CF34-10E	X	X	2367M97G01	Bracket	72-09-01	GE
CF34-10E	X		2367M98G01	Bracket	72-09-01	GE
CF34-10E	X	X	2367M99P01	Plate, Blank Off	72-09-01	GE
CF34-10E	X	X	2368M76G01	Bracket	72-09-01	GE
CF34-10E	X		2368M79P01	Tube	LMM 72-09-00	GE
CF34-10E	X		2369M19G01	Tube	LMM 72-09-00	GE
CF34-10E	X	X	2403M66G01	Bracket	72-23-13	GE
CF34-10E	X	X	2403M67G01	Bracket	72-09-01	GE
CF34-10E	X		2406M26G01	Tube/Hose, Heat Exchanger	LMM 72-09-00	GE
CF34-10E	X		2412M06G01	Tube, Fuel	LMM 72-09-00	GE
CF34-10E	X		2413M57P01	Tube	LMM 72-09-00	GE
CF34-10E	X		2413M58G01	Tube, Fuel	LMM 72-09-00	GE
CF34-10E	X		2413M59G01	Tube	LMM 72-09-00	GE
CF34-10E	X		2415M45G01	Bracket Oil Tube	72-09-01	GE
CF34-10E	X		2415M53G01	Tube, Oil Scavenge	LMM 72-09-00	GE
CF34-10E	X		2416M25G01	Oil Tube Sump	LMM 72-09-00	GE
CF34-10E	X		2416M26G01	Oil Tube Sump	LMM 72-09-00	GE
CF34-10E	X		2423M97G01	Oil Supply	LMM 72-09-00	GE
CF34-10E	X		2424M04G01	Bracket	72-09-01	GE
CF34-10E	X		2424M05G01	Bracket Tube P3	72-09-01	GE
CF34-10E	X		2424M06G01	Bracket	72-09-01	GE
CF34-10E	X		2424M08G01	Bracket	72-09-01	GE
CF34-10E	X	X	2424M09G01	Bracket	72-09-01	GE
CF34-10E	X		2424M16G01	Bracket	72-09-01	GE
CF34-10E	X		2424M17G01	Bracket, Support	72-09-01	GE
CF34-10E	X		2424M18G01	Bracket	72-09-01	GE
CF34-10E	X	X	2424M19G01	Bracket Support	72-09-01	GE
CF34-10E	X	X	2430M95P01	Clevis	72-31-05	GE
CF34-10E	X		2459M32G01	Support, Bracket	72-09-01	GE
CF34-10E	X	X	2464M88P01	Seal Rotating, Air and Oil NO.4 Bearing FWD	72-54-12	GE
CF34-10E	X	X	2489M01P01	Retainer, Fan Rotor Blade	72-00-01, Par 5C	GE
CF34-10E	X	X	2496M52G01	Bracket, Valve Support	72-09-01	GE
CF34-10E	X	X	2496M53G01	Bracket, Wire	72-09-01	GE
CF34-10E	X	X	2496M56G01	Bracket	72-09-01	GE
CF34-10E	X	X	2496M61G01	Bracket	72-09-01	GE
CF34-10E	X	X	2496M72G01	Bracket	72-09-01	GE
CF34-10E	X		2496M77P01	Tube	72-09-00	GE
CF34-10E	X	X	2502M82G01	Bracket	72-09-01	GE
CF34-10E	X		2502M83G01	Bracket Support	72-09-01	GE
CF34-10E	X	X	2531M05G01	Tube	72-09-00	GE
CF34-10E	X	X	2601M03G01	Flowpath, Segment Fan	72-23-07	GE
CF34-10E	X	X	2601M04G01	Flowpath, Segment Fan	72-23-07	GE
CF34-10E	X	X	2601M05G01	Flowpath, Segment Fan	72-23-07	GE
CF34-10E	X	X	2601M06G01	Flowpath, Segment Fan	72-23-07	GE
CF34-10E	X	X	2601M07G01	Flowpath, Segment Fan	72-23-07	GE
CF34-10E	X	X	2601M08G01	Flowpath, Segment Fan	72-23-07	GE
CF34-10E	X	X	2601M09G01	Flowpath, Segment Fan	72-23-07	GE
CF34-10E	X		2601M10G01	Segment, Fan Flowpath	72-23-07	GE
CF34-10E	X		2601M11G01	Segment, Fan Flowpath	72-23-07	GE
CF34-10E	X		2601M12G01	Segment, Fan Flowpath	72-23-07	GE
CF34-10E	X	X	2601M13G01	Flowpath, Segment Fan	72-23-07	GE
CF34-10E	X	X	2601M14G01	Flowpath, Segment Fan	72-23-07	GE
CF34-10E	X		341-3201-501	Tube, Center Vent	LMM 78-00-00	GE
CF34-10E	X		341-5822-501	Bracket	72-09-01	GE
CF34-10E	X		341-5825-501	Bracket Assy, Elect W8A Harness	72-09-01	GE
CF34-10E	X		341-5826-501	Bracket	72-09-01	GE
CF34-10E	X		341-5828-501	Bracket Assy	72-09-01	GE
CF34-10E	X		341-5854-501	Bracket	72-09-01	GE
CF34-10E	X		341-5869-501	Bracket	72-09-01	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF34-10E	X		4128T16P02	Shroud	72-32-02	GE
CF34-10E	X		45P1152	Spool, Booster	72-21-08	GE
CF34-10E	X	X	45P1157	Lug	72-21-11	GE
CF34-10E	X	X	45P1158	Lug	72-21-11	GE
CF34-10E	X		45P1173	Spool, Booster	72-21-08	GE
CF34-10E	X	X	45P1221	Blade, Booster Stg 2	72-21-07	GE
CF34-10E	X	X	45P1222	Blade, Booster Stg 2	72-21-07	GE
CF34-10E	X	X	45P1223	Blade, Booster Stg 2	72-21-07	GE
CF34-10E	X	X	45P1224	Blade, Booster Stg 2	72-21-07	GE
CF34-10E	X	X	45P1231	Blade, Booster Stg 3	72-21-07	GE
CF34-10E	X	X	45P1232	Blade, Booster Stg 3	72-21-07	GE
CF34-10E	X	X	45P1233	Blade, Booster Stg 3	72-21-07	GE
CF34-10E	X	X	45P1234	Blade, Booster Stg 3	72-21-07	GE
CF34-10E	X	X	45P1241	Blade, Booster Stg 4	72-21-07	GE
CF34-10E	X	X	45P1242	Blade, Booster Stg 4	72-21-07	GE
CF34-10E	X	X	45P1243	Blade, Booster Stg 4	72-21-07	GE
CF34-10E	X	X	45P1244	Blade, Booster Stg 4	72-21-07	GE
CF34-10E	X	X	45P2238	Tube	72-22-06	GE
CF34-10E	X	X	45P2332	Seal, Rotating	72-22-09	GE
CF34-10E	X		45P2624	Tube	72-09-04	GE
CF34-10E	X		45P4223	Bracket-Mid	72-00-01, Par 5Q	GE
CF34-10E	X		9108M27P05	BOLT	72-23-14	GE
CF34-10E	X		9370M47P01	Spray Shield	72-09-01	GE
CF34-10E	X		9507M21P07	Rod, BRG	72-31-05	GE
CF34-10E	X	X	9992M86G09	Plug	72-31-11	GE
CF34-10E	X	X	9992M86G10	Plug Assy, Borescope	72-31-11	GE
CF34-10E	X		B1316-00177	Valve - Vent	LMM 72-09-00	GE
CF34-10E	X		B1316-01185	Nut	72-22-10	GE
CF34-10E	X		B1316-02110	Spool, Booster	72-21-08	GE
CF34-10E	X	X	B1316-04154	Manifold, Oil	72-09-04	GE
CF34-10E	X	X	B1316-04156	Nozzle, Oil 2R	72-09-03	GE
CF34-10E	X		E411P02	Vane, Comp Sstr Stage 1	72-31-02	GE
CF34-10E	X		E412P02	Vane, Comp Sstr Stage 2	72-31-02	GE
CF34-10E	X		J522P10	Nipple	72-09-04	GE
CF34-10E	X		S700C1503-17	Line Block	72-09-01	GE
CF34-10E, 8C, 8E GE90-100	X		AS1895/1-225	Coupling	72-09-01 LMM 72-09-00	GE
CF34-10E, CF34-8C, 8E	X	X	4115T82G01	Strainer, Sump	72-63-10 72-64-12	GE
CF34-10E, CF34-8E, GE90, GE90-100	X		AS1895-1-300	Coupling, V-Band	72-09-01 LMM 72-09-00	GE
CF34-3	X		4037T15P02	Segment	72-32-00	GE
CF34-3	X		5047T87P04	Cover	72-09-10	GE
CF34-3	X		5047T88P04	Cover	72-09-10	GE
CF34-3	X		5083T52G01	Cover	72-09-10	GE
CF34-3, 3A1	X		3020T67G01	Washer, Key	72-09-06	GE
CF34-3, 3A1	X		3022T63P04	Clamp	72-09-06	GE
CF34-3, 3A1	X		5085T60G02	Tube	72-09-05	GE
CF34-3A1 (BJ/RJ)	X		4037T16P01	Segment	72-32-00	GE
CF34-8C	X		2037T83G01	Bracket	LMM 72-09-00	GE
CF34-8C	X	X	4115T36P01	Ring, Mating	72-64-19	GE
CF34-8C	X		4115T79P01	Plug, Axis B Cranking	72-64-19	GE
CF34-8C	X	X	4115T90P03	Plug, Axis	72-64-08	GE
CF34-8C	X	X	4116T30G01	Bracket	72-63-04	GE
CF34-8C	X		4116T31G01	Bracket Assy	72-63-04	GE
CF34-8C	X	X	4117T26P01	Nut, Coupling Aft	72-56-02	GE
CF34-8C	X		4117T32P02	Cap, Aft Blind	72-57-33	GE
CF34-8C	X	X	4117T66P03	Locknut	72-21-03	GE
CF34-8C	X	X	4117T66P04	Locknut	72-21-03	GE
CF34-8C	X	X	4117T83G04	Tube, Oil Drain	72-09-04	GE
CF34-8C	X		4118T28G01	Plug, Borescope	72-56-06	GE
CF34-8C	X		4118T36G02	Wall, Sump Assy Rear	72-59-09	GE
CF34-8C	X		4118T51P01	Ring	72-59-10	GE
CF34-8C	X		4119T28G01	Bracket	72-56-08	GE
CF34-8C	X		4120T57P02	Tube	LMM 72-09-00	GE
CF34-8C	X		4120T61G01	Tube, AGB Supply Oil	LMM 72-09-00	GE
CF34-8C	X		4120T86G01	Manifold	LMM 72-09-00	GE
CF34-8C	X		4120T87G01	Bracket	72-09-04	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF34-8C	X		4121T49P01	Bracket	LMM 72-09-00	GE
CF34-8C	X		4121T50G01	Tube	LMM 72-09-00	GE
CF34-8C	X		4121T61G01	Tube	LMM 72-09-00	GE
CF34-8C	X		4121T75P01	Mount	72-09-01	GE
CF34-8C	X	X	4121T76P01	Mount	72-09-01	GE
CF34-8C	X		4122T47G01	Bracket, Elec CA-W1	72-09-01	GE
CF34-8C	X		4122T64G01	Manifold, Oil	72-09-04	GE
CF34-8C	X		4123T22G01	Bracket	LMM 72-09-00	GE
CF34-8C	X		4123T66G01	Bracket, Bifurcation Cable	LMM 72-09-00	GE
CF34-8C	X	X	4123T77P01	Manifold, VG Actuator Rod End Fuel	72-09-04	GE
CF34-8C	X		4123T78P01	Manifold-VG Actuator Head End Fuel	LMM 72-09-00	GE
CF34-8C	X		4124T39P01	Sleeve	72-51-02	GE
CF34-8C	X		4125T40P01	Seal, Compressor Discharge	72-33-08	GE
CF34-8C	X	X	4126T29P02	OGV	72-23-06	GE
CF34-8C	X		4126T42G01	Link	71-20-02	GE
CF34-8C	X		4126T93P02	Bolt	71-20-04	GE
CF34-8C	X		4126T96G01	Tube	LMM 72-09-00	GE
CF34-8C	X	X	4128T51P03	Shaft, Support Rear Actuator	72-32-07	GE
CF34-8C	X	X	4128T52P12	Clevis, Stage 1 Shaft	72-32-07	GE
CF34-8C	X	X	4128T52P15	Clevis, Stage 4 Shaft	72-32-07	GE
CF34-8C	X		4128T52P16	Clevis, IGV Shaft	72-32-07	GE
CF34-8C	X	X	4128T52P17	Clevis, Stage 3 Shaft	72-32-07	GE
CF34-8C	X	X	4128T52P18	Clevis, Stage 2 Shaft	72-32-07	GE
CF34-8C	X		4128T67P04	Blisk, Stage 3	72-33-03	GE
CF34-8C	X		4128T89P01	Support, Center Actuation Shaft	72-32-07	GE
CF34-8C	X	X	4129T09P04	Vane, Variable Compressor Stator Stage 1	72-32-04	GE
CF34-8C	X		4129T15G01	Plate, No. 2 Bearing Retainer	72-21-06	GE
CF34-8C	X		4129T42P01	Seal	72-33-12	GE
CF34-8C	X		4129T59P02	Blisk, Stage 3	72-33-03	GE
CF34-8C	X	X	4129T63P03	Vane, Variable Compressor Stator Stage 3	72-32-04	GE
CF34-8C	X	X	4129T64P03	Vane, Variable Compressor Stator Stage 4	72-32-04	GE
CF34-8C	X		4129T92G01	Linkage Assy, Compressor Actuation	72-32-07	GE
CF34-8C	X		4129T92G03	Linkage	72-00-32	GE
CF34-8C	X		4131T28P04	OGV	72-23-06	GE
CF34-8C	X	X	4131T28P05	OGV	72-23-06	GE
CF34-8C	X		4131T28P06	OGV	72-23-06	GE
CF34-8C	X		4131T28P07	OGV	72-23-06	GE
CF34-8C	X	X	4131T46P02	Plate, Main Engine Mount Retainer	71-20-11	GE
CF34-8C	X		4132T53G01	Manifold	LMM 72-09-00	GE
CF34-8C	X		4137T46G01	Bracket, Fuel Supply	LMM 72-09-00	GE
CF34-8C	X		4137T87G01	Tube	LMM 72-09-00	GE
CF34-8C	X		4137T94G01	Bracket	LMM 72-09-00	GE
CF34-8C	X		4138T20G01	Yoke	71-20-05	GE
CF34-8C	X		4139T27G01	Tube	LMM 72-09-00	GE
CF34-8C	X		4139T29G01	Tube, Oil	72-09-04	GE
CF34-8C	X		4139T91P01	Tube	LMM 72-09-00	GE
CF34-8C	X	X	4139T94G01	Tube, Operability Bleed Valve	72-09-04	GE
CF34-8C	X		4140T40G01	Tube, B-Sump Supply Oil	LMM 72-09-00	GE
CF34-8C	X	X	4143T12G01	Tube, Operability Bleen Valve	72-63-04	GE
CF34-8C	X		4143T46G01	Tube	LMM 72-09-00	GE
CF34-8C	X		4143T51G01	Tube	LMM 72-09-00	GE
CF34-8C	X		4143T56P01	Tube/Hose	LMM 72-09-00	GE
CF34-8C	X		4145T32G09	Nozzle, HPT Inner Support	72-44-05	GE
CF34-8C	X		4157T18G01	Bracket, W1, W2 Electrical Cable	72-09-01	GE
CF34-8C	X		4157T40G01	Tube, P3 Air	LMM 72-09-00	GE
CF34-8C	X		4157T56G01	Manifold, A-Sump Air Pressure	LMM 72-09-00	GE
CF34-8C	X		4157T70P01	Tube Hose Assy	LMM 72-09-00	GE
CF34-8C	X		4157T82G01	Tube	72-09-04	GE
CF34-8C	X	X	4157T84G01	Tube, B Sump Scavenge Oil	72-09-04	GE
CF34-8C	X	X	4157T85G01	Tube, B Sump Scavenge Oil	72-09-04	GE
CF34-8C	X		4158T11P01	Tube And Hose , MFP To Flowbody Fuel	72-09-04	GE
CF34-8C	X		4158T23G01	Tube	LMM 72-09-00	GE
CF34-8C	X		4158T27G01	Bracket	LMM 72-09-00	GE
CF34-8C	X		4158T84G01	Bracket	72-63-04	GE
CF34-8C	X		4158T87G01	Bracket, W1, W2 Electrical Cable	72-09-01	GE
CF34-8C	X	X	4159T02G01	Bracket Assy, Right Hand Upper	72-63-04	GE
CF34-8C	X	X	4159T17P01	Tube And Hose, C Sump Oil	72-09-04	GE
CF34-8C	X		4159T19G01	Bracket, Igniter Lead	72-09-01	GE
CF34-8C	X		4159T54G01	Tube, B-Sump Scavenge Oil	LMM 72-09-00	GE
CF34-8C	X		4159T58G01	Manifold	LMM 72-09-00	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF34-8C	X		4159T59G01	Manifold	LMM 72-09-00	GE
CF34-8C	X		4159T62G01	Tube	LMM 72-09-00	GE
CF34-8C	X		4906T51P01	OGV	72-23-06	GE
CF34-8C	X		4906T51P02	OGV	72-23-06	GE
CF34-8C	X		4906T51P05	OGV	72-23-06	GE
CF34-8C	X		4906T51P07	OGV	72-23-06	GE
CF34-8C	X		4906T58P01	OGV	72-23-06	GE
CF34-8C	X		4906T58P02	OGV	72-23-06	GE
CF34-8C	X		5058T28G14	Link, Comp VG Preset Assy	72-32-07	GE
CF34-8C	X		5058T28G15	Link, Comp VG Preset Assy	72-32-07	GE
CF34-8C	X		5058T28G16	Link, Comp VG Preset Assy	72-32-07	GE
CF34-8C	X		5058T28G17	Link, Comp VG Preset Assy	72-32-07	GE
CF34-8C	X		5058T28G18	Link, Comp VG Preset Assy	72-32-07	GE
CF34-8C	X	X	5125T52P02	Vane, Variable Compressor Stator IGTV	72-32-04	GE
CF34-8C	X	X	5125T54P04	Vane, Variable Compressor Stator Stage 2	72-32-04	GE
CF34-8C	X		AE711152-11	Hose, Drain-Slave Actuator	LMM 72-09-00	GE
CF34-8C	X		CN627-0003-015	Duct Assy	LMM 72-09-00	GE
CF34-8C	X		CN627-0072-001	Bracket	LMM 72-09-00	GE
CF34-8C	X		CN627-2003-003	Pipe Assy, Pressure	LMM 72-09-00	GE
CF34-8C	X		CN627-2005-001	Pipe Assy, Suction	LMM 72-09-00	GE
CF34-8C	X		CN627-2007-001	Pipe Assy, Drain Case	LMM 72-09-00	GE
CF34-8C	X		CN627-2017-203	Bracket	72-09-01	GE
CF34-8C	X		CN627-2018-203	Bracket	LMM 72-09-00	GE
CF34-8C	X		CN627-2043-001	Bracket	LMM 72-09-00	GE
CF34-8C	X		CN627-4013-003	Bracket	72-09-01	GE
CF34-8C	X	X	CN627-4014-001	Bracket	72-09-01	GE
CF34-8C	X		CN627-4032-005	Bracket	72-09-01	GE
CF34-8C	X	X	CN627-4033-007	Bracket	72-09-01	GE
CF34-8C	X	X	CN627-4045-001	Bracket Assy	72-09-01	GE
CF34-8C	X		CN627-6002-003	Pipe Subassembly, A-Section	LMM 72-09-00	GE
CF34-8C	X		CN627-6005-003	Pressure Pipe	LMM 72-09-00	GE
CF34-8C	X		CN627-6006-003	Raft Assy, Gearbox	LMM 72-09-00	GE
CF34-8C	X	X	CN627-6014-005	Bracket Assy	72-09-01	GE
CF34-8C	X		CN627-6044-003	Bracket Assy-Flowbody	LMM 72-09-00	GE
CF34-8C	X		CN627-7041-201	Bracket	72-09-01	GE
CF34-8C	X		CN627-8002-003	Tube, Drain - Hydraulic	LMM 72-09-00	GE
CF34-8C	X		CN627-8002-005	pipe-assy hyd drain	71-71-00	GE
CF34-8C	X		CN627-8004-001	Tube, Drain - IDG/Starter	LMM 72-09-00	GE
CF34-8C	X		CN627-8004-003	Pipe Assy, IDG/Starter Drain	LMM 72-09-00	GE
CF34-8C	X		CN627-8007-003	Pipe Assy, Front Frame	72-09-04	GE
CF34-8C	X	X	CN627-8007-005	Pipe Assy, Front Frame	72-09-04	GE
CF34-8C	X		CN627-8032-001	Tube, Fuel Drain	LMM 72-09-00	GE
CF34-8C	X		CN627-8032-003	Pipe Assy, Fuel Drain	LMM 72-09-00	GE
CF34-8C	X		CN627-8033-001	Tube, Fuel Drain	LMM 72-09-00	GE
CF34-8C	X		CN627-8034-001	Pipe Assy-Fuel Drain 1 (ECS)	LMM 72-09-00	GE
CF34-8C	X		CN627-8035-001	Pipe Assy, Fuel Drain 2	LMM 72-09-00	GE
CF34-8C	X		CN627-8036-003	Pipe Assi, Drain	LMM 72-09-00	GE
CF34-8C	X		CN627-8047-005	Pipe Assy - Air/Oil Separator No. 1	LMM 72-09-00	GE
CF34-8C	X		CN627-8048-003	Pipe Assy	LMM 72-09-00	GE
CF34-8C	X		CN627-8052-001	Pipe, Drain Line Master	LMM 72-09-00	GE
CF34-8C	X		CN628-0155-005	Bracket	72-09-01	GE
CF34-8C	X		J1212P05	Nut	72-09-01	GE
CF34-8C, 8E	X		2037M37G01	Bracket,Tube	LMM 72-09-00	GE
CF34-8C, 8E	X		2161M42G01	Tube And Hose, Sump Supply Tube	LMM 72-09-00	GE
CF34-8C, 8E	X	X	3044T13P07	Plug, Borescope	72-32-08	GE
CF34-8C, 8E	X		4033T54P09	Bearing, Rod End	72-32-07	GE
CF34-8C, 8E	X	X	4114T06P03	Pin, Fan Blade Retaining	72-21-12 & LMM 72-21-00	GE
CF34-8C, 8E	X	X	4115T38P02	Ring, Mating	72-64-19	GE
CF34-8C, 8E	X		4115T39P01	Ring, Axis C Mating	72-64-19	GE
CF34-8C, 8E	X	X	4115T39P02	Ring, Axis C Mating	72-64-19	GE
CF34-8C, 8E	X		4115T78P01	Cover, Radial Drive Shaft	72-63-05	GE
CF34-8C, 8E	X	X	4117T27P01	Seal, Rotating Labyrinth	72-57-24	GE
CF34-8C, 8E	X		4117T74P01	Retainer, Transition	72-57-31	GE
CF34-8C, 8E	X	X	4117T85P01	Shield	72-57-04	GE
CF34-8C, 8E	X	X	4118T12G04	Ring, Inner	72-52-08	GE
CF34-8C, 8E	X		4120T51P02	Manifold	LMM 72-09-00	GE
CF34-8C, 8E	X	X	4124T54G02	Nut Assy, Self Locking Gang	72-44-05	GE
CF34-8C, 8E	X	X	4124T55G02	Nut Assy, Self Locking Gang (Sml)	72-44-05	GE
CF34-8C, 8E	X		4124T98P03	Damper, Blade Stage 1	72-51-11	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF34-8C, 8E	X		4125T32P01	Damper	72-51-05	GE
CF34-8C, 8E	X	X	4125T67P01	Damper	72-51-16	GE
CF34-8C, 8E	X	X	4126T27G02	Ring	72-23-06	GE
CF34-8C, 8E	X		4128T50G03	Support	72-32-07	GE
CF34-8C, 8E	X		4128T57G03	Bellcrank	72-32-07	GE
CF34-8C, 8E	X	X	4129T09P03	Vane, Variable Compressor Stator Stage 1	72-32-04	GE
CF34-8C, 8E	X		4129T14P02	Connector, IGV Actuating Ring	72-32-03	GE
CF34-8C, 8E	X		4129T17G04	Shaft, Actuator	72-32-07	GE
CF34-8C, 8E	X		4129T63P04	Vane, Variable Compressor Stator Stage 3	72-32-04	GE
CF34-8C, 8E	X	X	4129T63P05	Vane, Variable Comp Sstr Stage 3	72-32-04	GE
CF34-8C, 8E	X		4129T64P04	Vane, Variable Compressor Stator Stage 4	72-32-04	GE
CF34-8C, 8E	X	X	4129T64P05	Vane, Variable Comp Sstr Stage 4	72-32-04	GE
CF34-8C, 8E	X	X	4129T81P01	Link, Assy IGV4	72-32-07	GE
CF34-8C, 8E	X	X	4129T81P02	Link, Assy IGV4	72-32-07	GE
CF34-8C, 8E	X	X	4129T81P03	Link, Assy IGV4	72-32-07	GE
CF34-8C, 8E	X	X	4129T81P04	Link, Assy IGV4	72-32-07	GE
CF34-8C, 8E	X	X	4129T83P01	Bellcrank	72-32-07	GE
CF34-8C, 8E	X	X	4131T28P02	OGV	72-23-06	GE
CF34-8C, 8E	X		4131T28P03	OGV	72-23-06	GE
CF34-8C, 8E	X		4138T06P01	Scoop	72-31-12	GE
CF34-8C, 8E	X		4138T77G02	Link, Engine Mount Fail Safe	71-00-20	GE
CF34-8C, 8E	X	X	4151T42P01	Seal Plate	72-57-06	GE
CF34-8C, 8E	X	X	4151T44P02	Liner	72-57-06	GE
CF34-8C, 8E	X	X	4151T53P01	Seal	72-57-07	GE
CF34-8C, 8E	X		4151T68G01	Tube	LMM 72-09-00	GE
CF34-8C, 8E	X		4151T90P01	Plug	72-56-12	GE
CF34-8C, 8E	X	X	4151T91P01	Shield	72-57-02	GE
CF34-8C, 8E	X		4159T03G01	Bracket Assy, Lower	72-63-04	GE
CF34-8C, 8E	X		4180T11P01	Cover	LMM 72-09-00	GE
CF34-8C, 8E	X		4187T06G01	Manifold	LMM 72-09-00	GE
CF34-8C, 8E	X		5052T14P03	Bearing, Rod End RH Thread	72-32-07	GE
CF34-8C, 8E	X		5052T14P04	Bearing, Rod End (LH)	72-32-07	GE
CF34-8C, 8E	X	X	5121T35G07	Plug	72-41-24	GE
CF34-8C, 8E	X	X	5125T54P03	Vane, Variable Compressor Stator Stage 2	72-32-04	GE
CF34-8C, 8E	X		5125T55P05	Vane, Variable Compressor Stator Stage 3	72-32-04	GE
CF34-8C, 8E	X		5125T56P05	Vane, Variable Compressor Stator Stage 4	72-32-04	GE
CF34-8C, 8E	X		5125T63G04	Arm, Compressor Stator	72-32-01	GE
CF34-8C, 8E					LMM 72-09-00	
GE90-100	X		AS1895/4-125	Clamp	72-09-04	GE
CF34-8C, 8E, 10E	X	X	4115T35P02	Mating Ring	72-62-12	GE
CF34-8C, 8E, 10E	X	X	4115T36P02	Ring, Mating	72-64-19	GE
CF34-8C, 8E, 10E	X		LR47179	Bowl	79-00-00	GE
CF34-8C, 8E, 10E, GE90-100	X		AS1895-4-125	Coupling	72-09-04	GE
CF34-8E	X		14E0320007	Tube, Drain	LMM 72-09-00	GE
CF34-8E	X		2036M18G01	Tube Bleed Air	LMM 72-09-00	GE
CF34-8E	X		2036M32G01	Bracket	LMM 72-09-00	GE
CF34-8E	X		2036M33G01	Tube, Operability BV Fuel Return	LMM 72-09-00	GE
CF34-8E	X		2036M34P01	Tube	LMM 72-09-00	GE
CF34-8E	X		2036M66G01	Tube, PS3	72-09-04	GE
CF34-8E	X		2036M67G01	Manifold	LMM 72-09-00	GE
CF34-8E	X		2036M71G01	Tube, C Sump Air Pressurization	72-09-04	GE
CF34-8E	X		2036M76G01	Tube	LMM 72-09-00	GE
CF34-8E	X		2036M86G01	Deflector	75-33-00	GE
CF34-8E	X		2037M45G01	Bracket	LMM 72-09-00	GE
CF34-8E	X		2037M51G01	Bracket	LMM 72-09-00	GE
CF34-8E	X		2037M74G01	Bracket	LMM 72-09-00	GE
CF34-8E	X		2037M79G01	Bracket	LMM 72-09-00	GE
CF34-8E	X		2037M83G01	Bracket	LMM 72-09-00	GE
CF34-8E	X		2160M25P01	Tube	LMM 72-09-00	GE
CF34-8E	X		2161M26P01	Tube/Hose	LMM 72-09-00	GE
CF34-8E	X		2161M27P01	Tube, Hose, MFP to Cooler Fuel	LMM 72-09-00	GE
CF34-8E	X		2161M29G01	Tube	LMM 72-09-00	GE
CF34-8E	X		2161M34P01	Tube	LMM 72-09-00	GE
CF34-8E	X		2161M36P01	Manifold and Hose	LMM 72-09-00	GE
CF34-8E	X		2161M38G01	Tube	LMM 72-09-00	GE
CF34-8E	X		2161M43G01	Tube	LMM 72-09-00	GE
CF34-8E	X		2161M44G01	Tube	LMM 72-09-00	GE
CF34-8E	X		2161M49G01	Tube	LMM 72-09-00	GE
CF34-8E	X		2161M53P01	Manifold and Hose, VG Actuator Head End Fuel	LMM 72-09-00	GE
CF34-8E	X		2161M81G01	Tube	LMM 72-09-00	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF34-8E	X		2162M82G01	Manifold, A Sump Air Pressurization	LMM 72-09-00	GE
CF34-8E	X	X	4114T06P02	Pin, Fan Blade Retaining	72-21-12	GE
CF34-8E	X	X	4115T37P02	Ring, Mating	72-64-19	GE
CF34-8E	X	X	4116T66P04	Shaft, Radial Drive	72-63-03	GE
CF34-8E	X	X	4118T92G01	Support Assy, Baffle Rear	72-56-05	GE
CF34-8E	X		4123T21G01	Bracket	72-09-00	GE
CF34-8E	X		4125T19P01	Sleeve	72-51-02	GE
CF34-8E	X	X	4129T13G03	Ring Segment, IGV Actuating	72-32-03	GE
CF34-8E	X		4129T60P01	Blisk, Stage 1 & 2	72-33-01	GE
CF34-8E	X		4138T22P01	Scoop	72-31-12	GE
CF34-8E	X		4138T43P02	Pin, Engine Mount	71-20-16	GE
CF34-8E	X		4138T70G02	Link, Engine Mount (RH)	71-20-06	GE
CF34-8E	X		4145T01P01	OGV	72-23-06	GE
CF34-8E	X		4145T01P03	OGV UnCamber Fan Frame	72-23-06, 72-23-00	GE
CF34-8E	X		4145T01P04	OGV	72-23-06	GE
CF34-8E	X		4145T01P05	OGV	72-23-06	GE
CF34-8E	X		4145T03P01	OGV	72-23-06	GE
CF34-8E	X		4145T03P03	Vane, OGV	72-23-06	GE
CF34-8E	X		4145T03P04	OGV	72-23-06	GE
CF34-8E	X		4145T03P05	OGV	72-23-06	GE
CF34-8E	X		4145T67P01	Bolt	71-20-16	GE
CF34-8E	X		4151T08P02	Bracket, Radial Standoff	78-00-10 & LMM 78-00-00	GE
CF34-8E	X		4151T08P03	Bracket	LMM 72-09-00	GE
CF34-8E	X	X	4151T09G01	Bracket Assy, Axial Bumper	78-00-10	GE
CF34-8E	X		4151T23P01	Sleeve	72-59-07	GE
CF34-8E	X		4158T84G02	Bracket	72-63-04	GE
CF34-8E	X	X	4159T02G02	Bracket Assy, Right Hand Upper	72-63-04	GE
CF34-8E	X		4159T49G01	Bracket	LMM 72-09-00	GE
CF34-8E	X		4159T50G01	Deflector	LMM 72-09-00	GE
CF34-8E	X		4187T10P01	Tube/Hose	LMM 72-09-00	GE
CF34-8E	X		4187T16G01	Tube	LMM 72-09-00	GE
CF34-8E	X		4906T51P03	OGV	72-23-06	GE
CF34-8E	X		4906T51P06	OGV	72-23-06	GE
CF34-8E	X		4906T92P02	OGV	72-23-06	GE
CF34-8E	X		4906T92P03	OGV	72-23-06	GE
CF34-8E	X		4906T93P01	OGV	72-23-06	GE
CF34-8E	X		4906T93P02	OGV	72-23-06	GE
CF34-8E	X		4906T93P03	OGV	72-23-06	GE
CF34-8E	X		4923T84G01	Deflector	75-33-00	GE
CF34-8E, 8C	X	X	4159T63G01	Tube, B Sump Purge Air	72-00-00	GE
CF34-BJ	X		4018T16P04	Ring	72-61-00	GE
CF34-BJ	X		5099T09P04	Shroud	72-45-00, 72-45-15	GE
CF34-BJ	X		5126T22G05	Ring Assy-Stage 5 Actuator	72-32-01	GE
CF34-BJ-1A	X		4028T41P02	Guide, Stage 1 Air Nozzle	72-40-00	GE
CF34-RJ	X		3035T40P04	Ring, Stage 2 Retaining	72-33-00	GE
CF34-RJ	X		4020T08G01	Tube	72-09-05	GE
CF34-RJ	X		4024T16G01	Tube	72-09-05	GE
CF34-RJ	X		4025T01G03	Bracket Assy	72-61-00	GE
CF34-RJ	X		4027T37G01	Tube	72-09-05	GE
CF34-RJ	X		4027T93G01	Tube	72-09-05	GE
CF34-RJ	X		4028T41P03	Guide, Stage 1 Air Nozzle	72-45-00	GE
CF34-RJ	X	X	4037T15P01	Segment	72-32-00	GE
CF34-RJ	X		4044T31G01	Tube	72-09-05	GE
CF34-RJ	X		4047T42G01	Tube	72-09-05	GE
CF34-RJ	X		4047T42G02	Tube	72-09-05	GE
CF34-RJ	X		4047T62G01	Tube	72-09-05	GE
CF34-RJ	X		4048T05P01	Tube, Elbow	72-09-05	GE
CF34-RJ	X		4048T05P02	Tube, Elbow	72-09-05	GE
CF34-RJ	X		4048T06P01	Tube, Elbow	72-09-05	GE
CF34-RJ	X		4048T06P02	Tube, Elbow	72-09-05	GE
CF34-RJ	X		4071T11G04	Tube	72-09-05	GE
CF34-RJ	X		4071T11G05	Tube	72-09-05	GE
CF34-RJ	X		4071T11G06	Tube	72-09-05	GE
CF34-RJ	X		4071T32G01	Tube	72-09-05	GE
CF34-RJ	X		4074T39P04	Pin, Engine Mount Expandable	72-44-00	GE
CF34-RJ	X		4074T49G01	Sling	72-41-00	GE
CF34-RJ	X	X	4085T92P01	Hose Assy	72-09-05	GE
CF34-RJ	X		4096T20G01	Tube	72-09-05	GE
CF34-RJ	X		4096T21G01	Tube	72-09-05	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF34-RJ	X	X	4096T22G01	Tube	72-09-05	GE
CF34-RJ	X		4096T54G01	Tube	72-09-05	GE
CF34-RJ	X		4096T72P01	Hose/Tube	72-09-05	GE
CF34-RJ	X		4096T72P02	Hose/Tube	72-09-05	GE
CF34-RJ	X		4096T90G01	Tube	72-09-05	GE
CF34-RJ	X		4104T07G01	Tube	72-09-05	GE
CF34-RJ	X		4147T83G01	Tube	72-09-05	GE
CF34-RJ	X	X	4154T82P02	Tube	72-09-05	GE
CF34-RJ	X		4159T90P03	Hose, Rod End Actuator	72-09-05	GE
CF34-RJ	X		4189T24G01	Plug, Crank	72-61-00	GE
CF34-RJ	X		4923T10G01	Shaft, Actuator	72-32-01	GE
CF34-RJ	X		5023T52G01	Tube	72-09-05	GE
CF34-RJ	X		5023T81G01	Tube	72-09-05	GE
CF34-RJ	X		5024T06G01	Tube	72-09-05	GE
CF34-RJ	X		5024T14G03	Sector, Outlet Guide Vane	72-32-00	GE
CF34-RJ	X	X	5026T46G02	Bellcrank, Actuator	72-32-01	GE
CF34-RJ	X		5038T21G01	Tube	72-09-05	GE
CF34-RJ	X		5038T30G01	Tube	72-09-05	GE
CF34-RJ	X		5047T30G03	Support, Forward Bearing	72-32-01	GE
CF34-RJ	X		5047T54G01	Tube	72-09-05	GE
CF34-RJ	X		5047T68G01	Tube	72-09-05	GE
CF34-RJ	X		5047T75G01	Tube	72-09-05	GE
CF34-RJ	X		5050T49G03	Manifold, No.1 Bearing Oil	72-09-05	GE
CF34-RJ	X		5050T51G03	Tube	72-09-05	GE
CF34-RJ	X		5050T91P01	Tube	72-09-05	GE
CF34-RJ	X	X	5054T18G01	Tube	72-09-05	GE
CF34-RJ	X		5054T24G01	Tube Assy, Air Valve to C-Sump Aft	72-09-05	GE
CF34-RJ	X		5054T25G01	Tube	72-09-05	GE
CF34-RJ	X		5054T52P01	Hose	72-09-05	GE
CF34-RJ	X		5054T53P02	Hose	72-09-05	GE
CF34-RJ	X		5054T54P02	Hose	72-09-05	GE
CF34-RJ	X		5054T60P02	Adapter, Stage 5 Clevis	72-32-01	GE
CF34-RJ	X		5071T18G02	Tube	72-09-05	GE
CF34-RJ	X		5071T74G01	Tube	72-09-05	GE
CF34-RJ	X		5071T75G01	Tube Assy	72-09-05	GE
CF34-RJ	X		5071T76G01	Tube	72-09-05	GE
CF34-RJ	X	X	5071T81P03	Tube And Hose, Oil	72-09-05	GE
CF34-RJ	X		5071T81P04	Tube And Hose, Oil	72-09-05	GE
CF34-RJ	X		5071T82P03	Hose	72-09-05	GE
CF34-RJ	X		5071T82P04	Hose	72-09-05	GE
CF34-RJ	X		5071T83G02	Tube	72-09-05	GE
CF34-RJ	X		5071T84G01	Tube	72-09-05	GE
CF34-RJ	X		5071T85P01	Tube	72-09-05	GE
CF34-RJ	X		5071T85P02	Tube	72-09-05	GE
CF34-RJ	X		5071T86P01	Tube	72-09-05	GE
CF34-RJ	X		5071T86P02	Tube	72-09-05	GE
CF34-RJ	X		5071T94P01	Tube	72-09-05	GE
CF34-RJ	X		5071T94P02	Tube Assy	72-09-05	GE
CF34-RJ	X		5079T26P02	Tube	72-09-05	GE
CF34-RJ	X		5085T05P01	Tube And Hose, Oil Tank Return	72-09-05	GE
CF34-RJ	X		5085T05P02	Tube And Hose, Oil Tank Return	72-09-05	GE
CF34-RJ	X		5085T10G01	Hose	72-09-05	GE
CF34-RJ	X		5085T60G01	Tube	72-09-05	GE
CF34-RJ	X		5086T41G01	Hose Assy	72-09-05	GE
CF34-RJ	X		5121T77P01	Segment, IGV Upper Shroud Ring	72-32-00	GE
CF34-RJ	X		5125T42P01	Tube	72-09-05	GE
CF34-RJ	X		5922T71G01	Bellcrank Actuator	72-32-01	GE
CF34-RJ	X	X	6012T90G02	Tube	72-09-05	GE
CF34-RJ	X		6020T03G01	Sector Stage 4 Shrd And Seal	72-52-01	GE
CF34-RJ	X		6020T82P07	Blade, Stg 11	72-33-00	GE
CF34-RJ	X		6052T21P02	Mount	72-23-00	GE
CF34-RJ	X		6078T84P03	Hose And Tube, Fuel	72-09-05	GE
CF34-RJ	X		6087T20P02	Manifold, Fuel RH	72-09-05	GE
CF34-RJ	X		9070M64G01	Ring	72-63-14	GE
CF34-RJ (-3A1, 3B1)	X		5024T65G03	Support- Actuator Shaft AFT	72-32-01	GE
CF34-RJ, BJ	X	X	5071T32P01	Coupling	72-09-10	GE
CF6-50	X		1320M44G01	Bracket	72-09-04	GE
CF6-50	X		1555M40P02	Bracket	72-09-04	GE
CF6-50	X		1555M43P02	Bracket	72-09-04	GE
CF6-50	X		1752M12G01	Link	72-23-21	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-50	X		1777M23G01	Bracket, Flowmeter	72-09-04	GE
CF6-50	X		1978M88G01	Bracket	72-09-04	GE
CF6-50	X		1978M90G01	Bracket	72-09-04	GE
CF6-50	X		1990M89P01	Bracket, Tube CDP	72-09-04	GE
CF6-50	X		1991M24G01	Clamp, Support	72-09-04	GE
CF6-50	X		1999M21P02	Ring, Retainer	72-31-25	GE
CF6-50	X		2155M65G01	Bracket	72-09-04	GE
CF6-50	X		7005M95P01	Turnbuckle Assy	79-11-02	GE
CF6-50	X		9009M24P02	Turnbuckle	72-65-13	GE
CF6-50	X		9012M58G08	Valve Assy, Bypass	72-23-20	GE
CF6-50	X		9021M13P03	Seal, Retainer	72-23-01	GE
CF6-50	X		9031M61P21	Mount, Ground Handling	72-56-06	GE
CF6-50	X		9031M61P22	Mount, Ground Handling	72-56-06	GE
CF6-50	X		9032M25G01	Nut Assy, Bearing No.2 Slotted Round	72-21-13	GE
CF6-50	X		9032M63G02	Adapter	72-61-03	GE
CF6-50	X		9035M31G05	Duct, Flange Assy	78-32-03	GE
CF6-50	X		9042M73G02	Bracket	79-11-02	GE
CF6-50	X		9044M61G02	Bracket	72-50-03	GE
CF6-50	X		9044M62G02	Bracket	72-50-03	GE
CF6-50	X		9046M42P01	Nozzle, Oil	72-09-02	GE
CF6-50	X		9049M40G01	Mount Assy	72-22-02	GE
CF6-50	X		9049M40G02	Mount Assy, Gearbox	72-22-02	GE
CF6-50	X		9050M55G01	Liner, Turbine Rear Frame	72-58-02	GE
CF6-50	X		9050M55G02	Liner	72-58-02	GE
CF6-50	X		9057M74G01	Tube, Air CDP	72-09-03	GE
CF6-50	X		9067M34G07	Manifold	72-09-03	GE
CF6-50	X		9067M34G08	Manifold Assy, CDP	72-09-03	GE
CF6-50	X		9068M24P01	Link	72-23-21	GE
CF6-50	X		9068M50G01	Bracket	72-09-04	GE
CF6-50	X		9070M35G03	Tube	72-09-03	GE
CF6-50	X		9070M64P02	Ring Assy, Outer	72-65-00	GE
CF6-50	X		9070M65P02	Adapter, Qik Assy And Disc	72-65-14	GE
CF6-50	X		9118M76G01	Bellcrank Assy	72-23-21	GE
CF6-50	X		9118M92G01	Tube	72-09-03	GE
CF6-50	X		9126M78G01	Mainfold, Air VBV Signal	72-09-03	GE
CF6-50	X		9137M95G01	Connecting Link - Stg 5	72-32-09	GE
CF6-50	X		9155M56G01	Shield, Oil Bearing No. 5	72-54-10	GE
CF6-50	X		9169M46G01	Bracket Assy, Angle	72-09-04	GE
CF6-50	X		9175M93G11	Ring, Assy Fireseal	72-34-14	GE
CF6-50	X		9175M93G12	Ring Assy, Fireseal	72-34-14	GE
CF6-50	X		9176M52G10	Ring Assy	72-34-14	GE
CF6-50	X		9181M38P01	Link	72-65-13	GE
CF6-50	X		9181M38P03	Link, Mount Left Side	72-63-13	GE
CF6-50	X		9181M38P07	Link, Mount Left Side	72-63-13	GE
CF6-50	X		9181M38P09	Link, Mount Left Side	72-65-13	GE
CF6-50	X		9181M93G01	Nozzle, Oil	72-09-02	GE
CF6-50	X		9194M62P001A	Bracket, Transducer	72-09-04	GE
CF6-50	X		9205M84P05	Bolt, Expandable	72-23-11	GE
CF6-50	X		9294M11G01	Bracket	72-09-04	GE
CF6-50	X		9352M23G01	Bracket	72-09-04	GE
CF6-50	X		9355M92G01	Tube, Drain	72-09-03	GE
CF6-50	X		9365M68G01	Seal, Stationary Bearing No. 3	72-23-06	GE
CF6-50	X		9370M36G01	Bracket	72-09-04	GE
CF6-50	X		9601M43P01	Housing	72-61-06	GE
CF6-50	X		9646M87P03	Mount, Handling Ground	72-56-07	GE
CF6-50	X		9690M54P02	Nut	72-21-09	GE
CF6-50	X		9699M60P07	Shaft, RDL DR	72-62-03	GE
CF6-50	X		9699M67P01	Ring, Retainer	72-62-08	GE
CF6-50	X		9699M87P02	Housing, Radial Duplex Ball Bearing	72-63-07	GE
CF6-50	X		9699M88P01	Retainer, Bearing	72-63-08	GE
CF6-50, 80A	X		9047M29P01	Nut, Coupling Forward	72-24-04	GE
CF6-50, 80A	X		9047M29P02	Nut, Coupling Forward	72-24-04	GE
CF6-50, 80A	X		9049M92P01	Clevis, By Pass	72-23-20	GE
CF6-50, 80A	X		9051M51G03	Link, Connecting Stage 1	72-32-09	GE
CF6-50, 80A	X		9064M49G05	Bellcrank, Valve By-Pass	72-23-18	GE
CF6-50, 80A	X		9074M68G04	Fillet, Pylon	72-23-01	GE
CF6-50, 80A	X		9080M96G02	Bracket Assy - Actuator	72-32-10, 72-32-11	GE
CF6-50, 80A	X		9084M24P02	Mount, Actuating Lever	72-32-08	GE
CF6-50, 80A	X		9196M44G01	Manifold Assy, Bearing No. 1	72-21-14	GE
CF6-50, 80A, 6	X		9070M64G03	Ring Assy Outer	72-65-14	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-50, 80A, 80C2	X	X	9051M50G03	Link, Connecting IGV	72-32-09	GE
CF6-50, 80A, 80C2	X		9051M52G03	Connecting Link - Stg 2	72-32-09	GE
CF6-50, 80A, 80C2	X	X	9051M52G04	Link, Connecting Stage 2	72-32-09	GE
CF6-50, 80A, 80C2	X		9079M20G09	Ring Segment, Vane Actuation	72-32-06	GE
CF6-50, 80A, 80C2	X	X	9181M41P02	Link, Cpnnecting Stage 3	72-32-09	GE
CF6-50, 80A, 80C2, 80E	X		1856M41G01	Link Assy, Stg 5	72-32-09	GE
CF6-50, 80A, 80C2, 80E	X		9137M95G02	Connecting Link - Stg 5	72-32-09	GE
CF6-50, 80A, 80C2, 80E	X		9137M95G03	Connecting Link - Stg 5	72-32-09	GE
CF6-6	X		9051M51G01	Link Assy, Stg 1	72-32-09	GE
CF6-80A	X		1305M46P01	Connector	72-09-03	GE
CF6-80A	X		1305M73G01	Manifold, Air Cooling Supply	72-09-03	GE
CF6-80A	X		1306M22G01	Manifold, Shrouded Fuel Nozzle Feeder	72-09-03	GE
CF6-80A	X		1306M45G01	Tube, Fuel	72-09-03	GE
CF6-80A	X		1306M80G02	Tube	72-09-03	GE
CF6-80A	X		1332M37G01	Manifold	72-09-03	GE
CF6-80A	X		1347M93P01	Ring, Integral Seal Bearing No 6	72-57-14	GE
CF6-80A	X		1347M93P04	Ring, Integral Seal Bearing No 6	72-57-14	GE
CF6-80A	X		1862M79G01	Arrestor, Flame	72-24-05	GE
CF6-80A	X		9006M31G02	Tube	72-09-03	GE
CF6-80A	X		9011M20G02	Tube, Oil	72-09-03	GE
CF6-80A	X		9012M61G08	Bellcrank, Valve By-Pass	72-23-18	GE
CF6-80A	X		9021M13P04	Seal, Retainer	72-23-00	GE
CF6-80A	X		9205M84P04	Bolt, Expandable	72-23-10	GE
CF6-80A	X		9209M47G01	Connector	72-09-03	GE
CF6-80A	X		9209M47G02	Connector	72-09-03	GE
CF6-80A	X		9210M88G01	Tube-Vsv Head End Right	72-09-03	GE
CF6-80A	X		9215M84P02	Turnbuckle	72-65-10	GE
CF6-80A	X		9215M98P05	Retainer, Support Seal	72-23-01	GE
CF6-80A	X		9216M60G01	Bellcrank, Feedback	72-32-10	GE
CF6-80A	X		9217M52G01	Tube-Pump,Mec	72-09-03	GE
CF6-80A	X		9218M11P04	Shield, Heat	72-53-03	GE
CF6-80A	X		9218M11P06	Shield, Heat	72-53-03	GE
CF6-80A	X		9218M11P07	Shield, Heat	72-53-03	GE
CF6-80A	X		9219M29G02	Plug Assy, Borescope	72-55-13	GE
CF6-80A	X		9220M25G04	Gearbox, Mount Left	72-65-10	GE
CF6-80A	X		9221M25G01	Tube, Oil Scavenge Tgb	72-09-03	GE
CF6-80A	X		9221M58G01	Tube-B Sump Pressur	72-09-03	GE
CF6-80A	X		9221M60G01	Tube-Air B Sump Press Aft	72-09-03	GE
CF6-80A	X	X	9223M19G04	Thrust Link	72-65-10	GE
CF6-80A	X		9223M20G01	LS Aft Link	72-65-10	GE
CF6-80A	X		9223M21G01	RS Aft link	72-65-10	GE
CF6-80A	X		9226M55G01	Tube	72-09-03	GE
CF6-80A	X		9232M72G01	Transfer Gearbox Aft Adapter	72-63-04	GE
CF6-80A	X		9232M77P01	Covered Windage	72-51-05	GE
CF6-80A	X		9238M41G01	Tube-Vsv Rod End Right Side	72-09-03	GE
CF6-80A	X		9238M45G01	Tube-Vbv Head Right Side	72-09-03	GE
CF6-80A	X		9240M13G01	Tube, Cooling	72-09-03	GE
CF6-80A	X		9241M30G01	Hose-Cit Sig	72-09-03	GE
CF6-80A	X	X	9241M31G01	Hose-Cit Return	72-09-03	GE
CF6-80A	X		9241M48G02	Tube-Oil Tank Vent	72-09-03	GE
CF6-80A	X		9245M14G01	Tube-Air Vent	72-09-03	GE
CF6-80A	X		9245M71G03	Tube-ABG,Scav	72-09-03	GE
CF6-80A	X	X	9246M62G01	Manifold-Oil Main Supply Aft	72-09-03	GE
CF6-80A	X	X	9246M64G01	Tube-Supply	72-09-03	GE
CF6-80A	X		9246M84G01	Tube-B Scav	72-09-03	GE
CF6-80A	X		9249M20P01	Seal, Rotating Air/Oil	72-57-09	GE
CF6-80A	X		9249M20P03	Seal, Rotating Air/Oil	72-57-09	GE
CF6-80A	X		9249M20P04	Seal, Rotating Air/Oil	72-57-09	GE
CF6-80A	X		9249M27P01	Slinger, Oil Bearing No 6	72-57-08	GE
CF6-80A	X		9249M29P01	Seal, Shield	72-58-13	GE
CF6-80A	X		9250M65G01	Tube-Air Ps3 To Alt Sensor R/S	72-09-03	GE
CF6-80A	X		9254M34P01	Joint-Flexible	72-09-03	GE
CF6-80A	X		9254M54G01	Manifold-Oil	72-09-03	GE
CF6-80A	X		9257M11P02	Joint-Flexible	72-09-03	GE
CF6-80A	X		9257M19G01	Tube-Air Cdp	72-09-03	GE
CF6-80A	X		9257M32G06	Transition-Duct Supply	72-09-03	GE
CF6-80A	X		9257M41G01	Tube-Eductor Fwd	72-09-03	GE
CF6-80A	X		9257M62P01	Hose	72-09-03	GE
CF6-80A	X		9258M64G01	Tube-Air Hpt Cooling	72-09-03	GE
CF6-80A	X		9258M66G05	Tee-Air Hpt Cooling	72-09-03	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80A	X		9259M50G01	Tube-Air	72-09-03	GE
CF6-80A	X		9261M25G01	Manifold	72-09-03	GE
CF6-80A	X		9261M27G01	Manifold	72-09-03	GE
CF6-80A	X		9261M31G01	Manifold	72-09-03	GE
CF6-80A	X	X	9262M57G01	Manifold-Oil Main Supply	72-09-03	GE
CF6-80A	X		9262M84G02	Tube-Oil B Scav Aft Adapter	72-09-03	GE
CF6-80A	X		9263M92G02	HPT Aft Seal	72-53-08	GE
CF6-80A	X		9263M92G04	HPT Aft Seal	72-53-08	GE
CF6-80A	X	X	9268M26G05	Manifold-Oil Scavenge	72-09-03	GE
CF6-80A	X		9268M40G01	Tube-Oil Supply Mid	72-09-03	GE
CF6-80A	X		9268M44G01	Tube-Oil C Scavenge Aft	72-09-03	GE
CF6-80A	X		9268M46G01	Tube-Oil C Scav Aft	72-09-03	GE
CF6-80A	X		9269M24G01	Tube	72-09-03	GE
CF6-80A	X		9269M26G01	Tube	72-09-03	GE
CF6-80A	X		9269M53G03	Tube	72-09-03	GE
CF6-80A	X		9269M94G06	Tube-Oil Tank To Pump	72-09-03	GE
CF6-80A	X		9269M98G01	Tube-Low Pressure Recoup	72-09-03	GE
CF6-80A	X		9270M25G02	Tube-C Scavenge	72-09-03	GE
CF6-80A	X	X	9270M31P02	Tube	72-09-03	GE
CF6-80A	X		9270M32P03	Tube	72-09-03	GE
CF6-80A	X		9270M37P01	Section-Tube	72-09-03	GE
CF6-80A	X		9271M92G01	Tube-Oil B Scavenge Fwd	72-09-03	GE
CF6-80A	X		9271M94G01	Tube-Oil B Scavenge	72-09-03	GE
CF6-80A	X		9285M33G01	Manifold Fuel-Head End Vbv	72-09-03	GE
CF6-80A	X		9285M39P10	Hose-Oil	72-09-03	GE
CF6-80A	X		9285M40P01	Tube-Hose Supply	72-09-03	GE
CF6-80A	X		9285M94G01	Tube-Air Hpt Cooling Upper R/S	72-09-03	GE
CF6-80A	X		9285M96G01	Tube-Air Hpt Cooling	72-09-03	GE
CF6-80A	X		9285M98G01	Tube-Air Hpt Cooling	72-09-03	GE
CF6-80A	X		9288M10G01	Tube-Air Hpt Supply	72-09-03	GE
CF6-80A	X		9289M10G01	Tube-Oil Return	72-09-03	GE
CF6-80A	X		9289M11G01	Tube-Oil Supply	72-09-03	GE
CF6-80A	X		9291M60P01	Joint-Flex	72-09-03	GE
CF6-80A	X		9291M72G02	Tube-Oil	72-09-03	GE
CF6-80A	X		9292M39G01	Tube	72-09-03	GE
CF6-80A	X		9292M68G02	Tube-Air Ps3 To	72-09-03	GE
CF6-80A	X		9292M75G01	Manifold-Air	72-09-03	GE
CF6-80A	X		9292M94G01	Tube-Oil B Sump Supply L/S	72-09-03	GE
CF6-80A	X		9295M20G02	CRF Adaptor	72-34-21	GE
CF6-80A	X	X	9295M30G06	Segment, Actuation Ring Assy Stage 4	72-32-06	GE
CF6-80A	X		9295M72P04	Seal-Rotating Air/Oil 5R	72-53-13	GE
CF6-80A	X		9297M29G02	Tube-Fuel Vbv Head End Left Side	72-09-03	GE
CF6-80A	X		9297M31G02	Tube-Vsv Rod End	72-09-03	GE
CF6-80A	X		9297M44G01	Manifold-Cit Sensor	72-09-03	GE
CF6-80A	X		9298M18G02	Tube-Oil B Scav Aft Seg	72-09-03	GE
CF6-80A	X		9298M64G01	Tube-Oil B Sump Supply	72-09-03	GE
CF6-80A	X		9298M68G01	Tube-Oil	72-09-03	GE
CF6-80A	X		9299M60G05	Liner Assy, OGV	72-34-18	GE
CF6-80A	X		9299M66G01	RS Mount Link	72-65-10	GE
CF6-80A	X		9299M73P02	Spacer	72-53-04	GE
CF6-80A	X		9299M76P04	Ring, Damper	72-31-18	GE
CF6-80A	X		9303M44G02	Tube Hose Fuel-Head End Vsv	72-09-03	GE
CF6-80A	X		9303M46G01	Tube And Hose-Fuel Rod End Vsv	72-09-03	GE
CF6-80A	X		9303M48G01	Tube Hose Fuel-Head End Vbv	72-09-03	GE
CF6-80A	X		9303M50G01	Manifold Fuel-Rod End Vbv	72-09-03	GE
CF6-80A	X		9319M21P07	Ring, Damper	72-31-18	GE
CF6-80A	X		9319M21P08	Ring, Damper	72-31-18	GE
CF6-80A	X		9327M61G01	Tube-Air Cooling Valve	72-09-03	GE
CF6-80A	X		9327M79G01	Tube-Oil Pump	72-09-03	GE
CF6-80A	X		9327M81G02	Tube-Oil	72-09-03	GE
CF6-80A	X		9344M93G02	Tube-Fuel F/M To Cooler	72-09-03	GE
CF6-80A	X		9350M69G01	Tube Assy-P25 Air	72-09-03	GE
CF6-80A	X		9354M30G01	Tube-Air Hpt Recoup	72-09-03	GE
CF6-80A	X		9354M32G01	Tube-Air Hpt Recoup	72-09-03	GE
CF6-80A	X		9354M35G01	Tube-Air Hp Recoup Upper	72-09-03	GE
CF6-80A	X		9354M38G01	Tube-Air Recoup Lower	72-09-03	GE
CF6-80A	X		9354M87G01	Tube-Air Lpt Cooling Supply L/S	72-09-03	GE
CF6-80A	X		9355M20G02	Tube-Oil Tank Outlet Fwd	72-09-03	GE
CF6-80A	X		9355M41G01	Tube-Fuel	72-09-03	GE
CF6-80A	X		9355M69G01	Tube-Air Ps3	72-09-03	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80A	X		9356M46P03	Spacer	72-53-04	GE
CF6-80A	X		9356M46P04	Spacer	72-53-04	GE
CF6-80A	X		9356M46P05	Spacer	72-53-04	GE
CF6-80A	X		9358M58G01	Tube-Air Cdp	72-09-03	GE
CF6-80A	X		9360M85G01	Tube-Vsv Rod End	72-09-03	GE
CF6-80A	X		9360M87G01	Tube-Vsv Head End	72-09-03	GE
CF6-80A	X		9361M14G01	Tube-Air Ps3 Aft	72-09-03	GE
CF6-80A	X		9361M34G01	Tube-Oil Tank	72-09-03	GE
CF6-80A	X		9361M36G01	Tube-Oil Tank	72-09-03	GE
CF6-80A	X		9361M43G01	Tube-Air	72-09-03	GE
CF6-80A	X		9361M45G01	Tube-Air Mid	72-09-03	GE
CF6-80A	X		9361M49G01	Tube-Air Ps3 Aft	72-09-03	GE
CF6-80A	X	X	9361M62G01	Tube-Oil Vent	72-09-03	GE
CF6-80A	X		9361M72G02	Manifold-Air Lpt Cooling Lower	72-09-03	GE
CF6-80A	X		9361M75G01	Manifold-Air Lpt Cooling R/S	72-09-03	GE
CF6-80A	X		9361M81G01	Tube-Air	72-09-03	GE
CF6-80A	X		9362M26P01	fan speed cage (01-420, 72-21-00)	72-21-07	GE
CF6-80A	X		9362M32G01	No. 6 bearing aft cover	72-58-11	GE
CF6-80A	X		9362M34P03	Seal, Rotating Air/Oil	72-57-09	GE
CF6-80A	X		9362M38P01	Seal - Rorating Air/Oil 5R Aft	72-53-13	GE
CF6-80A	X		9362M38P02	Seal - Rorating Air/Oil 5R Aft	72-53-13	GE
CF6-80A	X	X	9363M24G02	Tube-Oil Transfer Gearbox Scavenge	72-09-03	GE
CF6-80A	X		9363M86G01	Tube-Fuel Supply	72-09-03	GE
CF6-80A	X		9364M67G01	Tube-Air Poc Fwd	72-09-03	GE
CF6-80A	X	X	9364M69P03	Tube-Fuel	72-09-03	GE
CF6-80A	X		9364M73G03	Eductor-Air Pmc	72-09-03	GE
CF6-80A	X		9366M17G01	Tube-Air Pmc Cooling	72-09-03	GE
CF6-80A	X		9366M44G02	Tube-Eductor Aft	72-09-03	GE
CF6-80A	X		9366M48G01	Tube-Air Poc Aft	72-09-03	GE
CF6-80A	X		9366M50G01	Tube-Air Poc Mid	72-09-03	GE
CF6-80A	X		9366M53G01	Tube-Fuel	72-09-03	GE
CF6-80A	X		9366M77G01	Tube-Fuel	72-09-03	GE
CF6-80A	X		9366M79G01	Tube-Fuel	72-09-03	GE
CF6-80A	X		9366M83G01	Tube	72-09-03	GE
CF6-80A	X		9367M58P01	Ring, Integral Seal Bearing No 6	72-57-14	GE
CF6-80A	X		9368M27G01	Tube-T2 Sensor Feedback	72-09-03	GE
CF6-80A	X		9369M22G01	Tube-Fuel	72-09-03	GE
CF6-80A	X		9369M60G01	Tube-Oil B Scavenge Aft	72-09-03	GE
CF6-80A	X		9369M71G01	Tube-Fuel Vbv Return Right Side	72-09-03	GE
CF6-80A	X		9370M81G01	Tube-Fuel Comb Drain	72-09-03	GE
CF6-80A	X	X	9370M83G01	Tube-Fuel Combustor Drain	72-09-03	GE
CF6-80A	X		9371M65G02	Tube-Air Lpt Case Cooling Aft	72-09-03	GE
CF6-80A	X		9371M67G03	Tube-Air Lpt Case Cooling Fwd	72-09-03	GE
CF6-80A	X		9371M72G01	Manfold-Air Lp Recoup Upr	72-09-03	GE
CF6-80A	X		9371M73G01	Manfold-Air Lp Recoup Mid	72-09-03	GE
CF6-80A	X		9371M92G01	Tube-Oil Supply Aft	72-09-03	GE
CF6-80A	X		9374M77P01	Rod End	72-65-10	GE
CF6-80A	X		9397M55P01	Seal, Rotating Air/Oil 5R	72-53-13	GE
CF6-80A	X		9696M28G03	Nut Assy, Bearing No 6	72-57-07	GE
CF6-80A	X		9696M28G05	Nut Assy, Bearing No 6	72-57-07	GE
CF6-80A, 80C2	X	X	9137M95G04	Link Assy, Connectine Stage 5	72-32-09	GE
CF6-80A, 80C2	X	X	9234M75P03	Cover, Impeller	72-53-04	GE
CF6-80A, 80C2	X		9258M64G02	Tube, Air HPT Cooling	72-09-03	GE
CF6-80A, 80C2	X		9258M66G01	Tee, Air HPT Cooling	72-09-03	GE
CF6-80A, 80C2	X	X	9258M67G01	Elbow, Air HPT Cooling	72-09-03	GE
CF6-80A, 80C2	X		9290M85P01	Ring, Piston	72-53-15	GE
CF6-80A, 80C2	X		9299M60G07	Liner Assy, OGV	72-34-18	GE
CF6-80A, 80C2	X		9304M93G02	Elbow, HPT Air	72-09-03	GE
CF6-80A, 80C2	X		9354M37G01	Elbow, HP Recoup	72-09-03	GE
CF6-80A, 80C2	X		9392M67P03	Seal-Rotating Air/Oil 5R	72-53-13	GE
CF6-80A, 80C2, 80E	X	X	1288M53G01	Nozzle, Oil	72-09-02	GE
CF6-80A, 80C2, 80E	X	X	9215M71P01	Oil Seal Mating Ring	72-65-07	GE
CF6-80A, 80C2, 80E	X	X	9215M71P02	Oil Seal Mating Ring	72-65-07	GE
CF6-80A, 80C2, 80E	X		9229M33P01	Joint-Flexible	72-09-03	GE
CF6-80A, 80C2, 80E	X		9671M82P04	Seal Ring	72-31-17	GE
CF6-80A, 80C2, CFM56-5A	X		2703-200	Coupling	72-09-04	GE/CFMI
CF6-80C2	X		109604	Vent, Tube and Hose	72-09-03	GE
CF6-80C2	X	X	109642	Hose	72-09-03	GE
CF6-80C2	X	X	109657	Tube and Hose VBV	72-09-03	GE
CF6-80C2	X		109992	Tube, Fuel Hose	72-09-03	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2	X		110013	Tube, Fuel Servo Heater	72-09-03	GE
CF6-80C2	X	X	110396	Tube, Fuel Hose	72-09-03	GE
CF6-80C2	X		110591	Hose, Upper Fan Drain	72-09-03	GE
CF6-80C2	X		110640	Tube, Fuel Servo Heater	72-09-03	GE
CF6-80C2	X		112684	Tube And Hose, Fuel VBV	72-09-03	GE
CF6-80C2	X		112685	Tube And Hose, Fuel VBV	72-09-03	GE
CF6-80C2	X		112993	Hose, P49	72-09-03	GE
CF6-80C2	X		113252	Tube And Hose, Fuel VSV	72-09-03	GE
CF6-80C2	X		113253	Tube And Hose, Fuel VSV	72-09-03	GE
CF6-80C2	X		113254	Tube And Hose, Fuel VBV	72-09-03	GE
CF6-80C2	X		113255	Tube And Hose, Fuel VBV	72-09-03	GE
CF6-80C2	X		113627	Tube/Hose	72-09-03	GE
CF6-80C2	X	X	113764	Tube Hose	72-09-03	GE
CF6-80C2	X		114307	Tube And Hose, Fuel	72-09-03	GE
CF6-80C2	X		114308	Tube And Hose, Fuel	72-09-03	GE
CF6-80C2	X	X	114309	Tube, Fuel Hose	72-09-03	GE
CF6-80C2	X		114311	Tube And Hose, Fuel VSV	72-09-03	GE
CF6-80C2	X		114856	Vent, Tube and Hose	72-09-03	GE
CF6-80C2	X		115207	Tube, Fuel Servo Heater	72-09-03	GE
CF6-80C2	X	X	115758	Tube/Hose	72-09-03	GE
CF6-80C2	X		118799	Hose, P3G	72-09-03	GE
CF6-80C2	X		108292-9	Hose, Oil	72-09-03	GE
CF6-80C2	X		112421-1	Tube And Hose, Oil IDG Cooling	72-09-03	GE
CF6-80C2	X		112421-12	Tube And Hose, Oil IDG Cooling	72-09-03	GE
CF6-80C2	X	X	112421-16	Tube, Hose Oil	72-09-03	GE
CF6-80C2	X	X	113252-1	Tube And Hose, Fuel VSV	72-09-03	GE
CF6-80C2	X		113253-1	Tube And Hose, Fuel VSV	72-09-03	GE
CF6-80C2	X	X	113254-2	Tube And Hose, Fuel VBV	72-09-03	GE
CF6-80C2	X	X	113255-1	Tube And Hose, Fuel VBV	72-09-03	GE
CF6-80C2	X		113635L0584-180	Hose, Teflon	72-09-03	GE
CF6-80C2	X	X	114741H00845	Hose, Teflon	72-09-03	GE
CF6-80C2	X	X	115207-1	Tube, Fuel Servo Heater	72-09-03	GE
CF6-80C2	X		1153M26G15	Clamp	72-00-00	GE
CF6-80C2	X	X	1288M68P01	Shield, Heat	72-00-04	GE
CF6-80C2	X		1288M68P06	Shield, Heat	72-58-14	GE
CF6-80C2	X		1288M76P01	Tube, Connector HPT	72-09-03	GE
CF6-80C2	X	X	1288M81G01	Tube, Oil Supply	72-58-14	GE
CF6-80C2	X	X	1289M38G01	Manifold, Fuel	72-09-03	GE
CF6-80C2	X	X	1289M67P09	Tube And Hose, Fuel H/M No. 1 Sensor To Mec	72-09-03	GE
CF6-80C2	X		1289M67P10	Tube And Hose, Fuel H/M No. 1 Sensor To Mec	72-09-03	GE
CF6-80C2	X		1289M67P11	Tube And Hose, Fuel H/M No. 1 Sensor To Mec	72-09-03	GE
CF6-80C2	X		1289M67P12	Tube And Hose, Fuel H/M No. 1 Sensor To Mec	72-09-03	GE
CF6-80C2	X		1289M67P13	Tube And Hose, Fuel H/M No. 1 Sensor To Mec	72-09-03	GE
CF6-80C2	X		1289M67P16	Tube And Hose, Fuel H/M No. 1 Sensor To Mec	72-09-03	GE
CF6-80C2	X	X	1289M70G01	Tube, No. 1 Scavenge Oil	72-09-03, Maybe 72-00-00	GE
CF6-80C2	X		1289M72G01	Manifold, Fuel	72-09-03	GE
CF6-80C2	X	X	1289M76G01	Tube, H/M No. 1 Sensor Fuel Drain	72-09-03	GE
CF6-80C2	X		1289M81G01	Tube, T2 Sensor Lower PB Fuel	72-09-03	GE
CF6-80C2	X	X	1290M22G01	Tube, LP Recoup Forward Air	72-09-03	GE
CF6-80C2	X		1290M23G01	Tube, LP Recoup Forward Air	72-09-03	GE
CF6-80C2	X	X	1290M24G01	Tube, LP Recoup Forward Air	72-09-03	GE
CF6-80C2	X	X	1290M24G08	Tube, LP Recoup Forward Air	72-09-03	GE
CF6-80C2	X		1290M26P01	Tube, Hose	72-09-03	GE
CF6-80C2	X		1290M34G01	Bracket	72-09-04	GE
CF6-80C2	X		1290M39G07	Tube, Air HP Recoup	72-09-03	GE
CF6-80C2	X		1290M39G08	Tube, Air HP Recoup	72-09-03	GE
CF6-80C2	X		1290M39G09	Tube, Air HP Recoup	72-09-03	GE
CF6-80C2	X	X	1290M43G01	Shroud, Fuel	72-09-03	GE
CF6-80C2	X	X	1290M44G01	Shroud, Fuel	72-09-03	GE
CF6-80C2	X		1290M57P003A	Bracket, Oil Scavenge	72-09-04	GE
CF6-80C2	X	X	1290M88G01	Duct, Air Acc	72-09-03	GE
CF6-80C2	X		1292M36P01	Tube	72-09-03	GE
CF6-80C2	X		1292M36P02	Tube	72-09-03	GE
CF6-80C2	X		1292M42P01	Bracket	72-09-04	GE
CF6-80C2	X	X	1292M74G01	Shaft, Drive	72-67-04	GE
CF6-80C2	X		1292M86P04	Bracket, Yoke	71-21-01	GE
CF6-80C2	X		1292M86P05	Bracket, Yoke	71-21-01	GE
CF6-80C2	X		1292M86P06	Bracket, Yoke	72-09-04	GE
CF6-80C2	X	X	1292M86P07	Bracket, Yoke	72-09-04	GE
CF6-80C2	X		1293M12P001B	Bracket	72-09-04	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2	X		1293M13P001B	Bracket	72-09-04	GE
CF6-80C2	X		1293M14P001B	Bracket	72-09-04	GE
CF6-80C2	X	X	1293M23G01	Tube, No. 1 Sensor Drain Fuel	72-09-03	GE
CF6-80C2	X		1293M30G01	Tube, Upper Scupper Drn	72-09-03	GE
CF6-80C2	X		1293M32G01	Tube, Lower Scupper Drain	72-09-03	GE
CF6-80C2	X		1293M34P01	Joint, Flexible	72-09-03	GE
CF6-80C2	X		1293M34P02	Joint, Flexible	72-09-03	GE
CF6-80C2	X		1293M34P03	Joint, Flexible	72-09-03	GE
CF6-80C2	X		1293M35G01	Duct, Air	72-09-03	GE
CF6-80C2	X	X	1293M35G02	Duct, Air	72-09-03	GE
CF6-80C2	X		1293M36G01	Duct, Air	72-09-03	GE
CF6-80C2	X		1293M36G02	Duct, Air	72-09-03	GE
CF6-80C2	X		1293M36G06	Duct, Air	72-09-03	GE
CF6-80C2	X		1293M36G07	Duct, Air	72-09-03	GE
CF6-80C2	X	X	1293M41P01	Tube And Hose, CIT	72-09-03	GE
CF6-80C2	X		1293M41P02	Tube And Hose, CIT	72-09-03	GE
CF6-80C2	X		1293M41P03	Tube And Hose, CIT	72-09-03	GE
CF6-80C2	X		1293M41P04	Tube And Hose, CIT	72-09-03	GE
CF6-80C2	X	X	1293M65G01	Tube, Cooling Signal Valve 11th Stage	72-09-03	GE
CF6-80C2	X	X	1293M67G01	Tube, Cooling Accessory Valve	72-09-03	GE
CF6-80C2	X		1293M73P001A	Bracket	72-09-04	GE
CF6-80C2	X		1293M73P001B	Bracket	72-09-04	GE
CF6-80C2	X		1293M73P001C	Bracket	72-09-04	GE
CF6-80C2	X		1293M74P01	Hose, Upper Fan Drain	72-09-03	GE
CF6-80C2	X		1293M74P02	Hose, Upper Fan Drain	72-09-03	GE
CF6-80C2	X		1293M74P03	Hose, Upper Fan Drain	72-09-03	GE
CF6-80C2	X		1293M74P04	Hose, Upper Fan Drain	72-09-03	GE
CF6-80C2	X		1293M79P01	Hose Assy	72-09-03	GE
CF6-80C2	X		1293M79P02	Hose Assy	72-09-03	GE
CF6-80C2	X	X	1293M79P03	Hose Assy	72-09-03	GE
CF6-80C2	X		1293M79P04	Hose Assy	72-09-03	GE
CF6-80C2	X		1294M10G01	Tube, Fuel	72-09-03	GE
CF6-80C2	X		1294M10G02	Tube, Fuel	72-09-03	GE
CF6-80C2	X		1294M10G03	Tube, Fuel	72-09-03	GE
CF6-80C2	X		1294M10G04	Tube, Fuel	72-09-03	GE
CF6-80C2	X		1294M10G05	Tube, Fuel	72-09-03	GE
CF6-80C2	X		1294M10G06	Tube, Fuel	72-09-03	GE
CF6-80C2	X		1294M22G06	Tube, Air B Sump	72-09-03	GE
CF6-80C2	X		1294M22G07	Tube, Air B Sump	72-09-03	GE
CF6-80C2	X		1294M28G01	Tube, T2 Sensor Upper PB Fuel	72-09-03	GE
CF6-80C2	X		1294M53P001A	Bracket	72-09-04	GE
CF6-80C2	X	X	1294M84G03	Bracket	72-09-04	GE
CF6-80C2	X		1294M88G01	Tube, C Scavenge Mid Oil	72-09-03	GE
CF6-80C2	X	X	1294M90G01	Tube, Oil C Sump Scavenge	72-09-03	GE
CF6-80C2	X		1297M10P001A	Bracket	72-09-04	GE
CF6-80C2	X		1297M13P04	Coupling, Rubber	72-09-04	GE
CF6-80C2	X		1297M14G01	Tube, Air HPT	72-09-03	GE
CF6-80C2	X		1297M14G04	Tube, Air HPT Cooling	72-09-03	GE
CF6-80C2	X		1297M14G06	Tube, Air HPT	72-09-03	GE
CF6-80C2	X		1297M14G07	Tube, Air HPT	72-09-03	GE
CF6-80C2	X		1297M14G08	Tube, Air HPT	72-09-03	GE
CF6-80C2	X		1297M14G09	Tube, Air HPT Cooling	72-09-03	GE
CF6-80C2	X		1297M14G10	Tube, Air HPT	72-09-03	GE
CF6-80C2	X	X	1297M14G11	Tube, Air HPT	72-09-03	GE
CF6-80C2	X		1297M14G13	Tube, Air HPT Cooling	72-09-03	GE
CF6-80C2	X		1297M14G14	Tube, Air HPT	72-09-03	GE
CF6-80C2	X		1297M16G03	Bracket, Ignition	72-09-04	GE
CF6-80C2	X		1297M16G04	Bracket, Ignition	72-09-04	GE
CF6-80C2	X		1297M17G03	Bracket	72-09-04	GE
CF6-80C2	X		1297M17G04	Bracket	72-09-04	GE
CF6-80C2	X		1297M37G03	Bracket	72-09-04	GE
CF6-80C2	X		1297M40G01	Bracket, Tube T12 Sensor	72-09-04	GE
CF6-80C2	X		1297M40G07	Bracket	72-09-04	GE
CF6-80C2	X		1297M41P001B	Bracket, T2	72-09-04	GE
CF6-80C2	X		1297M50G03	Bracket	72-09-04	GE
CF6-80C2	X		1297M52P001A	Bracket	72-09-04	GE
CF6-80C2	X	X	1297M56G01	Tube	72-09-03	GE
CF6-80C2	X		1297M65G01	Manifold, Air	72-09-03	GE
CF6-80C2	X	X	1297M72G05	Bracket	72-09-04	GE
CF6-80C2	X		1297M79G03	Tube, HPT/LPT Cooling	72-09-03	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2	X		13000106-0120C	Hose	72-09-03	GE
CF6-80C2	X		13000204-0100M	Hose, P25	72-09-03	GE
CF6-80C2	X	X	13000205-0065H	Hose, P3G	72-09-03	GE
CF6-80C2	X		130102C01475231	Hose, Teflon	72-09-03	GE
CF6-80C2	X	X	1301M13G03	Bracket	72-32-10	GE
CF6-80C2	X		1301M13G13	Bracket	72-32-10	GE
CF6-80C2	X	X	1301M16G01	Mount	72-32-11	GE
CF6-80C2	X		1301M70P02	Ring, Damper	72-63-00	GE
CF6-80C2	X	X	1302M11G01	Manifold, Fuel	72-09-03	GE
CF6-80C2	X		1302M30G01	Bracket	72-09-04	GE
CF6-80C2	X		1302M47G01	Manifold, Fuel CIT Drain	72-09-03	GE
CF6-80C2	X		1302M50G07	Bracket	72-09-04	GE
CF6-80C2	X		1302M80G02	Tube, 11th Stage	72-09-03	GE
CF6-80C2	X		1302M80G03	Tube, 11th Stage	72-09-03	GE
CF6-80C2	X		1302M86G01	Tube, Oil	72-09-03	GE
CF6-80C2	X	X	1302M96G01	Manifold, Fuel	72-09-03	GE
CF6-80C2	X		1303M30G02	Shroud	72-09-04	GE
CF6-80C2	X		1303M31G10	Manifold	72-09-03	GE
CF6-80C2	X		1303M31G12	Manifold	72-09-03	GE
CF6-80C2	X		1303M32G10	Manifold	72-09-03	GE
CF6-80C2	X		1303M32G12	Manifold	72-09-03	GE
CF6-80C2	X		1303M33G04	Manifold, Fuel Drain	72-09-03	GE
CF6-80C2	X	X	1303M33G05	Manifold, Fuel Drain	72-09-03	GE
CF6-80C2	X	X	1303M33G06	Manifold, Fuel Drain	72-09-03	GE
CF6-80C2	X		1303M43G01	Tube, B Sump Scavenge Oil	72-09-03	GE
CF6-80C2	X		1303M45G01	Tube, C Sump Scavenge Oil	72-09-03	GE
CF6-80C2	X		1303M45G03	Tube, C Sump Scavenge Oil	72-09-03	GE
CF6-80C2	X		1303M50P001A	Bracket	72-09-04	GE
CF6-80C2	X		1303M71G03	Tube, Air	72-09-03	GE
CF6-80C2	X		1303M88P001A	Bracket	72-09-04	GE
CF6-80C2	X		1304M23G01	Tube	72-09-03	GE
CF6-80C2	X		1304M26P03	Bolt, Shoulder	71-21-01	GE
CF6-80C2	X		1304M31P03	Bracket	72-09-04	GE
CF6-80C2	X		1304M31P04	Bracket	72-09-04	GE
CF6-80C2	X		1304M50G01	Tube, Expandable	72-09-03	GE
CF6-80C2	X		1304M52G01	Plug Assy, Borescope	72-52-13	GE
CF6-80C2	X		1305M42G01	Cap	72-09-03	GE
CF6-80C2	X	X	1307M10G01	Tube, CDP	72-09-03	GE
CF6-80C2	X	X	1307M10G02	Tube, CDP	72-09-03	GE
CF6-80C2	X		1307M10G03	Tube, CDP	72-09-03	GE
CF6-80C2	X		1307M14G01	Tube, 11th Stage	72-09-03	GE
CF6-80C2	X		1307M16G01	Tube, 11th Stage	72-09-03	GE
CF6-80C2	X		1307M16G02	Tube, 11th Stage	72-09-03	GE
CF6-80C2	X		1307M51G01	Bracket	72-09-04	GE
CF6-80C2	X		1307M76G01	Bracket	72-09-04	GE
CF6-80C2	X		1307M76G03	Bracket	72-09-04	GE
CF6-80C2	X		1307M89G01	Tube, Lower Heat Exchanger to Tank	72-09-03	GE
CF6-80C2	X		1308M31P001A	Bracket	72-09-04	GE
CF6-80C2	X	X	1308M32G03	Link, Support	72-09-04	GE
CF6-80C2	X		1308M32G04	Link, Support	72-09-04	GE
CF6-80C2	X	X	1308M32G05	Link, Support	72-09-04	GE
CF6-80C2	X	X	1308M32G06	Link, Support	72-09-04	GE
CF6-80C2	X	X	1308M32G07	Link, Support	72-09-04	GE
CF6-80C2	X	X	1308M32G11	Link, Support	72-09-04	GE
CF6-80C2	X		1308M32G17	Link, Support	72-09-04	GE
CF6-80C2	X	X	1308M32G20	Link, Support	72-09-04	GE
CF6-80C2	X	X	1308M32G21	Link, Support	72-09-04	GE
CF6-80C2	X	X	1308M32G22	Link, Support	72-09-04	GE
CF6-80C2	X		1308M32G23	Link, Support	72-09-04	GE
CF6-80C2	X	X	1308M32G27	Link Support	72-09-04	GE
CF6-80C2	X	X	1308M32G34	Link Support	72-09-04	GE
CF6-80C2	X		1308M38G08	Bracket	72-09-04	GE
CF6-80C2	X		1308M54G01	Tube, Mast Manifold to Module	72-09-03	GE
CF6-80C2	X		1308M56G01	Tube, Mast Manifold to Module	72-09-03	GE
CF6-80C2	X	X	1308M58G01	Tube, Mast Manifold to Module	72-09-03	GE
CF6-80C2	X	X	1308M58G02	Tube, Mast Manifold to Module Oil	72-09-03	GE
CF6-80C2	X		1308M70G03	Bracket	72-09-04	GE
CF6-80C2	X		1308M74G01	Tube	72-09-03	GE
CF6-80C2	X		1308M74G04	Tube	72-09-03	GE
CF6-80C2	X	X	1308M78G01	Tube, Fuel Pump Drain Fuel	72-09-03	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2	X	X	1308M78G02	Tube, Fuel Pump Drain Fuel	72-09-03	GE
CF6-80C2	X	X	1308M82G01	Tube, Starter Drain Oil	72-09-03	GE
CF6-80C2	X	X	1308M82G02	Tube, Starter Drain Oil	72-09-03	GE
CF6-80C2	X		1308M98G01	Tube, IDG Valve Aft Signal Air	72-09-03	GE
CF6-80C2	X	X	1309M10G02	Tube, Fuel Pump Drain Fuel	72-09-03	GE
CF6-80C2	X		1309M24G03	Bracket	72-09-04	GE
CF6-80C2	X		1309M37G01	Bracket	72-09-04	GE
CF6-80C2	X		1309M45G01	Tube, Fuel	72-09-03	GE
CF6-80C2	X		1309M45G03	Tube, Fuel	72-09-03	GE
CF6-80C2	X		1309M45G04	Tube, Fuel	72-09-03	GE
CF6-80C2	X		1309M64P01	Tube	72-09-03	GE
CF6-80C2	X		1309M64P02	Tube	72-09-03	GE
CF6-80C2	X		1309M64P03	Tube	72-09-03	GE
CF6-80C2	X		1309M64P04	Tube	72-09-03	GE
CF6-80C2	X		1309M64P05	Tube	72-09-03	GE
CF6-80C2	X		1309M64P07	Tube	72-09-03	GE
CF6-80C2	X		1309M68G03	Manifold, ACC Air	72-09-03	GE
CF6-80C2	X		1309M78G01	Duct, Air Wye	72-09-03	GE
CF6-80C2	X		1309M78G05	Duct, Air Wye	72-09-03	GE
CF6-80C2	X		1309M78G06	Duct, Air Wye	72-09-03	GE
CF6-80C2	X		1309M78G07	Duct, Air Wye	72-09-03	GE
CF6-80C2	X		1309M78G08	Duct, Air Wye	72-09-03	GE
CF6-80C2	X		1309M78G12	Duct, Air Wye	72-09-03	GE
CF6-80C2	X		1309M78G14	Duct, Air Wye	72-09-03	GE
CF6-80C2	X		1309M78G15	Duct, Air Wye	72-09-03	GE
CF6-80C2	X		1309M96P01	Tube And Hose, Turb	72-09-03	GE
CF6-80C2	X		1309M96P04	Tube And Hose, Turb	72-09-03	GE
CF6-80C2	X		1309M96P05	Tube And Hose, Turb	72-09-03	GE
CF6-80C2	X		1309M96P06	Tube And Hose, Turb	72-09-03	GE
CF6-80C2	X		1309M96P07	Tube And Hose, Turb	72-09-03	GE
CF6-80C2	X		1309M96P08	Tube And Hose, Turb	72-09-03	GE
CF6-80C2	X		1309M96P09	Tube And Hose, Turb	72-09-03	GE
CF6-80C2	X		1309M96P10	Tube And Hose, Turb	72-09-03	GE
CF6-80C2	X		1309M96P11	Tube And Hose, Turb	72-09-03	GE
CF6-80C2	X		1309M96P12	Tube And Hose, Turb	72-09-03	GE
CF6-80C2	X		1310M10G01	Tube, Fuel Drain Comb Forward	72-09-03	GE
CF6-80C2	X		1310M21G05	Tube, Air Accessory Gearbox Left Side	72-09-03	GE
CF6-80C2	X		1310M21G07	Tube, Air Accessory	72-09-03	GE
CF6-80C2	X		1310M23G01	Tube, Fuel Comb Drain	72-09-03	GE
CF6-80C2	X		1310M54P001A	Bracket	72-09-04	GE
CF6-80C2	X		1310M55P001B	Bracket	72-09-04	GE
CF6-80C2	X	X	1310M58P03	Tube	72-09-03	GE
CF6-80C2	X		1310M76G01	Tube, Cool	72-09-03	GE
CF6-80C2	X		1310M76G03	Tube, Cool	72-09-03	GE
CF6-80C2	X		1310M76G05	Tube, Cool	72-09-03	GE
CF6-80C2	X		1310M76G06	Tube, Cool	72-09-03	GE
CF6-80C2	X		1310M76G07	Tube, Cool	72-09-03	GE
CF6-80C2	X		1310M76G08	Tube, Cool	72-09-03	GE
CF6-80C2	X		1310M84G02	Tube, IDG Press RLF DR	72-09-03	GE
CF6-80C2	X		1310M84G03	Tube, IDG Press RLF DR	72-09-03	GE
CF6-80C2	X	X	1310M84G04	Tube, IDG Press RLF DR	72-09-03	GE
CF6-80C2	X	X	1310M90G01	Tube, Air B Sump Vent	72-09-03	GE
CF6-80C2	X		1310M91G03	Bracket	72-09-04	GE
CF6-80C2	X		1310M94G01	Tube, CDP	72-09-03	GE
CF6-80C2	X		1313M24G05	Bracket, Shield	72-09-04	GE
CF6-80C2	X		1314M20P03	Bracket, Stop Link	72-09-04	GE
CF6-80C2	X		1314M20P04	Bracket, Stop Link	72-09-04	GE
CF6-80C2	X		1314M47G01	Bracket, Power Pack	72-09-04	GE
CF6-80C2	X		1314M47G02	Bracket, Power Pack	72-09-04	GE
CF6-80C2	X		1314M47G03	Bracket, Power Pack	72-09-04	GE
CF6-80C2	X	X	1315M18G02	Mast, LWR DR	72-09-04	GE
CF6-80C2	X	X	1315M18G04	Mast, LWR DR	72-09-04	GE
CF6-80C2	X	X	1315M20G01	Bracket	72-09-04	GE
CF6-80C2	X		1315M24G01	Tube, Fuel DR+D8124 HMT2 Sensor	72-09-03	GE
CF6-80C2	X	X	1315M27G01	Bracket	72-09-04	GE
CF6-80C2	X		1315M30G01	Bracket	72-09-04	GE
CF6-80C2	X	X	1315M35G01	Tube, Air HPT Supply	72-09-03	GE
CF6-80C2	X		1315M35G02	Tube, Air HPT Supply	72-09-03	GE
CF6-80C2	X		1315M35G03	Tube, Air HPT Supply	72-09-03	GE
CF6-80C2	X		1315M38G01	Tube, Lower (LH)	72-09-03	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2	X		1315M38G02	Tube, Lower (LH)	72-09-03	GE
CF6-80C2	X		1315M38G03	Tube, Lower (LH)	72-09-03	GE
CF6-80C2	X		1315M46G01	Bracket, Tube	72-09-04	GE
CF6-80C2	X		1315M56G03	Tube, Air HPT Cooling Supply Lower (LH)	72-09-03	GE
CF6-80C2	X	X	1315M56G05	Tube, Air HPT Cooling Supply Lower (LH)	72-09-03	GE
CF6-80C2	X		1315M56G06	Tube, Air HPT Cooling Supply Lower (LH)	72-09-03	GE
CF6-80C2	X		1315M56G07	Tube, Air HPT Cooling Supply Lower (LH)	72-09-03	GE
CF6-80C2	X		1315M58G03	Manifold, Air	72-09-03	GE
CF6-80C2	X		1315M59G02	Tube, Under Cowl Cooling	72-09-03	GE
CF6-80C2	X		1315M72P001A	Bracket	72-09-04	GE
CF6-80C2	X		1315M81G01	Bracket	72-09-04	GE
CF6-80C2	X		1315M83G03	Bracket	72-09-04	GE
CF6-80C2	X		1315M84G04	Bracket	72-09-04	GE
CF6-80C2	X		1315M91G01	Tube, T2 Sensor Upper Fuel	72-09-03	GE
CF6-80C2	X		1315M96G03	Bracket, Clevis Acc Duct	72-09-04	GE
CF6-80C2	X		1315M96G05	Bracket, Clevis Acc Duct	72-09-04	GE
CF6-80C2	X		1315M98G03	Bracket	72-09-04	GE
CF6-80C2	X		1315M98P001A	Bracket	72-09-04	GE
CF6-80C2	X		1315M98P003A	Bracket	72-09-04	GE
CF6-80C2	X		1315M98P005A	Bracket	72-09-04	GE
CF6-80C2	X		1321M14G05	Bracket	72-09-04	GE
CF6-80C2	X		1321M15G02	Tube	72-09-03	GE
CF6-80C2	X		1321M23G01	Tube, B Scavenge Forward Oil	72-09-03	GE
CF6-80C2	X		1321M27G01	Tube, Fuel	72-09-03	GE
CF6-80C2	X		1321M32P08	Bracket, Link	72-09-04	GE
CF6-80C2	X		1321M32P09	Bracket, Link	72-09-04	GE
CF6-80C2	X		1321M32P11	Bracket, Link	72-09-04	GE
CF6-80C2	X		1321M32P16	Bracket, Link	72-09-04	GE
CF6-80C2	X		1321M32P18	Bracket, Link	72-09-04	GE
CF6-80C2	X		1321M32P19	Bracket, Link	72-09-04	GE
CF6-80C2	X		1321M32P20	Bracket, Link	72-09-04	GE
CF6-80C2	X	X	1321M42G04	Tube, Flowmeter To IDG	72-09-03	GE
CF6-80C2	X		1321M48G01	Tube, IDG Fuel/Oil	72-09-03	GE
CF6-80C2	X		1321M57G01	Tube, Heat Exchanger	72-09-03	GE
CF6-80C2	X	X	1321M57G03	Tube, Heat Exchanger	72-09-03	GE
CF6-80C2	X		1321M63G01	Tube, CDP Air	72-09-03	GE
CF6-80C2	X		1321M63G03	Tube, CDP Air	72-09-03	GE
CF6-80C2	X		1321M65G01	Tube, Air	72-09-03	GE
CF6-80C2	X		1321M73G01	Tube, Cooling	72-09-03	GE
CF6-80C2	X	X	1321M85G01	Bracket	72-09-04	GE
CF6-80C2	X	X	1321M86G01	Bracket	72-09-04	GE
CF6-80C2	X		1321M88P001A	Bracket	72-09-04	GE
CF6-80C2	X	X	1321M89G01	Tube, Signal Valve Drain	72-09-03	GE
CF6-80C2	X	X	1321M91G01	Tube, Hydraulic Drain Upper Oil	72-09-03	GE
CF6-80C2	X	X	1321M93G01	Tube, Hydraulic Drain Lower Oil	72-09-03	GE
CF6-80C2	X		1321M96P001A	Bracket	72-09-04	GE
CF6-80C2	X	X	1321M97G01	Tube, Air HPT Cooling	72-09-03	GE
CF6-80C2	X		1321M97G03	Tube, Air HPT Cooling	72-09-03	GE
CF6-80C2	X		1321M97G04	Tube, Air HPT Cooling	72-09-03	GE
CF6-80C2	X		1325M18G03	Tube, Air LPT Supply	72-09-03	GE
CF6-80C2	X		1325M18G04	Tube, Air LPT Supply	72-09-03	GE
CF6-80C2	X		1325M20G01	Tube, Oil	72-09-03	GE
CF6-80C2	X		1325M22G01	Tube, Oil	72-09-03	GE
CF6-80C2	X		1325M24G01	Tube, Oil	72-09-03	GE
CF6-80C2	X		1325M30G05	Bracket, Fuel	72-09-04	GE
CF6-80C2	X	X	1325M37G01	Tube, Oil IDG Cooling	72-09-03	GE
CF6-80C2	X	X	1325M45G01	Tube, Fuel	72-09-03	GE
CF6-80C2	X		1325M53G01	Tube, IDG Drain Oil	72-09-03	GE
CF6-80C2	X	X	1325M55G01	Tube, No. 1 Drain Fuel	72-09-03	GE
CF6-80C2	X		1325M57G01	Tube	72-09-03	GE
CF6-80C2	X		1325M58G01	Tube, VBV/VSV Drain Fuel	72-09-03	GE
CF6-80C2	X		1325M62G01	Tube, Oil D Scavenge	72-09-03	GE
CF6-80C2	X		1325M62G01A	Tube, Oil D Scavenge	72-09-03	GE
CF6-80C2	X		1325M62G03	Tube, Oil D Scavenge	72-09-03	GE
CF6-80C2	X		1325M62G03A	Tube, Oil D Scavenge	72-09-03	GE
CF6-80C2	X		1325M62G04	Tube, Oil D Scavenge	72-09-03	GE
CF6-80C2	X		1325M64G01	Tube, Oil D Sump	72-09-03	GE
CF6-80C2	X		1325M64G02	Tube, Oil D Sump	72-09-03	GE
CF6-80C2	X		1325M64G04	Tube, Oil D Lube	72-09-03	GE
CF6-80C2	X		1325M77G05	Bracket, Lower IDG	72-09-04	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2	X	X	1325M77G07	Bracket, Lower IDG	72-09-04	GE
CF6-80C2	X		1325M79P02	Bracket, Link	72-09-04	GE
CF6-80C2	X		1325M79P03	Bracket, Link	72-09-04	GE
CF6-80C2	X		1325M86P001B	Bracket	72-09-04	GE
CF6-80C2	X		1325M90G02	Tube, Oil	72-09-03	GE
CF6-80C2	X		1325M98P001B	Bracket, T2	72-09-04	GE
CF6-80C2	X		1326M15G01	Tube, Oil	72-09-03	GE
CF6-80C2	X	X	1326M39G01	Tube, Oil IDG Cooler Outlet	72-09-03	GE
CF6-80C2	X		1326M44G01	Tube, Fuel	72-09-03	GE
CF6-80C2	X		1326M44G02	Tube, Fuel	72-09-03	GE
CF6-80C2	X		1326M46G02	Tube, T2 Sensor Lower Drain	72-09-03	GE
CF6-80C2	X		1326M48G01	Tube, D Scavenge Forward Oil	72-09-03	GE
CF6-80C2	X		1326M48G02	Tube, D Scavenge Forward Oil	72-09-03	GE
CF6-80C2	X	X	1326M50G01	Tube, PO	72-09-03	GE
CF6-80C2	X	X	1326M52G01	Tube, Fuel T2	72-09-03	GE
CF6-80C2	X		1326M79P001A	Bracket	72-09-04	GE
CF6-80C2	X		1326M82P01	Tube And Hose, IDG Oil Cooling	72-09-03	GE
CF6-80C2	X		1326M82P02	Tube And Hose, IDG Oil Cooling	72-09-03	GE
CF6-80C2	X	X	1326M82P03	Tube And Hose, IDG Oil Cooling	72-09-03	GE
CF6-80C2	X		1326M84G07	Bracket	72-09-04	GE
CF6-80C2	X	X	1326M85G01	Tube, Oil Scavenge	72-09-03	GE
CF6-80C2	X	X	1326M85G03	Tube, Oil Scavenge	72-09-03	GE
CF6-80C2	X		1326M87G01	Tube, Oil Scavenge Outlet	72-09-03	GE
CF6-80C2	X	X	1326M90P03	Tube/Hose	72-09-03	GE
CF6-80C2	X		1326M90P04	Tube/Hose	72-09-03	GE
CF6-80C2	X	X	1326M91G01	Tube	72-09-03	GE
CF6-80C2	X	X	1327M22G01	Link, Side	72-65-10	GE
CF6-80C2	X	X	1327M24G01	Link, AGB Transverse	72-65-10	GE
CF6-80C2	X	X	1327M75P01	Sleeve, Damper	72-53-13	GE
CF6-80C2	X	X	1332M15G01	Tube, Oil	72-09-03	GE
CF6-80C2	X	X	1332M30G01	Tube, Air PS3 Forward	72-09-03	GE
CF6-80C2	X	X	1332M30G02	Tube, Air PS3 Forward	72-09-03	GE
CF6-80C2	X		1332M32G05	Bracket	72-09-04	GE
CF6-80C2	X		1332M50P02	Tube	72-09-03	GE
CF6-80C2	X		1332M50P03	Tube	72-09-03	GE
CF6-80C2	X		1332M50P04	Tube	72-09-03	GE
CF6-80C2	X		1332M50P09	Tube	72-09-03	GE
CF6-80C2	X		1332M50P12	Tube, Hose	72-09-03	GE
CF6-80C2	X		1332M52P01	Hose	72-09-03	GE
CF6-80C2	X		1332M52P02	Hose	72-09-03	GE
CF6-80C2	X	X	1332M52P03	Hose	72-09-03	GE
CF6-80C2	X		1332M52P04	Hose	72-09-03	GE
CF6-80C2	X		1332M57G01	Tube, Mec Servo Drain Fuel	72-09-03	GE
CF6-80C2	X	X	1332M59G01	Tube, Oil Tank	72-09-03	GE
CF6-80C2	X		1332M59G03	Tube, Oil Tank	72-09-03	GE
CF6-80C2	X		1332M61G01	Tube, Oil	72-09-03	GE
CF6-80C2	X		1332M61G02	Tube, Oil	72-09-03	GE
CF6-80C2	X	X	1332M61G03	Tube, Oil	72-09-03	GE
CF6-80C2	X	X	1332M63G01	Manifold, Mec Spline	72-09-03	GE
CF6-80C2	X	X	1332M63G02	Manifold, Mec Spline	72-09-03	GE
CF6-80C2	X		1332M65G01	Tube, Accessory Drain Fuel	72-09-03	GE
CF6-80C2	X		1332M80G01	Tube, Air (P14)	72-09-03	GE
CF6-80C2	X		1332M88P001B	Bracket	72-09-04	GE
CF6-80C2	X		1332M89G01	Tube, Oil	72-09-03	GE
CF6-80C2	X		1332M95G01	Tube, Manifold Oil	72-09-03	GE
CF6-80C2	X		1333M76G04	Link, Support	72-09-04	GE
CF6-80C2	X		1333M76G05	Link, Support	72-09-04	GE
CF6-80C2	X	X	1333M76G06	Link, Support	72-09-04	GE
CF6-80C2	X		1333M76G07	Link, Support	72-09-04	GE
CF6-80C2	X		1333M76G08	Link, Support	72-09-04	GE
CF6-80C2	X		1333M76G09	Link, Support	72-09-04	GE
CF6-80C2	X		1333M76G10	Link, Support	72-09-04	GE
CF6-80C2	X	X	1333M76G11	Link, Support	72-09-04	GE
CF6-80C2	X		1333M76G12	Link, Support	72-09-04	GE
CF6-80C2	X		1333M76G13	Link, Support	72-09-04	GE
CF6-80C2	X		1334M12G01	Tube, Air (PS3)	72-09-03	GE
CF6-80C2	X		1334M14G01	Tube, Air	72-09-03	GE
CF6-80C2	X		1334M16G01	Tube, Air	72-09-03	GE
CF6-80C2	X		1334M18G01	Tube, Fan Mid	72-09-03	GE
CF6-80C2	X		1334M20G01	Tube, Fan Upper	72-09-03	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2	X		1334M22G01	Tube, Air	72-09-03	GE
CF6-80C2	X		1334M26G01	Tube, Fan Upper	72-09-03	GE
CF6-80C2	X	X	1334M28P05	Tube, Fuel	72-09-03	GE
CF6-80C2	X		1334M28P06	Tube, Fuel	72-09-03	GE
CF6-80C2	X		1334M28P07	Tube, Fuel	72-09-03	GE
CF6-80C2	X		1334M28P08	Tube, Fuel	72-09-03	GE
CF6-80C2	X		1334M29G03	Tube, Fuel	72-09-03	GE
CF6-80C2	X		1334M31G01	Tube, Fuel	72-09-03	GE
CF6-80C2	X		1334M39G01	Tube, Air	72-09-03	GE
CF6-80C2	X		1334M43P001A	Bracket	72-09-04	GE
CF6-80C2	X		1334M44P001A	Bracket, Angle	72-09-04	GE
CF6-80C2	X		1334M49G05	Bracket	72-09-04	GE
CF6-80C2	X		1334M49G07	Bracket	72-09-04	GE
CF6-80C2	X		1334M49G09	Bracket	72-09-04	GE
CF6-80C2	X		1334M51G01	Tube, Oil	72-09-03	GE
CF6-80C2	X		1334M57G01	Tube, Air PMUX PS3 Upper	72-09-03	GE
CF6-80C2	X		1334M59G01	Tube, Air PMUX PS3	72-09-03	GE
CF6-80C2	X		1334M61G01	Tube, Air	72-09-03	GE
CF6-80C2	X		1334M63G01	Tube, Air	72-09-03	GE
CF6-80C2	X	X	1334M69G01	Tube, Fuel Lower T2 Sensor to CIT	72-09-03	GE
CF6-80C2	X		1334M76G03	Tube, Air LPT Supply	72-09-03	GE
CF6-80C2	X		1334M76G05	Tube, Air LPT Supply	72-09-03	GE
CF6-80C2	X		1334M78P001A	Bracket	72-09-04	GE
CF6-80C2	X		1334M82P001A	Bracket, PMUX	72-09-04	GE
CF6-80C2	X		1334M83P001A	Bracket	72-09-04	GE
CF6-80C2	X		1334M84G07	Bracket, Fan PMUX	72-09-04	GE
CF6-80C2	X		1334M95G01	Tube, Air PS3 Core Mid	72-09-03	GE
CF6-80C2	X	X	1334M95G02	Tube, Air PS3 Core Mid	72-09-03	GE
CF6-80C2	X		1334M97G02	Tube, 11th Stage	72-09-03	GE
CF6-80C2	X	X	1334M97G04	Tube, 11th Stage	72-09-07	GE
CF6-80C2	X	X	1335M10G01	Tube, 11th Stage	72-09-03	GE
CF6-80C2	X	X	1335M12G01	Tube, 11th Stage	72-09-03	GE
CF6-80C2	X	X	1335M29G01	Tube, Fuel	72-09-03	GE
CF6-80C2	X		1335M38G01	Manifold	72-09-03	GE
CF6-80C2	X		1335M39G01	Manifold	72-09-03	GE
CF6-80C2	X		1335M41G01	Tube, Fan Mid	72-09-03	GE
CF6-80C2	X		1335M75G01	Tube, Oil Scavenge	72-09-03	GE
CF6-80C2	X	X	1335M75G03	Tube, Oil Scavenge	72-09-03	GE
CF6-80C2	X		1335M92G03	Tube, A Sump Oil	72-09-03	GE
CF6-80C2	X	X	1335M92G04	Tube, A Sump Oil	72-09-03	GE
CF6-80C2	X		1337M11G01	Manifold	72-09-03	GE
CF6-80C2	X		1337M13G01	Tube, HP REL	72-09-03	GE
CF6-80C2	X		1337M13G02	Tube, HP REL	72-09-03	GE
CF6-80C2	X	X	1337M13G03	Tube, Air HP Recoup	72-09-03	GE
CF6-80C2	X		1337M23G01	Tube, Air	72-09-03	GE
CF6-80C2	X		1337M25G01	Tube, Fuel	72-09-03	GE
CF6-80C2	X		1337M28G01	Tube, Air	72-09-03	GE
CF6-80C2	X		1337M30G01	Tube, Air	72-09-03	GE
CF6-80C2	X		1337M48G01	Tube, Oil Lube	72-09-03	GE
CF6-80C2	X		1337M57G01	Tube, Oil Scavenge Chip Detector	72-09-03	GE
CF6-80C2	X		1337M67G01	Tube, T2 Sensor Upper P7 Fuel	72-09-03	GE
CF6-80C2	X		1337M69G02	Tube, AGB A/R R/S	72-09-03	GE
CF6-80C2	X	X	1337M69G03	Tube, AGB A/R R/S	72-09-03	GE
CF6-80C2	X		1337M71G05	Bracket	72-09-04	GE
CF6-80C2	X		1337M74G01	Tube, T2 Sensor Lower P7 Fuel	72-09-03	GE
CF6-80C2	X		1337M78G03	Bracket	72-09-04	GE
CF6-80C2	X	X	1337M79G02	Tube, HPT/LPT Cooling	72-09-03	GE
CF6-80C2	X		1337M79G05	Tube, HPT/LPT Cooling	72-09-03	GE
CF6-80C2	X		1337M79G06	Tube, HPT/LPT Cooling	72-09-03	GE
CF6-80C2	X		1337M80P001B	Bracket, Tube	72-09-04	GE
CF6-80C2	X		1337M81G01	Tube, IDG Oil Cooling	72-09-03	GE
CF6-80C2	X	X	1337M83G05	Bracket, IDG	72-09-04	GE
CF6-80C2	X		1337M92G01	Manifold, Fuel	72-09-03	GE
CF6-80C2	X		1337M94G01	Manifold, Fuel	72-09-03	GE
CF6-80C2	X		1337M96G01	Manifold, Fuel	72-09-03	GE
CF6-80C2	X		1337M98G01	Tube, Fuel	72-09-03	GE
CF6-80C2	X		1339M10G01	Tube, T2 Sensor Lower Fuel	72-09-03	GE
CF6-80C2	X		1339M10G02	Tube, T2 Sensor Lower Fuel	72-09-03	GE
CF6-80C2	X		1339M29G01	Tube, Air	72-09-03	GE
CF6-80C2	X		1339M29G02	Tube, Air	72-09-03	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2	X		1339M29G04	Tube, Air	72-09-03	GE
CF6-80C2	X		1339M29G06	Tube, Air	72-09-03	GE
CF6-80C2	X		1339M29G07	Tube, Air	72-09-03	GE
CF6-80C2	X	X	1339M29G09	Tube, Air	72-09-03	GE
CF6-80C2	X		1339M29G10	Tube, Air	72-09-03	GE
CF6-80C2	X		1339M29G11	Tube, Air	72-09-03	GE
CF6-80C2	X		1339M29G12	Tube, Air	72-09-03	GE
CF6-80C2	X	X	1339M29G13	Tube, Air	72-09-03	GE
CF6-80C2	X	X	1339M29G14	Tube, Air	72-09-03	GE
CF6-80C2	X		1339M39G01	Tube, Air	72-09-03	GE
CF6-80C2	X		1339M39G03	Tube, Air	72-09-03	GE
CF6-80C2	X		1339M39G04	Tube, Air	72-09-03	GE
CF6-80C2	X		1339M44G01	Tube, Under Cowl Cooling Air	72-09-03	GE
CF6-80C2	X		1339M63G01	Tube, Oil Lube Pump	72-09-03	GE
CF6-80C2	X		1339M65G01	Tube, AGB	72-09-03	GE
CF6-80C2	X		1339M65G03	Tube, AGB	72-09-03	GE
CF6-80C2	X		1339M67G01	Manifold, Pump Discharge	72-09-03	GE
CF6-80C2	X		1339M69G01	Tube, Oil Lube Pump	72-09-03	GE
CF6-80C2	X		1339M74G02	Bracket, Transmitter	72-09-04	GE
CF6-80C2	X		1339M75P001A	Bracket	72-09-04	GE
CF6-80C2	X		1339M76G02	Tube, Oil J Box Upper Drain	72-09-03	GE
CF6-80C2	X		1339M78G02	Tube, Oil	72-09-03	GE
CF6-80C2	X		1345M19P01	Link	72-09-04	GE
CF6-80C2	X		1345M21P01	Bracket	72-09-04	GE
CF6-80C2	X		1346M17G01	Manifold, Air	72-09-03	GE
CF6-80C2	X	X	1346M17G02	Manifold, Air	72-09-03	GE
CF6-80C2	X		1346M17G03	Manifold, Air Core Cowl	72-09-03	GE
CF6-80C2	X		1346M17G05	Manifold, Air Core Cowl	72-09-03	GE
CF6-80C2	X		1346M17G08	Manifold, Air Core Cowl	72-09-03	GE
CF6-80C2	X		1346M17G09	Manifold, Air Core Cowl	72-09-03	GE
CF6-80C2	X		1346M17G10	Manifold, Air Core Cowl	72-09-03	GE
CF6-80C2	X	X	1346M31G01	Tube, HPT Cooling Lower	72-09-03	GE
CF6-80C2	X		1346M31G05	Tube, HPT Cooling Lower	72-09-03	GE
CF6-80C2	X		1346M31G06	Tube, HPT Cooling Lower	72-09-03	GE
CF6-80C2	X	X	1346M33G01	Manifold, Oil Lube Supply	72-09-03	GE
CF6-80C2	X		1346M33G03	Manifold, Oil Lube Supply	72-09-03	GE
CF6-80C2	X		1346M36G03	Bracket	72-09-04	GE
CF6-80C2	X		1346M36G05	Bracket	72-09-04	GE
CF6-80C2	X		1346M36G07	Bracket	72-09-04	GE
CF6-80C2	X		1346M44P001B	Bracket	72-09-04	GE
CF6-80C2	X		1346M44P001C	Bracket, Oil Tank Tube	72-09-04	GE
CF6-80C2	X		1346M44P001D	Bracket, Oil Tank Tube	72-09-04	GE
CF6-80C2	X		1346M44P001E	Bracket, Oil Tank Tube	72-09-04	GE
CF6-80C2	X		1346M50P001A	Bracket	72-09-04	GE
CF6-80C2	X		1346M57G03	Tube, D Scavenge Forward Oil	72-09-03	GE
CF6-80C2	X		1346M57G05	Tube, D Scavenge Forward Oil	72-09-03	GE
CF6-80C2	X		1346M71G01	Bracket, EBU	72-09-04	GE
CF6-80C2	X		1346M74G01	Bracket, EBU	72-09-04	GE
CF6-80C2	X		1346M74G03	Bracket, EBU	72-09-04	GE
CF6-80C2	X		1346M76G01	Bracket, EBU	72-09-04	GE
CF6-80C2	X		1346M81G01	Manifold, Air Cooling	72-09-03	GE
CF6-80C2	X		1346M81G02	Manifold, Air Cooling	72-09-03	GE
CF6-80C2	X		1346M81G03	Manifold, Air Cooling	72-09-03	GE
CF6-80C2	X		1346M81G05	Manifold, Air Cooling	72-09-03	GE
CF6-80C2	X		1346M81G06	Manifold, Air Cooling	72-09-03	GE
CF6-80C2	X		1346M81G07	Manifold, Air Cooling	72-09-03	GE
CF6-80C2	X		1346M88G01	Tube, Oil Scavenge	72-09-03	GE
CF6-80C2	X	X	1346M88G02	Tube, Oil Scavenge	72-09-03	GE
CF6-80C2	X		1346M88G04	Tube, Oil Scavenge	72-09-03	GE
CF6-80C2	X		1346M90P001B	Bracket	72-09-04	GE
CF6-80C2	X		1346M97G07	Bracket, Upper IDG	72-09-04	GE
CF6-80C2	X	X	1349M10P01	Tube, Fuel Hose	72-09-03	GE
CF6-80C2	X	X	1349M10P04	Tube, Fuel Hose	72-09-03	GE
CF6-80C2	X		1349M21G01	Tube, Lube	72-09-03	GE
CF6-80C2	X		1349M23P001B	Bracket, Tube	72-09-04	GE
CF6-80C2	X	X	1349M24G01	Tube, Lower (RH)	72-09-03	GE
CF6-80C2	X	X	1349M26G01	Tube, Oil	72-09-03	GE
CF6-80C2	X		1349M26G02	Tube	72-09-03	GE
CF6-80C2	X		1349M30G03	Bracket, Oil Scavenge	72-09-04	GE
CF6-80C2	X		1349M31P001A	Bracket, Tube	72-09-04	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2	X		1349M32P001A	Bracket, Tube	72-09-04	GE
CF6-80C2	X		1349M34P001C	Bracket, Tube	72-09-04	GE
CF6-80C2	X		1349M35P001A	Bracket	72-09-04	GE
CF6-80C2	X		1349M35P001B	Bracket	72-09-04	GE
CF6-80C2	X		1349M43G01	Tube, Oil B Sump Scavenge	72-09-03	GE
CF6-80C2	X		1349M43G02	Tube, Oil B Sump Scavenge	72-09-03	GE
CF6-80C2	X		1349M55G01	Bracket, Electrical	72-09-04	GE
CF6-80C2	X		1349M65P001A	Bracket	72-09-04	GE
CF6-80C2	X		1349M85G01	Tube, Air PS3 Core Aft	72-09-03	GE
CF6-80C2	X		1349M85G02	Tube, Air PS3 Core Aft	72-09-03	GE
CF6-80C2	X	X	1349M87G01	Tube, Air R/S Valve Control	72-09-03	GE
CF6-80C2	X		1349M90P001A	Bracket, Fan EBU	72-09-04	GE
CF6-80C2	X		1349M93G01	Tube, Oil J Box Upper Drain	72-09-03	GE
CF6-80C2	X		1350M15G03	Bracket, Core Cowl Cooling	72-09-04	GE
CF6-80C2	X		1350M15G05	Bracket	72-09-04	GE
CF6-80C2	X		1350M16P001A	Bracket	72-09-04	GE
CF6-80C2	X		1350M41P001A	Bracket	72-09-04	GE
CF6-80C2	X		1350M51G01	Manifold, Drain Mast	72-09-03	GE
CF6-80C2	X		1350M69G01	Bracket, Sensor Mtg	72-09-04	GE
CF6-80C2	X		1350M69G03	Bracket	72-09-04	GE
CF6-80C2	X	X	1350M80G01	Tube, Oil Scavenge Chip	72-09-03	GE
CF6-80C2	X		1350M82G01	Tube, Mast Manifold to Module	72-09-03	GE
CF6-80C2	X	X	1350M82G02	Tube, Mast Manifold to Module	72-09-03	GE
CF6-80C2	X		1350M86G02	Bracket	72-09-04	GE
CF6-80C2	X	X	1350M93G01	Tube, Oil Tank	72-09-03	GE
CF6-80C2	X		1350M97G05	Bracket, EBU	72-09-04	GE
CF6-80C2	X		1370M75G02	Tube, Scavenge	72-09-03	GE
CF6-80C2	X	X	1374M30G03	Tube, Fuel	72-09-03	GE
CF6-80C2	X		1374M51G01	Manifold, Air	72-09-03	GE
CF6-80C2	X		1374M51G02	Manifold, Air	72-09-03	GE
CF6-80C2	X		1374M57P001B	Bracket	72-09-04	GE
CF6-80C2	X		1374M58G03	Bracket, Fuel Angle	72-09-04	GE
CF6-80C2	X		1374M58G05	Bracket, Fuel Angle	72-09-04	GE
CF6-80C2	X		1374M61G01	Bracket, ECU	72-09-04	GE
CF6-80C2	X		1374M61G02	Bracket, ECU	72-09-04	GE
CF6-80C2	X		1374M77G01	Bracket, EBU	72-09-04	GE
CF6-80C2	X	X	1374M82G01	Bracket, EBU	72-09-04	GE
CF6-80C2	X	X	1374M88G01	Tube, Air P14	72-09-03	GE
CF6-80C2	X		1375M12P01	Ring	72-31-18	GE
CF6-80C2	X		1375M12P02	Ring, Damper	72-31-18	GE
CF6-80C2	X		1378M53G03	Panel Assy, Accessories SHLD LH	72-66-01	GE
CF6-80C2	X	X	1380M14G09	Mount Forward	71-21-01	GE
CF6-80C2	X		1380M14G10	Mount Forward	71-21-01	GE
CF6-80C2	X		1380M33P01	Bolt	71-21-01	GE
CF6-80C2	X	X	1380M34P02	Bolt, Shear	71-21-01	GE
CF6-80C2	X		1380M42G09	Mount, Forward	71-21-01	GE
CF6-80C2	X		1380M42G10	Link, Assembly Frame	71-21-01, Par 4D	GE
CF6-80C2	X	X	1380M99G02	Bracket Assy, Actuator	72-32-10	GE
CF6-80C2	X		1383M20P001C	Bracket	72-09-04	GE
CF6-80C2	X		1383M20P001E	Bracket, EBU	72-09-04	GE
CF6-80C2	X		1383M31G01	Tube, CDP	72-09-03	GE
CF6-80C2	X		1383M33G01	Bracket, HPT And Core	72-09-04	GE
CF6-80C2	X		1383M35G01	Bracket, Fire Detector	72-09-04	GE
CF6-80C2	X	X	1383M37G01	Bracket, Upper Starter	72-09-04	GE
CF6-80C2	X		1383M40G01	Manifold, Drain Mast	72-09-03	GE
CF6-80C2	X		1383M40G02	Manifold, Drain Mast	72-09-03	GE
CF6-80C2	X		1383M44G01	Tube, IDG Fuel/Oil	72-09-03	GE
CF6-80C2	X		1383M46P001A	Bracket	72-09-04	GE
CF6-80C2	X		1383M47P001A	Bracket	72-09-04	GE
CF6-80C2	X		1383M51G01	Bracket, Tube Drain Stow	72-09-04	GE
CF6-80C2	X	X	1383M54G02	Tube, Mec Servo Drain Fuel	72-09-03	GE
CF6-80C2	X		1383M56G01	Tube, Fuel Comb Drain	72-09-03	GE
CF6-80C2	X		1383M56G02	Tube, Fuel Comb Drain	72-09-03	GE
CF6-80C2	X		1383M58G01	Tube, Mast Manifold to Module	72-09-03	GE
CF6-80C2	X		1383M60G01	Manifold, Fuel	72-09-03	GE
CF6-80C2	X	X	1383M62G01	Tube, VBV/VSV Drain Fuel	72-09-03	GE
CF6-80C2	X		1383M65G01	Tube, IDG Drain Oil	72-09-03	GE
CF6-80C2	X		1383M65G02	Tube, IDG Drain Oil	72-09-03	GE
CF6-80C2	X	X	1383M65G03	Tube, IDG Drain Oil	72-09-03	GE
CF6-80C2	X	X	1383M69G01	Tube, Oil IDG	72-09-03	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2	X		1383M69G02	Tube, Oil IDG	72-09-03	GE
CF6-80C2	X		1383M76G01	Bracket	72-09-04	GE
CF6-80C2	X		1383M77P001A	Bracket	72-09-04	GE
CF6-80C2	X		1383M79G01	Tube, Air IDG Valve Aft	72-09-03	GE
CF6-80C2	X	X	1383M79G02	Tube, Air IDG Valve Aft	72-09-03	GE
CF6-80C2	X		1383M81G01	Tube, Air	72-09-03	GE
CF6-80C2	X		1383M83G01	Tube, CDP	72-09-03	GE
CF6-80C2	X	X	1383M87G01	Tube, Lower Scupper Drain	72-09-03	GE
CF6-80C2	X		1440M41P01	Spacer, Flow Bleed Bias	72-09-03	GE
CF6-80C2	X		1440M64G01	Sensor, Flow Bleed Bias	72-09-03	GE
CF6-80C2	X	X	1440M64G02	Sensor, Flow Bleed Bias	72-09-03	GE
CF6-80C2	X		1442M11G01	Manifold, Fuel	72-09-03	GE
CF6-80C2	X	X	1442M11G02	Manifold, Fuel	72-09-03	GE
CF6-80C2	X		1442M13G01	Tube, VBV/VSV Drain Fuel	72-09-03	GE
CF6-80C2	X		1442M15G05	Tube, HPT/LPT Cooling	72-09-03	GE
CF6-80C2	X		1442M15G08	Tube, HPT/LPT Cooling	72-09-03	GE
CF6-80C2	X		1442M21G01	Tube, Under Cowl Cooling	72-09-03	GE
CF6-80C2	X	X	1442M25G01	Tube, Lower Heat Exchanger to Tank	72-09-03	GE
CF6-80C2	X	X	1442M25G02	Tube, Lower Heat Exchanger to Tank	72-09-03	GE
CF6-80C2	X	X	1442M27G01	Tube, Mast Manifold to Module	72-09-03	GE
CF6-80C2	X	X	1442M27G03	Tube, Mast Manifold to Module	72-09-03	GE
CF6-80C2	X		1442M31G02	Tube, Accessory Gearbox	72-09-03	GE
CF6-80C2	X		1442M46G01	Tube, Air P14 Lower	72-09-03	GE
CF6-80C2	X		1442M47P001B	Bracket, PS14	72-09-04	GE
CF6-80C2	X		1442M47P001C	Bracket, PS14	72-09-04	GE
CF6-80C2	X		1442M54G02	Tube, Oil	72-09-03	GE
CF6-80C2	X		1442M54G03	Tube, Oil	72-09-03	GE
CF6-80C2	X		1442M54G04	Tube, Oil	72-09-03	GE
CF6-80C2	X	X	1442M56G02	Tube, C Scavenge Mid Oil	72-09-03	GE
CF6-80C2	X		1442M58G02	Tube, B Scavenge Mid Oil	72-09-03	GE
CF6-80C2	X		1442M58G03	Tube, B Scavenge Mid Oil	72-09-03	GE
CF6-80C2	X		1442M63G01	Tube, Air HPT Supply	72-09-03	GE
CF6-80C2	X		1442M63G05	Tube, Air HPT Supply	72-09-03	GE
CF6-80C2	X		1442M63G07	Tube, 11th Stage Air Lower	72-09-03	GE
CF6-80C2	X		1442M66G03	Tube, Air Supply HPT R/S	72-09-03	GE
CF6-80C2	X		1442M66G05	Tube, Air Supply HPT R/S	72-09-03	GE
CF6-80C2	X		1442M66G06	Tube, Air Supply HPT R/S	72-09-03	GE
CF6-80C2	X		1442M68G01	Tube, Air Adapter	72-09-03	GE
CF6-80C2	X		1442M68G03	Tube, Air Adapter	72-09-03	GE
CF6-80C2	X		1442M76P01	Clevis	72-09-04	GE
CF6-80C2	X		1442M77P01	Bracket, Link Short	72-09-04	GE
CF6-80C2	X	X	1442M79G02	Tube, Oil	72-09-03	GE
CF6-80C2	X		1442M79G03	Tube, Oil Tank	72-09-03	GE
CF6-80C2	X	X	1442M80G02	Tube, Lube	72-09-03	GE
CF6-80C2	X	X	1442M80G03	Tube, Lube	72-09-03	GE
CF6-80C2	X		1442M81G03	Tube, Air HPT Supply	72-09-03	GE
CF6-80C2	X	X	1442M81G05	Tube, Air HPT Supply	72-09-03	GE
CF6-80C2	X		1442M81G06	Tube, Air HPT Supply	72-09-03	GE
CF6-80C2	X		1442M83G03	Tube, Air HPT Supply	72-09-03	GE
CF6-80C2	X		1442M83G05	Tube, Air HPT Supply	72-09-03	GE
CF6-80C2	X		1442M83G06	Tube, Air HPT Supply	72-09-03	GE
CF6-80C2	X		1442M91G01	Bracket Assembly, Clevis	72-09-04	GE
CF6-80C2	X		1442M91G03	Bracket Assembly, Clevis	72-09-04	GE
CF6-80C2	X		1446M13G01	Tube	72-09-03	GE
CF6-80C2	X		1446M15P01	Tube	72-09-03	GE
CF6-80C2	X		1446M17G03	Bracket, Mounting Servo	72-09-04	GE
CF6-80C2	X		1446M17G05	Bracket, Mounting Servo	72-09-04	GE
CF6-80C2	X	X	1446M17G07	Bracket, Mounting Servo	72-09-04	GE
CF6-80C2	X		1446M19G03	Tube, Air LPT Supply	72-09-03	GE
CF6-80C2	X		1446M19G05	Tube, Air LPT Supply	72-09-03	GE
CF6-80C2	X	X	1446M19G06	Tube, Air LPT Supply	72-09-03	GE
CF6-80C2	X	X	1446M19G07	Tube, Air LPT Supply	72-09-03	GE
CF6-80C2	X		1446M19G09	Tube, Air LPT Supply	72-09-03	GE
CF6-80C2	X		1446M24G01	Tube, Air HP Recoup	72-09-03	GE
CF6-80C2	X		1446M24G03	Tube, LS HP Recoup Air	72-09-03	GE
CF6-80C2	X	X	1446M70G01	Manifold, Fuel VSV	72-09-03	GE
CF6-80C2	X		1446M72G01	Bracket, Tube	72-09-04	GE
CF6-80C2	X		1446M79G01	Bracket	72-09-04	GE
CF6-80C2	X		1446M86G03	Bracket	72-09-04	GE
CF6-80C2	X		1446M86G05	Bracket	72-09-04	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2	X		1446M92P001A	Bracket, Support Vert	72-09-04	GE
CF6-80C2	X		1446M92P001B	Bracket, Support Vert	72-09-04	GE
CF6-80C2	X		1446M93P001A	Bracket, Support Upper	72-09-04	GE
CF6-80C2	X		1446M94P001A	Bracket, Support Corner	72-09-04	GE
CF6-80C2	X		1446M94P002A	Bracket, Support Corner	72-09-04	GE
CF6-80C2	X		1447M16G01	Tube, Oil Servo Heater	72-09-03	GE
CF6-80C2	X		1447M16G02	Tube, Oil Servo Heater	72-09-03	GE
CF6-80C2	X	X	1447M18G01	Tube, Oil Servo Heater	72-09-03	GE
CF6-80C2	X		1447M18G02	Tube, Oil Servo Heater	72-09-03	GE
CF6-80C2	X		1447M24G05	Bracket, Tube Air	72-09-04	GE
CF6-80C2	X		1447M43G03	Tube, Air HP Recoup	72-09-03	GE
CF6-80C2	X		1447M43G05	Tube, Air HP Recoup	72-09-03	GE
CF6-80C2	X		1447M43G06	Tube, RS HP Recoup Air	72-09-03	GE
CF6-80C2	X		1447M45G08	Tube, Air LPT Supply	72-09-03	GE
CF6-80C2	X		1447M51G05	Bracket, Tube Air	72-09-04	GE
CF6-80C2	X		1447M59G01	Tube, D Scavenge Forward Oil	72-09-03	GE
CF6-80C2	X		1447M59G01A	Tube, D Scavenge Forward Oil	72-09-03	GE
CF6-80C2	X		1447M59G02	Tube, D Scavenge Forward Oil	72-09-03	GE
CF6-80C2	X		1447M59G02A	Tube, D Scavenge Forward Oil	72-09-03	GE
CF6-80C2	X		1453M10G01	Tube, 11th Stage	72-09-03	GE
CF6-80C2	X	X	1453M10G02	Tube, 11th Stage	72-09-03	GE
CF6-80C2	X	X	1453M18G01	Tube, B Sump Scavenge Oil	72-09-03	GE
CF6-80C2	X		1453M18G02	Tube, B Sump Scavenge Oil	72-09-03	GE
CF6-80C2	X		1453M20P001A	Bracket, Double Angle	72-09-04	GE
CF6-80C2	X	X	1453M22G01	Tube, Pylon Drain Fuel	72-09-03	GE
CF6-80C2	X	X	1453M25G01	Tube, No. 1 Drain Fuel	72-09-03	GE
CF6-80C2	X	X	1453M27G01	Tube, No. 1 Drain Fuel	72-09-03	GE
CF6-80C2	X	X	1453M29G01	Manifold, Fuel Drain	72-09-03	GE
CF6-80C2	X	X	1453M29G02	Manifold, Fuel Drain	72-09-03	GE
CF6-80C2	X		1453M33G01	Bracket, Accelerometer	72-09-04	GE
CF6-80C2	X		1453M33G02	Bracket, Accelerometer	72-09-04	GE
CF6-80C2	X		1453M55G01	Bracket, HP Recoup	72-09-04	GE
CF6-80C2	X		1453M56G01	Bracket	72-09-04	GE
CF6-80C2	X	X	1453M58G01	Bracket	72-09-04	GE
CF6-80C2	X	X	1453M58G03	Bracket	72-09-04	GE
CF6-80C2	X		1453M73G01	Tube, Clear Sig	72-09-03	GE
CF6-80C2	X	X	1453M75G01	Tube, Fuel	72-09-03	GE
CF6-80C2	X		1453M77G01	Tube, Air Press	72-09-03	GE
CF6-80C2	X		1453M79G01	Bracket, Valve	72-09-04	GE
CF6-80C2	X		1453M81P01	Tube And Hose, Air/Oil	72-09-03	GE
CF6-80C2	X		1453M81P02	Tube And Hose, Air/Oil	72-09-03	GE
CF6-80C2	X		1453M81P03	Tube And Hose, Air/Oil	72-09-03	GE
CF6-80C2	X	X	1453M81P04	Tube And Hose, Air/Oil	72-09-03	GE
CF6-80C2	X		1453M81P07	Tube And Hose, Air/Oil	72-09-03	GE
CF6-80C2	X		1453M86G01	Tee, Air HP	72-09-03	GE
CF6-80C2	X		1453M87G01	Elbow, HP Recoup	72-09-03	GE
CF6-80C2	X		1453M88P01	Tube, Fuel	72-09-03	GE
CF6-80C2	X		1453M88P02	Tube, Fuel	72-09-03	GE
CF6-80C2	X		1453M88P03	Tube, Fuel	72-09-03	GE
CF6-80C2	X		1453M88P04	Tube, Fuel	72-09-03	GE
CF6-80C2	X		1453M90P05	Tube, Fuel	72-09-03	GE
CF6-80C2	X		1453M90P06	Tube, Fuel	72-09-03	GE
CF6-80C2	X		1453M90P07	Tube, Fuel	72-09-03	GE
CF6-80C2	X		1453M90P08	Tube, Fuel	72-09-03	GE
CF6-80C2	X		1453M98G03	Tube, Air PS3 Fan Upper	72-09-03	GE
CF6-80C2	X		1454M12G01	Tube, PMUX P49	72-09-03	GE
CF6-80C2	X		1454M16G01	Manifold, Press Sensing	72-09-03	GE
CF6-80C2	X		1454M16G02	Manifold, Press Sensing	72-09-03	GE
CF6-80C2	X		1454M16G03	Manifold, Press Sensing	72-09-03	GE
CF6-80C2	X	X	1454M16G04	Manifold, Press Sensing	72-09-03	GE
CF6-80C2	X		1454M18P001A	Bracket, Support	72-09-04	GE
CF6-80C2	X	X	1454M23G01	Tube, Oil	72-09-03	GE
CF6-80C2	X		1454M25G01	Bracket, V Power Door	72-09-04	GE
CF6-80C2	X		1454M25G03	Bracket, V Power Door	72-09-04	GE
CF6-80C2	X	X	1454M33G01	Tube, Compr Bleed Pressure	72-09-03	GE
CF6-80C2	X	X	1454M35G01	Tube, CDP	72-09-03	GE
CF6-80C2	X		1454M46G01	Valve, Check	72-09-03	GE
CF6-80C2	X		1454M46G02	Valve, Check	72-09-03	GE
CF6-80C2	X		1454M54G01	Tube, Air PS1	72-09-03	GE
CF6-80C2	X	X	1454M54G02	Tube, Air PS3	72-09-03	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2	X		1454M54G03	Tube, Air PS3	72-09-03	GE
CF6-80C2	X		1454M56G01	Tube, Air P25 Forward	72-09-03	GE
CF6-80C2	X	X	1454M56G02	Tube, Air P25 Forward	72-09-03	GE
CF6-80C2	X		1454M61G01	Tube, Air 11th Stage Valve	72-09-03	GE
CF6-80C2	X		1454M61G02	Tube, Air 11th Stage Valve	72-09-03	GE
CF6-80C2	X		1454M63P01	Tube	72-09-03	GE
CF6-80C2	X		1454M63P02	Tube	72-09-03	GE
CF6-80C2	X		1454M70P001A	Bracket, Strap	72-09-04	GE
CF6-80C2	X		1454M71P001A	Bracket, Electric Cable	72-09-04	GE
CF6-80C2	X		1454M72G01	Bracket, Support	72-09-04	GE
CF6-80C2	X		1454M74P001A	Bracket, Electrical	72-09-04	GE
CF6-80C2	X		1454M87G02	Valve, Check	72-09-03	GE
CF6-80C2	X		1454M88G02	Valve, Check Stage 11	72-09-03	GE
CF6-80C2	X		1455M10P001A	Bracket, Angle	72-09-04	GE
CF6-80C2	X		1455M17G01	Tube, Air P49 Aft	72-09-03	GE
CF6-80C2	X		1455M17G02	Tube, Air P49 Aft	72-09-03	GE
CF6-80C2	X		1455M17G03	Tube, Air P49 Aft	72-09-03	GE
CF6-80C2	X		1455M19G01	Bracket, Angle	72-09-04	GE
CF6-80C2	X		1455M20P001A	Bracket, Angle	72-09-04	GE
CF6-80C2	X		1455M20P003A	Bracket, Angle	72-09-04	GE
CF6-80C2	X	X	1455M23G02	Tube, Compr Bleed Pressure	72-09-03	GE
CF6-80C2	X		1455M32G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1455M32G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1455M39G01	Bracket	72-09-04	GE
CF6-80C2	X		1455M40G03	Bracket CA, Electrical	72-09-04	GE
CF6-80C2	X		1455M51P001A	Bracket	72-09-04	GE
CF6-80C2	X		1455M76G01	Tube, IDG Fuel/Oil	72-09-03	GE
CF6-80C2	X		1455M78P001A	Bracket	72-09-04	GE
CF6-80C2	X		1455M91G01	Tube, D Scavenge Forward	72-09-03	GE
CF6-80C2	X	X	1455M91G01A	Tube, D Scavenge Forward	72-09-03	GE
CF6-80C2	X		1456M10P001A	Bracket	72-09-04	GE
CF6-80C2	X	X	1456M12G01	Bracket, Clevis Duct	72-09-04	GE
CF6-80C2	X	X	1456M16G01	Tube	72-09-03	GE
CF6-80C2	X	X	1456M20G01	Tube, Lower (RH)	72-09-03	GE
CF6-80C2	X	X	1456M22G01	Tube, Pwr Dr Opening LH	72-09-03	GE
CF6-80C2	X	X	1456M25G01	Tube, CDP Air	72-09-03	GE
CF6-80C2	X		1456M31G01	Bracket, Tube Power	72-09-04	GE
CF6-80C2	X		1456M31G03	Bracket, Tube Power	72-09-04	GE
CF6-80C2	X		1456M49P001A	Bracket	72-09-04	GE
CF6-80C2	X		1456M54G01	Bracket	72-09-04	GE
CF6-80C2	X		1456M54G03	Bracket	72-09-04	GE
CF6-80C2	X		1456M55G01	Wye, Air HPT Cooling	72-09-03	GE
CF6-80C2	X		1456M55G03	Wye, Air HPT Cooling	72-09-03	GE
CF6-80C2	X		1456M55G04	Wye, Air HPT Cooling	72-09-03	GE
CF6-80C2	X		1456M59G01	Tube, Oil Lube	72-09-03	GE
CF6-80C2	X		1456M59G02	Tube, Oil D Lube	72-09-03	GE
CF6-80C2	X		1456M63G01	Tube, Air Bore	72-09-03	GE
CF6-80C2	X		1456M65G01	Tube, Air Bore	72-09-03	GE
CF6-80C2	X		1456M67P01	Tube And Hose, Oil IDG	72-09-03	GE
CF6-80C2	X		1456M67P02	Tube And Hose, Oil IDG	72-09-03	GE
CF6-80C2	X	X	1456M67P03	Tube And Hose, Oil IDG	72-09-03	GE
CF6-80C2	X		1456M67P04	Tube And Hose, Oil IDG	72-09-03	GE
CF6-80C2	X	X	1456M67P07	Tube And Hose, Oil IDG	72-09-03	GE
CF6-80C2	X		1456M67P08	Tube And Hose, Oil IDG	72-09-03	GE
CF6-80C2	X		1456M67P11	Tube And Hose, Oil IDG	72-09-03	GE
CF6-80C2	X		1456M67P12	Tube And Hose, Oil IDG	72-09-03	GE
CF6-80C2	X		1456M67P15	Tube And Hose, Oil IDG Cooling	72-09-03	GE
CF6-80C2	X	X	1456M67P16	Tube And Hose, Oil IDG Cooling	72-09-03	GE
CF6-80C2	X		1456M69G01	Tube, Air Bore	72-09-03	GE
CF6-80C2	X		1456M71G01	Tube, Air Bore	72-09-03	GE
CF6-80C2	X		1456M77G01	Tube, Air Bore	72-09-03	GE
CF6-80C2	X		1456M77G02	Tube, Air Bore	72-09-03	GE
CF6-80C2	X	X	1456M83G01	Tube, Oil IDG Cooling	72-09-03	GE
CF6-80C2	X		1456M85G01	Bracket, Bore Cooling	72-09-04	GE
CF6-80C2	X		1456M86G01	Bracket, Bore Cooling	72-09-04	GE
CF6-80C2	X		1456M87G01	Bracket, Bore Cooling Flex	72-09-04	GE
CF6-80C2	X		1456M88G01	Bracket, Bore Cooling Tube	72-09-04	GE
CF6-80C2	X		1456M91G01	Bracket, Bore Cooling Flex	72-09-04	GE
CF6-80C2	X		1456M96P001A	Bracket	72-09-04	GE
CF6-80C2	X		1456M97G01	Tube, Air LP Turb	72-09-03	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2	X		1456M97G03	Tube, Air LP Turb	72-09-03	GE
CF6-80C2	X		1456M97G04	Tube, Air LP Turb	72-09-03	GE
CF6-80C2	X		1456M97G05	Tube, Air LP Turb	72-09-03	GE
CF6-80C2	X		1456M97G06	Tube, Air LP Turb	72-09-03	GE
CF6-80C2	X		1456M97G08	Tube, Air LPT Cooling (LH)	72-09-03	GE
CF6-80C2	X	X	1456M97G09	Tube, Air LPT Cooling (LH)	72-09-03	GE
CF6-80C2	X		1456M97G10	Tube, Air LPT Cooling (LH)	72-09-03	GE
CF6-80C2	X		1456M99P001A	Bracket, Ignition Lead	72-09-04	GE
CF6-80C2	X		1468M14G01	Tube, Fuel Drain	72-09-03	GE
CF6-80C2	X		1468M19P001A	Bracket, Angle	72-09-04	GE
CF6-80C2	X	X	1468M20G01	Tube, Air P49 Mid	72-09-03	GE
CF6-80C2	X		1468M24P001A	Bracket, Tube	72-09-04	GE
CF6-80C2	X	X	1468M36G01	Bracket, CA Tray	72-09-04	GE
CF6-80C2	X		1468M43G01	Tube, 11th Stage	72-09-03	GE
CF6-80C2	X		1468M47G01	Tube, 11th Stage	72-09-03	GE
CF6-80C2	X		1468M53G01	Tube, Air Bore	72-09-03	GE
CF6-80C2	X		1468M57G01	Tube, Fuel Drain	72-09-03	GE
CF6-80C2	X	X	1468M57G02	Tube, Fuel Drain	72-09-03	GE
CF6-80C2	X		1468M72G01	Bracket, LPT Cooling Tube (LH)	72-09-04	GE
CF6-80C2	X		1468M79G01	Bracket, Double Angle LPTCC	72-09-04	GE
CF6-80C2	X		1468M84G01	Bracket, Manifold HP	72-09-04	GE
CF6-80C2	X		1468M87P001B	Bracket, Air Duct Start	72-09-04	GE
CF6-80C2	X		1469M28G01	Tube, LP Recoup	72-09-03	GE
CF6-80C2	X		1469M31G01	Bracket, V Bore Cooling	72-09-04	GE
CF6-80C2	X		1469M32G01	Tube, Expandable Seal Air	72-09-03	GE
CF6-80C2	X		1469M32G02	Tube, Expandable Seal Air	72-09-03	GE
CF6-80C2	X		1469M47P08	Tube/Hose	72-09-03	GE
CF6-80C2	X	X	1469M47P16	Tube, Hose VBV Fuel	72-09-03	GE
CF6-80C2	X		1469M49P08	Tube and Hose - Fuel, VBV	72-09-03	GE
CF6-80C2	X		1469M51P001A	Bracket, Angle	72-09-04	GE
CF6-80C2	X		1469M72G01	Tube, Air Bore	72-09-03	GE
CF6-80C2	X		1469M74G01	Tube, Air Bore	72-09-03	GE
CF6-80C2	X		1469M76P001A	Bracket, Air Tube Sig	72-09-04	GE
CF6-80C2	X		1469M80G01	Bracket, Support Starter	72-09-04	GE
CF6-80C2	X		1469M84G01	Tube, Air Bore	72-09-03	GE
CF6-80C2	X		1469M88G01	Bracket, Bore Cooling V (LH)	72-09-04	GE
CF6-80C2	X		1469M90P001B	Bracket	72-09-04	GE
CF6-80C2	X		1470M11P01	Bracket	72-09-04	GE
CF6-80C2	X		1470M11P03	Bracket	72-09-04	GE
CF6-80C2	X		1470M12P01	Bracket	72-09-04	GE
CF6-80C2	X		1470M15P01	Bracket, Manifold HPT	72-09-04	GE
CF6-80C2	X		1470M30G01	Bracket, Air Tube	72-09-04	GE
CF6-80C2	X		1470M31P001A	Bracket, Angle Ignition	72-09-04	GE
CF6-80C2	X		1470M32G01	Tube, Air R/S Valve	72-09-03	GE
CF6-80C2	X		1470M32G02	Tube, Air R/S Valve	72-09-03	GE
CF6-80C2	X		1470M32G03	Tube, Air R/S Valve	72-09-03	GE
CF6-80C2	X	X	1470M32G04	Tube, Air R/S Valve	72-09-03	GE
CF6-80C2	X		1470M39G02	Manifold, Air Cooling	72-09-03	GE
CF6-80C2	X		1470M39G04	Manifold, Air Cooling	72-09-03	GE
CF6-80C2	X		1470M39G05	Manifold, Air Cooling	72-09-03	GE
CF6-80C2	X		1470M39G07	Manifold, Air Cooling	72-09-03	GE
CF6-80C2	X	X	1470M39G08	Manifold, Air Cooling	72-09-03	GE
CF6-80C2	X		1470M39G09	Manifold, Air Cooling	72-09-03	GE
CF6-80C2	X		1470M39G12	Manifold, Air Cooling	72-09-03	GE
CF6-80C2	X		1470M44G01	Bracket, Tube	72-09-04	GE
CF6-80C2	X		1470M45P001A	Bracket, Electric Cable	72-09-04	GE
CF6-80C2	X		1470M46P001A	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1470M52P001A	Bracket, Electric Lead	72-09-04	GE
CF6-80C2	X		1470M53G01	Bracket, Electric Fan	72-09-04	GE
CF6-80C2	X		1470M53G02	Bracket, Electric Fan	72-09-04	GE
CF6-80C2	X		1470M55G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1470M56G01	Bracket, Electric Cable	72-09-04	GE
CF6-80C2	X		1470M60G01	Bracket, Fire Detector	72-09-04	GE
CF6-80C2	X		1470M61P001A	Bracket, Fire Detector	72-09-04	GE
CF6-80C2	X		1470M63G01	Bracket	72-09-04	GE
CF6-80C2	X		1470M66G01	Bracket, Tube Air	72-09-04	GE
CF6-80C2	X		1470M67G01	Bracket	72-09-04	GE
CF6-80C2	X		1470M79P001B	Bracket, Manifold	72-09-04	GE
CF6-80C2	X		1470M92G01	Bracket, Sensor	72-09-04	GE
CF6-80C2	X		1470M95P001A	Bracket	72-09-04	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2	X		1470M95P001B	Bracket	72-09-04	GE
CF6-80C2	X	X	1472M70G01	Spacer, AGB Mount	72-65-10	GE
CF6-80C2	X		1472M70G02	Spacer, AGB Mount	72-65-10	GE
CF6-80C2	X		1472M85P04	Fairing, Segment	72-23-01	GE
CF6-80C2	X		1472M85P06	Fairing, Segment	72-23-01	GE
CF6-80C2	X		1473M17P01	Bracket, Air Manifold Mtg Forward	72-09-04	GE
CF6-80C2	X		1473M20G01	Bracket, Air Manifold HPT	72-09-04	GE
CF6-80C2	X		1473M21G01	Bracket, Air Manifold	72-09-04	GE
CF6-80C2	X		1473M21G02	Bracket, HPT Air Manf	72-09-04	GE
CF6-80C2	X		1473M22G01	Bracket, Air Manifold HPT	72-09-04	GE
CF6-80C2	X		1473M32P01	Bracket, Air Manifold Mtg Forward	72-09-04	GE
CF6-80C2	X		1474M96P01	Bracket, Manifold Aft	72-09-04	GE
CF6-80C2	X		1474M96P02	Bracket	72-09-04	GE
CF6-80C2	X		1491M15P001A	Bracket, Tube Drain	72-09-04	GE
CF6-80C2	X		1491M17G01	Tube, Forward Oil Lube	72-09-03	GE
CF6-80C2	X	X	1491M17G02	Tube, Forward Oil Lube	72-09-03	GE
CF6-80C2	X		1491M19G01	Bracket, Fan Electric	72-09-04	GE
CF6-80C2	X	X	1491M20G02	Tube, Accessory Gearbox Oil Scavenge	72-09-03	GE
CF6-80C2	X		1491M20G04	Tube, Accessory Gearbox Oil Scavenge	72-09-03	GE
CF6-80C2	X	X	1491M22G01	Tube	72-09-03	GE
CF6-80C2	X		1491M29G01	Tube, Air P49 Forward	72-09-03	GE
CF6-80C2	X		1491M29G02	Tube, Air P49 Forward	72-09-03	GE
CF6-80C2	X		1491M36G01	Tube, Pylon Drain Fuel	72-09-03	GE
CF6-80C2	X		1491M38G01	Bracket	72-09-04	GE
CF6-80C2	X		1491M41P001A	Bracket, Tube	72-09-04	GE
CF6-80C2	X		1491M42P001A	Bracket, Pylon Drain	72-09-04	GE
CF6-80C2	X		1491M42P001B	Bracket, Pylon Drain	72-09-04	GE
CF6-80C2	X		1491M42P001C	Bracket, Pylon Drain	72-09-04	GE
CF6-80C2	X	X	1491M45G01	Tube, Pylon Drain Fuel	72-09-03	GE
CF6-80C2	X		1491M47P001A	Bracket, Clamp Cable	72-09-04	GE
CF6-80C2	X		1491M48G01	Tube, Heat Exchanger Oil	72-09-03	GE
CF6-80C2	X		1491M51P001A	Bracket	72-09-04	GE
CF6-80C2	X		1491M53G01	Bracket	72-09-04	GE
CF6-80C2	X		1491M56P01	Hose, P49	72-09-03	GE
CF6-80C2	X		1491M56P02	Hose, P49	72-09-03	GE
CF6-80C2	X		1491M56P03	Hose, P49	72-09-03	GE
CF6-80C2	X		1491M59P001A	Bracket, Tube Air	72-09-04	GE
CF6-80C2	X		1491M59P001B	Bracket, Tube Air	72-09-04	GE
CF6-80C2	X		1491M74G01	Bracket CA, Electrical	72-09-04	GE
CF6-80C2	X		1491M77G03	Bracket, Angle	72-09-04	GE
CF6-80C2	X		1492M12P001A	Bracket	72-09-04	GE
CF6-80C2	X		1492M15G01	Bracket, Support	72-09-04	GE
CF6-80C2	X		1492M16G01	Bracket, Support	72-09-04	GE
CF6-80C2	X		1492M18G01	Bracket, Fire Detector	72-09-04	GE
CF6-80C2	X		1492M19G01	Tube, Air Compressor	72-09-03	GE
CF6-80C2	X		1492M37G03	Tube	72-09-03	GE
CF6-80C2	X	X	1492M39G04	Tube	72-09-03	GE
CF6-80C2	X	X	1492M39G05	Tube	72-09-03	GE
CF6-80C2	X		1492M42P001A	Bracket, Electric Lead	72-09-04	GE
CF6-80C2	X		1492M50G01	Bracket, HPT And Core	72-09-04	GE
CF6-80C2	X		1492M51G01	Bracket, Manifold Core	72-09-04	GE
CF6-80C2	X		1492M52G01	Manifold, Lower Sensor	72-09-03	GE
CF6-80C2	X		1492M56G01	Tube, Air HP Turb Acc	72-09-03	GE
CF6-80C2	X		1492M56G03	Tube, Air HP Turb Acc	72-09-03	GE
CF6-80C2	X		1492M56G05	Tube, Air HP Turb Acc	72-09-03	GE
CF6-80C2	X		1492M56G06	Tube, Air HP Turb Acc	72-09-03	GE
CF6-80C2	X		1492M56G07	Tube, Air HP Turb Acc	72-09-03	GE
CF6-80C2	X	X	1492M56G08	Tube, Air HP Turb Acc	72-09-03	GE
CF6-80C2	X		1492M68P001A	Bracket, Tube Air	72-09-04	GE
CF6-80C2	X		1492M84G01	Bracket, Tube LP	72-09-04	GE
CF6-80C2	X		1492M90G01	Bracket, Tube LP	72-09-04	GE
CF6-80C2	X		1492M93G02	Nozzle, Manifold Core	72-09-03	GE
CF6-80C2	X		1492M96G02	Tube, Fuel LP Turb	72-09-03	GE
CF6-80C2	X	X	1492M98G01	Tube, Fuel Drain	72-09-03	GE
CF6-80C2	X		1516M25G01	Tube, Air	72-09-03	GE
CF6-80C2	X		1516M32G01	Bracket	72-09-04	GE
CF6-80C2	X		1516M33G01	Tube, Air	72-09-03	GE
CF6-80C2	X		1516M48G01	Bracket, Electric Cont	72-09-04	GE
CF6-80C2	X		1516M48G02	Bracket, Electric Cont	72-09-04	GE
CF6-80C2	X		1516M50G01	Bracket, Electric Cont	72-09-04	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2	X		1516M50G02	Bracket, Electric Cont	72-09-04	GE
CF6-80C2	X		1516M52G01	Bracket, ECU	72-09-04	GE
CF6-80C2	X		1516M52G02	Bracket, ECU	72-09-04	GE
CF6-80C2	X		1516M53G02	Clamp, Manifold	72-09-04	GE
CF6-80C2	X		1516M56P001A	Bracket, Angle	72-09-04	GE
CF6-80C2	X	X	1516M58G01	Bracket, Tube Integrated	72-09-04	GE
CF6-80C2	X		1516M63P001B	Bracket	72-09-04	GE
CF6-80C2	X		1516M64P001A	Bracket, Tube Fuel	72-09-04	GE
CF6-80C2	X		1516M67P001A	Bracket	72-09-04	GE
CF6-80C2	X		1516M89P001A	Bracket, Tube Support	72-09-04	GE
CF6-80C2	X		1516M96G01	Tube, Air	72-09-03	GE
CF6-80C2	X		1516M98G01	Tube, Air	72-09-03	GE
CF6-80C2	X		1517M10G01	Bracket, Manifold	72-09-04	GE
CF6-80C2	X		1517M11G01	Tube, Fuel Drain	72-09-03	GE
CF6-80C2	X		1517M13G01	Tube, Fuel Manifold Drain	72-09-03	GE
CF6-80C2	X		1517M13G02	Tube, Fuel Manifold Drain	72-09-03	GE
CF6-80C2	X	X	1517M13G03	Tube, Fuel Manifold Drain	72-09-03	GE
CF6-80C2	X		1517M16G01	Tube, Air PS3 Forward	72-09-03	GE
CF6-80C2	X		1517M20P001A	Bracket, Tube IDG	72-09-04	GE
CF6-80C2	X		1517M53G03	Bracket, Manifold	72-09-04	GE
CF6-80C2	X		1517M56P001B	Bracket, Manifold Core	72-09-04	GE
CF6-80C2	X	X	1517M58G01	Tube, Fuel T2 Sensor	72-09-03	GE
CF6-80C2	X	X	1517M62G01	Tube, Fuel T2	72-09-03	GE
CF6-80C2	X		1517M65G02	Manifold, Drain Mast	72-09-03	GE
CF6-80C2	X		1517M65G03	Manifold, Drain Mast	72-09-03	GE
CF6-80C2	X	X	1517M65G04	Manifold, Drain Mast	72-09-03	GE
CF6-80C2	X		1517M70G01	Tube, Fuel T2 Sensor	72-09-03	GE
CF6-80C2	X	X	1517M72G01	Tube	72-09-03	GE
CF6-80C2	X		1517M76G01	Bracket, Support	72-09-04	GE
CF6-80C2	X		1517M77P001A	Bracket, Electrical	72-09-04	GE
CF6-80C2	X		1517M78P001A	Bracket	72-09-04	GE
CF6-80C2	X		1517M79P001A	Bracket, Electric Cable	72-09-04	GE
CF6-80C2	X		1517M80P001A	Bracket, Electric Cable	72-09-04	GE
CF6-80C2	X		1517M81P001A	Bracket, Cable Support	72-09-04	GE
CF6-80C2	X		1517M82P01	Adapter	72-09-04	GE
CF6-80C2	X		1517M83G01	Bracket, Ignition	72-09-04	GE
CF6-80C2	X		1517M83G03	Bracket, Ignition	72-09-04	GE
CF6-80C2	X		1517M83G05	Bracket, Ignition	72-09-04	GE
CF6-80C2	X		1517M84P001A	Bracket	72-09-04	GE
CF6-80C2	X		1517M84P001B	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1517M84P001C	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1517M88P01	Bracket, Tube	72-09-04	GE
CF6-80C2	X		1517M91P001A	Bracket, Tube IDG Signal	72-09-04	GE
CF6-80C2	X		1518M62G01	Bracket Assy, Plate Identification	72-09-04	GE
CF6-80C2	X		1518M97P001A	Retainer	71-21-01	GE
CF6-80C2	X	X	1519M56P01	Adapter	72-67-01	GE
CF6-80C2	X		1531M25G01	Retainer	71-21-01	GE
CF6-80C2	X		1531M98G01	Bracket	72-09-04	GE
CF6-80C2	X		1531M99P001A	Bracket	72-09-04	GE
CF6-80C2	X		1536M55G01	Bracket, HPT Stator Aft	72-09-04	GE
CF6-80C2	X		1536M55G02	Bracket, Air Manifold	72-09-04	GE
CF6-80C2	X		1536M55G03	Bracket, Air Manifold	72-09-04	GE
CF6-80C2	X		1536M55G04	Bracket, Air Manifold	72-09-04	GE
CF6-80C2	X		1536M55G05	Bracket	72-09-04	GE
CF6-80C2	X		1536M57G01	Bracket, Air Manifold	72-09-04	GE
CF6-80C2	X		1536M60P11	Bracket	72-09-04	GE
CF6-80C2	X		1536M65G07	Manifold, Air HPT	72-09-03	GE
CF6-80C2	X		1536M65G08	Manifold, Air HPT	72-09-03	GE
CF6-80C2	X		1536M65G09	Manifold, Air HPT	72-09-03	GE
CF6-80C2	X		1536M77G02	Bracket, Air Manifold	72-09-04	GE
CF6-80C2	X		1536M79G02	Bracket, Air Manifold	72-09-04	GE
CF6-80C2	X		1536M96G01	Bracket, HPT Stator Aft	72-09-04	GE
CF6-80C2	X		1536M96G02	Bracket, Air Manifold	72-09-04	GE
CF6-80C2	X		1536M96G03	Bracket, Air Manifold	72-09-04	GE
CF6-80C2	X		1536M96G04	Bracket, Air Manifold	72-09-04	GE
CF6-80C2	X		1536M96G05	Bracket	72-09-04	GE
CF6-80C2	X		1536M97G01	Bracket, Air Manifold	72-09-04	GE
CF6-80C2	X		1536M98G01	Bracket, Air Manifold	72-09-04	GE
CF6-80C2	X		1536M98G02	Bracket, Air Manifold	72-09-04	GE
CF6-80C2	X		1536M99G02	Bracket, Air Manifold	72-09-04	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2	X		1537M24P001A	Bracket, Nut	72-09-04	GE
CF6-80C2	X		1537M30P001A	Bracket, Nut	72-09-04	GE
CF6-80C2	X		1537M87G01	Bracket	72-09-04	GE
CF6-80C2	X	X	1538M48G01	Bracket	72-09-04	GE
CF6-80C2	X		1539M75P01	Bracket	72-09-04	GE
CF6-80C2	X		1539M76P01	Bracket, Ground Handling	72-09-04	GE
CF6-80C2	X		1577M22G03	Bracket, Angle	72-09-04	GE
CF6-80C2	X		1577M22G05	Bracket, Angle	72-09-04	GE
CF6-80C2	X		1577M27G01	Tube, Oil	72-09-03	GE
CF6-80C2	X		1577M27G02	Tube, Oil	72-09-03	GE
CF6-80C2	X		1577M29G02	Tube, T2 Sensor Lower PB	72-09-03	GE
CF6-80C2	X		1577M31G02	Tube, T2 Sensor Lower P7	72-09-03	GE
CF6-80C2	X		1577M31G03	Tube, T2 Sensor Lower P7	72-09-03	GE
CF6-80C2	X		1577M37G03	Bracket, CA Tray	72-09-04	GE
CF6-80C2	X	X	1577M37G05	Bracket, CA Tray	72-09-04	GE
CF6-80C2	X		1577M38G01	Bracket, Cable Tray	72-09-04	GE
CF6-80C2	X		1577M39G03	Bracket, Cable Tray	72-09-04	GE
CF6-80C2	X		1577M40G01	Tube, Press Sensing PS3	72-09-03	GE
CF6-80C2	X	X	1577M40G02	Tube, Press Sensing PS3	72-09-03	GE
CF6-80C2	X		1577M40G03	Tube, Press Sensing PS3	72-09-03	GE
CF6-80C2	X		1577M40G04	Tube, Press Sensing PS3	72-09-03	GE
CF6-80C2	X		1577M40G05	Tube, Press Sensing PS3	72-09-03	GE
CF6-80C2	X		1577M44P001A	Bracket	72-09-04	GE
CF6-80C2	X		1577M54G01	Bracket, Support	72-09-04	GE
CF6-80C2	X		1577M57P001A	Bracket	72-09-04	GE
CF6-80C2	X		1577M63P001A	Bracket, Lower Fan	72-09-04	GE
CF6-80C2	X	X	1577M65G01	Tube, Air	72-09-03	GE
CF6-80C2	X		1577M67G01	Bracket	72-09-04	GE
CF6-80C2	X		1577M67G03	Bracket	72-09-04	GE
CF6-80C2	X		1577M69G01	Tube, Air 11th Stage Valve	72-09-03	GE
CF6-80C2	X	X	1577M69G03	Tube, Air 11th Stage Valve	72-09-03	GE
CF6-80C2	X	X	1577M69G04	Tube, Air 11th Stage Valve	72-09-03	GE
CF6-80C2	X		1577M71G01	Tube, Air 11th Stage Valve	72-09-03	GE
CF6-80C2	X	X	1577M71G02	Tube, Air 11th Stage Valve	72-09-03	GE
CF6-80C2	X	X	1577M71G03	Tube, Air 11th Stage Valve	72-09-03	GE
CF6-80C2	X		1577M73G01	Bracket, Solenoid Valve	72-09-04	GE
CF6-80C2	X	X	1577M81G02	Tube, Fuel LPT	72-09-03	GE
CF6-80C2	X		1577M83G02	Tube, Fuel LP	72-09-03	GE
CF6-80C2	X		1577M85P001A	Bracket	72-09-04	GE
CF6-80C2	X		1577M89P001A	Bracket	72-09-04	GE
CF6-80C2	X		1577M92P001A	Bracket, Spray	72-09-04	GE
CF6-80C2	X		1577M93G05	Bracket, Spray Shield	72-09-04	GE
CF6-80C2	X		1577M97P001A	Bracket	72-09-04	GE
CF6-80C2	X		1577M97P001C	Bracket	72-09-04	GE
CF6-80C2	X		1578M16P001A	Bracket, Support Lower	72-09-04	GE
CF6-80C2	X		1578M19P001A	Bracket, Tube	72-09-04	GE
CF6-80C2	X		1578M21P001B	Bracket, Support	72-09-04	GE
CF6-80C2	X		1578M22G01	Manifold, Air HP	72-09-03	GE
CF6-80C2	X		1578M22G02	Manifold, Air HP	72-09-03	GE
CF6-80C2	X		1578M22G05	Manifold, Air HP	72-09-03	GE
CF6-80C2	X		1578M22G06	Manifold, Air HP	72-09-03	GE
CF6-80C2	X		1578M24P001A	Bracket, Support	72-09-04	GE
CF6-80C2	X		1578M30G02	Link, Support	72-09-04	GE
CF6-80C2	X	X	1578M30G08	Link, Support	72-09-04	GE
CF6-80C2	X	X	1578M30G14	Link, Support	72-09-04	GE
CF6-80C2	X	X	1578M30G18	Link, Support	72-09-04	GE
CF6-80C2	X	X	1578M30G21	Link, Support	72-09-04	GE
CF6-80C2	X		1578M30G22	Link, Support	72-09-04	GE
CF6-80C2	X	X	1578M30G28	Link, Support	72-09-04	GE
CF6-80C2	X	X	1578M30G49	Link, Support	72-09-04	GE
CF6-80C2	X		1578M35P001A	Bracket, Lead	72-09-04	GE
CF6-80C2	X		1578M36P001B	Bracket, Spray	72-09-04	GE
CF6-80C2	X		1578M50G01	Manifold, T2 Drain	72-09-03	GE
CF6-80C2	X		1578M64P001A	Bracket, Fire	72-09-04	GE
CF6-80C2	X		1578M64P001B	Bracket, Fire Detector	72-09-04	GE
CF6-80C2	X		1578M80G01	Bracket, Tube	72-09-04	GE
CF6-80C2	X		1578M81G01	Bracket, Tube	72-09-04	GE
CF6-80C2	X		1578M83G03	Bracket, Tube LPT Cooling	72-09-04	GE
CF6-80C2	X		1578M85G01	Bracket, Manifold	72-09-04	GE
CF6-80C2	X		1578M85G03	Bracket, Manifold	72-09-04	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2	X		1578M87G01	Bracket, Tube Air HPT	72-09-04	GE
CF6-80C2	X		1578M89G05	Bracket, Tube Air	72-09-04	GE
CF6-80C2	X		1578M90G01	Bracket	72-09-04	GE
CF6-80C2	X		1578M90G03	Bracket	72-09-04	GE
CF6-80C2	X		1578M90G05	Bracket	72-09-04	GE
CF6-80C2	X		1578M92G01	Bracket	72-09-04	GE
CF6-80C2	X		1578M96G01	Bracket, Fire Detector	72-09-04	GE
CF6-80C2	X		1578M97G01	Bracket, Fire Detector	72-09-04	GE
CF6-80C2	X		1578M98G05	Bracket, Fire Detector	72-09-04	GE
CF6-80C2	X		1578M99P001D	Bracket, Fire Protection	72-09-04	GE
CF6-80C2	X		1581M13P001A	Bracket	72-09-04	GE
CF6-80C2	X		1581M26G01	Bracket, Manifold	72-09-04	GE
CF6-80C2	X		1581M26G03	Bracket, Manifold	72-09-04	GE
CF6-80C2	X		1581M26G05	Bracket, Manifold	72-09-04	GE
CF6-80C2	X		1581M28P001A	Bracket, Tube Power	72-09-04	GE
CF6-80C2	X	X	1581M31G03	Tube, Power Door Opr	72-09-03	GE
CF6-80C2	X		1581M35G01	Bracket, ECU	72-09-04	GE
CF6-80C2	X		1581M35G02	Bracket, ECU	72-09-04	GE
CF6-80C2	X		1581M36G01	Bracket	72-09-04	GE
CF6-80C2	X		1581M36G02	Bracket	72-09-04	GE
CF6-80C2	X		1581M36G05	Bracket	72-09-04	GE
CF6-80C2	X		1581M36G06	Bracket	72-09-04	GE
CF6-80C2	X		1581M56P01	Tube And Hose, Oil IDG	72-09-03	GE
CF6-80C2	X		1581M56P02	Tube And Hose, Oil IDG	72-09-03	GE
CF6-80C2	X		1581M56P03	Tube And Hose, Oil IDG	72-09-03	GE
CF6-80C2	X	X	1581M56P04	Tube And Hose, Oil IDG	72-09-03	GE
CF6-80C2	X		1582M10G01	Tube, B Sump Scavenge Oil	72-09-03	GE
CF6-80C2	X	X	1582M10G02	Tube, B Sump Scavenge Oil	72-09-03	GE
CF6-80C2	X		1582M10G03	Tube, B Sump Scavenge Oil	72-09-03	GE
CF6-80C2	X	X	1582M10G04	Tube, B Sump Scavenge Oil	72-09-03	GE
CF6-80C2	X	X	1582M12G01	Tube, C Scavenge Mid Oil	72-09-03	GE
CF6-80C2	X	X	1582M12G02	Tube, C Scavenge Mid Oil	72-09-03	GE
CF6-80C2	X	X	1582M14G01	Tube, C Sump Scavenge Oil	72-09-03	GE
CF6-80C2	X		1582M14G02	Tube, C Sump Scavenge Oil	72-09-03	GE
CF6-80C2	X		1582M14G03	Tube, C Sump Scavenge Oil	72-09-03	GE
CF6-80C2	X	X	1582M37G01	Tube, Oil Outlet IDG	72-09-03	GE
CF6-80C2	X		1582M40G01	Tube, No. 1 Sensor Drain Fuel	72-09-03	GE
CF6-80C2	X	X	1582M46G01	Tube, Oil IDG Fuel/Oil	72-09-03	GE
CF6-80C2	X	X	1582M48G01	Tube, VBV/VSV Drain Fuel	72-09-03	GE
CF6-80C2	X	X	1582M50G01	Tube, PO	72-09-03	GE
CF6-80C2	X		1582M53G01	Bracket, Manifold Fuel	72-09-04	GE
CF6-80C2	X		1582M53P001A	Bracket	72-09-04	GE
CF6-80C2	X		1582M89G01	Bracket, Manifold Fuel	72-09-04	GE
CF6-80C2	X		1582M89P001A	Bracket	72-09-04	GE
CF6-80C2	X		1582M92P001B	Bracket	72-09-04	GE
CF6-80C2	X		1582M97G01	Tube, Air	72-09-03	GE
CF6-80C2	X		1584M91G02	Tube, Oil	72-09-03	GE
CF6-80C2	X		1606M11G01	Tube, Air P25	72-09-03	GE
CF6-80C2	X		1606M19G01	Bracket, IDG Air/Oil	72-09-04	GE
CF6-80C2	X		1606M28G01	Bracket, Integrated	72-09-04	GE
CF6-80C2	X		1606M32P01	Bracket, Link	72-09-04	GE
CF6-80C2	X		1606M39G01	Tube, Fuel	72-09-03	GE
CF6-80C2	X	X	1606M39G02	Tube, Fuel	72-09-03	GE
CF6-80C2	X		1606M51G02	Tube, Air LPT Supply	72-09-03	GE
CF6-80C2	X		1606M51G03	Tube, Air LPT Supply	72-09-03	GE
CF6-80C2	X		1606M51G04	Tube, Air LPT Supply	72-09-03	GE
CF6-80C2	X		1606M51G05	Tube, Air LPT Supply	72-09-03	GE
CF6-80C2	X		1606M51G06	Tube, Air LPT Supply	72-09-03	GE
CF6-80C2	X		1606M51G07	Tube, Air LPT Supply	72-09-03	GE
CF6-80C2	X	X	1606M59G01	Tube, Accessory Drain Fuel	72-09-03	GE
CF6-80C2	X		1606M61G03	Bracket, HP Turb Active	72-09-04	GE
CF6-80C2	X		1606M68G01	Bracket	72-09-04	GE
CF6-80C2	X		1606M68G03	Bracket	72-09-04	GE
CF6-80C2	X		1642M10P001A	Bracket, Electrical	72-09-04	GE
CF6-80C2	X		1642M10P001B	Bracket, Electrical	72-09-04	GE
CF6-80C2	X		1642M11P001A	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1642M12G01	Bracket	72-09-04	GE
CF6-80C2	X		1642M13G02	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1642M13G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1642M13G05	Bracket, Electric	72-09-04	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2	X		1642M14G02	Bracket	72-09-04	GE
CF6-80C2	X		1642M14G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1642M14G05	Bracket	72-09-04	GE
CF6-80C2	X		1642M15P001A	Bracket, Gearbox	72-09-04	GE
CF6-80C2	X		1642M15P001B	Bracket, Gearbox	72-09-04	GE
CF6-80C2	X		1642M16G01	Bracket, Strap	72-09-04	GE
CF6-80C2	X		1642M17G02	Bracket, Electric Lead	72-09-04	GE
CF6-80C2	X		1642M17G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1642M44G01	Manifold, Press Sensing	72-09-03	GE
CF6-80C2	X		1642M44G02	Manifold, Press Sensing	72-09-03	GE
CF6-80C2	X		1642M44G03	Manifold, Press Sensing	72-09-03	GE
CF6-80C2	X		1642M52G01	Bracket	72-09-04	GE
CF6-80C2	X		1642M53P001A	Bracket, Gearbox	72-09-04	GE
CF6-80C2	X		1642M65P001A	Bracket, Electric Heat Shield	72-09-04	GE
CF6-80C2	X	X	1642M66G01	Tube, Fuel Drain	72-09-03	GE
CF6-80C2	X	X	1642M68G01	Manifold, Fuel Drain VSV	72-09-03	GE
CF6-80C2	X	X	1642M74G01	Tube, Oil Gearbox Supply	72-09-03	GE
CF6-80C2	X	X	1642M76G01	Valve, Check Stage 11	72-09-03	GE
CF6-80C2	X		1642M79G01	Bracket	72-09-04	GE
CF6-80C2	X		1642M80G01	Tube, Fuel Drain VSV	72-09-03	GE
CF6-80C2	X	X	1642M80G02	Tube, Fuel Drain VSV	72-09-03	GE
CF6-80C2	X		1642M95P001A	Bracket, Tube Power	72-09-04	GE
CF6-80C2	X	X	1643M27G01	Manifold	72-09-03	GE
CF6-80C2	X		1643M47G01	Manifold, HPT Cooling Air	72-09-03	GE
CF6-80C2	X		1643M47G02	Manifold, HPT Cooling Air	72-09-03	GE
CF6-80C2	X		1643M52P001A	Bracket, Tube Support	72-09-04	GE
CF6-80C2	X		1643M61G01	Tube, Air P49 Aft	72-09-03	GE
CF6-80C2	X		1643M74G02	Manifold, Drain	72-09-03	GE
CF6-80C2	X		1643M76G01	Bracket, Cable Electrical	72-09-04	GE
CF6-80C2	X		1643M77G01	Bracket, Support Fire	72-09-04	GE
CF6-80C2	X		1643M78G01	Bracket, Support Fire	72-09-04	GE
CF6-80C2	X		1643M79G01	Bracket, Fire Detector	72-09-04	GE
CF6-80C2	X		1643M80G01	Bracket	72-09-04	GE
CF6-80C2	X		1643M81P001A	Bracket, Ignition Cable	72-09-04	GE
CF6-80C2	X		1643M82P001A	Bracket, Support	72-09-04	GE
CF6-80C2	X		1643M85G01	Tube, Air Recoup LPT	72-09-03	GE
CF6-80C2	X		1643M86G01	Tube, Air LP Recoup	72-09-03	GE
CF6-80C2	X		1643M87G01	Tube, Air LP Recoup Mid	72-09-03	GE
CF6-80C2	X		1643M88G01	Tube, Air LP Recoup Forward	72-09-03	GE
CF6-80C2	X		1643M89P001A	Bracket, Tube Drain	72-09-04	GE
CF6-80C2	X		1643M91G01	Bracket, Air Tube Stage 7	72-09-04	GE
CF6-80C2	X		1663M56P01	Bracket, Mount	72-09-04	GE
CF6-80C2	X		1663M57P01	Bracket, Mount	72-09-04	GE
CF6-80C2	X	X	1663M63G02	Link	72-65-10	GE
CF6-80C2	X		1663M73G01	Nut	72-58-02	GE
CF6-80C2	X		1664M81P03	Shield, Heat	72-58-14	GE
CF6-80C2	X		1664M84G01	Shield, Heat	72-58-14	GE
CF6-80C2	X		1664M85G01	Plate	72-58-14	GE
CF6-80C2	X		1664M86P01	Slinger, Oil Bearing No 6	72-57-08	GE
CF6-80C2	X	X	1669M96P03	Seal	72-31-19	GE
CF6-80C2	X		1678M14G01	Bracket, Manifold Air CCC	72-09-04	GE
CF6-80C2	X		1678M23G02	Manifold, Fuel Spline	72-09-03	GE
CF6-80C2	X		1678M25G01	Manifold, Fuel Drain	72-09-03	GE
CF6-80C2	X		1678M27G01	Tube, Drain Bypass	72-09-03	GE
CF6-80C2	X		1678M35G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1678M38P001A	Bracket	72-09-04	GE
CF6-80C2	X		1678M41G01	Bracket, Tube	72-09-04	GE
CF6-80C2	X		1678M44G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1678M45G01	Bracket, Electrical	72-09-04	GE
CF6-80C2	X		1678M46G01	Bracket, Tube Oil Tank	72-09-04	GE
CF6-80C2	X		1678M48G01	Tube, Air 11th Stage Upper	72-09-03	GE
CF6-80C2	X		1678M48G02	Tube, Air 11th Stage Upper	72-09-03	GE
CF6-80C2	X	X	1678M50G01	Tube, Air HPT Supply	72-09-03	GE
CF6-80C2	X		1678M52G01	Tube, Oil	72-09-03	GE
CF6-80C2	X		1678M52G02	Tube, Oil	72-09-03	GE
CF6-80C2	X		1678M52G03	Tube, Oil	72-09-03	GE
CF6-80C2	X	X	1678M52G04	Tube, Oil	72-09-03	GE
CF6-80C2	X		1678M54G02	Tube, Oil	72-09-03	GE
CF6-80C2	X		1678M67P001B	Bracket	72-09-04	GE
CF6-80C2	X		1678M68G01	Bracket, Air/Oil Cooler	72-09-04	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2	X		1678M73P001B	Bracket, Ignition Lead	72-09-04	GE
CF6-80C2	X		1678M75G03	Tube, Air HPT Supply	72-09-03	GE
CF6-80C2	X		1678M76P001A	Bracket, Support Ign CA	72-09-04	GE
CF6-80C2	X		1678M77G01	Tube, Mast Manifold to Module	72-09-03	GE
CF6-80C2	X		1678M82G01	Tube, Oil No. 1 Scavenge	72-09-03	GE
CF6-80C2	X		1678M86G01	Tube, Air LPT Supply	72-09-03	GE
CF6-80C2	X		1678M86G02	Tube, Air LPT Supply	72-09-03	GE
CF6-80C2	X		1678M86G03	Tube, Air LPT Supply	72-09-03	GE
CF6-80C2	X		1678M86G04	Tube, Air LPT Supply	72-09-03	GE
CF6-80C2	X		1678M86G05	Tube, Air LPT Supply	72-09-03	GE
CF6-80C2	X		1678M86G06	Tube, Air LPT Supply	72-09-03	GE
CF6-80C2	X		1678M86G07	Tube, Air LPT Supply	72-09-03	GE
CF6-80C2	X		1678M87G01	Bracket, Support	72-09-04	GE
CF6-80C2	X		1678M91G01	Bracket, Hydraulic	72-09-04	GE
CF6-80C2	X		1679M14G01	Tube, Air 11th Stage Valve	72-09-03	GE
CF6-80C2	X		1679M16G01	Tube, Cooling	72-09-03	GE
CF6-80C2	X		1679M18G01	Bracket, Tube LP	72-09-04	GE
CF6-80C2	X		1679M19G01	Bracket, Manifold Core	72-09-04	GE
CF6-80C2	X	X	1679M24G01	Tube, Oil IDG Fuel/Oil	72-09-03	GE
CF6-80C2	X		1679M26P03	Tube, Hose	72-09-03	GE
CF6-80C2	X		1679M31G07	Bracket, Hydr Drain	72-09-04	GE
CF6-80C2	X	X	1679M35G01	Bracket	72-09-04	GE
CF6-80C2	X		1679M37P001A	Bracket	72-09-04	GE
CF6-80C2	X		1679M38G01	Bracket, Support Cable	72-09-04	GE
CF6-80C2	X		1679M39P001A	Bracket, Double Angle	72-09-04	GE
CF6-80C2	X		1679M40P001A	Bracket, Tube Mid Pylon	72-09-04	GE
CF6-80C2	X		1679M42P001A	Bracket	72-09-04	GE
CF6-80C2	X		1679M43G01	Bracket	72-09-04	GE
CF6-80C2	X		1679M43G03	Bracket, Electrical	72-09-04	GE
CF6-80C2	X		1679M44P001A	Bracket	72-09-04	GE
CF6-80C2	X		1679M45P001A	Bracket, Cable Support	72-09-04	GE
CF6-80C2	X		1679M48G01	Bracket, Electrical	72-09-04	GE
CF6-80C2	X		1679M49G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1679M53G01	Bracket, Support Starter	72-09-04	GE
CF6-80C2	X		1679M64P02	Clamp	72-00-00	GE
CF6-80C2	X		1679M72P001A	Bracket, Air Curtain	72-09-04	GE
CF6-80C2	X		1679M73P001A	Bracket, Air Curtain	72-09-04	GE
CF6-80C2	X		1679M75P001A	Bracket, Air Cooling	72-09-04	GE
CF6-80C2	X		1679M81G01	Bracket, Support Start Duct	72-09-04	GE
CF6-80C2	X		1679M81G03	Bracket, Support Start Duct	72-09-04	GE
CF6-80C2	X		1679M84G01	Bracket	72-09-04	GE
CF6-80C2	X		1679M90P001A	Bracket, Clamp Cable	72-09-04	GE
CF6-80C2	X		1679M92G01	Tube, Oil	72-09-03	GE
CF6-80C2	X		1679M92G02	Tube, Oil	72-09-03	GE
CF6-80C2	X	X	1703M92G02	Seal	72-32-04	GE
CF6-80C2	X	X	1703M92G03	Seal, Stationary	72-32-04	GE
CF6-80C2	X	X	1704M43P06	Blade, Booster LPC Stg 2	72-21-02	GE
CF6-80C2	X	X	1704M43P07	Blade, Booster LPC Stg 2	72-21-02	GE
CF6-80C2	X	X	1704M43P08	Blade, Booster LPC Stg 2	72-21-02	GE
CF6-80C2	X		1706M10G01	Bracket, Tube Oil Drain	72-09-04	GE
CF6-80C2	X		1706M11G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1706M11G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1706M11G05	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1706M16G01	Bracket, Fire Detector	72-09-04	GE
CF6-80C2	X	X	1706M17G01	Bracket, Start Support Duct	72-09-04	GE
CF6-80C2	X		1706M23P001A	Bracket, Spray	72-09-04	GE
CF6-80C2	X		1706M31P001A	Bracket, Tube Oil Cooling	72-09-04	GE
CF6-80C2	X		1706M32G01	Tube, Air P14 Lower	72-09-03	GE
CF6-80C2	X		1706M34G01	Tube, Mast Manifold to Module Oil	72-09-03	GE
CF6-80C2	X	X	1706M55G01	Bracket, Support	72-09-04	GE
CF6-80C2	X		1706M83P001A	Bracket, Tube	72-09-04	GE
CF6-80C2	X		1706M86G01	Bracket, CA Tray	72-09-04	GE
CF6-80C2	X		1706M95G01	Tube, Hydraulic Drain Lower Oil	72-09-03	GE
CF6-80C2	X		1706M97G01	Tube, Drain	72-09-03	GE
CF6-80C2	X		1707M15G01	Manifold, Oil Lube Supply	72-09-03	GE
CF6-80C2	X	X	1707M15G03	Manifold, Oil Lube Supply	72-09-03	GE
CF6-80C2	X		1707M21G01	Bracket, HP Recoup	72-09-04	GE
CF6-80C2	X		1707M26P001A	Bracket, Electric Cable Fan	72-09-04	GE
CF6-80C2	X		1707M27P001A	Bracket, Electric Cable Fan	72-09-04	GE
CF6-80C2	X		1707M28P001A	Bracket, Electric	72-09-04	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2	X		1707M32P001A	Bracket, Oil Scavenge	72-09-04	GE
CF6-80C2	X		1707M44G01	Bracket, Tube Fuel	72-09-04	GE
CF6-80C2	X		1707M44G03	Bracket, Tube Fuel	72-09-04	GE
CF6-80C2	X	X	1707M54P02	Hose	72-09-03	GE
CF6-80C2	X		1707M56G01	Bracket	72-09-04	GE
CF6-80C2	X		1707M57G01	Bracket, Electric Lead	72-09-04	GE
CF6-80C2	X		1707M59G01	Bracket, HP Recoup	72-09-04	GE
CF6-80C2	X		1707M60P001A	Bracket	72-09-04	GE
CF6-80C2	X		1707M61P001A	Bracket	72-09-04	GE
CF6-80C2	X		1707M62G01	Tube, Mid D Scavenge	72-09-03	GE
CF6-80C2	X	X	1707M62G02	Tube, Mid D Scavenge	72-09-03	GE
CF6-80C2	X	X	1707M68G01	Tube, Oil D Sump	72-09-03	GE
CF6-80C2	X		1707M70P001A	Bracket	72-09-04	GE
CF6-80C2	X		1707M77G01	Bracket	72-09-04	GE
CF6-80C2	X		1707M78G01	Bracket, Tube	72-09-04	GE
CF6-80C2	X		1707M80G01	Tube, Mid D Scavenge	72-09-03	GE
CF6-80C2	X	X	1707M80G02	Tube, Mid D Scavenge	72-09-03	GE
CF6-80C2	X		1707M85G02	Manifold, Air LPT	72-09-03	GE
CF6-80C2	X		1707M85G04	Manifold, Air LPT	72-09-03	GE
CF6-80C2	X		1707M85G05	Manifold, Air LPT	72-09-03	GE
CF6-80C2	X		1707M91P001A	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1707M92P001A	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1707M94P001A	Bracket, Electric Cable	72-09-04	GE
CF6-80C2	X	X	1707M95G01	Bracket, Electrical	72-09-04	GE
CF6-80C2	X		1707M97G01	Bracket, Electrical	72-09-04	GE
CF6-80C2	X		1707M98G01	Bracket, Electric Lead Shield	72-09-04	GE
CF6-80C2	X		1707M99P001A	Bracket, Hyd Suction	72-09-04	GE
CF6-80C2	X		1754M14P001A	Bracket, Bolt Frame Link	72-09-04	GE
CF6-80C2	X		1754M14P005A	Bracket, Bolt Frame Link	72-09-04	GE
CF6-80C2	X	X	1754M16P001A	Bracket, Support	72-09-04	GE
CF6-80C2	X	X	1754M69G01	Tube, Oil Supply	72-09-03	GE
CF6-80C2	X	X	1754M71G01	Tube, Scavenge	72-09-03	GE
CF6-80C2	X	X	1754M75G01	Tube, Scavenge	72-09-03	GE
CF6-80C2	X		1761M83G02	Tube, Oil B Scavenge Forward	72-09-03	GE
CF6-80C2	X		1761M85G01	Tube, C Sump Scavenge Oil	72-09-03	GE
CF6-80C2	X		1773M72G03	Bracket, Tube D Sump	72-09-04	GE
CF6-80C2	X		1774M10P001A	Bracket, Tube Mid Pylon	72-09-04	GE
CF6-80C2	X		1774M11P001A	Bracket, Electrical	72-09-04	GE
CF6-80C2	X		1774M14G01	Tube, Oil D Lube	72-09-03	GE
CF6-80C2	X		1774M23G01	Tube, Oil	72-09-03	GE
CF6-80C2	X		1774M23G02	Tube, Oil	72-09-03	GE
CF6-80C2	X		1774M56G01	Bracket, Strap	72-09-04	GE
CF6-80C2	X		1774M58G01	Bracket, Angle	72-09-04	GE
CF6-80C2	X		1774M60G01	Tube, Oil D Scavenge Aft	72-09-03	GE
CF6-80C2	X	X	1774M60G02	Tube, Oil D Scavenge Aft	72-09-03	GE
CF6-80C2	X		1774M75G01	Tube, Air HPT Cooling	72-09-03	GE
CF6-80C2	X		1774M75G02	Tube, Air HPT Cooling	72-09-03	GE
CF6-80C2	X		1774M75G03	Tube, Air HPT Cooling	72-09-03	GE
CF6-80C2	X	X	1774M75G04	Tube, Air HPT Cooling	72-09-03	GE
CF6-80C2	X		1774M75G05	Tube, Air HPT Cooling	72-09-03	GE
CF6-80C2	X		1774M75G06	Tube, Air HPT Cooling	72-09-03	GE
CF6-80C2	X		1774M91G01	Tube, Under Cowl Cooling	72-09-03	GE
CF6-80C2	X		1774M91G02	Tube, Core Compt Cooling Air	72-09-03	GE
CF6-80C2	X		1774M91G03	Tube, Core Compt Cooling Air	72-09-03	GE
CF6-80C2	X		1774M99P001A	Bracket	72-09-04	GE
CF6-80C2	X		1775M10G01	Bracket, Spray	72-09-04	GE
CF6-80C2	X		1775M24P001A	Bracket, Support	72-09-04	GE
CF6-80C2	X		1775M37G01	Bracket, T5 CA	72-09-04	GE
CF6-80C2	X		1775M45P001A	Bracket, PMUX	72-09-04	GE
CF6-80C2	X		1775M46P001A	Bracket, PMUX	72-09-04	GE
CF6-80C2	X		1775M48P001A	Bracket, T2	72-09-04	GE
CF6-80C2	X	X	1775M91G01	Tube, Air	72-09-03	GE
CF6-80C2	X		1778M68P02	Retainer, HPTR Blade Stg 2	72-53-19	GE
CF6-80C2	X		1797M15G01	Tube, Oil Supply	72-09-03	GE
CF6-80C2	X	X	1797M15G02	Elbow	72-09-03	GE
CF6-80C2	X	X	1800M10G02	Tube, Air LPT Supply	72-09-03	GE
CF6-80C2	X	X	1800M12G01	Manifold, Oil Gearbox	72-09-03	GE
CF6-80C2	X		1800M12G01A	Manifold, Oil Gearbox	72-09-03	GE
CF6-80C2	X		1800M14G01	Manifold, Oil Gearbox	72-09-03	GE
CF6-80C2	X	X	1800M14G02	Manifold, Oil Gearbox	72-09-03	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2	X		1800M16G01	Tube, Oil Lube Pump Dish	72-09-03	GE
CF6-80C2	X		1800M18G01	Manifold, Oil Lube Pump	72-09-03	GE
CF6-80C2	x		1800M58P01	Coupling	72-09-04	GE
CF6-80C2	X		1800M76P03	Tube	72-09-03	GE
CF6-80C2	X		1800M76P04	Tube	72-09-03	GE
CF6-80C2	X		1800M88G01	Bracket	72-09-04	GE
CF6-80C2	X	X	1800M98G01	Bracket	72-09-04	GE
CF6-80C2	X	X	1801M30G02	Bracket, Friction Damper	72-09-04	GE
CF6-80C2	X		1801M33G01	Bracket, Drain	72-09-04	GE
CF6-80C2	X		1801M47G01	Manifold, Air HPT Cooling	72-09-03	GE
CF6-80C2	X		1801M53G03	Bracket, EGT Support	72-09-04	GE
CF6-80C2	X		1801M59G01	Bracket, Manifold Cooling	72-09-04	GE
CF6-80C2	X		1801M93G01	Tube, Air Cooling HPB	72-09-03	GE
CF6-80C2	X		1801M98G01	Valve, Check Stage 11	72-09-03	GE
CF6-80C2	X		1801M98G02	Valve, Check Stage 11	72-09-03	GE
CF6-80C2	X		1801M98G04	Valve, Check Stage 11	72-09-03	GE
CF6-80C2	X		1801M98G05	Valve, Check Stage 11	72-09-03	GE
CF6-80C2	X		1801M98G08	Valve, Check Stage 11	72-09-03	GE
CF6-80C2	X		1801M98G10	Valve, Check Stage 11	72-09-03	GE
CF6-80C2	X		1801M98G11	Valve, Check Stage 11	72-09-03	GE
CF6-80C2	X		1801M99G04	Valve, Check	72-09-03	GE
CF6-80C2	X		1801M99G08	Valve, Check	72-09-03	GE
CF6-80C2	X		1801M99G10	Valve, Check	72-09-03	GE
CF6-80C2	X		1801M99G11	Valve, Check	72-09-03	GE
CF6-80C2	X		1806M79G02	Yoke, Forward Engine Mount	71-21-01	GE
CF6-80C2	X		1810M23P001A	Bracket	72-09-04	GE
CF6-80C2	X		1810M31G01	Manifold, Air Core Compt	72-09-03	GE
CF6-80C2	X		1810M41G01	Tube, Fuel Drain	72-09-03	GE
CF6-80C2	X		1810M46P001A	Bracket, Mec Drive	72-09-04	GE
CF6-80C2	X		1810M75P001A	Bracket, Oil Press Support	72-09-04	GE
CF6-80C2	X		1810M94G01	Bracket, Angle	72-09-04	GE
CF6-80C2	X		1811M33G01	Bracket, Tube Combustor	72-09-04	GE
CF6-80C2	X		1811M33G03	Bracket, Tube Combustor	72-09-04	GE
CF6-80C2	X		1811M34G01	Tube, Press Sensing PS3	72-09-03	GE
CF6-80C2	X		1811M42P001A	Bracket	72-09-04	GE
CF6-80C2	X	X	1811M53G02	Manifold, Press Sensing	72-09-03	GE
CF6-80C2	X	X	1811M57G02	Manifold, Press Sensing	72-09-03	GE
CF6-80C2	X		1811M59G01	Bracket	72-09-04	GE
CF6-80C2	X		1811M60G01	Bracket, Lower IDG	72-09-04	GE
CF6-80C2	X		1811M73G01	Bracket, Electrical	72-09-04	GE
CF6-80C2	X	X	1811M75P02	Bolt	72-09-04	GE
CF6-80C2	X		1823M12G05	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M13G05	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M13G07	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M14G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M15G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M16G01	Bracket, Tube Oil	72-09-04	GE
CF6-80C2	X		1823M18G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M19G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M19G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M19G07	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M20G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M20G07	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M23G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M24G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M25G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M25G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X	X	1823M26G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M27G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M27G05	Bracket	72-09-04	GE
CF6-80C2	X		1823M29G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M29G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M29G05	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M29G09	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M29G11	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M30G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M31G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M37G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M39G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M39G05	Bracket, Electric	72-09-04	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2	X		1823M41G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M42G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M46G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M51G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M51G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M65G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M66G01	Bracket	72-09-04	GE
CF6-80C2	X		1823M67G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M72G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M72G05	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M78G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M79G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M81G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1823M92G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M10G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M14G01	Bracket, Tray	72-09-04	GE
CF6-80C2	X		1824M16G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M16G05	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M16G09	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M17G01	Bracket, CA Tray	72-09-04	GE
CF6-80C2	X		1824M17G03	Bracket, CA Tray	72-09-04	GE
CF6-80C2	X		1824M18G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M18G05	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M22G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M23G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M25G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M26G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M26G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M27G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M32G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M36G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M36G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M36G05	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M38G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M39G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M41G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M41G05	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M49G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M49G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X	X	1824M50G01	Manifold, Oil A Sump	72-09-03	GE
CF6-80C2	X		1824M53G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M53G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M54G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M57G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M58G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M61G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M62G05	Bracket	72-09-04	GE
CF6-80C2	X		1824M63G05	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M66G01	Tube, Oil Tank	72-09-03	GE
CF6-80C2	X		1824M66G02	Tube, Oil Tank	72-09-03	GE
CF6-80C2	X		1824M69G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M70G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M70G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M72G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M72G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M73G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M75G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M76G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M78G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M79G01	Bracket	72-09-04	GE
CF6-80C2	X		1824M79G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M79G05	Bracket	72-09-04	GE
CF6-80C2	X		1824M80G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M82G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M82G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M84G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M85G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M85G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M86G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M87G01	Bracket, Electric	72-09-04	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2	X		1824M88P001A	Bracket	72-09-04	GE
CF6-80C2	X		1824M94G01	Bracket, Tube Fuel	72-09-04	GE
CF6-80C2	X		1824M94G03	Bracket, Tube Fuel	72-09-04	GE
CF6-80C2	X		1824M94G05	Bracket, Tube Fuel	72-09-04	GE
CF6-80C2	X		1824M95G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X	X	1824M95G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M96G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1824M99G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1825M11G03	Bracket, Electrical	72-09-04	GE
CF6-80C2	X		1825M12G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1825M12G02	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1825M12G05	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1825M12G06	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1825M13G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1825M14G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1825M14G05	Bracket, Electric	72-09-04	GE
CF6-80C2	X	X	1825M16G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1825M20P001A	Bracket	72-09-04	GE
CF6-80C2	X		1825M21G01	Bracket, Electric IDG Duct	72-09-04	GE
CF6-80C2	X		1825M22G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1825M23G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1825M24G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1825M25G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1825M26G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X	X	1825M27G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1825M28G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1825M28G05	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1825M30G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1825M30G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1825M31P001A	Bracket, Electrical	72-09-04	GE
CF6-80C2	X		1825M32G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X	X	1825M34G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1825M36G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1825M37G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1825M37G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1825M50G01	Tube, Oil	72-09-03	GE
CF6-80C2	X	X	1825M63G01	Tube, Fuel Pump Drain Fuel	72-09-03	GE
CF6-80C2	X	X	1825M64G01	Tube, Oil IDG	72-09-03	GE
CF6-80C2	X	X	1825M65G01	Manifold, Mec Spline	72-09-03	GE
CF6-80C2	X		1825M73G01	Bracket, Accessory Shield	72-09-04	GE
CF6-80C2	X		1825M74G01	Bracket, Shield	72-09-04	GE
CF6-80C2	X		1825M75G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X	X	1825M83G01	Tube, Air Turbine Cooling	72-09-03	GE
CF6-80C2	X		1825M85G01	Tube, Air Turbine Cooling	72-09-03	GE
CF6-80C2	X		1825M90G01	Bracket, T49	72-09-04	GE
CF6-80C2	X	X	1825M98G01	Tube, Air LPT Cooling	72-09-03	GE
CF6-80C2	X		1825M99G01	Tube, Air LPT Cooling	72-09-03	GE
CF6-80C2	X		1826M21G01	Manifold, Air LPT	72-09-03	GE
CF6-80C2	X		1826M26G01	Bracket, Manifold Air	72-09-04	GE
CF6-80C2	X		1826M27G01	Bracket, Manifold Air	72-09-04	GE
CF6-80C2	X		1826M31P001A	Bracket, Tube Air LPT	72-09-04	GE
CF6-80C2	X		1826M38G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1826M39G01	Tube, Oil	72-09-03	GE
CF6-80C2	X		1826M42G01	Bracket, Thermocouple	72-09-04	GE
CF6-80C2	X		1826M52G01	Bracket, Harness T49	72-09-04	GE
CF6-80C2	X		1826M57G01	Bracket, T49	72-09-04	GE
CF6-80C2	X		1826M58G01	Bracket, T49	72-09-04	GE
CF6-80C2	X		1826M62G01	Bracket, Tube Oil Supply	72-09-04	GE
CF6-80C2	X		1826M63G01	Bracket, Tube Oil Scavenge	72-09-04	GE
CF6-80C2	X		1826M65G01	Bracket, T49	72-09-04	GE
CF6-80C2	X		1826M67G01	Bracket, T49	72-09-04	GE
CF6-80C2	X	X	1826M68G01	Tube, Oil D Scavenge Aft	72-09-03	GE
CF6-80C2	X		1826M83G01	Bracket Assy	72-09-04	GE
CF6-80C2	X		1826M84G01	Bracket, T49	72-09-04	GE
CF6-80C2	X		1826M85P01	Bracket, Harness T49	72-09-04	GE
CF6-80C2	X		1826M87G01	Bracket, T49	72-09-04	GE
CF6-80C2	X		1826M92G01	Tube, Air LPT Supply	72-09-03	GE
CF6-80C2	X		1826M93G01	Tube, Air LPT Cooling	72-09-03	GE
CF6-80C2	X		1832M21G01	Bracket, Tube D Sump	72-09-04	GE
CF6-80C2	X		1832M61G03	Bracket, Electrical Cable	72-09-04	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2	X		1832M72G01	Tube, Oil C Sump Scavenge	72-09-03	GE
CF6-80C2	X		1835M10G01	Tube, Fuel Drain	72-09-03	GE
CF6-80C2	X		1835M12P03	Vent, Tube and Hose	72-09-03	GE
CF6-80C2	X		1835M23G01	Tube, Fuel Manifold Drain	72-09-03	GE
CF6-80C2	X	X	1835M51G01	Tube, D Supply	72-09-03	GE
CF6-80C2	X	X	1835M71G02	Tube, Fuel LP Turb	72-09-03	GE
CF6-80C2	X		1835M73G02	Tube, Fuel LP Turb	72-09-03	GE
CF6-80C2	X		1835M95G03	Tube, Air Cooling	72-09-03	GE
CF6-80C2	X		1835M95G07	Tube, Air Cooling	72-09-03	GE
CF6-80C2	X	X	1835M96G01	Tube, RS HP Recoup Air	72-09-03	GE
CF6-80C2	X		1836M10G01	Bracket	72-09-04	GE
CF6-80C2	X		1836M11G01	Bracket	72-09-04	GE
CF6-80C2	X		1836M12G01	Bracket	72-09-04	GE
CF6-80C2	X	X	1836M33G01	Tube	72-09-03	GE
CF6-80C2	X	X	1836M35G01	Tube	72-09-03	GE
CF6-80C2	X		1836M37G01	Bracket, Fuel	72-09-04	GE
CF6-80C2	X		1836M41G01	Manifold	72-09-03	GE
CF6-80C2	X		1836M47G03	Tube, Oil	72-09-03	GE
CF6-80C2	X		1836M64G02	Duct, Air	72-09-03	GE
CF6-80C2	X		1836M64G03	Duct, Air	72-09-03	GE
CF6-80C2	X		1836M68G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1836M74G01	Tube, Air (P14)	72-09-03	GE
CF6-80C2	X	X	1836M80G01	Tube, Manifold Drain Fuel	72-09-03	GE
CF6-80C2	X		1836M84G01	Tube, Fuel Manifold Drain	72-09-03	GE
CF6-80C2	X	X	1836M84G02	Tube, Fuel Manifold Drain	72-09-03	GE
CF6-80C2	X		1836M84G03	Tube, Fuel Manifold Drain	72-09-03	GE
CF6-80C2	X	X	1836M91G01	Tube, Mast Manifold to Module Oil	72-09-03	GE
CF6-80C2	X		1836M98G03	Bracket, CA Support	72-09-04	GE
CF6-80C2	X		1836M98G05	Bracket, CA Support	72-09-04	GE
CF6-80C2	X		1846M23G01	Link	71-20-05	GE
CF6-80C2	X		1848M31P03	Tube And Hose, Oil D	72-09-03	GE
CF6-80C2	X		1848M97G05	Bracket, Transmitter	72-09-04	GE
CF6-80C2	X		1849M74G01	Bracket, B Scavenge Support	72-09-04	GE
CF6-80C2	X	X	1853M92G02	Nut Assy	72-57-07	GE
CF6-80C2	X		1854M36P01	Spacet, Stage 1	72-21-11	GE
CF6-80C2	X		1856M41G05	Link Assy, Stg 5	72-32-09	GE
CF6-80C2	X		1856M90G01	Shim	72-21-14	GE
CF6-80C2	X		1866M21P01	Tube, LP Recoup Forward Air	72-09-03	GE
CF6-80C2	X		1866M29P01	Tube, Bent (Spd)	72-09-03	GE
CF6-80C2	X		1872M16G01	Tube, Fuel Manifold Drain	72-09-03	GE
CF6-80C2	X	X	1872M16G02	Tube, Fuel Manifold Drain	72-09-03	GE
CF6-80C2	X	X	1872M21G01	Duct, Air	72-09-03	GE
CF6-80C2	X		1872M21G02	Duct, Air	72-09-03	GE
CF6-80C2	X		1872M21G03	Duct, Air	72-09-03	GE
CF6-80C2	X	X	1872M21G04	Duct, Air	72-09-03	GE
CF6-80C2	X		1872M21G06	Duct, Air Wye	72-09-03	GE
CF6-80C2	X		1872M21G08	Duct, Air	72-09-03	GE
CF6-80C2	X	X	1872M22G01	Duct, Air Wye	72-09-03	GE
CF6-80C2	X		1872M22G02	Duct, Air Wye	72-09-03	GE
CF6-80C2	X		1872M22G04	Duct, Air Wye	72-09-03	GE
CF6-80C2	X	X	1872M25P001A	Bracket, Cable Support	72-09-04	GE
CF6-80C2	X		1872M29G01	Bracket, EBU	72-09-04	GE
CF6-80C2	X		1872M2G01	Duct, Air Wye	72-09-03	GE
CF6-80C2	X		1872M31G01	Tube, Air LPT Cooling (LH)	72-09-03	GE
CF6-80C2	X		1872M41P001A	Bracket, Cable Support	72-09-04	GE
CF6-80C2	X		1872M43G01	Tube, Air P14	72-09-03	GE
CF6-80C2	X	X	1872M58G01	Tube, Fuel Drain	72-09-03	GE
CF6-80C2	X		1872M60P001A	Bracket, Support	72-09-04	GE
CF6-80C2	X	X	1872M79G01	Bracket, Support	72-09-04	GE
CF6-80C2	X	X	1872M81G01	Tube, Fuel	72-09-03	GE
CF6-80C2	X		1872M87G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1872M88G01	Bracket, Support	72-09-04	GE
CF6-80C2	X		1872M91G01	Wye, Air HPT Cooling	72-09-03	GE
CF6-80C2	X		1872M94P01	Hose Assy	72-09-03	GE
CF6-80C2	X		1883M17G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X	X	1883M25G03	Tube, Air Curt	72-09-03	GE
CF6-80C2	X		1883M60G01	Shield, Spray	72-09-04	GE
CF6-80C2	X		1883M97P001A	Bracket, Electrical	72-09-04	GE
CF6-80C2	X		1884M13G01	Bracket, CA Support	72-09-04	GE
CF6-80C2	X		1884M29G01	Tube, Fuel Drain VSV	72-09-03	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2	X		1884M31G01	Bracket, Support	72-09-04	GE
CF6-80C2	X		1884M32P001A	Bracket, Support	72-09-04	GE
CF6-80C2	X		1884M34G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1884M35G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1884M36G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1884M41G01	Bracket, Mount	72-09-04	GE
CF6-80C2	X		1884M42G01	Bracket, Mount	72-09-04	GE
CF6-80C2	X		1884M45P001A	Bracket, Mount	72-09-04	GE
CF6-80C2	X		1884M46P001A	Bracket, Mount	72-09-04	GE
CF6-80C2	X		1884M52G01	Tube, Oil	72-09-03	GE
CF6-80C2	X		1884M55G03	Tube, Air LPT Cooling (LH)	72-09-03	GE
CF6-80C2	X		1884M62P001A	Bracket, Support	72-09-04	GE
CF6-80C2	X		1884M64G01	Bracket	72-09-04	GE
CF6-80C2	X		1884M66G01	Tube, C Scavenge Mid Oil	72-09-03	GE
CF6-80C2	X		1884M67G01	Bracket	72-09-04	GE
CF6-80C2	X		1884M76P001A	Bracket, Stif	72-09-04	GE
CF6-80C2	X		1884M82G01	Bracket	72-09-04	GE
CF6-80C2	X		1884M91P03	Tube, Air	72-09-03	GE
CF6-80C2	X		1884M92G01	Tube, Fuel Manifold Drain	72-09-03	GE
CF6-80C2	X		1884M93G01	Tube, Oil Return	72-09-03	GE
CF6-80C2	X	X	1884M96G01	Tube, Air Compartment	72-09-03	GE
CF6-80C2	X		1885M10G01	Tube, Expandable Seal	72-09-03	GE
CF6-80C2	X		1885M11G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1885M12G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1885M14G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1885M15G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1885M16G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1885M17G01	Bracket, Support	72-09-04	GE
CF6-80C2	X		1885M17G03	Bracket, Support	72-09-04	GE
CF6-80C2	X		1885M19G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1885M20G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X	X	1885M21G01	Tube, Air	72-09-03	GE
CF6-80C2	X		1885M21G03	Tube, Air Supply HPT R/S	72-09-03	GE
CF6-80C2	X		1885M22G01	Tube, Air	72-09-03	GE
CF6-80C2	X		1885M22G02	Tube, Air	72-09-03	GE
CF6-80C2	X		1885M22G03	Tube, 11th Stage Air (RH)	72-09-03	GE
CF6-80C2	X		1885M23G01	Tube, Air	72-09-03	GE
CF6-80C2	X	X	1885M24G01	Tube, Air	72-09-03	GE
CF6-80C2	X		1885M25G01	Bracket, Manifold	72-09-04	GE
CF6-80C2	X		1885M27G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1885M31G01	Bracket, Support	72-09-04	GE
CF6-80C2	X		1885M32G01	Tube, D Scavenge Forward	72-09-03	GE
CF6-80C2	X	X	1885M32G02	Tube, D Scavenge Forward	72-09-03	GE
CF6-80C2	X		1885M32G03	Tube, D Scavenge Forward	72-09-03	GE
CF6-80C2	X		1885M33G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1885M34P001A	Bracket	72-09-04	GE
CF6-80C2	X	X	1885M43G01	Tube, Air	72-09-03	GE
CF6-80C2	X	X	1885M46G01	Tube, Fuel Drain	72-09-03	GE
CF6-80C2	X		1885M47G01	Bracket	72-09-04	GE
CF6-80C2	X		1885M50G01	Bracket, Electrical	72-09-04	GE
CF6-80C2	X		1885M51G01	Bracket, Tube Fuel	72-09-04	GE
CF6-80C2	X		1885M52P001A	Bracket, Support	72-09-04	GE
CF6-80C2	X		1885M55G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1885M56G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1885M57G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1885M60P001A	Bracket	72-09-04	GE
CF6-80C2	X		1885M63G02	Bracket, Friction Damper	72-09-04	GE
CF6-80C2	X		1885M68G01	Bracket, Stage 11 Support	72-09-04	GE
CF6-80C2	X		1885M72G01	Bracket, LPT Tube	72-09-04	GE
CF6-80C2	X		1885M73G01	Bracket, LPT Cooling Tube	72-09-04	GE
CF6-80C2	X	X	1885M80G01	Duct, Air Wye	72-09-03	GE
CF6-80C2	X		1885M81G01	Duct, Air Wye	72-09-03	GE
CF6-80C2	X		1885M83G01	Manifold, Oil Gearbox	72-09-03	GE
CF6-80C2	X		1885M83G02	Manifold, Oil Gearbox	72-09-03	GE
CF6-80C2	X	X	1885M84G01	Manifold, Fuel	72-09-03	GE
CF6-80C2	X	X	1885M86G01	Tube, Lower Heat Exchanger to Tank	72-09-03	GE
CF6-80C2	X	X	1885M87G01	Tube, Oil IDG Cooler Outlet	72-09-03	GE
CF6-80C2	X		1885M93G01	Bracket, Support	72-09-04	GE
CF6-80C2	X		1885M97G01	Bracket, Electrical	72-09-04	GE
CF6-80C2	X		1885M98G01	Bracket, Electric	72-09-04	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2	X		1967M28P01	Bracket Assy	72-09-04	GE
CF6-80C2	X		1967M29G01	Bracket Assy	72-09-04	GE
CF6-80C2	X		1967M31G01	Tube, Air B Sump Vent	72-09-03	GE
CF6-80C2	X	X	1967M35G01	Tube, Air B Sump Vent	72-09-03	GE
CF6-80C2	X	X	1967M37G01	Shroud, Fuel	72-09-03	GE
CF6-80C2	X		1967M68G01	Bracket, Electrical	72-09-04	GE
CF6-80C2	X		1967M80G01	Tube, Air B Sump Vent	72-09-03	GE
CF6-80C2	X	X	1967M90G01	Tube	72-09-03	GE
CF6-80C2	X		1977M15G01	Bracket, Manifold	72-09-04	GE
CF6-80C2	X		1977M16G01	Bracket, Tube Hose	72-09-04	GE
CF6-80C2	X		1977M17P001A	Bracket, Tube Hose	72-09-04	GE
CF6-80C2	X		1977M25P001A	Bracket	72-09-04	GE
CF6-80C2	X		1977M26P001A	Bracket	72-09-04	GE
CF6-80C2	X		1977M27P001A	Bracket, Support	72-09-04	GE
CF6-80C2	X		1977M46G01	Bracket, Electrical	72-09-04	GE
CF6-80C2	X		1977M59P01	Bracket, Support (SPD)	72-09-04	GE
CF6-80C2	X		1977M60P01	Bracket, Support (SPD)	72-09-04	GE
CF6-80C2	X		1977M61P01	Bracket, Support (SPD)	72-09-04	GE
CF6-80C2	X		1977M62P01	Bracket, Support (SPD)	72-09-04	GE
CF6-80C2	X		1977M79G01	Bracket	72-09-04	GE
CF6-80C2	X		1977M88G01	Bracket	72-09-04	GE
CF6-80C2	X		1977M89G01	Tube, Fuel	72-09-03	GE
CF6-80C2	X		1977M90G01	Bracket, Support	72-09-04	GE
CF6-80C2	X		1978M22G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1978M23G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1978M64G01	Manifold, Oil Lube Pump	72-09-03	GE
CF6-80C2	X	X	1978M65G01	Tube, Oil IDG Cooling	72-09-03	GE
CF6-80C2	X		1978M68G01	Bracket, Angle	72-09-04	GE
CF6-80C2	X		1978M79G01	Duct, Air Inlet HP Turb	72-09-03	GE
CF6-80C2	X	X	1978M81G01	Tube	72-09-03	GE
CF6-80C2	X		1978M82G01	Bracket, Support	72-09-04	GE
CF6-80C2	X		1978M83G01	Bracket, Support	72-09-04	GE
CF6-80C2	X		1978M84G01	Bracket, Support	72-09-04	GE
CF6-80C2	X		1978M92G01	Bracket, Clevis	72-09-04	GE
CF6-80C2	X		1978M93G01	Bracket, Support Link	72-09-04	GE
CF6-80C2	X		1978M94G01	Bracket	72-09-04	GE
CF6-80C2	X		1978M95P001A	Bracket	72-09-04	GE
CF6-80C2	X		1978M96G01	Bracket, Support	72-09-04	GE
CF6-80C2	X		1990M11G01	Bracket, Manifold	72-09-04	GE
CF6-80C2	X		1990M12G01	Bracket, Air Duct Start	72-09-04	GE
CF6-80C2	X		1990M54G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1990M55G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1990M57G01	Tube, Oil Heat Exchanger	72-09-03	GE
CF6-80C2	X		1990M61G01	Manifold, Oil Lube Supply	72-09-03	GE
CF6-80C2	X		1990M62G01	Tube, Oil IDG Ht	72-09-03	GE
CF6-80C2	X		1990M63G01	Tube, Oil IDG Air/Oil	72-09-03	GE
CF6-80C2	X		1990M64P01	Bracket, Support	72-09-04	GE
CF6-80C2	X		1990M85G01	Tube, Oil Gearbox Supply	72-09-03	GE
CF6-80C2	X		1990M92G01	Tube, Oil	72-09-03	GE
CF6-80C2	X	X	1990M93G01	Tube, Air PS3 Core Aft	72-09-03	GE
CF6-80C2	X		1991M26G01	Bracket	72-09-04	GE
CF6-80C2	X		1991M27P01	Bracket	72-09-04	GE
CF6-80C2	X	X	1991M34G01	Duct, Air	72-09-03	GE
CF6-80C2	X		1991M37G01	Bracket, Electric Support	72-09-04	GE
CF6-80C2	X		1991M38G01	Bracket, Support	72-09-04	GE
CF6-80C2	X		1991M69G01	Tube, RS HP Recoup Air	72-09-03	GE
CF6-80C2	X	X	1991M70G01	Tube, Air HP Recoup Upper	72-09-03	GE
CF6-80C2	X		1991M79G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1991M88G01	Tube, D Scavenge Forward	72-09-03	GE
CF6-80C2	X		1991M88G02	Tube, D Scavenge Forward	72-09-03	GE
CF6-80C2	X		1991M88G03	Tube, D Scavenge Forward	72-09-03	GE
CF6-80C2	X		1991M88G04	Tube, D Scavenge Forward	72-09-03	GE
CF6-80C2	X		1991M98G01	Bracket, Support	72-09-04	GE
CF6-80C2	X		1996M10G01	Tube, Upper Scupper Drn	72-09-03	GE
CF6-80C2	X		1996M11G01	Manifold, Fuel	72-09-03	GE
CF6-80C2	X	X	1996M12G01	Tube, Oil Drain Module	72-09-03	GE
CF6-80C2	X	X	1996M13G01	Tube, Starter Drain Oil	72-09-03	GE
CF6-80C2	X	X	1996M14G01	Tube, Fuel Pump Drain Fuel	72-09-03	GE
CF6-80C2	X	X	1996M16G01	Tube, Hydraulic Drain Upper Oil	72-09-03	GE
CF6-80C2	X		1996M17G01	Tube, Lower Scupper Drain	72-09-03	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2	X		1996M20G01	Tube, Fuel Drain	72-09-03	GE
CF6-80C2	X		1996M21G01	Manifold, Drain	72-09-03	GE
CF6-80C2	X	X	1996M22G01	Tube, Fuel Drain	72-09-03	GE
CF6-80C2	X		1996M25G01	Tube, Fuel Drain	72-09-03	GE
CF6-80C2	X		1996M27G01	Tube, Fuel Drain	72-09-03	GE
CF6-80C2	X	X	1996M37G01	Tube, Fuel Pump Drain Fuel	72-09-03	GE
CF6-80C2	X	X	1996M38G01	Tube, Oil IDG	72-09-03	GE
CF6-80C2	X		1996M39G01	Tube, Mast Manifold to Module Oil	72-09-03	GE
CF6-80C2	X		1997M10G01	Bracket, Support	72-09-04	GE
CF6-80C2	X		1997M14G01	Manifold, Fuel Inl	72-09-03	GE
CF6-80C2	X		1997M16G01	Bracket, Support	72-09-04	GE
CF6-80C2	X		1997M17G01	Tube, Fuel Drain	72-09-03	GE
CF6-80C2	X		1997M18G01	Tube, Oil IDG Cooling	72-09-03	GE
CF6-80C2	X		1997M22G01	Tube, Oil IDG Supply	72-09-03	GE
CF6-80C2	X		1997M23G01	Manifold, Fuel Inner	72-09-03	GE
CF6-80C2	X		1997M24G01	Manifold, Fuel Outer	72-09-03	GE
CF6-80C2	X		1997M30G01	Tube, Fuel Manifold	72-09-03	GE
CF6-80C2	X		1997M36P01	Hose, Fuel Jumper	72-09-03	GE
CF6-80C2	X		1997M36P02	Hose, Fuel Jumper	72-09-03	GE
CF6-80C2	X		1997M36P03	Hose, Fuel Jumper	72-09-03	GE
CF6-80C2	X		1997M41G01	Bracket, Support	72-09-04	GE
CF6-80C2	X		1997M59G01	Bracket, EBU	72-09-04	GE
CF6-80C2	X		1997M62G01	Tube, Oil	72-09-03	GE
CF6-80C2	X		1997M63G01	Tube, Oil R/S Upper Pwr	72-09-03	GE
CF6-80C2	X		1997M64G01	Tube, Oil	72-09-03	GE
CF6-80C2	X		1997M65G01	Tube, Drain Opening (LH)	72-09-03	GE
CF6-80C2	X		1997M66G01	Tube, Upper Power Drain (RH)	72-09-03	GE
CF6-80C2	X		1997M67G01	Tube, Oil IDG Cooling	72-09-03	GE
CF6-80C2	X		1997M70G01	Bracket	72-09-04	GE
CF6-80C2	X		1997M73G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1997M76G01	Bracket, Tube Integrated	72-09-04	GE
CF6-80C2	X		1997M87G01	Bracket, Support	72-09-04	GE
CF6-80C2	X	X	1997M88G01	Tube, Lube	72-09-03	GE
CF6-80C2	X		1997M88G02	Tube, Lube	72-09-03	GE
CF6-80C2	X		1997M92G01	Tube, Oil Heat Exchanger	72-09-03	GE
CF6-80C2	X		1998M18G01	Tube, Oil IDG Cooling	72-09-03	GE
CF6-80C2	X		1998M46G01	Tube And Hose, Fuel	72-09-03	GE
CF6-80C2	X		1998M68G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1998M69G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		1998M70G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X	X	1998M73G01	Tube, Air LPT Cooling (LH)	72-09-03	GE
CF6-80C2	X		1998M80G01	Tube And Hose, Fuel	72-09-03	GE
CF6-80C2	X		2020M14G01	Tube, To Flowmeter	72-09-03	GE
CF6-80C2	X		2020M15G02	Tube, Flowmeter To IDG	72-09-03	GE
CF6-80C2	X		2020M16G02	Tube, IDG Cooling Oil	72-09-03	GE
CF6-80C2	X		2020M17G01	Manifold	72-09-03	GE
CF6-80C2	X		2020M18P06	Tube, Hose	72-09-03	GE
CF6-80C2	X		2020M20G01	Tube, IDG Oil Cooling	72-09-03	GE
CF6-80C2	X		2020M23G02	Tube, Oil 2 IDG	72-09-03	GE
CF6-80C2	X		2020M24G01	Tube, Oil D Sump	72-09-03	GE
CF6-80C2	X		2020M25G01	Manifold, Oil Lube Supply	72-09-03	GE
CF6-80C2	X		2020M27P001A	Bracket, Electric	72-09-04	GE
CF6-80C2	X		2020M29G01	Bracket, Support	72-09-04	GE
CF6-80C2	X		2020M43G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		2020M46G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		2020M47G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		2020M48G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		2020M49G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		2020M66G01	Bracket, Oil Manifold	72-09-04	GE
CF6-80C2	X		2020M69G01	Tube, Pylon Drain Fuel	72-09-03	GE
CF6-80C2	X		2020M71G01	Manifold, Drain Mast	72-09-03	GE
CF6-80C2	X		2020M72G01	Bracket, Tube Support	72-09-04	GE
CF6-80C2	X		2020M80G01	Tube, Fuel Manifold	72-09-03	GE
CF6-80C2	X		2020M82G01	Tube, Fuel Manifold	72-09-03	GE
CF6-80C2	X		2020M88G01	Tube, Oil Gearbox Supply	72-09-03	GE
CF6-80C2	X		2020M89G01	Tube, Oil	72-09-03	GE
CF6-80C2	X		2020M92G01	Bracket, EBU	72-09-04	GE
CF6-80C2	X		2020M95G02	Manifold, Air Core Cowl	72-09-03	GE
CF6-80C2	X		2020M96G01	Tube, Under Cowl Cooling	72-09-03	GE
CF6-80C2	X		2021M12G01	Bracket, Electric	72-09-04	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2	X		2021M12G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		2021M13P001A	Bracket	72-09-04	GE
CF6-80C2	X		2021M18G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		2021M18P001A	Bracket, Electric	72-09-04	GE
CF6-80C2	X		2021M20P001A	Bracket, Air Curtain	72-09-04	GE
CF6-80C2	X		2021M24P06	Hose, Teflon	72-09-03	GE
CF6-80C2	X		2021M26P001A	Bracket, Plate	72-09-04	GE
CF6-80C2	X		2021M28P001A	Bracket, Support	72-09-04	GE
CF6-80C2	X		2021M31P001A	Bracket, Support	72-09-04	GE
CF6-80C2	X		2021M32P001A	Bracket, Support	72-09-04	GE
CF6-80C2	X		2021M33G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		2021M37P06	Tube & Hose	72-09-03	GE
CF6-80C2	X		2021M38P03	Tube & Hose	72-09-03	GE
CF6-80C2	X		2021M38P09	Tube & Hose	72-09-03	GE
CF6-80C2	X		2021M40G01	Bracket, EBU	72-09-04	GE
CF6-80C2	X		2021M42P001B	Bracket, Hydr Support	72-09-04	GE
CF6-80C2	X		2021M43G01	Bracket, Hydraulic Support	72-09-04	GE
CF6-80C2	X		2021M45G01	Bracket, EBU	72-09-04	GE
CF6-80C2	X		2021M45P001A	Bracket	72-09-04	GE
CF6-80C2	X		2021M50G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		2021M61G01	Tube, Oil, IDG 1&2	72-09-03	GE
CF6-80C2	X		2021M63G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		2021M63G05	Bracket, Electric	72-09-04	GE
CF6-80C2	X		2021M64P001A	Bracket, Tube Mid Pylon	72-09-04	GE
CF6-80C2	X		2021M68G03	Bracket, Electric	72-09-04	GE
CF6-80C2	X		2021M71G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		2021M82G01	Bracket, Stowage	72-09-04	GE
CF6-80C2	X		2021M83G01	Bracket	72-09-04	GE
CF6-80C2	X		2021M84G01	Tube, Oil	72-09-03	GE
CF6-80C2	X		2021M90G01	Bracket, Support	72-09-04	GE
CF6-80C2	X		2021M91G01	Manifold, Fuel	72-09-03	GE
CF6-80C2	X		2021M92G01	Tube, Fuel IDG 2	72-09-03	GE
CF6-80C2	X		2021M94G01	Bracket, Fuel Angle	72-09-04	GE
CF6-80C2	X		2021M97G01	Bracket, Support	72-09-04	GE
CF6-80C2	X		2021M99G01	Bracket, Support	72-09-04	GE
CF6-80C2	X		2022M10G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		2022M11G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		2022M13G01	Tube, Fuel HMU	72-09-03	GE
CF6-80C2	X		2022M16G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		2022M18P001A	Bracket, Hyd Suction	72-09-04	GE
CF6-80C2	X		2022M19G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		2022M24G01	Bracket, Ignition Lead	72-09-04	GE
CF6-80C2	X		2022M28G01	Bracket, Cooling Manifold	72-09-04	GE
CF6-80C2	X		2022M29P001A	Bracket, Support	72-09-04	GE
CF6-80C2	X		2022M31G01	Bracket	72-09-04	GE
CF6-80C2	X		2022M32G01	Tube, Oil	72-09-03	GE
CF6-80C2	X		2022M35G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		2022M36P001A	Bracket, Electric	72-09-04	GE
CF6-80C2	X		2022M37G01	Tube, Fuel Drain VSV	72-09-03	GE
CF6-80C2	X		2022M38G01	Bracket, Ignition	72-09-04	GE
CF6-80C2	X		2022M40G01	Tube, Air B Sump Vent	72-09-03	GE
CF6-80C2	X		2022M48G01	Tube, Air B Sump Vent	72-09-03	GE
CF6-80C2	X		2022M49G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		2022M50G01	Tube, Air PS3	72-09-03	GE
CF6-80C2	X		2022M51G01	Tube, Air PS3 Forward	72-09-03	GE
CF6-80C2	X		2022M52G01	Tube, Press Sensing PS3	72-09-03	GE
CF6-80C2	X		2022M56G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		2022M57G01	Tube, Forward Oil Lube	72-09-03	GE
CF6-80C2	X		2022M57G02	Tube, Oil Lube	72-09-03	GE
CF6-80C2	X		2022M58G01	Duct, Air Wye	72-09-03	GE
CF6-80C2	X		2022M62G01	Bracket, Stowage	72-09-04	GE
CF6-80C2	X		2022M63G01	Tube, Fuel Manifold Drain	72-09-03	GE
CF6-80C2	X		2022M64P001A	Bracket, Hyd Suction	72-09-04	GE
CF6-80C2	X		2022M65P06	Tube & Hose	72-09-03	GE
CF6-80C2	X		2022M66G01	Bracket, Support	72-09-04	GE
CF6-80C2	X		2022M67P001A	Bracket, Tube Pylon	72-09-04	GE
CF6-80C2	X		2022M69G01	Bracket	72-09-04	GE
CF6-80C2	X		2022M70P001A	Bracket, Support	72-09-04	GE
CF6-80C2	X		2022M72G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		2022M73G01	Bracket, Electric	72-09-04	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2	X		2022M74G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		2022M76G01	Tube, Fuel HMU	72-09-03	GE
CF6-80C2	X		2022M78G01	Bracket, Mount	72-09-04	GE
CF6-80C2	X		2022M79G01	Bracket, Support	72-09-04	GE
CF6-80C2	X		2022M80G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		2022M82G01	Bracket, Support	72-09-04	GE
CF6-80C2	X		2022M83G01	Bracket, Support	72-09-04	GE
CF6-80C2	X		2022M84G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		2022M88G01	Bracket, Air/Oil Cooler	72-09-04	GE
CF6-80C2	X		2022M90G01	Bracket, Air/Oil Cooler	72-09-04	GE
CF6-80C2	X		2022M91P01	Bracket, Base	72-09-04	GE
CF6-80C2	X		2022M92G01	Bracket, Oil Press Support	72-09-04	GE
CF6-80C2	X		2022M93G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		2022M95G01	Bracket, Support	72-09-04	GE
CF6-80C2	X		2022M98P03	Tube & Hose	72-09-03	GE
CF6-80C2	X		2023M10G01	Tube, Air LPT Cooling (LH)	72-09-03	GE
CF6-80C2	X		2023M19G01	Tube And Hose, Oil D	72-09-03	GE
CF6-80C2	X		2023M19G02	Tube And Hose, Oil D	72-09-03	GE
CF6-80C2	X		2023M19G03	Tube And Hose, Oil D	72-09-03	GE
CF6-80C2	X		2023M24G01	Bracket, Oil Pressure	72-09-04	GE
CF6-80C2	X		2023M26G01	Tube, Oil	72-09-03	GE
CF6-80C2	X		2032M26G01	Tube, Oil	72-09-03	GE
CF6-80C2	X		2088M30G01	Tube, Oil Heat Exchanger	72-09-03	GE
CF6-80C2	X		2088M31G01	Tube, Oil IDG Cooling	72-09-03	GE
CF6-80C2	X		2088M40G01	Tube, D Scavenge Forward	72-09-03	GE
CF6-80C2	X		2088M41G01	Tube, Oil IDG Cooling	72-09-03	GE
CF6-80C2	X		2088M81P01	Hose, Oil	72-09-03	GE
CF6-80C2	X		2088M81P03	Hose, Oil	72-09-03	GE
CF6-80C2	X		2088M90G01	Bracket	72-09-04	GE
CF6-80C2	X		2088M93G01	Tube, Fuel Manifold	72-09-03	GE
CF6-80C2	X		2089M88G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X	X	2092M36G01	Bracket	72-23-01 or 72-09-04	GE
CF6-80C2	X	X	2092M37G01	Bracket, Forward Inner Liner	72-23-01 or 72-09-04	GE
CF6-80C2	X		2093M96G01	Tube, Air HPR Assembly	72-09-03	GE
CF6-80C2	X		2096M45G01	Tube, Oil Lube Pump Dish	72-09-03	GE
CF6-80C2	X		2096M46G01	Bracket, Transmitter	72-09-04	GE
CF6-80C2	X	X	2155M10G01	Manifold, Oil Gearbox	72-09-03	GE
CF6-80C2	X		2155M12G01	Tube, Oil Lube Pump Dish	72-09-03	GE
CF6-80C2	X	X	2155M18G01	Manifold, Drain Mast	72-09-03	GE
CF6-80C2	X	X	2155M26G01	Tube, Air 11th Stage Upper	72-09-03	GE
CF6-80C2	X	X	2155M35G01	Tube, Air	72-09-03	GE
CF6-80C2	X		2155M38G01	Tube, Oil IDG Supply	72-09-03	GE
CF6-80C2	X		2155M43G01	Tube, C Scavenge Aft	72-09-03	GE
CF6-80C2	X		2155M46G01	Bracket, Oil Manifold	72-09-04	GE
CF6-80C2	X	X	2155M55G01	Tube, Air PS3 Core Mid	72-09-03	GE
CF6-80C2	X		2155M59G01	Tube, Air LPT Cooling (LH)	72-09-03	GE
CF6-80C2	X		2155M63G01	Tube, Oil IDG Supply	72-09-03	GE
CF6-80C2	X		2155M64G01	Bracket, Support	72-09-04	GE
CF6-80C2	X	X	2155M66G01	Tube, Air PS3 Forward	72-09-03	GE
CF6-80C2	X		2155M67G01	Tube, Oil IDG Air/Oil	72-09-03	GE
CF6-80C2	X		2155M68G01	Tube, Oil IDG Ht	72-09-03	GE
CF6-80C2	X		2155M69G01	Bracket, Support	72-09-04	GE
CF6-80C2	X		2155M73G01	Tube, Oil IDG Ht	72-09-03	GE
CF6-80C2	X		2155M74G01	Tube, Oil IDG Air/Oil	72-09-03	GE
CF6-80C2	X		2155M75G01	Bracket, Support	72-09-04	GE
CF6-80C2	X		2155M79G01	Tube, Oil IDG Air/Oil	72-09-03	GE
CF6-80C2	X		2155M80G01	Tube, Oil IDG Ht	72-09-03	GE
CF6-80C2	X		2155M81G01	Tube, Fuel Manifold	72-09-03	GE
CF6-80C2	X		2155M83G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		2155M84P01	Bracket, Support	72-09-04	GE
CF6-80C2	X		2155M85G01	Tube, Air	72-09-03	GE
CF6-80C2	X		2155M85G02	Tube, Air	72-09-03	GE
CF6-80C2	X		2155M87G01	Bracket, EBU	72-09-04	GE
CF6-80C2	X		2155M88G01	Bracket, Tube Hose	72-09-04	GE
CF6-80C2	X		2155M91G01	Bracket, Tube Oil Supply	72-09-04	GE
CF6-80C2	X	X	2156M27G01	Tube, Fuel Filter To	72-09-03	GE
CF6-80C2	X		2156M38G01	Tube, D Scavenge Forward	72-09-03	GE
CF6-80C2	X		2156M46G01	Bracket	72-09-04	GE
CF6-80C2	X		2156M67G01	Bracket, Fire Detector	72-09-04	GE
CF6-80C2	X		2156M83P01	Bracket, Support Tube	72-09-04	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2	X		2168M36G01	Bracket, Transmitter	72-09-04	GE
CF6-80C2	X		2168M57P01	Bracket, Support	72-09-04	GE
CF6-80C2	X		2168M58P01	Bracket, Support	72-09-04	GE
CF6-80C2	X		2168M87P01	Bracket	72-09-04	GE
CF6-80C2	X		2168M88G01	Tube, Air 11th Stage Upper	72-09-03	GE
CF6-80C2	X		2168M89G01	Tube, Air 11th Stage Lower	72-09-03	GE
CF6-80C2	X		2168M97P01	Bracket, Support PS3 Tube	72-09-04	GE
CF6-80C2	X		2169M46G01	Tube And Hose, Fuel	72-09-03	GE
CF6-80C2	X	X	2186M32G01	Tube, Fuel Drain	72-09-03	GE
CF6-80C2	X		2186M89G01	Tube, Press Sensing PS3	72-09-03	GE
CF6-80C2	X		2186M91G01	Manifold, Press Sensing	72-09-03	GE
CF6-80C2	X		2186M93G01	Bracket, Gearbox	72-09-04	GE
CF6-80C2	X		2192M10P01	Bracket, Support PS3 Tube	72-09-04	GE
CF6-80C2	X		2192M32G01	Bracket, Support	72-09-04	GE
CF6-80C2	X		2192M35G01	Bracket, Transmitter	72-09-04	GE
CF6-80C2	X		2192M65G01	Bracket, Support	72-09-04	GE
CF6-80C2	X		2193M87G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		2193M99G01	Tube, Expandable Seal	72-09-03	GE
CF6-80C2	X		224-2270-501	Bracket, Hold Open Rod	72-09-04	GE
CF6-80C2	X	X	224-2270-502	Bracket, Hold Open Rod	72-09-04	GE
CF6-80C2	X		224-2270-503	Bracket Assy, Hold Open	72-09-04	GE
CF6-80C2	X		224-2270-504	Bracket Assy, Hold Open	72-09-04	GE
CF6-80C2	X		224-2271-501	Bracket, Hold Open Rod	72-09-04	GE
CF6-80C2	X		224-2271-502	Bracket, Hold Open Rod	72-09-04	GE
CF6-80C2	X		224-2271-503	Bracket, Hold Open Rod	72-09-04	GE
CF6-80C2	X		224-2271-504	Bracket, Hold Open Rod	72-09-04	GE
CF6-80C2	X		224-2271-506	Bracket, Hold Open Rod	72-09-04	GE
CF6-80C2	X	X	224-2271-507	Bracket, Hold Open Rod	72-09-04	GE
CF6-80C2	X		224-2271-508	Bracket, Hold Open Rod	72-09-04	GE
CF6-80C2	X	X	224-2336-501	Bracket Assy, Engine Hold	72-09-04	GE
CF6-80C2	X		224-4308-533	Tube Assy, Fan Air Valve	72-09-03	GE
CF6-80C2	X		224-4417-501	Bracket	72-09-04	GE
CF6-80C2	X		224-9758-503	Bracket Assy	72-09-04	GE
CF6-80C2	X		224D4301-511	Duct	72-09-03	GE
CF6-80C2	X		2285M10G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		2285M11G01	Tube, Starter Drain Oil	72-09-03	GE
CF6-80C2	X	X	2285M14G01	Manifold, Fuel Drain	72-09-03	GE
CF6-80C2	X		2285M16G01	Bracket, T49	72-09-04	GE
CF6-80C2	X		2285M48G01	Bracket, Electric	72-09-04	GE
CF6-80C2	X		2285M64G01	Tube, Oil Supply	72-09-03	GE
CF6-80C2	X	X	2286M25G01	Tube, Oil Lube Pump	72-09-03	GE
CF6-80C2	X		2411M27P01	Bracket, Support	72-09-04	GE
CF6-80C2	X	X	2412-550	Clamp	72-09-04	GE
CF6-80C2	X	X	2413M60G01	Manifold, Oil Gearbox	72-09-03	GE
CF6-80C2	X	X	2420M28G01	Tube, Oil Lube Pump	72-09-03	GE
CF6-80C2	X	X	2420M30G01	Bracket, Oil Monitoring	72-09-04	GE
CF6-80C2	X		2420M70G01	Manifold	72-09-03	GE
CF6-80C2	X		2420M71G01	Manifold	72-09-03	GE
CF6-80C2	X		2436M60G01	Manifold, Fuel (RH)	72-09-03	GE
CF6-80C2	X		2436M61G01	Manifold	72-09-03	GE
CF6-80C2	X		2695M75G01	Tube	72-09-03	GE
CF6-80C2	X		3283094-8	Bracket Kit, Actuation Sys Lock	72-09-04	GE
CF6-80C2	X		3283094-9	Bracket Kit, Actuation Sys Lock	72-09-04	GE
CF6-80C2	X		332A280-5	Hose-Hydraulic Supply	71-00-04	Boeing
CF6-80C2	X		451R013-1	Tube, Siphon Drain Manifold	72-09-03	GE
CF6-80C2	X		451R013-2	Tube, Siphon Drain Manifold	72-09-03	GE
CF6-80C2	X		521R012	Bracket, Mounting Siphon Tube	72-09-04	GE
CF6-80C2	X	X	7084-225	Coupling	72-09-04	GE
CF6-80C2	X		7143M83P75	Tubing, Shrink	72-09-03	GE
CF6-80C2	X		7143M83P87	Tubing, Shrink	72-09-03	GE
CF6-80C2	X		7143M83P88	Tubing, Shrink	72-09-03	GE
CF6-80C2	X		7148M86P01	Tubing, Spiral	72-09-03	GE
CF6-80C2	X		7148M86P02	Tubing, Sprial	72-09-03	GE
CF6-80C2	X		7148M86P03	Tubing, Spiral	72-09-03	GE
CF6-80C2	X		7148M86P04	Tubing, Spiral	72-09-03	GE
CF6-80C2	X		7148M86P05	Tubing, Spiral	72-09-03	GE
CF6-80C2	X		7148M86P06	Tubing, Spiral	72-09-03	GE
CF6-80C2	X		7148M86P07	Tubing, Spiral	72-09-03	GE
CF6-80C2	X		7148M86P11	Tubing, Spiral	72-09-03	GE
CF6-80C2	X		7148M86P12	Tubing, Spiral	72-09-03	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2	X		7148M86P13	Tubing, Spiral	72-09-03	GE
CF6-80C2	X		7148M86P14	Tubing, Spiral	72-09-03	GE
CF6-80C2	X		7148M86P15	Tubing, Spiral	72-09-03	GE
CF6-80C2	X		7148M86P16	Tubing, Spiral	72-09-03	GE
CF6-80C2	X		7156M75P03	Tubing, Shrink	72-09-03	GE
CF6-80C2	X		7156M76P03	Tubing, Shrink	72-09-03	GE
CF6-80C2	X		7156M77P03	Tubing, Shrink	72-09-03	GE
CF6-80C2	X		7156M78P03	Tubing, Shrink	72-09-03	GE
CF6-80C2	X		7156M79P03	Tubing, Shrink	72-09-03	GE
CF6-80C2	X		7156M80P03	Tubing, Shrink	72-09-03	GE
CF6-80C2	X		7156M81P03	Tubing, Shrink	72-09-03	GE
CF6-80C2	X		7161M60P04	Tubing, Shrink	72-09-03	GE
CF6-80C2	X		7161M61P04	Tubing, Shrink	72-09-03	GE
CF6-80C2	X		7161M62P04	Tubing, Shrink	72-09-03	GE
CF6-80C2	X		7161M63P04	Tubing, Shrink	72-09-03	GE
CF6-80C2	X		7161M64P04	Tubing, Shrink	72-09-03	GE
CF6-80C2	X		7161M65P04	Tubing, Shrink	72-09-03	GE
CF6-80C2	X		7161M66P04	Tubing, Shrink	72-09-03	GE
CF6-80C2	X	X	8622-450	Coupling	72-09-04	GE
CF6-80C2	X		8896-200	Clamp, Coupling	72-09-04	GE
CF6-80C2	X		9010M96P01	Bracket, Hoist	72-09-04	GE
CF6-80C2	X		9010M96P02	Bracket, Hoist	72-09-04	GE
CF6-80C2	X		9016M13P03	Bracket, Shock Mounted	72-09-04	GE
CF6-80C2	X		9016M13P04	Bracket, Shock Mounted	72-09-04	GE
CF6-80C2	X	X	9047M29P03	Nut, Coupling Forward	72-24-04	GE
CF6-80C2	X		9106M66P04	Ring	72-57-10	GE
CF6-80C2	X		9125M65G17	Arm, Stage 5 Vane Actuation Assy	72-32-07	GE
CF6-80C2	X		9125M65G18	Arm, Stage 5 Vane Actuation Assy	72-32-07	GE
CF6-80C2	X		9137M30P01	Rod, Push Actuation Lever	72-32-10	GE
CF6-80C2	X	X	9137M95G05	Link Assy, Connecting Stage 5	72-32-09	GE
CF6-80C2	X	X	9187M73P164	Coupling	72-09-04	GE
CF6-80C2	X		9187M73P24	Coupling	72-09-04	GE
CF6-80C2	X	X	9205M87G03	Bolt, Shoulder Hex Hd	71-21-01	GE
CF6-80C2	X		9206M89G01	Manifold, Stage 8 Upper	72-09-03	GE
CF6-80C2	X		9206M97G02	Manifold, Stage 7	72-09-03	GE
CF6-80C2	X		9206M99G01	Manifold, Stage 8 Lower	72-09-03	GE
CF6-80C2	X	X	9218M20G01	Tube, Pressurization	72-09-03	GE
CF6-80C2	X		9220M87G01	Adapter, Scavenge Sump Compressor	72-09-03	GE
CF6-80C2	X		9220M87G02	Adapter, Scavenge Sump Compressor	72-09-03	GE
CF6-80C2	X		9220M87G03	Adapter, Scavenge Sump Compressor	72-09-03	GE
CF6-80C2	X	X	9222M97P01	Clamp-Coupling	72-09-04	GE
CF6-80C2	X	X	9232M38G02	Nozzle, Oil	72-09-02	GE
CF6-80C2	X		9234M75P05	Cover, Impeller	72-53-04	GE
CF6-80C2	X	X	9258M64G03	Tube, Air HPT Cooling	72-09-03	GE
CF6-80C2	X		9258M66G06	Tee, Air HPT Cooling	72-09-03	GE
CF6-80C2	X		9258M67G04	Elbow, Air HPT Cooling	72-09-03	GE
CF6-80C2	X		9258M67G05	Elbow, Air HPT Cooling	72-09-03	GE
CF6-80C2	X	X	9269M55P01	Elbow	72-09-03	GE
CF6-80C2	X		9295M10G01	Tube, Scavenge Sump Compressor	72-09-03	GE
CF6-80C2	X		9295M10G02	Tube, Scavenge Sump Compressor	72-09-03	GE
CF6-80C2	X		9299M15P04	Tube, Cooling Air HPT	72-09-03	GE
CF6-80C2	X	X	9299M76P05	Ring	72-31-18	GE
CF6-80C2	X		9304M93G03	Elbow, HPT Air	72-09-03	GE
CF6-80C2	X	X	9304M93G04	Elbow, HPT Air	72-09-03	GE
CF6-80C2	X	X	9312M70G05	Adapter, Gearbox	72-65-02	GE
CF6-80C2	X		9318M28P16	Tube, Stage 1 Air Nozzle	72-09-03	GE
CF6-80C2	X		9320M19P04	Ring, Piston	72-34-20	GE
CF6-80C2	X		9320M37G01	Manifold, Stage 7	72-09-03	GE
CF6-80C2	X		9320M38G01	Manifold, Upper Stage 10	72-09-03	GE
CF6-80C2	X		9320M38G03	Manifold, Stage 10 Upper	72-09-03	GE
CF6-80C2	X		9320M39G01	Manifold, Lower Stage 10	72-09-03	GE
CF6-80C2	X		9320M39G02	Manifold, Stage 10 Lower	72-09-03	GE
CF6-80C2	X		9326M60P01	Spacer, Stg 1	72-21-11	GE
CF6-80C2	X		9331M83G02	Cover, Pump Hydraulic	72-65-02	GE
CF6-80C2	X		9331M83G03	Cover	72-65-01	GE
CF6-80C2	X		9333M77P01	Bracket	72-09-04	GE
CF6-80C2	X		9333M77P02	Bracket	72-09-04	GE
CF6-80C2	X		9333M78P01	Bracket, Support	72-09-04	GE
CF6-80C2	X		9333M78P02	Bracket, Support	72-09-04	GE
CF6-80C2	X		9333M91P04	Hose	72-09-03	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2	X		9333M94P001A	Cover, Heat Shield	72-00-05	GE
CF6-80C2	X		9333M94P001B	Cover, Heat Shield	72-00-05	GE
CF6-80C2	X	X	9333M96G07	Bracket	72-09-04	GE
CF6-80C2	X		9333M98G01	Bracket	72-09-04	GE
CF6-80C2	X		9348M84G03	Link	71-20-05	GE
CF6-80C2	X		9348M84P02	Link	71-20-05	GE
CF6-80C2	X		9358M66P37	Strap	72-09-04	GE
CF6-80C2	X		9359M13P01	Cover, Bleed Off	72-09-04	GE
CF6-80C2	X		9360M61G01	Bracket, Accelerometer	72-09-04	GE
CF6-80C2	X	X	9370M46P01	Shield	72-09-04	GE
CF6-80C2	X		9374M53P01	Ring, Integral Seal Bearing No 6	72-57-14	GE
CF6-80C2	X	X	9374M59P01	Ring-Retaining Brg No 6R	72-58-14	GE
CF6-80C2	X		9374M60G03	Nut Assy, Bearing 6	72-57-07	GE
CF6-80C2	X		9374M75G01	Retainer, Stage 2 Shroud	72-52-05	GE
CF6-80C2	X		9374M75G03	Retainer, Stage 2 Shroud	72-52-05	GE
CF6-80C2	X		9374M75G04	Retainer, Stage 2 Shroud	72-52-05	GE
CF6-80C2	X		9377M36G05	Manifold, Fuel Drain	72-09-03	GE
CF6-80C2	X		9377M36G06	Manifold, Fuel Drain	72-09-03	GE
CF6-80C2	X	X	9377M36G07	Manifold, Fuel Drain	72-09-03	GE
CF6-80C2	X		9377M46G02	Tube, Oil Scavenge	72-09-03	GE
CF6-80C2	X		9377M46G03	Tube, Oil Scavenge	72-09-03	GE
CF6-80C2	X		9378M30G03	Manifold, Drain	72-09-03	GE
CF6-80C2	X		9378M30G04	Manifold, Drain	72-09-03	GE
CF6-80C2	X		9378M67P01	Vent, Tube and Hose	72-09-03	GE
CF6-80C2	X		9378M67P02	Vent, Tube and Hose	72-09-03	GE
CF6-80C2	X		9378M67P03	Vent, Tube and Hose	72-09-03	GE
CF6-80C2	X		9378M67P04	Vent, Tube and Hose	72-09-03	GE
CF6-80C2	X	X	9378M73G01	Tube, Transition	72-09-03	GE
CF6-80C2	X		9378M73G02	Tube, Transition	72-09-03	GE
CF6-80C2	X	X	9378M73G03	Tube, Transition	72-09-03	GE
CF6-80C2	X		9378M80G01	Tube, Air HP Recoup	72-09-03	GE
CF6-80C2	X		9378M80G03	Tube, Air HP Recoup	72-09-03	GE
CF6-80C2	X		9378M80G04	Tube, Air HP Recoup	72-09-03	GE
CF6-80C2	X		9378M82G01	Tube, Air HP Recoup	72-09-03	GE
CF6-80C2	X		9378M83G01	Tube, Air HP Recoup	72-09-03	GE
CF6-80C2	X		9378M83G02	Tube, Air HP Recoup	72-09-03	GE
CF6-80C2	X		9378M83G03	Tube, Air HP Recoup Upper	72-09-03	GE
CF6-80C2	X		9378M83G04	Tube, Air HP Recoup Upper	72-09-03	GE
CF6-80C2	X		9378M85G01	Tube, Air HP Recoup Lower	72-09-03	GE
CF6-80C2	X	X	9378M85G02	Tube, Air HP Recoup Lower	72-09-03	GE
CF6-80C2	X		9378M85G03	Tube, Air HP Recoup Lower	72-09-03	GE
CF6-80C2	X		9380M67G02	Nut, Retainer	71-20-05	GE
CF6-80C2	X		9381M37P001A	Bracket	72-09-04	GE
CF6-80C2	X		9381M38P001A	Bracket	72-09-04	GE
CF6-80C2	X		9381M41G03	Bracket Assy, LCH Thrust Reverser	72-09-04	GE
CF6-80C2	X		9381M41G06	Bracket Assy, LCH Thrust Reverser	72-09-04	GE
CF6-80C2	X		9381M74G01	Tube, Scavenge	72-09-03	GE
CF6-80C2	X		9381M76G01	Tube, Oil	72-09-03	GE
CF6-80C2	X	X	9381M78G01	Tube, Scavenge	72-09-03	GE
CF6-80C2	X		9382M10G02	Manifold, Oil	72-09-03	GE
CF6-80C2	X		9382M10G03	Manifold, Oil	72-09-03	GE
CF6-80C2	X		9382M12G01	Manifold, Lube	72-09-03	GE
CF6-80C2	X	X	9382M14G01	Manifold, Lube Forward	72-09-03	GE
CF6-80C2	X		9382M16G01	Bracket	72-09-04	GE
CF6-80C2	X		9382M17G01	Tube, Scavenge	72-09-03	GE
CF6-80C2	X		9382M21P01	Duct, Vent Insulated	72-09-03	GE
CF6-80C2	X		9382M21P02	Duct, Vent Insulated	72-34-01	GE
CF6-80C2	X		9382M21P03	Duct, Vent Insulated	72-09-03	GE
CF6-80C2	X		9382M22G01	Duct, Vent Insulated	72-09-03	GE
CF6-80C2	X		9382M24G01	Tube, Oil Supply	72-09-03	GE
CF6-80C2	X		9382M25G01	Tube, Scavenge	72-09-03	GE
CF6-80C2	X	X	9382M40G01	Manifold, Oil Supply	72-09-03	GE
CF6-80C2	X		9382M92G02	Hinge	72-23-20	GE
CF6-80C2	X		9383M35P02	Bracket	72-09-04	GE
CF6-80C2	X	X	9383M47P03	Link	71-21-01	GE
CF6-80C2	X		9383M47P05	Link, Yoke	71-21-01	GE
CF6-80C2	X	X	9383M47P08	Link	71-21-01	GE
CF6-80C2	X		9383M47P09	Link	72-00-01	GE
CF6-80C2	X		9383M59P003A	Bracket, Nut	72-09-04	GE
CF6-80C2	X		9383M62P001A	Bracket, Nut	72-09-04	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2	X		9383M63P001A	Bracket, Nut	72-09-04	GE
CF6-80C2	X	X	9383M87G01	Manifold, Oil No. 5 Bearing	72-09-03	GE
CF6-80C2	X	X	9392M10G01	Bellcrank	72-23-18	GE
CF6-80C2	X		9392M11G01	Tube, Oil In	72-09-03	GE
CF6-80C2	X		9392M11G02	Tube, Oil In	72-34-01	GE
CF6-80C2	X		9392M16G01	Tube, Oil Supply	72-09-03	GE
CF6-80C2	X		9392M26G01	Tube, Expandable Seal Air	72-09-03	GE
CF6-80C2	X		9392M38G01	Tube, Oil Supply	72-09-03	GE
CF6-80C2	X	X	9392M57P02	Nozzle, Oil	72-09-02	GE
CF6-80C2	X	X	9392M64P03	Nozzle, Oil	72-09-02	GE
CF6-80C2	X		9392M80P01	Bracket, Plate Ident	72-09-04	GE
CF6-80C2	X		9395M60P01	Bracket	72-09-04	GE
CF6-80C2	X		9397M18P01	Adapter, Inlet Gearbox	72-61-03	GE
CF6-80C2	X		9397M52P01	Tube, Igniter Plug	72-09-03	GE
CF6-80C2	X		9397M76G01	Tube, Oil	72-09-03	GE
CF6-80C2	X		9397M76G02	Tube, Oil	72-09-03	GE
CF6-80C2	X	X	9397M86G01	Bracket, Forward Inner Liner	72-09-04	GE
CF6-80C2	X	X	9397M87G01	Bracket, Forward Inner Liner	72-23-01	GE
CF6-80C2	X		9397M94G02	Lug- Locking Stg 4	72-21-14	GE
CF6-80C2	X	X	AE1010744M0174	Hose	72-09-03	GE
CF6-80C2	X		AE706823-2	Hose Assy, Upper Pump Suction	72-09-03	GE
CF6-80C2	X		J1328P08A	Tube, Coupling	72-09-03	GE
CF6-80C2	X		J178E0156A	Hose, Teflon	72-09-03	GE
CF6-80C2	X		J178E0156G	Hose, Teflon	72-09-03	GE
CF6-80C2	X		J178E0156J	Hose, Teflon	72-09-03	GE
CF6-80C2	X		J178E0156L	Hose Assy	72-09-03	GE
CF6-80C2	X		J178E0156R	Hose, Teflon	72-09-03	GE
CF6-80C2	X		J178F0125A	Hose Assy	72-09-03	GE
CF6-80C2	X		J178F0125B	Hose Assy	72-09-03	GE
CF6-80C2	X		J178F0125C	Hose Assy	72-09-03	GE
CF6-80C2	X		J178F0125G	Hose Assy	72-09-03	GE
CF6-80C2	X		J178H0171A	Hose Assy	72-09-03	GE
CF6-80C2	X		J178H0171B	Hose Assy	72-09-03	GE
CF6-80C2	X		J178H0171C	Hose Assy	72-09-03	GE
CF6-80C2	X		J178H0171G	Hose Assy	72-09-03	GE
CF6-80C2	X		J179E0084A	Hose, Teflon	72-09-03	GE
CF6-80C2	X		J179E0110A	Hose, Teflon	72-09-03	GE
CF6-80C2	X		J179E0145A	Hose, Teflon	72-09-03	GE
CF6-80C2	X		J179E0145D	Hose, Teflon	72-09-03	GE
CF6-80C2	X		J179H0100A	Hose, Teflon	72-09-03	GE
CF6-80C2	X		J179H0100B	Hose, Teflon	72-09-03	GE
CF6-80C2	X		J179H0100C	Hose, Teflon	72-09-03	GE
CF6-80C2	X		J179H0100G	Hose, Teflon	72-09-03	GE
CF6-80C2	X		J179H0100J	Hose, Teflon	72-09-03	GE
CF6-80C2	X		J179H0100L	Hose, Teflon	72-09-03	GE
CF6-80C2	X		J179H0100R	Hose, Teflon	72-09-03	GE
CF6-80C2	X		J180H0086C170	Hose Assy	72-09-03	GE
CF6-80C2	X		J180H0086G170	Hose Assy	72-09-03	GE
CF6-80C2	X		J180H0171C090	Hose Assy	72-09-03	GE
CF6-80C2	X		J180H0171G090	Hose Assy	72-09-03	GE
CF6-80C2	X		J180H0190C90	Hose Assy	72-09-03	GE
CF6-80C2	X		J180H0190G90	Hose Assy	72-09-03	GE
CF6-80C2	X		J181D0147A231	Hose, Teflon	72-09-03	GE
CF6-80C2	X		J181E0147A231	Hose, Teflon	72-09-03	GE
CF6-80C2	X		J186L0584A180	Hose, Teflon	72-09-03	GE
CF6-80C2	X		J186L0584B180	Hose, Teflon	72-09-03	GE
CF6-80C2	X		J186L0584C180	Hose, Teflon	72-09-03	GE
CF6-80C2	X		J186L0584E180	Hose, Teflon	72-09-03	GE
CF6-80C2	X	X	J186L0584G180	Hose, Teflon	72-09-03	GE
CF6-80C2	X		J191H0084A	Hose, Teflon	72-09-03	GE
CF6-80C2	X		J191H0084B	Hose, Teflon	72-09-03	GE
CF6-80C2	X		J191H0084C	Hose, Teflon	72-09-03	GE
CF6-80C2	X		J191H0084G	Hose, Teflon	72-09-03	GE
CF6-80C2	X		J191H0084P	Hose, Teflon	72-09-03	GE
CF6-80C2	X		J191H0084S	Hose, Teflon	72-09-03	GE
CF6-80C2	X		J191H0084T	Hose, Teflon	72-09-03	GE
CF6-80C2	X	X	J264B0100FD	Hose Assy	72-09-03	GE
CF6-80C2	X		MS8000G094CA	Hose Assy	72-09-03	GE
CF6-80C2	X		MS8000G110CA	Hose	72-09-03	GE
CF6-80C2	X		MS8000G145CA	Hose, Teflon	72-09-03	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2	X		MS8000G147EA231	Hose, Teflon	72-09-03	GE
CF6-80C2	X		MS8002K084CA	Hose, Teflon	72-09-03	GE
CF6-80C2	X		MS9552-010	Bracket, Flat	72-09-04	GE
CF6-80C2	X		MS9552-014	Bracket, Flat	72-09-04	GE
CF6-80C2	X		MS9552-206	Bracket, Flat	72-09-04	GE
CF6-80C2	X		MS9556-06	Bracket, Electric	72-09-04	GE
CF6-80C2	X		MS9592-027	Bracket, Angle	72-09-04	GE
CF6-80C2	X		MS9592-062	Bracket	72-09-04	GE
CF6-80C2	X		MS9592-172	Bracket, Angle	72-09-04	GE
CF6-80C2	X		MS9593-006	Bracket, Angle	72-09-04	GE
CF6-80C2	X		MS9593-010	Bracket, Angle	72-09-04	GE
CF6-80C2	X		R289P06	Tube, Elbow	72-09-03	GE
CF6-80C2	X		S41612-0100L	Hose, Teflon	72-09-03	GE
CF6-80C2, 80A	X	X	2320-550	Coupling	72-09-04	GE
CF6-80C2, 80A	X	X	2320-750	Coupling	72-09-04	GE
CF6-80C2, 80A	X	X	9187M73P156	Coupling	72-09-04	GE
CF6-80C2, 80A	X	X	9196M44G04	Manifold Assembly	72-21-14	GE
CF6-80C2, 80A	X	X	9362M80P01	Nozzle, Oil	72-09-02	GE
CF6-80C2, 80A, 80E	X	X	1288M42P04	Shield	72-34-20 & 72-34-08	GE
CF6-80C2, 80A, 80E	X	X	1333M65G01	Ring, Seg Actuation	72-32-06	GE
CF6-80C2, 80A, 80E	X	X	1333M65G02	Ring, Actuation Assy Stage 1	72-32-06	GE
CF6-80C2, 80A, 80E	X	X	1333M65G03	Ring Segment, Vane Actuation	72-32-06	GE
CF6-80C2, 80A, 80E	X	X	9196M44G03	Manifold Assy, Bearing No. 1	72-21-14	GE
CF6-80C2, 80A, 80E	X	X	9285M39P11	Hose	72-09-03	GE
CF6-80C2, 80A, 80E, 50, 6	X	X	9295M30G05	Segment, Actuation Ring Stage 3	72-32-06	GE
CF6-80C2, 80E	X	X	1288M68P03	Shield, Heat	72-58-14	GE
CF6-80C2, 80E	X	X	1288M68P05	Shield, Heat	72-58-14	GE
CF6-80C2, 80E	X	X	1290M21G01	Duct, Air LP Recoup Aft	72-09-03	GE
CF6-80C2, 80E	X	X	1290M22G04	Tube, LP Recoup Forward Air	72-09-03	GE
CF6-80C2, 80E	X	X	1290M23G06	Tube, LP Recoup Forward Air	72-09-03	GE
CF6-80C2, 80E	X	X	1303M35P01	Coupling, Flanged	72-09-03	GE
CF6-80C2, 80E	X	X	1303M35P02	Coupling	72-09-03	GE
CF6-80C2, 80E	X	X	1304M17P01	Flanged Bushing	72-32-11	GE
CF6-80C2, 80E	X	X	1304M28P05	Retainer	72-56-09	GE
CF6-80C2, 80E	X	X	1304M31P05	Bracket	72-09-04	GE
CF6-80C2, 80E	X	X	1304M52G03	Plug	72-52-13	GE
CF6-80C2, 80E	X	X	1304M80P01	Ring, Damper	72-63-12	GE
CF6-80C2, 80E	X	X	1308M32G01	Link, Support	72-09-04	GE
CF6-80C2, 80E	X	X	1308M32G02	Link, Support	72-09-04	GE
CF6-80C2, 80E	X	X	1308M32G08	Link, Support	72-09-04	GE
CF6-80C2, 80E	X	X	1308M32G12	Link, Support	72-09-04	GE
CF6-80C2, 80E	X	X	1308M32G24	Link, Support	72-09-04	GE
CF6-80C2, 80E	X	X	1313M25G03	Bracket	72-09-04	GE
CF6-80C2, 80E	X	X	1315M98G05	Bracket, Clevis	72-09-04	GE
CF6-80C2, 80E	X	X	1321M15G01	Tube	72-51-06	CFM
CF6-80C2, 80E	X	X	1321M73G02	Tube, Cooling	72-09-03	GE
CF6-80C2, 80E	X	X	1322M34P01	Nut	72-34-06	GE
CF6-80C2, 80E	X	X	1322M35G01	Nozzle, Oil	72-09-02	GE
CF6-80C2, 80E	X		1326M37G01	Seal	72-09-04	GE
CF6-80C2, 80E	X	X	1327M74P01	Seal, Bearing No. 5 RLR Spacer	72-53-13	GE
CF6-80C2, 80E	X	X	1327M82G01	Bracket	72-09-04	GE
CF6-80C2, 80E	X	X	1332M50P01	Tube	72-09-03	GE
CF6-80C2, 80E	X	X	1332M50P10	Tube	72-09-03	GE
CF6-80C2, 80E	X	X	1335M92G01	Tube, A Sump Oil	72-09-03	GE
CF6-80C2, 80E	X	X	1335M94G01	Tube, TGB Oil Supply	72-09-03	GE
CF6-80C2, 80E	X		1347M94P07	Ring, Integral Seal Bearing No. 6	72-57-14	GE
CF6-80C2, 80E	X	X	1370M56P01	Shield, Heat	72-34-20	GE
CF6-80C2, 80E	X	X	1380M85G01	Sensor	72-21-07	GE
CF6-80C2, 80E	X		1383M54G01	Tube, Mec Servo Drain Fuel	72-09-03	GE
CF6-80C2, 80E	X	X	1446M24G05	Tube, Air Supply HP	72-09-03	GE
CF6-80C2, 80E	X	X	1453M86G02	Tee, Air HP	72-09-03	GE
CF6-80C2, 80E	X	X	1453M87G02	Elbow, HP Recoup	72-09-03	GE
CF6-80C2, 80E	X	X	1456M71G02	Tube, Air Bore	72-09-03	GE
CF6-80C2, 80E	X	X	1469M28G03	Tube, LP Recoup	72-09-03	GE
CF6-80C2, 80E	X		1469M74G02	Tube, Air Bore	72-09-03	GE
CF6-80C2, 80E	X		1469M86G01	Tube, Air Bore	72-09-03	GE
CF6-80C2, 80E	X	X	1474M24G01	Bracket	72-56-09	GE
CF6-80C2, 80E	X	X	1479M59G01	Bracket	72-56-09	GE
CF6-80C2, 80E	X	X	1491M20G01	Tube, Accessory Gearbox Oil Scavenge	72-09-03	GE
CF6-80C2, 80E	X	X	1491M20G07	Tube, Accessory Gearbox Oil Scavenge	72-09-03	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2, 80E	X		1492M14P001A	Bracket, Support	72-09-04	GE
CF6-80C2, 80E	X		1492M17G01	Bracket, Support	72-09-04	GE
CF6-80C2, 80E	X	X	1578M30G12	Link, Support	72-09-04	GE
CF6-80C2, 80E	X	X	1578M30G36	Link	72-09-04	GE
CF6-80C2, 80E	X		1606M32P02	Bracket, Link	72-09-04	GE
CF6-80C2, 80E	X	X	1642M70G01	Bracket, Tube Air	72-09-04	GE
CF6-80C2, 80E	X	X	1642M98G01	Valve, Check Stage 11	72-09-03	GE
CF6-80C2, 80E	X	X	1706M41G02	Bracket	72-56-09	GE
CF6-80C2, 80E	X	X	1706M68G01	Bracket, Support	72-09-04	GE
CF6-80C2, 80E	X	X	1754M73G01	Tube, Oil	72-09-03	GE
CF6-80C2, 80E	X	X	1774M79P01	Bracket	72-56-06 - 80C2 72-56-09 - 80E	GE
CF6-80C2, 80E	X	X	1797M87G01	Tube, Oil Supply	72-09-03	GE
CF6-80C2, 80E	X	X	1797M87G02	Tube, Oil Supply	72-09-03	GE
CF6-80C2, 80E	X	X	1800M87G01	Shroud, Fuel Line	72-09-03	GE
CF6-80C2, 80E	X	X	1814M25P01	Shield, Bolt HPT	72-51-08	GE
CF6-80C2, 80E	X	X	1825M84G01	Manifold, Air Turbine	72-09-03	GE
CF6-80C2, 80E	X	X	1826M46G01	Tube, Air HPT Cooling	72-09-03	GE
CF6-80C2, 80E	X	X	1856M41G02	Link Assy, Stage 5	72-32-09	GE
CF6-80C2, 80E	X		1865M25P01	Ring, Retaining	72-53-14	GE
CF6-80C2, 80E	X	X	1967M33G01	Duct, Air LP Recoup Aft	72-09-03	GE
CF6-80C2, 80E	X		1967M74G01	Plate	72-09-04	GE
CF6-80C2, 80E	X	X	1977M71G01	Tube, LP Recoup	72-09-03	GE
CF6-80C2, 80E	X	X	1990M17G01	Bracket, Fuel	72-09-04	GE
CF6-80C2, 80E	X	X	1990M30G01	Tube, Oil 4 & 5 Bearing	72-09-03	GE
CF6-80C2, 80E	X	X	1991M71G01	Tube, Air Supply HP	72-09-03	GE
CF6-80C2, 80E	X	X	1991M72G01	Tube, Air HP Recoup Lower	72-09-03	GE
CF6-80C2, 80E	X	X	2032M95G08	Lug	72-31-18	GE
CF6-80C2, 80E	X	X	2032M95G10	Lug	72-31-18	GE
CF6-80C2, 80E	X	X	2032M95G11	Lug	72-31-18	GE
CF6-80C2, 80E	X	X	2032M95G12	Lug	72-31-18	GE
CF6-80C2, 80E	X	X	2032M95G13	Lug	72-31-18	GE
CF6-80C2, 80E	X	X	2092M52G01	Tube, Air HPR Assembly	72-09-03	GE
CF6-80C2, 80E	X	X	2092M53G01	Tube, Air HPR Assembly	72-09-03	GE
CF6-80C2, 80E	X	X	2168M98G01	Tube, Air PS3	72-09-03	GE
CF6-80C2, 80E	X	X	2285M80G01	Tube, Oil	72-09-03	GE
CF6-80C2, 80E	X	X	2285M89G01	Tube, Oil Lube Pump Spline	72-09-03	GE
CF6-80C2, 80E	X	X	2420M72G01	Manifold, Fuel Left Side	72-09-03	GE
CF6-80C2, 80E	X	X	2420M73G01	Manifold, Fuel (RH)	72-09-03	GE
CF6-80C2, 80E	X	X	2686M86P01	Shaft, Horizontal Drive	72-64-00	GE
CF6-80C2, 80E	X	X	2695M73G01	Manifold	72-09-03	GE
CF6-80C2, 80E	X	X	9049M91P06	Clevis	72-23-20	GE
CF6-80C2, 80E	X	X	9051M50G04	Link, Connecting IGW	72-32-09	GE
CF6-80C2, 80E	X	X	9051M51G04	Link, Connecting Stage 1	72-32-09	GE
CF6-80C2, 80E	X	X	9173M90G33	Lug	72-31-18	GE
CF6-80C2, 80E	X	X	9181M42P02	Link, Connecting Stage 4	72-32-09	GE
CF6-80C2, 80E	X	X	9331M84G01	Nozzle, Oil	72-09-02	GE
CF6-80C2, 80E	X		9356M78P02	Seal, Metal Ring	72-52-14	GE
CF6-80C2, 80E	X	X	9372M47P01	Connector, Oil	72-63-12	GE
CF6-80C2, 80E	X	X	9373M77G01	Retainer Assy, Stage 2 HPT	72-52-13	GE
CF6-80C2, 80E	X	X	9381M68G01	Bellcrank, Valve By-Pass	72-23-18	GE
CF6-80C2, 80E	X		9381M70P01	Segment, Support Thrust	72-23-01	GE
CF6-80C2, 80E	X		9381M70P02	Segment, Support Thrust	72-23-01	GE
CF6-80C2, 80E	X	X	9381M83G01	Nut Assy, Selflocking Gang Channel	72-34-01	GE
CF6-80C2, 80E	X	X	9381M89G01	Nut Assembly	72-34-01	GE
CF6-80C2, 80E	X	X	9382M10G04	Manifold, Oil	72-09-03	GE
CF6-80C2, 80E	X	X	9382M36G01	Tube, Air	72-09-03 72-34-20	GE
CF6-80C2, 80E	X	X	9382M36G02	Tube, Air	72-09-03 72-34-20	GE
CF6-80C2, 80E	X		9382M36G02A	Tube, Air	72-09-03 72-34-20	CFM
CF6-80C2, 80E	X		9382M36G03	Tube, Air	72-09-03 72-34-20	GE
CF6-80C2, 80E	X	X	9382M36G04	Tube, Air	72-09-03 72-34-20	GE
CF6-80C2, 80E	X		9382M36G05	Tube, Air	72-09-03 72-34-20	GE
CF6-80C2, 80E	X	X	9382M36G06	Tube, Air	72-09-03 72-34-20	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CF6-80C2, 80E	X		AE709962-1	Hose	72-09-03	GE
CF6-80C2, 80E1	X	X	9374M50G03	Cover	72-58-10	GE
CF6-80C2, 8E	X	X	9187M73P180	Coupling	72-09-04	GE
CF6-80C2, 8E	X	X	9373M48P01	Cover-Lube Nozzle	72-65-11	GE
CF6-80C2, 8E	X	X	9374M12P01	Nut-RND	72-21-09	GE
CF6-80C2,80E	X		2636M07G01	Manifold, Fuel Left Side	72-09-03	GE
CF6-80E	X		115518	Tube, Fuel	72-09-03	GE
CF6-80E	X		1308M32G10	Link, Support	72-09-04, Par 40	GE
CF6-80E	X	X	1315M18G05	Mask, Drain	72-09-03	GE
CF6-80E	X		1346M17G06	Manifold, Air	72-09-03	GE
CF6-80E	X		1578M30G03	Link, Support	72-09-04	GE
CF6-80E	X	X	1578M30G07	Link	72-09-04	GE
CF6-80E	X	X	1622M98G05	Bracket, Actuation	72-32-10	GE
CF6-80E	X		1639M11P03	Disk, LPT Stg 1	72-57-02	GE
CF6-80E	X		1639M12P03	Disk, LPT Stg 2	72-57-02	GE
CF6-80E	X		1639M13P03	Disk, LPT Stg 3	72-57-02	GE
CF6-80E	X		1639M14P02	Disk, LPT Stg 4	72-57-02	GE
CF6-80E	X		1639M15P03	Disk, LPT Stg 5	72-57-02	GE
CF6-80E	X		1639M20P08	Shaft, Torque Cone	72-57-03	GE
CF6-80E	X		1644M55G04	Bracket, Actuator	72-32-10	GE
CF6-80E	X		1669M31P03	Blade, Spacer Stage 1	72-21-11	GE
CF6-80E	X		1669M73P02	Seal, CDP	72-31-10	GE
CF6-80E	X		1697M82P01	Pin, Shear	71-20-06	GE
CF6-80E	X	X	1701M33G01	Tube, Air	72-09-03	GE
CF6-80E	X		1772M76G02	Manifold, Air Core	72-09-03	GE
CF6-80E	X		1779M46G01	Bracket	72-09-04	GE
CF6-80E	X		1779M74G01	Manifold, Drain Fuel	72-09-03	GE
CF6-80E	X		1779M76G01	Manifold, Drain Fuel	72-09-03	GE
CF6-80E	X		1802M16G02	Tube	72-09-03	GE
CF6-80E	X		1803M24G01	Tube, Air Compartment	72-09-03	GE
CF6-80E	X		1803M48G01	Tube	72-09-03	GE
CF6-80E	X		1803M48G02	Tube	72-09-03	GE
CF6-80E	X		1803M60G01	Bracket	72-09-04	GE
CF6-80E	X		1815M29G14	Nozzle, Stage 2	72-56-02	GE
CF6-80E	X		1826M48G01	Tube	72-09-03	GE
CF6-80E	X		1832M83G01	Tube, Oil	72-09-03	GE
CF6-80E	X		1833M28G01	Tube, Oil Supply	72-09-03	GE
CF6-80E	X		1833M51P107	Clamp, Cushion Loop	72-09-04	GE
CF6-80E	X	X	1848M68G01	Tube	72-09-03	GE
CF6-80E	X	X	1848M87G01	Tube	72-09-03	GE
CF6-80E	X	X	1849M14G01	Tube	72-09-03	GE
CF6-80E	X		1849M16G01	Tube	72-09-03	GE
CF6-80E	X		1849M37G01	Tube, Fuel Drain	72-09-03	GE
CF6-80E	X		1850M14G01	Tube, Oil Drain	72-09-03	GE
CF6-80E	X		1862M73P01	Damper, Seal	72-53-23	GE
CF6-80E	X		1998M11G01	Duct, Air HPT Cooling	72-09-03	GE
CF6-80E	X		1998M47G01	Tube, Supply Oil	72-09-003	GE
CF6-80E	X		2093M33P02	Link	72-21-01	GE
CF6-80E	X		2156M35G01	Tube, Under Cowl Cooling	72-09-03	GE
CF6-80E	X		2404M09G01	Tube	72-09-03	GE
CF6-80E	X		AE713834-509	Hose, Hydraulic	72-09-03	GE
CF6-80E	X	X	AE713834-511	Hose	72-09-03	GE
CF6-80E	X	X	AE713834-515	Hose	72-09-03	GE
CF6-80E, 8C2	X		9382M21P06	Duct, Vent Insulated	72-34-01	GE
CF6-80E1	X	X	1578M30G16	Link	72-09-04	GE
CF6-80E1	X	X	277-1703-503	Bracket Assy	72-09-04	GE
CF6-80E1	X		277-1703-521	Bracket Assy	72-09-04	GE
CF6-80E1	X	X	9372M82G02	Nozzle, Oil	72-09-02	GE
CFM56-2C	X	X	1155M46G03	Tube	72-09-03	CFM
CFM56-2C	X		1155M49P001A	Bracket	72-09-04	CFM
CFM56-2C	X		1155M70P001A	Bracket	72-09-04	CFM
CFM56-2C	X		1155M72P001A	Bracket	72-09-04	CFM
CFM56-2C	X		1155M73P001A	Bracket	72-09-04	CFM
CFM56-2C	X		1155M73P003A	Bracket	72-09-04	CFM
CFM56-2C	X		1155M74P001A	Bracket	72-09-04	CFM
CFM56-2C	X		1155M75P001A	Bracket	72-09-04	CFM
CFM56-2C	X		1155M78P001A	Bracket	72-09-04	CFM
CFM56-2C	X		1156M38P003A	Bracket	72-09-04	CFM
CFM56-2C	X		1156M39P003A	Bracket	72-09-04	CFM
CFM56-2C	X		1156M40P001A	Bracket	72-09-04	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-2C	X		1156M55P001A	Bracket	72-09-04	CFM
CFM56-2C	X		1156M56P001A	Bracket	72-09-04	CFM
CFM56-2C	X		1466M75G01	Tube	72-09-09, 72-09-04	CFM
CFM56-2C	X		1466M76G01	Tube	72-09-09, 72-09-04	CFM
CFM56-2C	X		1716M25G01	Bracket	72-09-04	CFM
CFM56-2C	X		1716M26G01	Bracket	72-09-04	CFM
CFM56-2C	X		1716M28P001A	Bracket	72-09-04	CFM
CFM56-2C	X		301-292-420-0	Vane, OGV	72-23-03	CFM
CFM56-2C	X		301-298-109-0	Sensor, No. 1 Speed	72-22-15	CFM
CFM56-2C	X		301-302-509-0	Spacer, InterStage	72-21-07	CFM
CFM56-2C	X	X	301-307-810-0	Spacer	72-21-10	CFM
CFM56-2C	X		301-360-004-0	Link	72-09-04	CFM
CFM56-2C	X		301-379-707-0	Bracket	72-09-04	CFM
CFM56-2C	X	X	301-379-708-0	Bracket	72-09-04	CFM
CFM56-2C	X		301-414-507-0	Bracket	72-09-04	CFM
CFM56-2C	X		301-414-508-0	Bracket	72-09-04	CFM
CFM56-2C	X		301-414-811-0	Bracket	72-09-04	CFM
CFM56-2C	X		301-414-812-0	Bracket	72-09-04	CFM
CFM56-2C	X		301-452-009-0	Bracket	72-09-04	CFM
CFM56-2C	X		301-452-011-0	Bracket	72-09-04	CFM
CFM56-2C	X		301-452-709-0	Bracket	72-09-04	CFM
CFM56-2C	X		301-452-711-0	Bracket	72-09-04	CFM
CFM56-2C	X		301-457-505-0	Bracket	72-09-04	CFM
CFM56-2C	X		301-463-915-0	Cone, Spinner Rear	72-21-05	CFM
CFM56-2C	X		301-509-701-0	Pad, Assy Drive Starter	72-63-02	CFM
CFM56-2C	X		301-509-702-0	Pad, Assy Drive Starter	72-63-02	CFM
CFM56-2C	X		301-524-106-0	Bracket	72-09-04	CFM
CFM56-2C	X		301-547-707-0	Bracket	72-09-04	CFM
CFM56-2C	X		301-547-708-0	Bracket	72-09-04	CFM
CFM56-2C	X		301-553-809-0	Bracket	72-09-04	CFM
CFM56-2C	X		301-553-810-0	Bracket	72-09-04	CFM
CFM56-2C	X		301-554-119-0	Bracket	72-09-04	CFM
CFM56-2C	X		301-554-120-0	Bracket	72-09-04	CFM
CFM56-2C	X		301-554-121-0	Bracket	72-09-04	CFM
CFM56-2C	X		301-554-122-0	Bracket	72-09-04	CFM
CFM56-2C	X		301-560-605-0	Bracket	72-09-04	CFM
CFM56-2C	X		301-567-609-0	Bracket	72-09-04	CFM
CFM56-2C	X		301-573-705-0	Bracket	72-09-04	CFM
CFM56-2C	X		301-577-908-0	Bracket	72-09-04	CFM
CFM56-2C	X		301-578-006-0	Bracket	72-09-04	CFM
CFM56-2C	X		301-578-108-0	Bracket	72-09-04	CFM
CFM56-2C	X		301-584-804-0	Tube, VSV Rod End	72-09-03	CFM
CFM56-2C	X		301-589-204-0	Tube, Oil	72-09-03	CFM
CFM56-2C	X		305-001-710-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-017-904-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-021-506-0	Bracket	72-09-04	CFM
CFM56-2C	X	X	305-026-014-0	Panel, Acoustical Mid	72-23-09	CFM
CFM56-2C	X		305-042-802-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-056-405-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-057-207-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-057-407-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-057-411-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-061-607-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-065-310-0	Panel, Acoustical Fwd	72-54-20	CFM
CFM56-2C	X		305-065-610-0	Panel, Acoustical	72-23-09	CFM
CFM56-2C	X		305-079-503-0	Plate, Blanking	72-23-35	CFM
CFM56-2C	X		305-081-303-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-081-305-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-081-805-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-093-209-0	Bracket	72-09-04	CFM
CFM56-2C	X	X	305-100-700-0	Nozzle, Suction	72-63-14	CFM
CFM56-2C	X		305-200-352-0	Flange, Outer LH	78-36-01	CFM
CFM56-2C	X		305-229-803-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-249-801-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-265-303-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-265-304-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-265-304-6	Bracket	72-09-04	CFM
CFM56-2C	X		305-265-305-6	Bracket	72-09-04	CFM
CFM56-2C	X		305-276-602-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-276-603-0	Bracket	72-09-04	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-2C	X		305-276-603-6	Bracket	72-09-04	CFM
CFM56-2C	X		305-276-604-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-276-604-6	Bracket	72-09-04	CFM
CFM56-2C	X		305-276-902-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-293-102-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-293-152-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-293-202-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-293-304-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-301-206-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-301-303-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-301-803-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-301-804-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-301-903-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-301-904-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-303-603-0	Tube, Fuel VBV Supply	72-09-03	CFM
CFM56-2C	X		305-305-003-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-305-102-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-305-207-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-305-208-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-305-210-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-308-803-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-308-804-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-308-806-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-309-604-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-309-605-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-314-605-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-314-606-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-316-307-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-317-903-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-318-002-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-321-101-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-321-803-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-321-903-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-324-602-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-327-003-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-327-203-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-328-202-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-328-401-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-328-403-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-328-502-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-328-601-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-328-603-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-328-701-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-328-801-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-328-803-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-328-805-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-328-901-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-328-903-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-329-102-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-329-202-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-330-001-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-330-201-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-330-203-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-330-302-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-330-401-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-330-403-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-330-903-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-330-907-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-331-304-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-333-701-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-333-802-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-333-803-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-334-002-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-334-102-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-334-601-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-335-401-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-335-501-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-335-601-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-335-703-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-335-705-0	Bracket	72-09-04	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-2C	X		305-335-901-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-336-001-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-337-103-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-337-104-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-337-106-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-337-205-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-337-302-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-337-303-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-337-901-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-338-801-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-340-501-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-341-801-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-341-902-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-348-202-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-349-401-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-349-501-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-349-601-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-349-602-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-349-701-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-349-801-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-349-901-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-349-902-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-370-401-0	Bracket	72-09-04	CFM
CFM56-2C	X	X	305-408-404-0	Panel, Acoustical	72-23-09	CFM
CFM56-2C	X		305-408-501-0	Panel, Acoustical Aft	72-23-09	CFM
CFM56-2C	X		305-408-505-0	Panel, Acoustical Aft	72-23-09	CFM
CFM56-2C	X	X	305-408-605-0	Panel, Acoustical	72-23-09	CFM
CFM56-2C	X		305-424-101-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-433-102-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-548-601-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-548-701-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-549-201-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-551-100-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-551-200-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-552-003-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-552-101-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-557-601-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-557-901-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-558-102-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-558-301-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-558-701-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-558-901-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-559-001-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-559-101-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-559-202-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-561-602-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-561-702-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-561-802-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-586-902-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-615-607-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-708-600-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-710-104-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-711-100-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-711-200-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-711-201-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-711-201-6	Bracket	72-09-04	CFM
CFM56-2C	X		305-711-400-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-711-401-6	Bracket	72-09-04	CFM
CFM56-2C	X		305-711-800-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-712-001-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-713-700-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-714-500-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-714-500-6	Bracket	72-09-04	CFM
CFM56-2C	X		305-715-000-6	Bracket	72-09-04	CFM
CFM56-2C	X		305-716-200-6	Bracket	72-09-04	CFM
CFM56-2C	X		305-716-250-6	Bracket	72-09-04	CFM
CFM56-2C	X		305-716-300-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-716-801-6	Bracket	72-09-04	CFM
CFM56-2C	X		305-716-901-6	Bracket	72-09-04	CFM
CFM56-2C	X		305-724-500-0	Bracket	72-09-04	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-2C	X		305-724-602-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-724-701-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-725-400-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-728-600-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-728-700-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-735-100-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-735-300-6	Bracket	72-09-04	CFM
CFM56-2C	X		305-735-350-6	Bracket	72-09-04	CFM
CFM56-2C	X		305-736-500-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-737-503-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-737-504-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-737-505-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-737-553-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-737-554-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-737-555-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-738-404-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-738-405-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-738-406-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-738-454-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-738-455-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-738-456-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-741-500-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-741-501-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-743-300-6	Bracket	72-09-04	CFM
CFM56-2C	X		305-743-301-6	Bracket	72-09-04	CFM
CFM56-2C	X		305-743-400-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-743-401-6	Bracket	72-09-04	CFM
CFM56-2C	X		305-750-000-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-750-100-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-752-200-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-753-001-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-755-900-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-757-900-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-761-200-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-800-001-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-801-301-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-801-601-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-812-001-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-816-001-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-816-101-0	Bracket	72-09-04	CFM
CFM56-2C	X		305-875-801-0	Bracket	72-09-04	CFM
CFM56-2C	X		334-008-523-0	Bracket	72-09-04	CFM
CFM56-2C	X		9236M64G01	Bracket	72-09-04	CFM
CFM56-2C	X		9276M97P001A	Bracket	72-09-04	CFM
CFM56-2C	X		9368M33G01	Bracket	72-09-04	CFM
CFM56-2C	X		9368M33G02	Bracket	72-09-04	CFM
CFM56-2C	X		9386M70G01	Bracket	72-09-04	CFM
CFM56-2C	X		9393M27G01	Bracket	72-09-04	CFM
CFM56-2C	X		9393M27G02	Bracket	72-09-04	CFM
CFM56-2C	X		9393M31G01	Bracket	72-09-04	CFM
CFM56-2C	X		9394M16G01	Manifold, Fuel Supply	72-09-03	CFM
CFM56-2C	X		9502M52G01	Bracket	72-09-04	CFM
CFM56-2C	X		9502M53G01	Bracket	72-09-04	CFM
CFM56-2C	X		9502M55P001A	Bracket	72-09-04	CFM
CFM56-2C	X		9502M71G01	Bracket	72-09-04	CFM
CFM56-2C	X		9502M72G01	Bracket	72-09-04	CFM
CFM56-2C	X		9503M26G01	Bracket	72-09-04	CFM
CFM56-2C	X		9503M26G02	Bracket	72-09-04	CFM
CFM56-2C	X		9515M32G01	Bracket	72-09-04	CFM
CFM56-2C	X		9516M96P001A	Bracket	72-09-04	CFM
CFM56-2C	X		9517M11G01	Bracket	72-09-04	CFM
CFM56-2C	X		9517M11G02	Bracket	72-09-04	CFM
CFM56-2C	X		9517M85G01	Bracket	72-09-04	CFM
CFM56-2C	X		9972M71P001A	Bracket	72-09-04	CFM
CFM56-2C	X		9974M30G01	Bracket	72-09-04	CFM
CFM56-2C	X		9974M31G01	Bracket	72-09-04	CFM
CFM56-2C	X		205-146-501-0	Plug, Nozzle	72-62-11	CFM
CFM56-2C	X		238-0801-553	Tube	71-00-17	ROHR
CFM56-2C	X		301-515-607-0	Platform, Fan Blade	72-21-06	CFM
CFM56-2C, 3	X		1275M37P01	Shaft, HPC Front	72-31-07	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-2C, 3	X		1275M37P02	Shaft, HPC Front	72-31-07	CFM
CFM56-2C, 3	X		1276M26G01	Sleeve, Coupling Feedback	72-32-13	CFM
CFM56-2C, 3	X		1276M66G01	Shroud Assy, Compressor Stator IGV	72-32-06	CFM
CFM56-2C, 3	X		1276M66G02	Shroud Assy, Compressor Stator IGV	72-32-06	CFM
CFM56-2C, 3	X		1276M85P02	Bellcrank, Upper Support	72-32-15	CFM
CFM56-2C, 3	X		1276M86P02	Bellcrank, Lower Support	72-32-15	CFM
CFM56-2C, 3	X		1276M90G01	Stop	72-33-20	CFM
CFM56-2C, 3	X		1277M35G01	Shield	72-53-02	CFM
CFM56-2C, 3	X		1277M36G02	Shield	72-53-02	CFM
CFM56-2C, 3	X		1277M36G03	Shield	72-53-02	CFM
CFM56-2C, 3	X		1277M36G04	Shield	72-53-02	CFM
CFM56-2C, 3	X		1277M36G06	Shield	72-53-02	CFM
CFM56-2C, 3	X		1277M36G07	Shield	72-53-02	CFM
CFM56-2C, 3	X		1318M40G05	Link, Assy	72-32-14	CFM
CFM56-2C, 3	X	X	1466M14G02	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-2C, 3	X	X	1466M14G03	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-2C, 3	X		1466M73G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-2C, 3	X		1466M74G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-2C, 3	X		1475M88P01	Damper, Forward Sleeve	72-52-07	CFM
CFM56-2C, 3	X		1476M86G01	Shield, Air	72-53-02	CFM
CFM56-2C, 3	X		1590M30G01	Shaft, HPC Front	72-31-07	CFM
CFM56-2C, 3	X		1590M30G02	Shaft, HPC Front	72-31-07	CFM
CFM56-2C, 3	X		1590M30G03	Shaft, HPC Front	72-31-07	CFM
CFM56-2C, 3	X		1590M30G04	Shaft, HPC Front	72-31-07	CFM
CFM56-2C, 3	X		1590M32G01	Shaft, HPC Front	72-31-07	CFM
CFM56-2C, 3	X		1590M32G02	Shaft, HPC Front	72-31-07	CFM
CFM56-2C, 3	X		1590M32G03	Shaft, HPC Front	72-31-07	CFM
CFM56-2C, 3	X		1895M18G03	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-2C, 3	X		1895M18G04	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-2C, 3	X		1895M18G05	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-2C, 3	X		1896M95G02	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-2C, 3	X		1896M95G03	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-2C, 3	X		301-321-612-0	Fairing	72-56-04	CFM
CFM56-2C, 3	X		301-324-107-0	Shield	72-54-20	CFM
CFM56-2C, 3	X		301-324-109-0	Shield	72-54-20	CFM
CFM56-2C, 3	X		301-324-110-0	Shield, LPT Stator Shroud Stage 2	72-54-20	CFM
CFM56-2C, 3	X		301-324-304-0	Shield, LPT Stator Shroud	72-54-20	CFM
CFM56-2C, 3	X		301-324-504-0	Shield	72-54-20	CFM
CFM56-2C, 3	X		301-330-618-0	Shaft, Stub	72-55-02	CFM
CFM56-2C, 3	X		301-330-619-0	Shaft, Stub	72-55-02	CFM
CFM56-2C, 3	X		301-330-624-0	Shaft, Stub	72-55-02	CFM
CFM56-2C, 3	X		301-330-626-0	Shaft, Stub LPT	72-55-02	CFM
CFM56-2C, 3	X		301-331-121-0	Disk, LPT Stage 1	72-54-03	CFM
CFM56-2C, 3	X		301-331-124-0	Disk, LPT Stage 1	72-54-03	CFM
CFM56-2C, 3	X		301-331-125-0	Disk, LPT Stage 1	72-54-03	CFM
CFM56-2C, 3	X		301-331-126-0	Disk, LPT Stage 1	72-54-03	CFM
CFM56-2C, 3	X		301-331-127-0	Disk, LPT Stage 1	72-54-03	CFM
CFM56-2C, 3	X		301-331-221-0	Disk, LPT Stage 2	72-54-03	CFM
CFM56-2C, 3	X		301-331-224-0	Disk, LPT Stage 2	72-54-03	CFM
CFM56-2C, 3	X		301-331-225-0	Disk, LPT Stage 2	72-54-03	CFM
CFM56-2C, 3	X		301-331-227-0	Disk, LPT Stage 2	72-54-03	CFM
CFM56-2C, 3	X		301-331-318-0	Disk, LPT Stage 3	72-54-03	CFM
CFM56-2C, 3	X	X	301-331-321-0	Disk, LPT Stage 3	72-54-03	CFM
CFM56-2C, 3	X	X	301-331-322-0	Disk, LPT Stage 3	72-54-03	CFM
CFM56-2C, 3	X		301-331-419-0	Disk, LPT Stage 4	72-54-03	CFM
CFM56-2C, 3	X		301-331-425-0	Disk, LPT Stage 4	72-54-03	CFM
CFM56-2C, 3	X		301-331-427-0	Disk, LPT Stage 4	72-54-03	CFM
CFM56-2C, 3	X		301-331-429-0	Disk, LPT Stage 4	72-54-03	CFM
CFM56-2C, 3	X	X	301-331-923-0	Ring, LPT 3 Rotating	72-54-06	CFM
CFM56-2C, 3	X		301-332-014-0	Shield	72-54-20	CFM
CFM56-2C, 3	X	X	301-332-108-0	Retainer, Blade LPT Rtr Stage 1	72-54-20	CFM
CFM56-2C, 3	X		301-332-207-0	Retainer, Blade LPT Rtr Stage 2	72-54-20	CFM
CFM56-2C, 3	X		301-332-313-0	Retainer, Blade LPT Rotor	72-54-20	CFM
CFM56-2C, 3	X		301-333-401-0	Sleeve	72-55-20	CFM
CFM56-2C, 3	X		301-348-410-0	Sleeve, Speed Sensor	72-22-17	CFM
CFM56-2C, 3	X		301-386-005-0	Support	72-54-14	CFM
CFM56-2C, 3	X		301-465-213-0	Cone, Spinner Front	72-21-05	CFM
CFM56-2C, 3	X	X	301-475-207-6	Baffle, Oil Bearing No. 1	72-22-14	CFM
CFM56-2C, 3	X		301-554-406-0	Plug Assy, Borescope	72-53-09	CFM
CFM56-2C, 3	X		301-554-407-0	Plug Assy, Borescope	72-53-09	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-2C, 3	X		305-046-922-0	Sump	72-56-06	CFM
CFM56-2C, 3	X		305-047-506-0	Manifold, Oil Bearing 1	72-22-07, 72-09-03	CFM
CFM56-2C, 3	X		305-050-901-0	Tube, Oil	72-09-03	CFM
CFM56-2C, 3	X		305-056-106-0	Support, Conical LPT	72-54-05	CFM
CFM56-2C, 3	X		305-056-109-0	Support, Conical LPT	72-54-05	CFM
CFM56-2C, 3	X		305-056-110-0	Support, Conical LPT	72-54-05	CFM
CFM56-2C, 3	X		305-056-111-0	Support, Conical LPT	72-54-05	CFM
CFM56-2C, 3	X		305-056-112-0	Support, Conical LPT	72-54-05	CFM
CFM56-2C, 3	X		305-056-115-0	Support, LPT Conical	72-54-05	CFM
CFM56-2C, 3	X		305-056-116-0	Support, LPT Conical	72-54-05	CFM
CFM56-2C, 3	X		305-056-117-0	Support, Conical LPT	72-54-05	CFM
CFM56-2C, 3	X		305-056-118-0	Support, Conical LPT	72-54-05	CFM
CFM56-2C, 3	X		305-056-119-0	Support, Conical LPT	72-54-05	CFM
CFM56-2C, 3	X	X	305-056-120-0	Support, Conical LPT	72-54-05	CFM
CFM56-2C, 3	X		305-056-121-0	Support, Conical LPT	72-54-05	CFM
CFM56-2C, 3	X		305-056-122-0	Support, Conical LPT	72-54-05	CFM
CFM56-2C, 3	X		305-056-123-0	Conical Support	72-54-05	CFM
CFM56-2C, 3	X		305-056-124-0	Support, Conical LPT	72-54-05	CFM
CFM56-2C, 3	X		305-087-403-0	Manifold, Oil Bearing No.3	72-23-18	CFM
CFM56-2C, 3	X		305-098-407-0	Seal, Oil FWD Rotating	72-55-12	CFM
CFM56-2C, 3	X		305-371-305-0	Cover	72-56-07	CFM
CFM56-2C, 3	X		305-371-308-0	Cover	72-56-07	CFM
CFM56-2C, 3	X		305-371-801-0	Cage	72-56-08	CFM
CFM56-2C, 3	X		305-379-801-0	Tube Assy	72-09-03	CFM
CFM56-2C, 3	X		305-380-401-0	Flange	72-56-09	CFM
CFM56-2C, 3	X		305-381-303-0	Plug, Borescope	72-54-20	CFM
CFM56-2C, 3	X		305-386-308-0	Ring, Sect Support Aft Cooling Manifold	72-54-07	CFM
CFM56-2C, 3	X	X	305-386-309-0	Ring, Sect Support Aft Cooling Manifold	72-54-07	CFM
CFM56-2C, 3	X		305-386-408-0	Ring, Sect Support Aft Cooling Manifold	72-54-07	CFM
CFM56-2C, 3	X		305-386-506-0	Ring, Sect Support Aft Cooling Manifold	72-54-07	CFM
CFM56-2C, 3	X		305-386-609-0	Ring, Sect Support Aft Cooling Manifold	72-54-07	CFM
CFM56-2C, 3	X		305-386-708-0	Ring, Sect Support Aft Cooling Manifold	72-54-07	CFM
CFM56-2C, 3	X		305-387-301-0	Bracket	72-09-04	CFM
CFM56-2C, 3	X		305-387-302-0	Bracket	72-09-04	CFM
CFM56-2C, 3	X		305-402-403-0	Bracket	72-09-04	CFM
CFM56-2C, 3	X		305-402-404-0	Bracket	72-09-04	CFM
CFM56-2C, 3	X		305-402-503-0	Bracket	72-09-04	CFM
CFM56-2C, 3	X		305-402-504-0	Bracket	72-09-04	CFM
CFM56-2C, 3	X		305-428-901-0	Screen, Thermal	72-54-20	CFM
CFM56-2C, 3	X		305-437-301-0	Bracket	72-09-04	CFM
CFM56-2C, 3	X		305-437-601-0	Bracket	72-09-04	CFM
CFM56-2C, 3	X		305-482-601-0	Bracket	72-09-04	CFM
CFM56-2C, 3	X		305-980-005-6	Elbow Assy	72-56-01, 72-09-03	CFM
CFM56-2C, 3	X		335-025-703-0	Spacer	72-21-15	CFM
CFM56-2C, 3	X		335-071-001-0	Cover	72-56-07	CFM
CFM56-2C, 3	X		335-071-002-0	Cover	72-56-07	CFM
CFM56-2C, 3	X		9232M90P06	Nut Assy, Gang Channel	72-41-10	CFM
CFM56-2C, 3	X	X	9232M90P07	Nut Assy, Gang Channel	72-41-10	CFM
CFM56-2C, 3	X		9232M90P08	Nut Assy, Gang Channel	72-41-10	CFM
CFM56-2C, 3	X	X	9232M90P09	Nut Assy, Gang Channel	72-41-10	CFM
CFM56-2C, 3	X		9279M20P01	Ring Assy, Actuation Compressor Stator	72-32-11	CFM
CFM56-2C, 3	X		9279M21P01	Ring Assy, Actuation Compressor Stator	72-32-11	CFM
CFM56-2C, 3	X		9336M78G01	Seal, Fwd Stationary No 3	72-23-19	CFM
CFM56-2C, 3	X		9375M37G01	Bracket	72-09-04	CFM
CFM56-2C, 3	X		9375M37G02	Bracket	72-09-04	CFM
CFM56-2C, 3	X		9375M70G01	Bracket	72-09-04	CFM
CFM56-2C, 3	X		9375M71P001A	Bracket	72-09-04	CFM
CFM56-2C, 3	X	X	9375M90G03	Manifold, Fuel (LH)	72-41-04, 72-09-03	CFM
CFM56-2C, 3	X	X	9375M90G05	Manifold, Fuel	72-41-04	CFM
CFM56-2C, 3	X	X	9375M90G06	Manifold, Fuel (RH)	72-41-04	CFM
CFM56-2C, 3	X		9375M90G09	Manifold, Fuel (LH)	72-41-04	CFM
CFM56-2C, 3	X		9375M90G10	Manifold, Fuel	72-41-04	CFM
CFM56-2C, 3	X	X	9375M90G11	Manifold, Fuel	72-41-04, 72-09-03	CFM
CFM56-2C, 3	X	X	9375M90G12	Manifold, Fuel	72-41-04	CFM
CFM56-2C, 3	X		9386M40P001A	Bracket	72-09-04	CFM
CFM56-2C, 3	X		9386M69G01	Bracket	72-09-04	CFM
CFM56-2C, 3	X		9386M71G01	Bracket	72-09-04	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-2C, 3	X	X	9386M77G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-2C, 3	X	X	9386M85G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-2C, 3	X		9386M85G02	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-2C, 3	X		9393M93G01	Tube, Drain Fuel Supply	72-09-03	CFM
CFM56-2C, 3	X		9502M69G01	Bracket	72-09-04	CFM
CFM56-2C, 3	X		9511M57P01	Shaft, HPC Front	72-31-07	CFM
CFM56-2C, 3	X	X	9514M54G02	Duct, HPT Rotor Air	72-31-11	CFM
CFM56-2C, 3	X		9514M75P03	Retainer, Blade	72-52-06	CFM
CFM56-2C, 3	X		9514M75P04	Retainer, Blade HPT Rtr Rear	72-52-06	CFM
CFM56-2C, 3	X		9514M75P07	Retainer, Blade	72-52-06	CFM
CFM56-2C, 3	X		9524M44P01	Damper, Aft Sleeve	72-52-09	CFM
CFM56-2C, 3	X		9528M56G01	Nut, Shield	72-41-06	CFM
CFM56-2C, 3	X		9528M57G03	Shield, Nut	72-41-06	CFM
CFM56-2C, 3	X		9528M62P02	Damper, Forward Sleeve	72-52-07	CFM
CFM56-2C, 3	X		9529M85G05	Shield, Bolt HPT Nozzle Support	72-41-05	CFM
CFM56-2C, 3	X		9909873-101	Duct	72-09-03	CFM
CFM56-2C, 3	X	X	9989M47P03	Seal, Rotating No. 3 Bearing	72-61-04	CFM
CFM56-2C, 3	X		9375M90G04	Manifold, Fuel	72-41-04	CFM
CFM56-2C, 3, 5A	X		1276M28P01	Stop	72-32-01	CFM
CFM56-2C, 3, 5A	X	X	1318M50G01	Link, Connecting Actuation Ring IGV	72-32-11	CFM
CFM56-2C, 3, 5A	X		301-360-005-0	Link Assy, Mount RH AGB	72-23-14	CFM
CFM56-2C, 3, 5A	X		301-465-214-0	Cone, Spinner Front	72-21-05	CFM
CFM56-2C, 3, 5A	X		301-473-720-0	Panel, Fan Duct	72-23-07	CFM
CFM56-2C, 3, 5A	X	X	301-473-725-0	Panel, Fan Duct	72-23-07	CFM
CFM56-2C, 3, 5A	X		301-537-905-0	Nut, No. 1 Bearing	72-22-13	CFM
CFM56-2C, 3, 5A	X	X	301-544-406-0	Tube Assy, Oil No.2 Bearing	72-09-03	CFM
CFM56-2C, 3, 5A	X		305-047-507-0	Manifold, Oil No. 1 Bearing	72-22-07, 72-09-03	CFM
CFM56-2C, 3, 5A	X	X	305-047-508-0	Manifold, Oil No. 1 Bearing	72-22-07	CFM
CFM56-2C, 3, 5A	X		305-082-809-0	Panel, Fan Duct	72-23-07	CFM
CFM56-2C, 3, 5A	X	X	305-082-812-0	Panel, Fan Duct	72-23-07	CFM
CFM56-2C, 3, 5A	X	X	305-097-903-0	Bumper Bearing	72-55-13	CFM
CFM56-2C, 3, 5A	X		305-356-605-0	Link Assy, Mount LH AGB	72-23-14	CFM
CFM56-2C, 3, 5A	X		305-397-201-0	Tube, Air	72-09-03	CFM
CFM56-2C, 3, 5A	X	X	305-397-801-0	Flange	72-23-27	CFM
CFM56-2C, 3, 5A	X		335-025-704-0	Spacer	72-21-15	CFM
CFM56-2C, 3, 5A	X		9134M25P119	Bracket	72-09-04	CFM
CFM56-2C, 3, 5A	X	X	9386M79G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-2C, 3, 5A	X		9513M33P01	Rod, Master Bellcrank	72-32-13	CFM
CFM56-2C, 3, 5A	X	X	9528M57G01	Nut, Shield	72-41-06	CFM
CFM56-2C, 3, 5A, 5B	X	X	301-544-407-0	Tube Assy, Oil No.2 Bearing	72-09-03	CFM
CFM56-2C, 3, 5A, 5B	X		305-047-401-0	Coupling, Tube	72-22-20	CFM
CFM56-2C, 3, 5A, 5B	X		305-087-405-6	Elbow, Air Igniter Lead Cooling	72-23-18	CFM
CFM56-2C, 3, 5A, 5B	X		305-355-901-0	Tube, Nipple	72-23-35	CFM
CFM56-2C, 3, 5A, 5B	X		305-397-203-0	Tube, Air	72-23-26	CFM
CFM56-2C, 3, 5A, 5B, 5C	X	X	9511M34P01	Link Assy, Bellcrank	72-32-15	CFM
CFM56-2C, 3, 5A, 5B, 5C	X		9523M35G01	Arm, Vane Actuation Compressor Stator Assy	72-32-10	CFM
CFM56-2C, 3, 5A, 5B, 5C	X		9938M48G05	Arm, Vane Actuation Compressor Stator Assy	72-32-10	CFM
CFM56-2C, 3, 5A, 5B, 5C	X		9940M32G04	Rod, Tie	72-32-14	CFM
CFM56-2C, 3, 5A, 5B, 5C	X		9984M22P01	Weight, Balance	72-31-20	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X	X	301-297-909-0	Ring, Retainer	72-22-16	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		301-298-006-0	Nut, Inner Ring Bearing No. 1	72-22-13	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		301-298-803-0	Shim	72-55-20	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		301-298-804-0	Shim	72-55-20	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		301-298-805-0	Shim	72-55-20	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		301-298-806-0	Shim	72-55-20	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		301-298-807-0	Shim	72-55-20	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		301-298-808-0	Shim	72-55-20	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		301-298-809-0	Shim	72-55-20	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		301-298-810-0	Shim	72-55-20	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		301-298-811-0	Shim	72-55-20	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		301-298-812-0	Shim	72-55-20	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		301-298-813-0	Shim	72-55-20	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		9513M21P07	Link, Connecting	72-32-11	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		9513M22P06	Link, Connecting	72-32-11	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		9513M34G01	Rod, Master	72-32-13	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		9725M81P02	Spacer, Bearing	72-61-15	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X	X	9938M48G06	Arm, Vane Actuation Compressor Stator Assy	72-32-10	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		9944M44P02	Bushing, Flange	72-32-11	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X	X	9967M48P01	Plug, Mach Thread	72-41-11	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		9971M82P02	Ring, Retaining	72-52-10	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		9972M39P01	Retainer, Bearing	72-61-15	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X	X	9972M48P01	Nut, Puller No. 3 Bearing	72-61-06	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		9992M67P12	Bushing, Stage 2 Inner	72-32-09	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		9992M83P01	Plug, Borescope	72-32-20	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		9992M85P01	Cap, Borescope	72-32-20	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X	X	9992M86G07	Plug Assy, Boroscope (Stage 6)	72-32-20	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		9999M37P02	Washer, Flat	72-32-20	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		AS3217-207	Ring	72-22-20	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		AS3217-253	Ring, Retaining	72-22-20	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		AS3218-247	Ring, Retaining	72-22-20	CFM
CFM56-2C, 3, 5A, 5B, 5C	X		1318M40G02	Link, Assy	72-32-14	CFM
CFM56-2C, 3, 5A, 5B, 5C	X		1318M40G03	Link Assy	72-32-14	CFM
CFM56-2C, 3, 5A, 5B, 5C	X		1318M41G02	Link, Assy Compressor Stator Stage 3	72-32-14	CFM
CFM56-2C, 3, 5A, 5B, 5C	X		1385M33G02	Arm, Vane Actuation Compressor Stator Assy	72-32-10	CFM
CFM56-2C, 3, 5A, 5B, 5C	X		1834M58G01	Arm, Vane Actuation Compressor Stator Assy	72-32-10	CFM
CFM56-2C, 3, 5A, 5B, 5C	X		1834M59G01	Arm, Vane Actuation Compressor Stator Assy	72-32-10	CFM
CFM56-2C, 3, 5A, 5B, 5C	X		301-360-006-0	Link Assy, Mount RH AGB	72-23-14	CFM
CFM56-2C, 3, 5A, 5B, 5C	X		301-581-006-0	Sleeve, Sealing	72-54-20	CFM
CFM56-2C, 3, 5A, 5B, 5C	X		305-058-401-0	Shield	72-56-20	CFM
CFM56-2C, 3, 5A, 5B, 5C	X		305-356-606-0	Link Assy, Mount LH AGB	72-23-14	CFM
CFM56-2C, 3, 5A, 5B, 5C	X	X	305-415-401-0	Pin Assy, Straight	72-63-18	CFM
CFM56-2C, 3, 5A, 5B, 5C	X	X	305-356-620-0	Link Assy, Mount LH AGB	72-23-14	CFM
CFM56-2C, 3, 5A, 5B, 5C	X		J205P1100	Ring, Retainer	72-22-20	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X	X	1318M50G03	Link, Connecting Actuation Ring IGV	72-32-11	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X	X	1318M51G01	Link, Connecting Actuation Ring Stage 1	72-32-11	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X	X	1318M51G03	Link, Connecting Actuation Ring Stage 1	72-32-11	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X	X	1318M52G01	Link, Connecting Actuation Ring Stage 2	72-32-11	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X	X	1318M52G03	Link, Connecting Actuation Ring Stage 2	72-32-11	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X	X	1318M53G03	Link, Connecting Actuation Ring Stage 3	72-32-11	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X	X	1385M33G03	Arm, Vane Actuation Compressor Stator Assy	72-32-10	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		1385M34G01	Arm, Vane Actuation Compressor Stator Assy	72-32-10	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X	X	1476M51P01	Rod, Master Bellcrank Vane Actuation	72-32-13	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		1476M52P01	Bushing	72-32-13, Par 4H	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		1476M52P03	Bushing	72-32-15	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X	X	1476M80P01	Rod, Master Bellcrank Vane Actuation	72-32-13	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X	X	1558M35G01	Rod, Master Bellcrank Vane Actuation	72-32-13	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		1559M33P23	Bushing, Stage 1 Inner	72-32-09	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		1559M33P24	Bushing, Stage 1 Inner	72-32-09	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		1559M33P26	Bushing, Stage 3	72-32-09	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X	X	1591M23P02	Link, Bellcrank Vane Actuation	72-32-15	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X	X	1591M24G01	Link, Bellcrank Vane Actuation	72-32-15	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X	X	1663M70P02	Ring, Retaining Key	72-31-14	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X	X	1834M58G02	Arm, Actuation IGV & Stage 3	72-32-10	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X	X	1834M59G02	Arm, Actuation IGV & Stage 3	72-32-10	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X	X	1864M97P01	Sleeve, Damper	72-52-11	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X	X	301-360-020-0	Link Assy, Mount RH AGB	72-23-14	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		301-475-207-0	Baffle, Oil Bearing No. 1	72-22-14	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		301-537-803-0	Washer, Key	72-22-16	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X	X	301-544-203-0	Washer, Key	72-22-16	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X	X	301-566-807-0	Pin	72-23-10	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		301-581-007-0	Sleeve, Sealing	72-54-20	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		305-071-101-0	Bracket	72-09-04	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		305-118-301-0	Ring	72-63-08	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X	X	305-118-305-0	Ring	72-63-08	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		305-396-303-0	Ring, Oil Separator	72-22-05	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X	X	305-398-901-0	Nut	72-22-16	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X	X	335-070-401-0	Flange	72-56-12	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X	X	9115M80P06	Bolt, Slab Head	72-31-20	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		9125M42P03	Ring, Seal	72-31-12	CFM
CFM56-2C, 3, 5A, 5B, 5C, 7B	X		9992M84P01	Cap	72-32-20	CFM
CFM56-2C, 3, 5A, 5B, 7B	X		301-367-605-0	Bolt, D Head	72-55-11	CFM
CFM56-2C, 3, 5A, 5B, 7B	X	X	305-396-306-0	Ring, Oil Separator	72-22-05	CFM
CFM56-2C, 3, 5A, 5B, 7B	X	X	305-408-301-0	Tube, Vent Rear	72-55-10	CFM
CFM56-2C, 3, 5A, 5B, 7B	X	X	336-024-708-0	Cover, Oil Inlet Assy	72-56-06	CFM
CFM56-2C, 3, 5A, 5B, 7B	X		9993M72P01	Cover, Plate	72-09-04	CFM
CFM56-2C, 3, 5A, 5C	X		1385M33G01	Arm, Vane Actuation Compressor Stator Assy	72-32-10	CFM
CFM56-2C, 3, 5A, 5C, 7B	X		301-298-814-0	Shim	72-55-20	CFM
CFM56-2C, 3, 5A, 5C, 7B	X		301-298-815-0	Shim	72-55-20	CFM
CFM56-2C, 3, 5A, 5C, 7B	X		301-298-816-0	Shim	72-55-20	CFM
CFM56-2C, 3, 5A, 5C, 7B	X		301-298-817-0	Shim	72-55-20	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-2C, 3, 5A, 5C, 7B	X		301-298-818-0	Shim	72-55-20	CFM
CFM56-2C, 3, 5A, 5C, 7B	X		301-298-819-0	Shim	72-55-20	CFM
CFM56-2C, 3, 5A, 7B	X		301-333-307-0	Support, Tube	72-55-20	CFM
CFM56-2C, 3, 5A, 7B	X	X	305-415-103-0	Support, Tube	72-55-20	CFM
CFM56-2C, 3, 5A, 7B	X		340-161-101-0	Support, Tube	72-55-20	CFM
CFM56-2C, 3, 5A, 7B	X	X	340-161-201-0	Support, Tube	72-55-20	CFM
CFM56-2C, 5A	X		1324M37P001A	Bracket	72-09-04	CFM
CFM56-2C, 5A	X		301-543-303-0	Manifold, Oil Bearing Supply	72-09-03	CFM
CFM56-2C, 5A	X		301-569-403-0	Bracket	72-09-04	CFM
CFM56-2C, 5A	X		301-585-405-0	Tube, Open VBVB	72-09-03	CFM
CFM56-2C, 5A	X	X	301-585-406-0	Tube, Open VBVB	72-09-03	CFM
CFM56-2C, 5A	X		301-585-805-0	Tube, Close VBVB	72-09-03	CFM
CFM56-2C, 5A	X	X	301-585-806-0	Tube, Close VBVB	72-09-03	CFM
CFM56-2C, 5A	X		305-061-606-0	Bracket	72-09-04	CFM
CFM56-2C, 5A	X		305-331-101-0	Bracket	72-09-04	CFM
CFM56-2C, 5A	X		305-363-505-0	Pin, Mounting	72-23-10	CFM
CFM56-2C, 5A	X		305-484-602-0	Cone, Spinner Front	72-21-05	CFM
CFM56-2C, 5A	X		334-007-109-0	Housing, Inner Radial Driveshaft	72-23-05	CFM
CFM56-2C, 5A	X		9386M71G02	Bracket	72-09-04	CFM
CFM56-2C, 5A	X		9393M12G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-2C, 5A	X		9393M37G01	Bracket	72-09-04	CFM
CFM56-2C, 5A	X		9393M37G05	Bracket	72-09-04	CFM
CFM56-2C, 5A	X	X	9393M65G01	Tube, Drain Fuel	72-09-03	CFM
CFM56-2C, 5A	X		301-465-216-0	Cone, Spinner Front	72-21-05	CFM
CFM56-2C, 5A	X		301-472-415-0	Panel, Fan Duct	72-23-07	CFM
CFM56-2C, 5A	X		301-472-417-0	Panel, Fan Duct	72-23-07	CFM
CFM56-2C, 5A, 5B	X	X	301-417-104-0	Tube, Guide	72-09-03	CFM
CFM56-2C, 5A, 5B	X	X	301-464-713-0	Tube, Guide Speed Sensor No. 1	72-23-12	CFM
CFM56-2C, 5A, 5B	X		301-543-403-0	Manifold, Oil	72-09-03	CFM
CFM56-2C, 5A, 5B	X	X	301-547-206-0	Bearing, Plain	72-23-06	CFM
CFM56-2C, 5A, 5B	X		305-037-204-0	Tube, Guide	72-23-24	CFM
CFM56-2C, 5A, 5B	X		305-321-802-0	Bracket	72-09-04	CFM
CFM56-2C, 5A, 5B	X		305-321-902-0	Bracket	72-09-04	CFM
CFM56-2C, 5A, 5B	X	X	305-397-001-0	Tube, Oil to IGB	72-09-03	CFM
CFM56-2C, 5A, 5B, 5C	X		1324M38G01	Bracket	72-09-04	CFM
CFM56-2C, 5A, 5B, 5C	X		1621M82G01	Tube, Drain Fuel	72-09-03	CFM
CFM56-2C, 5A, 5B, 5C	X		9009M29P01	Support	72-63-14	CFM
CFM56-2C, 5A, 5B, 5C	X	X	9393M59G05	Manifold, Fuel Ring (RH)	72-09-03	CFM
CFM56-2C, 5A, 5B, 5C	X	X	9394M34G01	Tube, Drain Fuel	72-09-03	CFM
CFM56-3	X		1155M48P001A	Bracket	72-09-04	CFM
CFM56-3	X		1155M48P001B	Bracket	72-09-04	CFM
CFM56-3	X		1276M25P01	Coupling, Feedback Variable Stator	72-32-13	CFM
CFM56-3	X		1283M36P001A	Bracket	72-09-04	CFM
CFM56-3	X		1283M39P001A	Bracket	72-09-04	CFM
CFM56-3	X		1283M39P003A	Bracket	72-09-04	CFM
CFM56-3	X		1318M95G01	Bracket	72-09-04	CFM
CFM56-3	X		1443M11G01	Tube, Air Start Bleed Inlet	72-09-03	CFM
CFM56-3	X		1443M15G01	Bracket	72-09-04	CFM
CFM56-3	X		1443M18G01	Tube, Air Signal Start Bleed	72-09-03	CFM
CFM56-3	X		1443M20P001A	Bracket	72-09-04	CFM
CFM56-3	X		1443M36G01	Bracket	72-09-04	CFM
CFM56-3	X		1443M36G03	Bracket	72-09-04	CFM
CFM56-3	X		1443M82P01	Tube, Air Start Bleed Inlet	72-09-03	CFM
CFM56-3	X		1444M59G01	Tube, Air Signal Start Bleed	72-09-03	CFM
CFM56-3	X		1444M61G01	Bracket	72-09-04	CFM
CFM56-3	X		1444M64G03	Baffle, Air Start Bleed	72-09-04	CFM
CFM56-3	X		1446M84G01	Tube	72-09-03	CFM
CFM56-3	X		1466M14G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-3	X		1466M23P001A	Bracket	72-09-04	CFM
CFM56-3	X		1466M24G01	Bracket	72-09-04	CFM
CFM56-3	X		1466M31G01	Bracket	72-09-04	CFM
CFM56-3	X		1466M37G01	Bracket	72-09-04	CFM
CFM56-3	X		1466M54G01	Tube, Air Signal Start Bleed	72-09-03	CFM
CFM56-3	X		1466M57G01	Bracket	72-09-04	CFM
CFM56-3	X		1466M58G01	Bracket	72-09-04	CFM
CFM56-3	X		1466M59G01	Bracket	72-09-04	CFM
CFM56-3	X		1466M61G01	Bracket	72-09-04	CFM
CFM56-3	X		1466M62G01	Bracket	72-09-04	CFM
CFM56-3	X		1466M63G01	Bracket	72-09-04	CFM
CFM56-3	X		1466M64G01	Bracket	72-09-04	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-3	X		1466M65G01	Bracket	72-09-04	CFM
CFM56-3	X		1466M68G01	Bracket	72-09-04	CFM
CFM56-3	X		1466M69G01	Bracket	72-09-04	CFM
CFM56-3	X		1466M70G01	Bracket	72-09-04	CFM
CFM56-3	X		1466M72G01	Bracket	72-09-04	CFM
CFM56-3	X		1466M77G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-3	X		1466M78G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-3	X		1466M83G01	Tube, Drain Fuel Supply	72-09-03	CFM
CFM56-3	X		1466M85G01	Bracket	72-09-04	CFM
CFM56-3	X		1466M86G01	Bracket	72-09-04	CFM
CFM56-3	X	X	1466M88G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-3	X		1466M89G01	Bracket	72-09-04	CFM
CFM56-3	X		1590M32G04	Shaft, HPC Front	72-31-07	CFM
CFM56-3	X		1895M18G06	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-3	X		1895M18G11	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-3	X		1895M18G12	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-3	X		1895M18G21	Manifold, Air HPT Clearance Control	72-09-03	CFM
CFM56-3	X		1895M18G22	Manifold, Air HPT Clearance Control	72-09-03	CFM
CFM56-3	X		1895M48G02	Bracket, Hinged	72-09-04	CFM
CFM56-3	X		1895M49G01	Bracket, Hinged	72-09-04	CFM
CFM56-3	X		1896M95G06	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-3	X		1971M20G01	Bracket	72-09-04	CFM
CFM56-3	X		1971M32G01	Tube, Air Signal Start Bleed	72-09-03	CFM
CFM56-3	X		2028M21P01	Coupling	72-32-13	CFM
CFM56-3	X		2028M21P02	Coupling, Feedback	72-32-13	CFM
CFM56-3	X		2046M50G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-3	X		2046M51G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-3	X		2046M52G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-3	X		2046M61G01	Manifold, Air HPT Clearance Control	72-09-03	CFM
CFM56-3	X		2283M48G01	Tube, Drain VSV	72-09-03	CFM
CFM56-3	X		301-331-226-0	Disk, LPT Stage 2	72-54-03	CFM
CFM56-3	X		301-409-807-0	Cover, Cooling Air Manifold	72-54-20	CFM
CFM56-3	X		305-050-906-0	Tube, Oil	72-09-03	CFM
CFM56-3	X		305-050-907-0	Tube, Oil	72-09-03	CFM
CFM56-3	X		332A1900-22	Bracket	71-00-04	Boeing
CFM56-3	X		332A1900-37	Bracket	71-00-04	Boeing
CFM56-3	X		332A1901-33	Bracket	71-00-04	Boeing
CFM56-3	X		332A1901-48	Bracket	71-00-04	Boeing
CFM56-3	X		332A1902-32	Bracket	71-00-04	Boeing
CFM56-3	X		332A1902-33	Bracket	71-00-04	Boeing
CFM56-3	X		332A1903-4	Bracket	71-00-04	Boeing
CFM56-3	X		332A1903-69	Bracket	71-00-04	Boeing
CFM56-3	X		332A1905-18	Bracket	71-00-04	Boeing
CFM56-3	X		332A1907-14	Bracket	71-00-04	Boeing
CFM56-3	X		332A1907-15	Bracket	71-00-04	Boeing
CFM56-3	X		332A1908-58	Deflector, QEC	71-00-04	Boeing
CFM56-3	X		332A1911-1	Bracket	71-00-04	Boeing
CFM56-3	X		332A1911-3	Bracket	71-00-04	Boeing
CFM56-3	X		332A1913-17	Bracket	71-00-04	Boeing
CFM56-3	X		332A1913-4	Bracket	71-00-04	Boeing
CFM56-3	X		334-007-110-0	Shaft, Inner Drive	72-23-06	CFM
CFM56-3	X		335-002-304-0	Blade, Fan BSTR Rotor Stg 2	72-21-02	CFM
CFM56-3	X		335-002-305-0	Blade, Fan BSTR Rotor Stg 2	72-21-02	CFM
CFM56-3	X		335-002-405-0	Blade, Fan BSTR Rotor Stg 3	72-21-02	CFM
CFM56-3	X		335-002-407-0	Blade, Fan BSTR Rotor Stg 3	72-21-02	CFM
CFM56-3	X		335-002-505-0	Blade, Fan BSTR Rotor Stg 4	72-21-02	CFM
CFM56-3	X		335-003-304-0	Support, Assy No. 1 Bearing	72-22-02	CFM
CFM56-3	X		335-003-305-0	Support, Assy No. 1 Bearing	72-22-02	CFM
CFM56-3	X		335-003-308-0	Support, Assy No. 1 Bearing	72-22-02	CFM
CFM56-3	X		335-009-804-0	Seal, Air Forward & Aft Rotor	72-21-08	CFM
CFM56-3	X		335-009-805-0	Seal, Air Forward & Aft Rotor	72-21-08	CFM
CFM56-3	X		335-009-903-0	Seal, Air Forward & Aft Rotor	72-21-08	CFM
CFM56-3	X		335-010-002-0	Spacer, Booster Spool	72-21-07	CFM
CFM56-3	X		335-010-102-0	Support, Assy No. 2 Bearing	72-22-03	CFM
CFM56-3	X		335-010-104-0	Support, Assy No. 2 Bearing	72-22-03	CFM
CFM56-3	X		335-010-402-0	Tube, Drain	72-22-08	CFM
CFM56-3	X		335-011-004-0	Fairing	72-23-04	CFM
CFM56-3	X		335-011-005-0	Fairing	72-23-04	CFM
CFM56-3	X		335-011-021-0	Fairing	72-23-04	CFM
CFM56-3	X		335-011-205-0	Cone, Spinner Rear	72-21-05	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-3	X		335-011-207-0	Cone, Spinner Rear	72-21-05	CFM
CFM56-3	X	X	335-011-208-0	Cone, Spinner Rear	72-21-05	CFM
CFM56-3	X		335-011-305-0	Panel, Forward	72-23-08	CFM
CFM56-3	X	X	335-011-307-0	Panel, Forward	72-23-08	CFM
CFM56-3	X		335-011-903-0	Panel, Acoustical Mid	72-23-08	CFM
CFM56-3	X		335-011-904-0	Panel, Acoustical Mid	72-23-08	CFM
CFM56-3	X		335-016-301-0	Tube	72-23-12	CFM
CFM56-3	X		335-016-501-0	Tube, Guide	72-23-12	CFM
CFM56-3	X		335-016-601-0	Tube, Supply Oil	72-23-12	CFM
CFM56-3	X		335-016-602-0	Tube, Supply Oil	72-09-03	CFM
CFM56-3	X		335-017-202-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-017-207-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-017-209-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-017-212-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-017-303-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-017-310-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-017-312-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-017-315-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X	X	335-017-403-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X	X	335-017-409-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X	X	335-017-410-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X	X	335-017-413-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X	X	335-017-416-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-019-021-0	Fairing	72-23-04	CFM
CFM56-3	X		335-020-901-0	Bracket	72-09-04	CFM
CFM56-3	X		335-020-902-0	Bracket	72-09-04	CFM
CFM56-3	X		335-020-902-6	Bracket	72-09-04	CFM
CFM56-3	X		335-021-001-0	Bracket	72-09-04	CFM
CFM56-3	X		335-021-002-0	Bracket	72-09-04	CFM
CFM56-3	X		335-021-002-6	Bracket	72-09-04	CFM
CFM56-3	X		335-021-102-6	Bracket	72-09-04	CFM
CFM56-3	X		335-022-802-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-022-806-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-022-808-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-022-811-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-022-903-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-022-908-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-022-909-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-022-911-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-022-914-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X	X	335-023-603-0	Spacer, Fan Blade	72-21-10	CFM
CFM56-3	X		335-023-604-0	Spacer, Fan Blade	72-21-10	CFM
CFM56-3	X		335-023-605-0	Spacer, Fan Blade	72-21-10	CFM
CFM56-3	X		335-023-607-0	Spacer, Fan Blade	72-21-10	CFM
CFM56-3	X		335-025-701-0	Spacer	72-21-15	CFM
CFM56-3	X		335-030-602-0	Housing, Inner Rad Dr Sft	72-23-05	CFM
CFM56-3	X		335-030-701-0	Housing Fan	72-23-05	CFM
CFM56-3	X		335-031-111-0	Panel, Fan Duct	72-23-07	CFM
CFM56-3	X		335-031-201-0	Panel, Fan Duct	72-23-07	CFM
CFM56-3	X	X	335-031-211-0	Panel, Fan Duct	72-23-07	CFM
CFM56-3	X		335-031-301-0	Panel, Fan Duct	72-23-07	CFM
CFM56-3	X		335-031-311-0	Panel, Fan Duct	72-23-07	CFM
CFM56-3	X		335-031-501-0	Panel, Fan Duct	72-23-07	CFM
CFM56-3	X	X	335-031-502-0	Panel, Fan Duct	72-23-07	CFM
CFM56-3	X		335-031-601-0	Panel, Fan Duct	72-23-07	CFM
CFM56-3	X		335-031-611-0	Panel, Fan Duct	72-23-07	CFM
CFM56-3	X		335-031-701-0	Tube, Guide	72-23-12	CFM
CFM56-3	X		335-032-102-0	Tube, Guide	72-23-12	CFM
CFM56-3	X		335-032-401-0	Tube, Seal Drain	72-09-03	CFM
CFM56-3	X		335-032-403-0	Tube, Seal Drain	72-09-03	CFM
CFM56-3	X		335-032-405-0	Tube, Seal Drain	72-09-03	CFM
CFM56-3	X		335-032-406-0	Tube, Seal Drain	72-09-03	CFM
CFM56-3	X		335-033-601-0	Tube, Guide No. 1 Speed Sensor	72-23-12	CFM
CFM56-3	X	X	335-034-101-0	Panel, Fan Duct	72-23-07	CFM
CFM56-3	X		335-034-111-0	Panel, Fan Duct	72-23-07	CFM
CFM56-3	X		335-034-201-0	Panel, Fan Duct	72-23-07	CFM
CFM56-3	X		335-034-209-0	Panel, Fan Duct	72-23-07	CFM
CFM56-3	X		335-034-501-0	OGV	72-23-03	CFM
CFM56-3	X		335-034-502-0	OGV	72-23-03	CFM
CFM56-3	X		335-034-503-0	OGV	72-23-03	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-3	X		335-034-604-0	OGV	72-23-03	CFM
CFM56-3	X		335-034-605-0	OGV	72-23-03	CFM
CFM56-3	X		335-034-606-0	OGV	72-23-03	CFM
CFM56-3	X		335-034-621-0	OGV	72-23-03	CFM
CFM56-3	X		335-034-622-0	OGV	72-23-03	CFM
CFM56-3	X		335-034-623-0	OGV	72-23-03	CFM
CFM56-3	X		335-034-624-0	OGV	72-23-03	CFM
CFM56-3	X		335-034-701-0	OGV	72-23-03	CFM
CFM56-3	X		335-034-702-0	OGV	72-23-03	CFM
CFM56-3	X		335-034-703-0	OGV	72-23-03	CFM
CFM56-3	X		335-035-001-0	Bracket	72-09-04	CFM
CFM56-3	X		335-035-003-0	Bracket	72-09-04	CFM
CFM56-3	X		335-035-004-0	Bracket	72-09-04	CFM
CFM56-3	X		335-035-005-0	Bracket	72-09-04	CFM
CFM56-3	X		335-035-101-0	Bracket	72-09-04	CFM
CFM56-3	X		335-035-103-0	Bracket	72-09-04	CFM
CFM56-3	X		335-035-104-0	Bracket	72-09-04	CFM
CFM56-3	X		335-035-105-0	Bracket	72-09-04	CFM
CFM56-3	X		335-038-003-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-038-009-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-038-010-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-038-012-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-038-015-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-038-103-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-038-109-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-038-110-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-038-112-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-038-115-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-038-203-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-038-210-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-038-212-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-038-215-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-038-217-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-038-303-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-038-310-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-038-311-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-038-313-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-038-316-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-039-101-0	Tube, Scavenge Oil	72-23-12	CFM
CFM56-3	X		335-063-104-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-063-109-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-063-111-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-063-113-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-063-115-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-063-606-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-063-610-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-063-611-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-063-613-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-063-616-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-3	X		335-063-902-0	Skin, Fillet	72-23-09	CFM
CFM56-3	X		335-064-101-0	Bracket	72-09-04	CFM
CFM56-3	X		335-064-301-0	Bracket	72-09-04	CFM
CFM56-3	X		335-066-701-0	Tube, Seal Drain Overboard	72-56-05	CFM
CFM56-3	X		335-070-203-0	Bracket	72-09-04	CFM
CFM56-3	X		335-072-801-0	Tube, Oil to IGB	72-09-03	CFM
CFM56-3	X		335-073-201-0	Manifold, No. 3 Bearing Oil Supply	72-23-18	CFM
CFM56-3	X		335-075-301-0	Tube, Supply Oil	72-09-03	CFM
CFM56-3	X		335-075-302-0	Tube, Supply Oil	72-09-03	CFM
CFM56-3	X		335-075-501-0	Tube	72-09-03	CFM
CFM56-3	X		335-075-901-0	Tube, Scavenge Oil	72-09-03	CFM
CFM56-3	X		335-076-702-0	Bracket	72-09-04	CFM
CFM56-3	X		335-076-703-0	Bracket	72-23-15	CFM
CFM56-3	X		335-076-802-0	Bracket	72-09-04	CFM
CFM56-3	X		335-076-803-0	Bracket	72-09-04	CFM
CFM56-3	X		335-077-001-0	Mount, Gearbox Rear Assy	72-23-15	CFM
CFM56-3	X		335-077-201-0	Pin, Straight Assy	72-63-18	CFM
CFM56-3	X		335-077-501-0	Link, Rod Assy	72-23-14	CFM
CFM56-3	X		335-077-502-0	Link, Rod Assy	72-23-14	CFM
CFM56-3	X		335-077-510-0	Link, Rod Assy	72-23-14	CFM
CFM56-3	X		335-077-710-0	Rod	72-23-14	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-3	X		335-078-102-0	Bearing, Rod End	72-23-14	CFM
CFM56-3	X		335-078-103-0	Bearing, Rod End	72-23-14	CFM
CFM56-3	X		335-078-110-0	Bearing, Rod End	72-23-14	CFM
CFM56-3	X		335-078-302-0	Bearing, Rod End	72-23-14	CFM
CFM56-3	X		335-078-303-0	Bearing, Rod End	72-23-14	CFM
CFM56-3	X		335-078-310-0	Bearing, Rod End	72-23-14	CFM
CFM56-3	X		335-079-102-6	Bracket	72-09-04	CFM
CFM56-3	X		335-079-202-6	Bracket	72-09-04	CFM
CFM56-3	X		335-081-104-0	Bracket	72-09-04	CFM
CFM56-3	X		335-081-105-0	Bracket	72-09-04	CFM
CFM56-3	X		335-081-106-0	Bracket	72-09-04	CFM
CFM56-3	X		335-081-107-0	Bracket	72-09-04	CFM
CFM56-3	X		335-081-107-6	Bracket	72-09-04	CFM
CFM56-3	X		335-081-108-0	Bracket	72-09-04	CFM
CFM56-3	X		335-081-108-6	Bracket	72-09-04	CFM
CFM56-3	X		335-081-109-0	Bracket	72-09-04	CFM
CFM56-3	X		335-081-109-6	Bracket	72-09-04	CFM
CFM56-3	X		335-081-204-0	Bracket	72-09-04	CFM
CFM56-3	X		335-081-205-0	Bracket	72-09-04	CFM
CFM56-3	X		335-081-206-0	Bracket	72-09-04	CFM
CFM56-3	X		335-081-207-0	Bracket	72-09-04	CFM
CFM56-3	X		335-081-207-6	Bracket	72-09-04	CFM
CFM56-3	X		335-081-208-0	Bracket	72-09-04	CFM
CFM56-3	X		335-081-208-6	Bracket	72-09-04	CFM
CFM56-3	X		335-081-209-0	Bracket	72-09-04	CFM
CFM56-3	X		335-081-209-6	Bracket	72-09-04	CFM
CFM56-3	X		335-081-401-0	Bracket	72-09-04	CFM
CFM56-3	X		335-084-803-0	Panel, Fan Duct	72-23-07	CFM
CFM56-3	X		335-084-903-0	Panel, Fan Duct	72-23-07	CFM
CFM56-3	X		335-085-003-0	Panel, Fan Duct	72-23-07	CFM
CFM56-3	X		335-085-103-0	Panel, Fan Duct	72-23-07	CFM
CFM56-3	X		335-085-201-0	Mount, Accessory Drive Clevis	72-23-15	CFM
CFM56-3	X		335-085-401-0	Bracket	72-09-04	CFM
CFM56-3	X		335-085-402-0	Bracket	72-09-04	CFM
CFM56-3	X		335-085-501-0	Bracket	72-09-04	CFM
CFM56-3	X		335-085-502-0	Bracket	72-09-04	CFM
CFM56-3	X		335-086-705-0	Bracket	72-09-04	CFM
CFM56-3	X		335-086-707-0	Bracket	72-09-04	CFM
CFM56-3	X		335-088-002-0	Spacer, Fan Disk	72-21-14	CFM
CFM56-3	X		335-104-303-0	Tube, Oil	72-09-03	CFM
CFM56-3	X		335-105-201-0	Stop, Axial	72-21-14	CFM
CFM56-3	X	X	335-105-305-0	Damper, Assembly	72-21-16	CFM
CFM56-3	X	X	335-105-306-0	Damper	72-21-16	CFM
CFM56-3	X	X	335-106-402-0	Cone, Spinner Front	72-21-05	CFM
CFM56-3	X		335-106-403-0	Cone, Spinner Front	72-21-05	CFM
CFM56-3	X		335-106-404-0	Cone, Spinner Front	72-21-05	CFM
CFM56-3	X		335-106-405-0	Cone, Spinner Front	72-21-05	CFM
CFM56-3	X		335-107-501-0	Shim, Fan Blade	72-21-22	CFM
CFM56-3	X		335-107-504-0	Shim	72-21-22	CFM
CFM56-3	X		335-107-732-0	Slide	72-23-37	CFM
CFM56-3	X		335-107-742-0	Slide	72-23-37	CFM
CFM56-3	X		335-107-752-0	Slide	72-23-37	CFM
CFM56-3	X		335-107-762-0	Slide	72-23-37	CFM
CFM56-3	X		335-109-101-0	Slide	72-23-37	CFM
CFM56-3	X		335-109-201-0	Slide	72-23-37	CFM
CFM56-3	X		335-109-301-0	Slide	72-23-37	CFM
CFM56-3	X		335-109-401-0	Slide	72-23-37	CFM
CFM56-3	X		335-180-001-0	Bracket	72-09-04	CFM
CFM56-3	X		335-180-101-0	Bracket	72-09-04	CFM
CFM56-3	X		335-180-201-0	Bracket	72-09-04	CFM
CFM56-3	X		335-180-601-0	Bracket	72-09-04	CFM
CFM56-3	X		335-181-201-0	Tube, Fuel Nozzle Supply	72-09-03	CFM
CFM56-3	X		335-181-402-0	Bracket	72-09-04	CFM
CFM56-3	X		335-181-602-0	Bracket	72-09-04	CFM
CFM56-3	X		335-181-802-0	Bracket	72-09-04	CFM
CFM56-3	X		335-195-110-0	Bracket	72-09-04	CFM
CFM56-3	X		335-196-210-0	Bracket	72-09-04	CFM
CFM56-3	X		335-197-410-0	Bracket	72-09-04	CFM
CFM56-3	X		335-197-710-0	Bracket	72-09-04	CFM
CFM56-3	X		335-199-701-0	Bracket	72-09-04	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-3	X		335-199-702-0	Bracket	72-09-04	CFM
CFM56-3	X		335-199-703-0	Bracket	72-09-04	CFM
CFM56-3	X		335-199-802-0	Bracket	72-09-04	CFM
CFM56-3	X		335-199-902-0	Bracket	72-09-04	CFM
CFM56-3	X		335-200-001-0	Bracket	72-09-04	CFM
CFM56-3	X		335-200-002-0	Bracket	72-09-04	CFM
CFM56-3	X		335-200-301-0	Bracket	72-09-04	CFM
CFM56-3	X		335-200-302-0	Bracket	72-09-04	CFM
CFM56-3	X		335-200-303-0	Bracket	72-09-04	CFM
CFM56-3	X		335-200-501-0	Bracket	72-09-04	CFM
CFM56-3	X		335-200-502-0	Bracket	72-09-04	CFM
CFM56-3	X		335-200-503-0	Bracket	72-09-04	CFM
CFM56-3	X		335-200-601-0	Bracket	72-09-04	CFM
CFM56-3	X		335-200-602-0	Bracket	72-09-04	CFM
CFM56-3	X		335-200-603-0	Bracket	72-09-04	CFM
CFM56-3	X		335-200-701-0	Bracket	72-09-04	CFM
CFM56-3	X		335-200-702-0	Bracket	72-09-04	CFM
CFM56-3	X		335-200-801-0	Bracket	72-09-04	CFM
CFM56-3	X		335-200-802-0	Bracket	72-09-04	CFM
CFM56-3	X		335-200-803-0	Bracket	72-09-04	CFM
CFM56-3	X		335-200-804-0	Bracket	72-09-04	CFM
CFM56-3	X		335-200-901-0	Bracket	72-09-04	CFM
CFM56-3	X		335-200-902-0	Bracket	72-09-04	CFM
CFM56-3	X		335-200-903-0	Bracket	72-09-04	CFM
CFM56-3	X		335-201-101-0	Bracket	72-09-04	CFM
CFM56-3	X		335-201-102-0	Bracket	72-09-04	CFM
CFM56-3	X		335-201-103-0	Bracket	72-09-04	CFM
CFM56-3	X		335-201-104-0	Bracket	72-09-04	CFM
CFM56-3	X		335-201-310-0	Bracket	72-09-04	CFM
CFM56-3	X		335-201-410-0	Bracket	72-09-04	CFM
CFM56-3	X		335-201-510-0	Bracket	72-09-04	CFM
CFM56-3	X		335-201-610-0	Bracket	72-09-04	CFM
CFM56-3	X		335-201-801-0	Bracket	72-09-04	CFM
CFM56-3	X		335-201-802-0	Bracket	72-09-04	CFM
CFM56-3	X		335-201-803-0	Bracket	72-09-04	CFM
CFM56-3	X		335-201-804-0	Bracket	72-09-04	CFM
CFM56-3	X		335-202-001-0	Bracket	72-09-04	CFM
CFM56-3	X		335-202-002-0	Bracket	72-09-04	CFM
CFM56-3	X		335-202-003-0	Bracket	72-09-04	CFM
CFM56-3	X		335-202-004-0	Bracket	72-09-04	CFM
CFM56-3	X		335-202-007-0	Bracket	72-09-04	CFM
CFM56-3	X		335-202-008-0	Bracket	72-09-04	CFM
CFM56-3	X		335-202-201-0	Bracket	72-09-04	CFM
CFM56-3	X		335-202-202-0	Bracket	72-09-04	CFM
CFM56-3	X		335-202-203-0	Bracket	72-09-04	CFM
CFM56-3	X		335-204-001-0	Tube, PBP	72-09-03	CFM
CFM56-3	X		335-204-002-0	Tube, PBP	72-09-03	CFM
CFM56-3	X		335-204-201-0	Tube, PBP	72-09-03	CFM
CFM56-3	X		335-204-204-0	Tube, PB	72-09-03	CFM
CFM56-3	X		335-204-208-0	Tube, PB	72-09-03	CFM
CFM56-3	X		335-204-401-0	Tube, PC	72-09-03	CFM
CFM56-3	X		335-204-601-0	Tube, PC	72-09-03	CFM
CFM56-3	X		335-204-603-0	Tube, PC	72-09-03	CFM
CFM56-3	X		335-204-801-0	Tube, TC3	72-09-03	CFM
CFM56-3	X		335-204-811-0	Tube, TC3	72-09-03	CFM
CFM56-3	X		335-205-001-0	Tube, TC3	72-09-03	CFM
CFM56-3	X		335-205-004-0	Tube, TC3	72-09-03	CFM
CFM56-3	X		335-205-005-0	Tube, TC3	72-09-03	CFM
CFM56-3	X		335-205-006-0	Tube, TC3	72-09-03	CFM
CFM56-3	X		335-205-201-0	Tube, TC2	72-23-11	CFM
CFM56-3	X		335-205-401-0	Tube, TC2	72-09-03	CFM
CFM56-3	X		335-205-402-0	Tube, TC2	72-09-03	CFM
CFM56-3	X		335-205-601-0	Tube, TC1	72-09-03	CFM
CFM56-3	X	X	335-205-801-0	Tube, TC1	72-09-03	CFM
CFM56-3	X		335-206-001-0	Tube, TC1	72-09-03	CFM
CFM56-3	X		335-206-003-0	Tube, TC1	72-09-03	CFM
CFM56-3	X		335-206-201-0	Tube, TS5	72-09-03	CFM
CFM56-3	X		335-206-401-0	Tube, TS9	72-09-03	CFM
CFM56-3	X		335-206-601-0	Tube, PB	72-09-03	CFM
CFM56-3	X		335-208-801-0	Tube, PB	72-23-11	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-3	X		335-208-803-0	Tube, PB	72-23-11	CFM
CFM56-3	X		335-208-805-0	Tube, PB	72-23-11	CFM
CFM56-3	X		335-209-502-0	Bracket	72-09-04	CFM
CFM56-3	X		335-209-702-0	Bracket	72-09-04	CFM
CFM56-3	X		335-210-201-0	Bracket	72-09-04	CFM
CFM56-3	X		335-210-202-0	Bracket	72-09-04	CFM
CFM56-3	X		335-210-203-0	Bracket	72-09-04	CFM
CFM56-3	X		335-210-301-0	Bracket	72-09-04	CFM
CFM56-3	X		335-210-302-0	Bracket	72-09-04	CFM
CFM56-3	X		335-210-502-0	Bracket	72-09-04	CFM
CFM56-3	X		335-210-503-0	Bracket	72-09-04	CFM
CFM56-3	X		335-210-701-0	Bracket	72-09-04	CFM
CFM56-3	X		335-210-702-0	Bracket	72-09-04	CFM
CFM56-3	X		335-210-804-0	Bracket	72-09-04	CFM
CFM56-3	X		335-211-002-0	Bracket	72-09-04	CFM
CFM56-3	X		335-212-601-0	Bracket	72-09-04	CFM
CFM56-3	X		335-212-701-0	Bracket	72-09-04	CFM
CFM56-3	X		335-212-801-0	Bracket	72-09-04	CFM
CFM56-3	X		335-213-501-0	Bracket	72-09-04	CFM
CFM56-3	X		335-213-502-0	Bracket	72-09-04	CFM
CFM56-3	X		335-214-901-0	Tube, TC1 Shunt	72-09-03	CFM
CFM56-3	X		335-214-902-0	Tube, TC1 Shunt	72-09-03	CFM
CFM56-3	X		335-215-101-0	Tube, TC2 Shunt	72-09-03	CFM
CFM56-3	X		335-216-301-0	Tube, Fuel Supply Assy	72-09-03	CFM
CFM56-3	X		335-216-302-0	Tube, Fuel Supply Assy	72-09-03	CFM
CFM56-3	X		335-216-401-0	Tube, Fuel Noz Supply Assy	72-09-03	CFM
CFM56-3	X		335-216-402-0	Tube, Fuel Noz Supply Assy	72-09-03	CFM
CFM56-3	X		335-216-403-0	Tube, Fuel Noz Supply Assy	72-09-03	CFM
CFM56-3	X		335-216-603-0	Elbow, Special	72-09-04	CFM
CFM56-3	X		335-217-701-0	Bracket	72-09-04	CFM
CFM56-3	X		335-217-702-0	Bracket	72-09-04	CFM
CFM56-3	X		335-217-801-0	Bracket	72-09-04	CFM
CFM56-3	X		335-217-802-0	Bracket	72-09-04	CFM
CFM56-3	X		335-217-806-0	Bracket	72-09-04	CFM
CFM56-3	X		335-218-101-0	Bracket	72-09-04	CFM
CFM56-3	X		335-218-102-0	Bracket	72-09-04	CFM
CFM56-3	X		335-218-801-0	Bracket	72-09-04	CFM
CFM56-3	X		335-218-802-0	Bracket	72-09-04	CFM
CFM56-3	X		335-219-301-0	Bracket	72-09-04	CFM
CFM56-3	X		335-219-305-0	Bracket	72-09-04	CFM
CFM56-3	X		335-219-701-0	Bracket	72-09-04	CFM
CFM56-3	X		335-219-704-0	Bracket	72-09-04	CFM
CFM56-3	X		335-221-702-0	Tube, Stage 5 Bleed	72-09-03	CFM
CFM56-3	X		335-221-903-0	Tube, Stage 5 Bleed	72-09-03	CFM
CFM56-3	X		335-222-301-0	Bracket	72-09-04	CFM
CFM56-3	X		335-222-501-0	Bracket	72-09-04	CFM
CFM56-3	X		335-222-601-0	Bracket	72-09-04	CFM
CFM56-3	X		335-222-901-0	Bracket	72-09-04	CFM
CFM56-3	X		335-223-201-0	Bracket	72-09-04	CFM
CFM56-3	X		335-224-002-0	Tube, Stage 5 Bleed	72-09-03	CFM
CFM56-3	X		335-224-301-0	Hose, Oil Front Bearing Supply	72-09-03	CFM
CFM56-3	X		335-224-350-0	Hose, Oil Front Bearing Supply	72-09-03	CFM
CFM56-3	X		335-224-505-0	Tube, TC3	72-09-03	CFM
CFM56-3	X		335-224-508-0	Tube, TC3	72-09-03	CFM
CFM56-3	X		335-224-704-0	Tube, PB	72-09-03	CFM
CFM56-3	X		335-224-707-0	Tube, PB	72-09-03	CFM
CFM56-3	X		335-224-903-0	Bracket	72-09-04	CFM
CFM56-3	X		335-225-401-0	Bracket	72-09-04	CFM
CFM56-3	X		335-225-501-0	Bracket	72-09-04	CFM
CFM56-3	X		335-225-701-0	Bracket	72-09-04	CFM
CFM56-3	X		335-225-902-0	Bracket	72-09-04	CFM
CFM56-3	X		335-226-401-0	Bracket	72-09-04	CFM
CFM56-3	X		335-226-501-0	Bracket	72-09-04	CFM
CFM56-3	X		335-227-602-0	Hose, Oil Tank Overflow	72-09-03	CFM
CFM56-3	X		335-227-650-0	Hose, Oil Tank Overflow	72-09-03	CFM
CFM56-3	X		335-227-802-0	Tube, Oil Filling	72-09-03	CFM
CFM56-3	X		335-228-901-0	Bracket	72-09-04	CFM
CFM56-3	X		335-229-002-0	Shield, Heat	72-09-04	CFM
CFM56-3	X		335-230-001-0	Bracket	72-09-04	CFM
CFM56-3	X		335-234-201-0	Bracket	72-09-04	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-3	X		335-234-402-0	Bracket	72-09-04	CFM
CFM56-3	X	X	335-235-301-0	Tube, Shunt	72-09-03	CFM
CFM56-3	X		335-235-604-0	Bracket	72-09-04	CFM
CFM56-3	X		335-235-901-0	Bracket	72-09-04	CFM
CFM56-3	X		335-236-201-0	Bracket	72-09-04	CFM
CFM56-3	X		335-236-301-0	Bracket	72-09-04	CFM
CFM56-3	X		335-236-701-0	Bracket	72-09-04	CFM
CFM56-3	X		335-236-801-0	Bracket	72-09-04	CFM
CFM56-3	X		335-236-802-0	Bracket	72-09-04	CFM
CFM56-3	X		335-236-901-0	Bracket	72-09-04	CFM
CFM56-3	X		335-237-001-0	Bracket	72-09-04	CFM
CFM56-3	X		335-237-101-0	Bracket	72-09-04	CFM
CFM56-3	X		335-237-202-0	Bracket	72-09-04	CFM
CFM56-3	X		335-237-301-0	Bracket	72-09-04	CFM
CFM56-3	X		335-237-401-0	Bracket	72-09-04	CFM
CFM56-3	X		335-237-501-0	Tube, PS12	72-09-03	CFM
CFM56-3	X		335-237-601-0	Bracket	72-09-04	CFM
CFM56-3	X		335-241-905-0	Bracket	72-09-04	CFM
CFM56-3	X		335-245-202-0	Bracket	72-09-04	CFM
CFM56-3	X		335-245-700-0	Bracket	72-23-35	CFM
CFM56-3	X		335-245-701-0	Bracket	72-09-04	CFM
CFM56-3	X		335-246-000-0	Bracket	72-23-35	CFM
CFM56-3	X		335-246-001-0	Bracket	72-09-04	CFM
CFM56-3	X		335-246-300-0	Bracket	72-23-35	CFM
CFM56-3	X		335-246-301-0	Bracket	72-09-04	CFM
CFM56-3	X		335-246-601-0	Bracket	72-23-35	CFM
CFM56-3	X		335-246-602-0	Bracket	72-23-35	CFM
CFM56-3	X		335-246-903-0	Bracket	72-23-17	CFM
CFM56-3	X		335-246-904-0	Bracket	72-09-04	CFM
CFM56-3	X		335-247-003-0	Bracket	72-09-04	CFM
CFM56-3	X		335-247-103-0	Bracket	72-23-17	CFM
CFM56-3	X		335-247-104-0	Bracket	72-09-04	CFM
CFM56-3	X		335-247-203-0	Bracket	72-09-04	CFM
CFM56-3	X		335-247-602-0	Bracket	72-09-04	CFM
CFM56-3	X		335-247-603-0	Bracket	72-23-17	CFM
CFM56-3	X		335-247-604-0	Bracket	72-09-04	CFM
CFM56-3	X		335-247-702-0	Bracket	72-23-17	CFM
CFM56-3	X		335-247-703-0	Bracket	72-23-17	CFM
CFM56-3	X		335-247-704-0	Bracket	72-09-04	CFM
CFM56-3	X		335-249-001-0	Hose, Fuel Actuator Return	72-09-03	CFM
CFM56-3	X		335-249-050-0	Hose, Fuel Actuator Return	72-09-03	CFM
CFM56-3	X		335-250-208-0	Tube, CIT Sensor Supply PB	72-09-03	CFM
CFM56-3	X		335-250-211-0	Tube, CIT Sensor Supply PB	72-09-03	CFM
CFM56-3	X		335-250-406-0	Tube, CIT Sensor	72-09-03	CFM
CFM56-3	X		335-250-407-0	Tube, CIT Sensor	72-09-03	CFM
CFM56-3	X		335-251-002-0	Tube, Close VSV	72-09-03	CFM
CFM56-3	X	X	335-251-003-0	Tube, Close VSV	72-09-03	CFM
CFM56-3	X		335-251-005-0	Tube, Close VSV	72-09-03	CFM
CFM56-3	X		335-251-203-0	Tube, Air CBP	72-09-03	CFM
CFM56-3	X		335-251-204-0	Tube, Air CBP	72-09-03	CFM
CFM56-3	X		335-251-602-0	Tube, Fuel VSV Supply	72-09-03	CFM
CFM56-3	X		335-251-603-0	Tube, Fuel VSV Supply	72-09-03	CFM
CFM56-3	X		335-251-803-0	Tube, Fuel VBV Supply	72-09-03	CFM
CFM56-3	X	X	335-251-805-0	Tube, Fuel VBV Supply	72-09-03	CFM
CFM56-3	X		335-251-809-0	Tube, Fuel VBV Supply	72-09-03	CFM
CFM56-3	X		335-252-404-0	Tube, Fuel Return	72-09-03	CFM
CFM56-3	X		335-252-405-0	Tube, Fuel Return	72-09-03	CFM
CFM56-3	X		335-252-407-0	Tube, Fuel Return	72-09-03	CFM
CFM56-3	X		335-252-604-0	Tube, Fuel Stage 5 Bleed Valve	72-09-03	CFM
CFM56-3	X		335-252-605-0	Tube, Fuel Stage 5 Bleed Valve	72-09-03	CFM
CFM56-3	X		335-252-804-0	Tube, Fuel Stage 9 Bleed Valve	72-09-03	CFM
CFM56-3	X		335-252-805-0	Tube, Fuel Stage 9 Bleed Valve	72-09-03	CFM
CFM56-3	X		335-252-806-0	Tube, Fuel Stage 9 Bleed Valve	72-09-03	CFM
CFM56-3	X		335-253-003-0	Tube, Fuel VBV Close	72-09-03	CFM
CFM56-3	X	X	335-253-005-0	Tube, Fuel VBV Close	72-09-03	CFM
CFM56-3	X		335-253-403-0	Tube, Air PS3 Supply	72-09-03	CFM
CFM56-3	X		335-253-404-0	Tube, Air PS3 Supply	72-09-03	CFM
CFM56-3	X		335-254-603-0	Tube, Oil Aft Sump Supply	72-09-03	CFM
CFM56-3	X		335-254-803-0	Tube, Oil Aft Sump Scavenge	72-09-03	CFM
CFM56-3	X		335-255-203-0	Hose, Oil Rear Sump	72-09-03	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-3	X		335-255-251-0	Hose, Oil Rear Sump	72-09-03	CFM
CFM56-3	X		335-255-401-0	Hose, Rear Sump Scavenge	72-09-03	CFM
CFM56-3	X		335-255-404-0	Hose, Rear Sump Scavenge	72-09-03	CFM
CFM56-3	X		335-255-450-0	Hose, Rear Sump Scavenge	72-09-03	CFM
CFM56-3	X		335-255-451-0	Hose, Rear Sump Scavenge	72-09-03	CFM
CFM56-3	X		335-255-452-0	Hose, Rear Sump Scavenge	72-09-03	CFM
CFM56-3	X		335-255-801-0	Hose, Front Bearing Return	72-09-03	CFM
CFM56-3	X		335-255-804-0	Hose, Front Bearing Return	72-09-03	CFM
CFM56-3	X		335-255-850-0	Hose, Front Bearing Return	72-09-03	CFM
CFM56-3	X		335-255-851-0	Hose, Front Bearing Return	72-09-03	CFM
CFM56-3	X		335-256-004-0	Tube Assy, Oil	72-09-03	CFM
CFM56-3	X		335-256-005-0	Tube Assy, Oil	72-09-03	CFM
CFM56-3	X		335-256-203-0	Tube, Anti Siphon	72-09-03	CFM
CFM56-3	X		335-256-204-0	Tube, Anti Siphon	72-09-03	CFM
CFM56-3	X		335-256-402-0	Tube Assy, Air PS12	72-23-11	CFM
CFM56-3	X		335-256-600-0	Tube Assy, Air PS12	72-23-11	CFM
CFM56-3	X		335-256-601-0	Tube Assy, Air PS12	72-09-03	CFM
CFM56-3	X		335-256-800-0	Tube, PS12	72-23-11	CFM
CFM56-3	X		335-256-803-0	Tube, PS12	72-09-03	CFM
CFM56-3	X		335-257-001-0	Tube, PS12	72-23-11	CFM
CFM56-3	X		335-257-200-0	Tube, PS12	72-23-11	CFM
CFM56-3	X		335-257-601-0	Tube, Oil Suction Tank	72-09-03	CFM
CFM56-3	X	X	335-257-602-0	Tube, Oil Suction Tank	72-09-03	CFM
CFM56-3	X		335-257-650-0	Tube, Oil Suction Tank	72-09-03	CFM
CFM56-3	X		335-257-651-0	Tube, Oil Suction Tank	72-09-03	CFM
CFM56-3	X		335-257-652-0	Tube, Oil Suction Tank	72-09-03	CFM
CFM56-3	X		335-257-805-0	Tube, Oil Tank Return	72-09-03	CFM
CFM56-3	X		335-257-808-0	Tube, Oil Tank Return	72-09-03	CFM
CFM56-3	X		335-258-001-0	Tube, Air Ignition	72-09-03	CFM
CFM56-3	X		335-258-002-0	Tube, Air Ignition	72-09-03	CFM
CFM56-3	X		335-258-401-0	Bracket	72-09-04	CFM
CFM56-3	X		335-258-402-0	Bracket	72-09-04	CFM
CFM56-3	X		335-258-500-0	Bracket	72-09-04	CFM
CFM56-3	X		335-258-501-0	Bracket	72-09-04	CFM
CFM56-3	X		335-258-801-0	Bracket	72-09-04	CFM
CFM56-3	X		335-258-901-0	Bracket	72-09-04	CFM
CFM56-3	X		335-259-303-0	Bracket	72-09-04	CFM
CFM56-3	X		335-259-304-0	Bracket	72-09-04	CFM
CFM56-3	X		335-259-400-0	Bracket	72-23-35	CFM
CFM56-3	X		335-259-402-0	Bracket	72-09-04	CFM
CFM56-3	X		335-259-902-0	Bracket	72-09-04	CFM
CFM56-3	X		335-259-903-0	Bracket	72-09-04	CFM
CFM56-3	X		335-259-904-0	Bracket	72-23-21	CFM
CFM56-3	X		335-260-002-0	Bracket	72-09-04	CFM
CFM56-3	X		335-260-003-0	Bracket	72-09-04	CFM
CFM56-3	X		335-260-004-0	Bracket	72-09-04	CFM
CFM56-3	X		335-260-005-0	Bracket	72-09-04	CFM
CFM56-3	X		335-261-301-0	Bracket	72-09-04	CFM
CFM56-3	X		335-261-500-0	Tube, Air PS3 Supply	72-09-03	CFM
CFM56-3	X	X	335-261-551-0	Tube, Air PS3 Supply	72-09-03	CFM
CFM56-3	X		335-261-600-0	Bracket	72-23-35	CFM
CFM56-3	X		335-261-601-0	Bracket	72-23-35	CFM
CFM56-3	X		335-261-602-0	Bracket	72-09-04	CFM
CFM56-3	X		335-261-603-0	Bracket	72-09-04	CFM
CFM56-3	X		335-261-800-0	Bracket	72-23-35	CFM
CFM56-3	X		335-261-801-0	Bracket	72-09-04	CFM
CFM56-3	X		335-262-000-0	Bracket	72-23-35	CFM
CFM56-3	X		335-262-001-0	Bracket	72-09-04	CFM
CFM56-3	X		335-262-002-0	Bracket	72-09-04	CFM
CFM56-3	X		335-262-003-0	Bracket	72-09-04	CFM
CFM56-3	X		335-262-005-0	Bracket	72-09-04	CFM
CFM56-3	X		335-262-301-0	Adapter, Bushing	72-09-04	CFM
CFM56-3	X		335-263-201-0	Tube, Fuel VBV Drain	72-09-03	CFM
CFM56-3	X		335-263-202-0	Tube, Fuel VBV Drain	72-09-03	CFM
CFM56-3	X		335-263-400-0	Tube Assy, Vent Oil Tank	72-09-03	CFM
CFM56-3	X		335-263-403-0	Tube Assy, Vent Oil Tank	72-09-03	CFM
CFM56-3	X		335-263-450-0	Tube Assy, Vent Oil Tank	72-09-03	CFM
CFM56-3	X		335-263-451-0	Tube Assy, Vent Oil Tank	72-09-03	CFM
CFM56-3	X		335-263-452-0	Tube Assy, Vent Oil Tank	72-09-03	CFM
CFM56-3	X		335-263-507-0	Tube, Fuel Supply	72-09-03	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-3	X		335-263-510-0	Tube, Fuel Supply	72-09-03	CFM
CFM56-3	X		335-263-554-0	Tube, Fuel Supply	72-09-03	CFM
CFM56-3	X		335-263-555-0	Tube, Fuel Supply	72-09-03	CFM
CFM56-3	X		335-263-602-0	Tube, Oil Rear Sump Scavenge	72-09-03	CFM
CFM56-3	X		335-263-802-0	Tube, Oil Rear Sump Supply	72-09-03	CFM
CFM56-3	X		335-263-803-0	Tube, Oil Rear Sump Supply	72-09-03	CFM
CFM56-3	X		335-264-011-0	Tube	72-09-03	CFM
CFM56-3	X		335-264-015-0	Tube, Fuel Nozzle Supply	72-09-03	CFM
CFM56-3	X		335-264-300-0	Hose, Fuel Close	72-09-03	CFM
CFM56-3	X		335-264-350-0	Hose, Fuel Close	72-09-03	CFM
CFM56-3	X		335-264-703-0	Bracket	72-09-04	CFM
CFM56-3	X		335-264-705-0	Bracket	72-09-04	CFM
CFM56-3	X		335-264-706-0	Bracket	72-09-04	CFM
CFM56-3	X		335-264-707-0	Bracket	72-09-04	CFM
CFM56-3	X	X	335-264-801-0	Hose, Fuel Stage 9 BI V (PBP)	72-09-03	CFM
CFM56-3	X		335-264-850-0	Hose, Fuel Stage 9 BI V (PBP)	72-09-03	CFM
CFM56-3	X		335-264-901-0	Hose, Fuel Stage 5 BI V (PB)	72-09-03	CFM
CFM56-3	X		335-264-950-0	Hose, Fuel Stage 5 BI V (PB)	72-09-03	CFM
CFM56-3	X		335-265-000-0	Hose, CIT Sensor Supply	72-09-03	CFM
CFM56-3	X		335-265-100-0	Hose, CIT Sensor Supply	72-09-03	CFM
CFM56-3	X		335-265-102-0	Hose, CIT Sensor Supply	72-09-03	CFM
CFM56-3	X		335-265-150-0	Hose, CIT Sensor Supply	72-09-03	CFM
CFM56-3	X		335-265-151-0	Hose, CIT Sensor Supply	72-09-03	CFM
CFM56-3	X		335-265-204-0	Bracket	72-09-04	CFM
CFM56-3	X		335-265-205-0	Bracket	72-09-04	CFM
CFM56-3	X	X	335-265-600-0	Hose, Fuel Open	72-09-03	CFM
CFM56-3	X		335-265-650-0	Hose, Fuel Open	72-09-03	CFM
CFM56-3	X		335-266-001-0	Tube, Anti Siphon Oil Tank	72-09-03	CFM
CFM56-3	X		335-266-002-0	Tube, Anti Siphon Oil Tank	72-09-03	CFM
CFM56-3	X		335-266-250-0	Tube, Air CBP	72-09-03	CFM
CFM56-3	X		335-266-300-0	Hose, Discharge Heat Oil	72-09-03	CFM
CFM56-3	X		335-266-302-0	Hose, Discharge Heat Oil	72-09-03	CFM
CFM56-3	X		335-266-303-0	Hose, Discharge Heat Oil	72-09-03	CFM
CFM56-3	X		335-266-350-0	Hose, Discharge Heat Oil	72-09-03	CFM
CFM56-3	X		335-266-351-0	Hose, Discharge Heat Oil	72-09-03	CFM
CFM56-3	X		335-266-352-0	Hose, Discharge Heat Oil	72-09-03	CFM
CFM56-3	X		335-266-353-0	Hose, Discharge Heat Oil	72-09-03	CFM
CFM56-3	X		335-266-400-0	Tube, Fuel Return Heater	72-09-03	CFM
CFM56-3	X		335-266-405-0	Tube, Fuel Return Heater	72-09-03	CFM
CFM56-3	X		335-266-605-0	Tube, Heat Exchanger Return Oil	72-09-03	CFM
CFM56-3	X		335-266-800-0	Tube, Oil	72-09-03	CFM
CFM56-3	X		335-267-002-0	Tube, Fuel Supply Heater	72-09-03	CFM
CFM56-3	X		335-267-200-0	Tube, Oil Suction	72-09-03	CFM
CFM56-3	X		335-267-400-0	Tube, Oil Supply Gearbox	72-09-03	CFM
CFM56-3	X		335-267-806-0	Hose, Oil TGB Scavenge	72-09-03	CFM
CFM56-3	X		335-267-807-0	Hose, Oil TGB Scavenge	72-09-03	CFM
CFM56-3	X		335-267-808-0	Hose, Oil TGB Scavenge	72-09-03	CFM
CFM56-3	X		335-267-809-0	Hose, Oil TGB Scavenge	72-09-03	CFM
CFM56-3	X		335-267-852-0	Hose, Oil TGB Scavenge	72-09-03	CFM
CFM56-3	X		335-267-853-0	Hose, Oil TGB Scavenge	72-09-03	CFM
CFM56-3	X		335-268-001-0	Tube, Oil Pressure Oil Tank Cover	72-09-03	CFM
CFM56-3	X		335-268-404-0	Tube, Oil Supply TGB	72-09-03	CFM
CFM56-3	X		335-268-600-0	Hose, Oil Tank Return	72-09-03	CFM
CFM56-3	X		335-268-601-0	Hose, Oil Tank Return	72-09-03	CFM
CFM56-3	X		335-268-650-0	Hose, Oil Tank Return	72-09-03	CFM
CFM56-3	X		335-268-651-0	Hose, Oil Tank Return	72-09-03	CFM
CFM56-3	X		335-268-652-0	Hose, Oil Tank Return	72-09-03	CFM
CFM56-3	X		335-268-900-0	Hose, Oil Front Bearing Supply	72-09-03	CFM
CFM56-3	X		335-268-950-0	Hose, Oil Front Bearing Supply	72-09-03	CFM
CFM56-3	X		335-269-409-0	Tube, Manifold	72-23-21	CFM
CFM56-3	X		335-269-410-0	Tube, Manifold	72-23-21	CFM
CFM56-3	X		335-269-702-0	Bracket	72-09-04	CFM
CFM56-3	X		335-269-703-0	Bracket	72-09-04	CFM
CFM56-3	X		335-269-802-0	Bracket	72-09-04	CFM
CFM56-3	X		335-269-803-0	Bracket	72-09-04	CFM
CFM56-3	X		335-270-100-0	Bracket	72-09-04	CFM
CFM56-3	X		335-270-101-0	Bracket	72-09-04	CFM
CFM56-3	X		335-270-200-0	Bracket	72-09-04	CFM
CFM56-3	X		335-270-201-0	Bracket	72-09-04	CFM
CFM56-3	X		335-270-600-0	Bracket	72-09-04	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-3	X		335-270-700-0	Bracket	72-09-04	CFM
CFM56-3	X		335-270-802-0	Tube, Manifold	72-23-21	CFM
CFM56-3	X		335-270-803-0	Tube, Manifold	72-23-21	CFM
CFM56-3	X		335-271-000-0	Bracket	72-09-04	CFM
CFM56-3	X		335-271-100-0	Bracket	72-09-04	CFM
CFM56-3	X		335-271-601-0	Tube, Oil Filling	72-09-03	CFM
CFM56-3	X		335-271-650-0	Tube, Oil Filling	72-09-03	CFM
CFM56-3	X		335-272-103-0	Bracket	72-09-04	CFM
CFM56-3	X		335-272-802-0	Bracket	72-23-35	CFM
CFM56-3	X		335-272-803-0	Bracket	72-09-04	CFM
CFM56-3	X		335-272-902-0	Bracket	72-09-04	CFM
CFM56-3	X		335-273-001-0	Bracket	72-23-35	CFM
CFM56-3	X		335-273-002-0	Bracket	72-09-04	CFM
CFM56-3	X		335-273-401-0	Bracket	72-09-04	CFM
CFM56-3	X		335-273-902-0	Bracket	72-23-35	CFM
CFM56-3	X		335-273-904-0	Bracket	72-09-04	CFM
CFM56-3	X		335-275-401-0	Bracket	72-09-04	CFM
CFM56-3	X		335-275-402-0	Bracket	72-09-04	CFM
CFM56-3	X		335-275-903-0	Pin	72-23-10	CFM
CFM56-3	X		335-276-003-0	Tube, Fl Stage 5 Bl V Actuator Supply	72-09-03	CFM
CFM56-3	X		335-276-203-0	Tube, Fl Stage 9 Bl V Actuator Supply	72-09-03	CFM
CFM56-3	X		335-277-005-0	Bracket	72-09-04	CFM
CFM56-3	X		335-277-007-0	Bracket	72-09-04	CFM
CFM56-3	X		335-277-008-0	Bracket	72-09-04	CFM
CFM56-3	X		335-277-202-0	Bracket	72-09-04	CFM
CFM56-3	X		335-277-203-0	Bracket	72-09-04	CFM
CFM56-3	X		335-277-602-0	Bracket	72-09-04	CFM
CFM56-3	X		335-277-603-0	Bracket	72-09-04	CFM
CFM56-3	X		335-277-701-0	Bracket	72-09-04	CFM
CFM56-3	X		335-277-903-0	Bracket	72-09-04	CFM
CFM56-3	X		335-278-002-0	Bracket	72-09-04	CFM
CFM56-3	X		335-278-003-0	Bracket	72-09-04	CFM
CFM56-3	X		335-278-102-0	Bracket	72-09-04	CFM
CFM56-3	X		335-278-103-0	Bracket	72-09-04	CFM
CFM56-3	X		335-278-201-0	Bracket	72-09-04	CFM
CFM56-3	X		335-278-202-0	Bracket	72-09-04	CFM
CFM56-3	X		335-278-203-0	Bracket	72-09-04	CFM
CFM56-3	X		335-278-301-0	Bracket	72-09-04	CFM
CFM56-3	X		335-278-302-0	Bracket	72-09-04	CFM
CFM56-3	X		335-278-401-0	Bracket	72-09-04	CFM
CFM56-3	X		335-278-402-0	Bracket	72-09-04	CFM
CFM56-3	X		335-278-602-0	Bracket	72-23-35	CFM
CFM56-3	X		335-278-603-0	Bracket	72-09-04	CFM
CFM56-3	X		335-278-604-0	Bracket	72-09-04	CFM
CFM56-3	X		335-278-605-0	Bracket	72-09-04	CFM
CFM56-3	X		335-278-702-0	Bracket	72-09-04	CFM
CFM56-3	X		335-278-704-0	Bracket	72-09-04	CFM
CFM56-3	X		335-278-804-0	Bracket	72-09-04	CFM
CFM56-3	X		335-278-805-0	Bracket	72-09-04	CFM
CFM56-3	X		335-278-904-0	Bracket	72-09-04	CFM
CFM56-3	X		335-279-701-0	Bracket	72-23-35	CFM
CFM56-3	X		335-279-703-0	Bracket	72-09-04	CFM
CFM56-3	X		335-279-704-0	Bracket	72-09-04	CFM
CFM56-3	X		335-280-801-0	Bracket	72-09-04	CFM
CFM56-3	X		335-282-001-0	Tube, Over Flow	72-09-03	CFM
CFM56-3	X		335-282-002-0	Tube, Over Flow	72-09-03	CFM
CFM56-3	X		335-282-003-0	Tube, Over Flow	72-09-03	CFM
CFM56-3	X		335-282-201-0	Tube, Oil Rear Sump	72-09-03	CFM
CFM56-3	X		335-282-902-0	Bracket	72-09-04	CFM
CFM56-3	X		335-283-001-0	Bracket	72-09-04	CFM
CFM56-3	X		335-283-002-0	Bracket	72-09-04	CFM
CFM56-3	X		335-284-002-0	Bracket	72-09-04	CFM
CFM56-3	X		335-284-901-0	Bracket	72-09-04	CFM
CFM56-3	X		335-284-902-0	Bracket	72-09-04	CFM
CFM56-3	X		335-285-201-0	Bracket	72-09-04	CFM
CFM56-3	X		335-285-202-0	Bracket	72-09-04	CFM
CFM56-3	X		335-285-203-0	Bracket	72-09-04	CFM
CFM56-3	X		335-285-801-0	Tube, P7	72-09-03	CFM
CFM56-3	X		335-285-806-0	Tube, P7	72-09-03	CFM
CFM56-3	X		335-286-004-0	Tube, P7	72-09-03	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-3	X		335-286-008-0	Tube, P7	72-09-03	CFM
CFM56-3	X		335-286-206-0	Tube, PB	72-09-03	CFM
CFM56-3	X		335-286-210-0	Tube, PB	72-09-03	CFM
CFM56-3	X		335-286-601-0	Tube, Fuel P7	72-09-03	CFM
CFM56-3	X		335-287-102-0	Bracket	72-09-04	CFM
CFM56-3	X		335-287-601-0	Bracket	72-09-04	CFM
CFM56-3	X		335-287-901-0	Bracket	72-09-04	CFM
CFM56-3	X		335-287-903-0	Bracket	72-09-04	CFM
CFM56-3	X		335-287-904-0	Bracket	72-09-04	CFM
CFM56-3	X		335-287-905-0	Bracket	72-09-04	CFM
CFM56-3	X		335-288-201-0	Bracket	72-09-04	CFM
CFM56-3	X		335-288-401-0	Bracket	72-09-04	CFM
CFM56-3	X		335-288-501-0	Bracket	72-23-35	CFM
CFM56-3	X		335-288-502-0	Bracket	72-09-04	CFM
CFM56-3	X		335-290-901-0	Bracket	72-09-04	CFM
CFM56-3	X		335-290-902-0	Bracket	72-09-04	CFM
CFM56-3	X		335-291-001-0	Bracket	72-09-04	CFM
CFM56-3	X		335-291-501-0	Bracket	72-09-04	CFM
CFM56-3	X		335-291-502-0	Bracket	72-09-04	CFM
CFM56-3	X		335-291-503-0	Bracket	72-09-04	CFM
CFM56-3	X		335-291-504-0	Bracket	72-09-04	CFM
CFM56-3	X		335-291-505-0	Bracket	72-09-04	CFM
CFM56-3	X		335-293-301-0	Bracket	72-09-04	CFM
CFM56-3	X		335-293-302-0	Bracket	72-09-04	CFM
CFM56-3	X		335-293-801-0	Tube, PB	72-09-03	CFM
CFM56-3	X		335-300-601-0	Pad, Fuel Pump Assy	72-63-02	CFM
CFM56-3	X		335-302-400-0	Gearshaft Assy, 62 Tooth	72-63-03	CFM
CFM56-3	X		335-306-400-0	Tube Assy	72-62-07	CFM
CFM56-3	X		335-308-001-0	Tube, Assy	72-09-03	CFM
CFM56-3	X		335-309-602-0	Cover	72-63-09	CFM
CFM56-3	X		335-309-800-0	Spacer	72-63-13	CFM
CFM56-3	X		335-319-603-0	Shaft Assy	72-62-06	CFM
CFM56-3	X		335-322-801-0	Cover, Assy	72-63-09	CFM
CFM56-3	X		335-322-802-0	Cover	72-63-09	CFM
CFM56-3	X		335-322-803-0	Cover, Assy	72-63-09	CFM
CFM56-3	X		335-352-001-0	Sleeve, Fan Center	72-21-17	CFM
CFM56-3	X		336-053-703-0	Link Rod, Feedback VBV	72-23-16	CFM
CFM56-3	X		336-057-803-0	Clevis	72-23-16	CFM
CFM56-3	X		649-430-063-0	Hose, Fuel Close	72-09-03	CFM
CFM56-3	X		649-430-083-0	Hose, Fuel Close	72-09-03	CFM
CFM56-3	X		649-430-208-0	Hose, Fuel Open	72-09-03	CFM
CFM56-3	X		649-430-248-0	Hose, Fuel Open	72-09-03	CFM
CFM56-3	X	X	649-433-040-0	Hose, Fuel Stage 9 BI V (PC)	72-09-03	CFM
CFM56-3	X		649-433-046-0	Hose, Oil Rear Sump	72-09-03	CFM
CFM56-3	X		649-433-049-0	Hose, Oil Front Bearing Supply	72-09-03	CFM
CFM56-3	X		649-433-050-0	Hose, Oil Tank Return	72-09-03	CFM
CFM56-3	X	X	649-433-083-0	Hose, Fuel Close	72-09-03	CFM
CFM56-3	X		649-433-237-0	Hose, Fuel Stage 5 BI V (PB)	72-09-03	CFM
CFM56-3	X		649-433-248-0	Hose, Fuel Open	72-09-03	CFM
CFM56-3	X		649-433-250-0	Hose, Fuel Actuator Return	72-09-03	CFM
CFM56-3	X		649-433-434-0	Hose, Oil Tank Overflow	72-09-03	CFM
CFM56-3	X		649-434-040-0	Hose, Fuel Stage 9	72-09-03	CFM
CFM56-3	X		649-434-046-0	Hose, Oil Rear Sump	72-09-03	CFM
CFM56-3	X		649-434-049-0	Hose, Oil Front Bearing Supply	72-09-03	CFM
CFM56-3	X		649-434-050-0	Hose, Oil Tank Return	72-09-03	CFM
CFM56-3	X	X	649-434-083-0	Hose, Fuel Close	72-09-03	CFM
CFM56-3	X		649-434-237-0	Hose, Fuel Stage 5 BI V (PB)	72-09-03	CFM
CFM56-3	X		649-434-248-0	Hose, Fuel Open	72-09-03	CFM
CFM56-3	X		649-434-250-0	Hose, Fuel Actuator Return	72-09-03	CFM
CFM56-3	X		649-434-434-0	Hose, Oil Tank Overflow	72-09-03	CFM
CFM56-3	X		9256M95P001A	Bracket	72-09-04	CFM
CFM56-3	X		9256M95P001B	Bracket	72-09-04	CFM
CFM56-3	X		9335M34G05	Manifold, Air HPT Clearance Control	72-09-03	CFM
CFM56-3	X		9335M34G06	Manifold, Air HPT Clearance Control	72-09-03	CFM
CFM56-3	X		9335M34G07	Manifold, Air HPT Clearance Control	72-09-03	CFM
CFM56-3	X		9335M44P001A	Bracket	72-09-04	CFM
CFM56-3	X		9335M46P001A	Bracket	72-09-04	CFM
CFM56-3	X		9335M48G01	Bracket	72-09-04	CFM
CFM56-3	X		9335M62P001A	Bracket	72-09-04	CFM
CFM56-3	X		9335M64P001A	Bracket	72-09-04	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-3	X		9338M90P001A	Bracket	72-09-04	CFM
CFM56-3	X		9339M91P001A	Bracket	72-09-04	CFM
CFM56-3	X		9339M92P001A	Bracket	72-09-04	CFM
CFM56-3	X		9339M94P001A	Bracket	72-09-04	CFM
CFM56-3	X		9342M30G01	Tube, Air Signal PS3	72-09-03	CFM
CFM56-3	X		9342M30G02	Tube, Air Signal PS3	72-09-03	CFM
CFM56-3	X		9342M45P001A	Bracket	72-09-04	CFM
CFM56-3	X		9342M67P001A	Bracket	72-09-04	CFM
CFM56-3	X		9342M72P003A	Bracket	72-09-04	CFM
CFM56-3	X		9342M97P001A	Bracket	72-09-04	CFM
CFM56-3	X		9368M61P001A	Bracket	72-09-04	CFM
CFM56-3	X		9375M10G01	Manifold, Fuel	72-09-03	CFM
CFM56-3	X		9375M10G03	Manifold, Fuel	72-09-03	CFM
CFM56-3	X		9375M12G01	Manifold	72-09-03	CFM
CFM56-3	X		9375M12G03	Manifold	72-09-03	CFM
CFM56-3	X		9375M16G01	Manifold, Fuel	72-09-03	CFM
CFM56-3	X		9375M16G03	Manifold	72-09-03	CFM
CFM56-3	X		9375M18G01	Tube, Drain Main Fuel Supply	72-09-03	CFM
CFM56-3	X		9375M18G02	Tube, Drain Main Fuel Supply	72-09-03	CFM
CFM56-3	X		9375M20G01	Manifold, Fuel	72-09-03	CFM
CFM56-3	X		9375M20G03	Manifold, Fuel	72-09-03	CFM
CFM56-3	X		9375M22G01	Bracket	72-09-04	CFM
CFM56-3	X		9375M23G01	Bracket	72-09-04	CFM
CFM56-3	X		9375M24G04	Tube	72-09-03	CFM
CFM56-3	X		9375M26G02	Tube, CIT Sensor	72-09-03	CFM
CFM56-3	X		9375M26G04	Tube	72-09-03	CFM
CFM56-3	X		9375M32G01	Bracket	72-09-04	CFM
CFM56-3	X		9375M32G02	Bracket	72-09-04	CFM
CFM56-3	X		9375M41P001A	Bracket	72-09-04	CFM
CFM56-3	X		9375M42P001A	Bracket	72-09-04	CFM
CFM56-3	X		9375M45P001A	Bracket	72-09-04	CFM
CFM56-3	X		9375M47P001A	Bracket	72-09-04	CFM
CFM56-3	X		9375M48G01	Bracket	72-09-04	CFM
CFM56-3	X		9375M49G01	Bracket	72-09-04	CFM
CFM56-3	X		9375M61G01	Tube, Air Bleed	72-09-03	CFM
CFM56-3	X		9375M66P001A	Bracket	72-09-04	CFM
CFM56-3	X		9375M68G02	Tube, Air 9th Stage	72-09-03	CFM
CFM56-3	X		9375M77G01	Bracket	72-09-04	CFM
CFM56-3	X		9375M77G02	Bracket	72-09-04	CFM
CFM56-3	X		9375M90G13	Manifold, Fuel (LH)	72-41-04, 72-09-03	CFM
CFM56-3	X		9375M90G14	Manifold, Fuel (RH)	72-41-04, 72-09-03	CFM
CFM56-3	X		9376M11G02	Bracket	72-09-04	CFM
CFM56-3	X		9376M13P001A	Bracket	72-09-04	CFM
CFM56-3	X		9376M34G01	Bracket	72-09-04	CFM
CFM56-3	X		9376M35G01	Bracket	72-09-04	CFM
CFM56-3	X		9376M36P001A	Bracket	72-09-04	CFM
CFM56-3	X		9376M67P001A	Bracket	72-09-04	CFM
CFM56-3	X		9386M17G04	Manifold, Fuel Drain	72-09-03	CFM
CFM56-3	X		9386M30G01	Tube, Fuel Drain	72-09-03	CFM
CFM56-3	X		9386M38P001A	Bracket	72-09-04	CFM
CFM56-3	X		9386M64P001A	Bracket	72-09-04	CFM
CFM56-3	X		9386M71G04	Bracket	72-09-04	CFM
CFM56-3	X		9386M75G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-3	X		9386M83G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-3	X		9386M83G02	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-3	X	X	9386M83G03	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-3	X		9387M13G05	Bracket	72-09-04	CFM
CFM56-3	X		9387M34G01	Tube, Drain Fuel	72-09-03	CFM
CFM56-3	X		9387M39P001A	Bracket	72-09-04	CFM
CFM56-3	X		9387M48G01	Tube, Drain Fuel	72-09-03	CFM
CFM56-3	X		9387M50G01	Manifold	72-09-03	CFM
CFM56-3	X		9387M58G01	Manifold, Drain	72-09-03	CFM
CFM56-3	X		9387M62G01	Bracket	72-09-04	CFM
CFM56-3	X		9387M66G01	Bracket	72-09-04	CFM
CFM56-3	X		9387M79G01	Bracket	72-09-04	CFM
CFM56-3	X		9513M20P06	Link, Connecting	72-32-11	CFM
CFM56-3	X		BC107-01	Box, Trim EGT	77-21-43	CFM
CFM56-3	X		P201P01	Vane, Comp Sstr Stage 1	72-32-02	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-3	X		P201P02	Vane, Comp Sstr Stage 1	72-32-02	CFM
CFM56-3	X		P201P03	Vane, Comp Sstr Stage 1	72-32-02	CFM
CFM56-3	X		P201P04	Vane, Comp Sstr Stage 1	72-32-02	CFM
CFM56-3	X		P201P07	Vane, Comp Sstr Stage 1	72-32-02	CFM
CFM56-3	X		P201P08	Vane, Comp Sstr Stage 1	72-32-02	CFM
CFM56-3	X		P202P03	Vane, Comp Sstr Stage 2	72-32-02	CFM
CFM56-3	X		P202P04	Vane, Comp Sstr Stage 2	72-32-02	CFM
CFM56-3	X		P213P01	Vane, Comp Sstr Stage 3	72-32-02	CFM
CFM56-3	X		P213P02	Vane, Comp Sstr Stage 3	72-32-02	CFM
CFM56-3	X		P251P03	Vane, Comp Sstr Stg 1	72-32-02	CFM
CFM56-3	X		P251P04	Vane, Comp Sstr Stg 1	72-32-02	CFM
CFM56-3	X		P251P05	Vane, Comp Sstr Stg 1	72-32-02	CFM
CFM56-3	X		P251P06	Vane, Comp Sstr Stg 1	72-32-02	CFM
CFM56-3	X		P251P07	Vane, Comp Sstr Stg 1	72-32-02	CFM
CFM56-3	X		P251P08	Vane, Comp Sstr Stg 1	72-32-02	CFM
CFM56-3	X		P252P03	Vane, Comp Sstr Stg 2	72-32-02	CFM
CFM56-3	X		P252P04	Vane, Comp Sstr Stg 2	72-32-02	CFM
CFM56-3	X		P253P07	Vane, Comp Sstr Stg 3	72-32-02	CFM
CFM56-3	X		P253P08	Vane, Comp Sstr Stg 3	72-32-02	CFM
CFM56-3	X		P253P09	Vane, Comp Sstr Stg 3	72-32-02	CFM
CFM56-3	X		P253P10	Vane, Comp Sstr Stg 3	72-32-02	CFM
CFM56-3	X	X	335-009-306-0	Spool, Booster	72-21-04	CFM
CFM56-3, 2C	X		1319M25P02	Seal, CDP	72-31-08	CFM
CFM56-3, 5A	X		1359M86P02	Seal, CDP	72-31-08	CFM
CFM56-3, 5A	X		1359M86P03	Seal, CDP	72-31-08	CFM
CFM56-3, 5A	X		305-044-602-0	Pin, Shoulder	72-55-20	CFM
CFM56-3, 5A	X	X	335-008-601-0	Tube, Pressurizing Air	72-22-08	CFM
CFM56-3, 5A	X	X	335-008-602-0	Tube, Pressurizing Air	72-22-08	CFM
CFM56-3, 5A	X	X	335-010-601-0	Tube, Oil No. 1 Bearing Scavenge	72-22-08	CFM
CFM56-3, 5A	X		335-010-801-0	Tube Assy, Oil No. 1 And No. 2 Bearing	72-09-03	CFM
CFM56-3, 5A	X		335-104-305-0	Tube, Oil	72-09-03	CFM
CFM56-3, 5A	X		335-107-702-0	Slide	72-23-37	CFM
CFM56-3, 5A	X		335-107-712-0	Slide	72-23-37	CFM
CFM56-3, 5A	X		335-107-722-0	Slide	72-23-37	CFM
CFM56-3, 5A	X		335-203-801-0	Hose, Fuel Stage 9	72-09-03	CFM
CFM56-3, 5A	X		335-203-850-0	Hose, Fuel Stage 9	72-09-03	CFM
CFM56-3, 5A	X	X	335-213-701-0	Mount Assy, Shock Top	72-23-14	CFM
CFM56-3, 5A	X	X	335-214-301-0	Mount, Shock Bottom	72-23-17	CFM
CFM56-3, 5A	X		335-255-201-0	Hose, Oil Rear Sump	72-09-03	CFM
CFM56-3, 5A	X		335-255-250-0	Hose, Oil Rear Sump	72-09-03	CFM
CFM56-3, 5A	X		649-430-010-0	Hose, Fuel Stage 9	72-09-03	CFM
CFM56-3, 5A	X		649-430-040-0	Hose, Fuel Stage 9 Bl V (PC)	72-09-03	CFM
CFM56-3, 5A	X		9135M62P01	Plug, Thread	72-41-11	CFM
CFM56-3, 5A	X		P210P01	Vane, Comp Sstr Stage 2	72-32-02	CFM
CFM56-3, 5A	X		P223P03	Vane, Comp Sstr Stage 3	72-32-02	CFM
CFM56-3, 5A	X		P223P04	Vane, Comp Sstr Stage 3	72-32-02	CFM
CFM56-3, 5A	X		P250P01	Vane, Comp Sstr IGV	72-32-02	CFM
CFM56-3, 5A	X		335-021-301-0	Pin, Mounting	72-23-10	CFM
CFM56-3, 5A, 5B	X		335-107-102-0	Scoop	72-23-36	CFM
CFM56-3, 5A, 5B	X	X	335-108-701-0	Slide	72-23-37	CFM
CFM56-3, 5A, 5B	X	X	335-108-801-0	Slide	72-23-37	CFM
CFM56-3, 5A, 5B	X	X	335-108-901-0	Slide	72-23-37	CFM
CFM56-3, 5A, 5B	X		336-095-501-0	Scoops	72-23-36	CFM
CFM56-3, 5A, 5B 5C, 7B	X		305-483-703-0	Seal, Ring	72-09-01	CFM
CFM56-3, 5A, 5B, 5C	X		335-311-202-0	Ring, Mating	72-63-08	CFM
CFM56-3, 5A, 5B, 5C	X		335-311-204-0	Ring, Mating	72-63-21	CFM
CFM56-3, 5A, 5B, 5C	X		335-311-205-0	Ring, Mating	72-63-21	CFM
CFM56-3, 5A, 5B, 5C	X		335-318-205-0	Ring, Mating	72-63-21	CFM
CFM56-3, 5A, 5B, 5C	X		649-411-850-0	Clamp, Hinged	72-09-04	CFM
CFM56-3, 5A, 5B, 5C	X	X	9339M40G04	Seal, Fwd Stationary No 3	72-23-19	GE
CFM56-3, 5A, 5B, 5C	X		P201P05	Vane, Comp Sstr Stage 1	72-32-02	CFM
CFM56-3, 5A, 5B, 5C	X		P201P06	Vane, Comp Sstr Stage 1	72-32-02	CFM
CFM56-3, 5A, 5B, 5C	X		P201P15	Vane, Compressor Stator Stage 1	72-32-02	CFM
CFM56-3, 5A, 5B, 5C	X		P201P16	Vane, Compressor Stator Stage 1	72-32-02	CFM
CFM56-3, 5A, 5B, 5C	X		P202P01	Vane, Comp Sstr Stage 2	72-32-02	CFM
CFM56-3, 5A, 5B, 5C	X		P202P02	Vane, Comp Sstr Stage 2	72-32-02	CFM
CFM56-3, 5A, 5B, 5C	X		P202P09	Vane, Compressor Stator Stage 2	72-32-02	CFM
CFM56-3, 5A, 5B, 5C	X		P202P10	Vane, Compressor Stator Stage 2	72-32-02	CFM
CFM56-3, 5A, 5B, 5C	X		P210P02	Vane, Comp Sstr IGV	72-32-02	CFM
CFM56-3, 5A, 5B, 5C	X		P223P01	Vane, Comp Sstr Stage 3	72-32-02	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-3, 5A, 5B, 5C	X		P223P02	Vane, HPC S3	72-32-02	CFM
CFM56-3, 5A, 5B, 5C	X	X	P223P07	Vane, Compressor Stator Stage 3	72-32-02	CFM
CFM56-3, 5A, 5B, 5C	X	X	P223P08	Vane, Compressor Stator Stage 3	72-32-02	CFM
CFM56-3, 5A, 5B, 5C, 7B	X		1324M13P04	Adapter, Bushing	72-41-11	CFM
CFM56-3, 5A, 5B, 5C, 7B	X		1444M26P001A	Bracket	72-09-04	CFM
CFM56-3, 5A, 5B, 5C, 7B	X		1527M12P001A	Bracket	72-09-04	CFM
CFM56-3, 5A, 5B, 5C, 7B	X		1895M53P01	Cover, Plate	72-09-04	CFM
CFM56-3, 5A, 5B, 5C, 7B	X		301-552-304-0	Bracket	72-09-04	CFM
CFM56-3, 5A, 5B, 5C, 7B	X		305-127-704-0	Mating Ring	72-63-07	CFM
CFM56-3, 5A, 5B, 5C, 7B	X		305-483-731-0	Ring, Seal	72-09-01	CFM
CFM56-3, 5A, 5B, 5C, 7B	X		338-060-001-0	Bracket	72-09-04	CFM
CFM56-3, 5A, 5B, 5C, 7B	X		340-005-202-0	Bracket	72-09-04	CFM
CFM56-3, 5A, 5B, 5C, 7B	X		340-005-302-0	Bracket	72-09-04	CFM
CFM56-3, 5A, 5B, 5C, 7B	X		340-005-402-0	Bracket	72-09-04	CFM
CFM56-3, 5A, 5B, 5C, 7B	X		340-005-502-0	Bracket	72-09-04	CFM
CFM56-3, 5A, 5B, 5C, 7B	X		340-005-602-0	Bracket	72-09-04	CFM
CFM56-3, 5A, 5B, 5C, 7B	X		340-005-801-0	Bracket	72-09-04	CFM
CFM56-3, 5A, 5B, 5C, 7B	X		340-005-802-0	Bracket	72-09-04	CFM
CFM56-3, 5A, 5B, 5C, 7B	X		340-006-202-0	Bracket	72-09-04	CFM
CFM56-3, 5A, 5B, 5C, 7B	X		340-006-301-0	Bracket	72-09-04	CFM
CFM56-3, 5A, 5B, 5C, 7B	X		340-006-504-0	Bracket	72-09-04	CFM
CFM56-3, 5A, 5B, 5C, 7B	X		340-006-604-0	Bracket	72-09-04	CFM
CFM56-3, 5A, 5B, 5C, 7B	X		340-006-704-0	Bracket	72-09-04	CFM
CFM56-3, 5A, 5B, 5C, 7B	X		340-006-804-0	Bracket	72-09-04	CFM
CFM56-3, 5A, 5B, 5C, 7B	X		41P5117	Bracket	72-09-04	CFM
CFM56-3, 5A, 5B, 5C, 7B	X		649-412-307-0	Clamp, Loop	72-09-04	CFM
CFM56-3, 5A, 5B, 5C, 7B	X		930085-04	Bracket	72-09-04	CFM
CFM56-3, 5A, 5B, 5C, 7B	X	X	9523M35G03	Arm, Vane Actuation Compressor Stator Assy	72-32-10	CFM
CFM56-3, 5A, 5B, 5C, 7B	X	X	9992M86G08	Plug Assy, Boroscope (Stage 7 And 8)	72-32-20	CFM
CFM56-3, 5A, 5B, 5C, 7B	X		MS9902-06	Plug, Mach Thread Drilled	72-63-20	CFM
CFM56-3, 5A, 5B, 5C, 7B	X		P210P04	Vane, Comp Sstr IGV	72-32-02	CFM
CFM56-3, 5A, 5B, 7B	X	X	335-104-308-0	Tube, Oil	72-09-03	CFM
CFM56-3, 5A, 5B, 7B	X	X	335-104-309-0	Tube, Oil	72-09-03	CFM
CFM56-3, 5A, 5B, 7B	X		336-024-706-0	Cover Assy, Oil Inlet	72-56-06	CFM
CFM56-3, 5B	X		J818P060A	Bolt, Shear Double Hex Head	72-21-11	CFM
CFM56-3, 5B, 5C	X		1443M13G01	Tube, Air Start Bleed Diffuser	72-09-03	CFM
CFM56-3, 5B, 5C, 7B	X	X	1895M34G01	Bracket	72-09-04	CFM
CFM56-3, 5B, 5C, 7B	X	X	1895M35G01	Bracket	72-09-04	CFM
CFM56-3, 5B, 5C, 7B	X	X	P241P01	Vane, Comp Sstr Stage 1	72-32-02	CFM
CFM56-3, 5B, 5C, 7B	X	X	P241P02	Vane, Comp Sstr Stage 1	72-32-02	CFM
CFM56-3, 5B, 5C, 7B	X		P242P01	Vane, Comp Sstr Stage 2	72-32-02	CFM
CFM56-3, 5B, 5C, 7B	X	X	P242P02	Vane, Comp Sstr Stage 2	72-32-02	CFM
CFM56-3, 5B, 5C, 7B	X	X	P243P01	Vane, Compressor Stator Stage 3	72-32-02	CFM
CFM56-3, 5B, 5C, 7B	X		P243P02	Vane, Compressor Stator Stage 3	72-32-02	CFM
CFM56-3, 7B	X		332A1200-9	Duct Segment	71-00-04	Boeing
CFM56-3, 7B	X		332A1324-5	Bracket	71-00-04	Boeing
CFM56-3, 7B	X		332A2326-30	Duct Assy	71-00-04	Boeing
CFM56-3, 7B	X		332A2390-21	Duct Assy	71-00-04	Boeing
CFM56-3, 7B	X		332A2390-31	Duct Assy	71-00-04	Boeing
CFM56-3, 7B	X		335-301-200-0	Pad Assy, Drive	72-63-02	CFM
CFM56-3, 7B	X		335-305-600-0	Support, Gear Box	72-62-04	CFM
CFM56-3, 7B	X		335-305-601-0	Support, Gear Box	72-62-04	CFM
CFM56-3, 7B	X	X	335-306-900-0	Spacer	72-62-13	CFM
CFM56-3, 7B	X	X	335-311-700-0	Bracket	72-09-04	CFM
CFM56-3, 7B	X		335-311-800-0	Spool	72-63-20	CFM
CFM56-3, 7B	X		335-312-602-0	Shaft	72-63-05	CFM
CFM56-3, 7B	X		335-312-603-0	Shaft, Assy-Drive Luber	72-63-05	CFM
CFM56-3, 7B	X		335-316-800-0	Clamp	72-62-13	CFM
CFM56-3, 7B	X		335-321-801-6	Shim	72-52-00	CFM
CFM56-3, 7B	X		335-321-806-0	Shim	72-52-00	CFM
CFM56-3, 7B	X		335-321-901-6	Shim	72-52-00	CFM
CFM56-3, 7B, CF6, GE90	X		332A1313-1	Duct, Assy	71-00-04	Boeing
CFM56-5A	X		108280-213	Hose	71-00-17	ROHR
CFM56-5A	X		108280-55	Hose	72-09-03	CFM
CFM56-5A	X	X	1319M22P02	Ring, Retainer HPT Front	72-52-09	CFM
CFM56-5A	X		1319M24P02	Damper, Forward Sleeve	72-52-07	CFM
CFM56-5A	X		1324M16G01	Bracket	72-09-04	CFM
CFM56-5A	X		1324M17G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5A	X	X	1324M17G02	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5A	X		1324M17G03	Tube, Air LPT Cooling	72-09-03	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5A	X		1324M19G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5A	X		1324M19G02	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5A	X		1324M19G03	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5A	X		1324M21G01	Manifold, Air Turbine Clearance Control	72-09-03	CFM
CFM56-5A	X		1324M21G02	Manifold, Air Turbine Clearance Control	72-09-03	CFM
CFM56-5A	X	X	1324M21G03	Manifold, Air Turbine Clearance Control	72-09-03	CFM
CFM56-5A	X	X	1324M25G01	Bracket	72-09-04	CFM
CFM56-5A	X		1324M26P001A	Bracket	72-09-04	CFM
CFM56-5A	X		1324M27G01	Bracket	72-09-04	CFM
CFM56-5A	X		1324M28G01	Bracket	72-09-04	CFM
CFM56-5A	X		1324M78P001A	Bracket	72-09-04	CFM
CFM56-5A	X		1324M81P02	Flange	72-09-03	CFM
CFM56-5A	X		1324M82G01	Tube, Air Stage 5	72-09-03	CFM
CFM56-5A	X		1348M28G01	Tube, Air Start	72-09-03	CFM
CFM56-5A	X		1348M28G02	Tube, Air Start	72-09-03	CFM
CFM56-5A	X		1348M36G01	Bracket	72-09-04	CFM
CFM56-5A	X		1348M39P001A	Bracket	72-09-04	CFM
CFM56-5A	X		1348M71G01	Tube, Drain	72-09-03	CFM
CFM56-5A	X		1348M92G02	Bracket	72-09-04	CFM
CFM56-5A	X		1358M17P01	Bushing	72-53-05	CFM
CFM56-5A	X		1358M18P01	Spacer	72-53-05	CFM
CFM56-5A	X		1358M37G02	Support, Seal Outer HPT Stator	72-51-04	CFM
CFM56-5A	X		1358M37G03	Support, Seal Outer HPT Stator	72-51-04	CFM
CFM56-5A	X		1358M37G04	Support, Seal Outer HPT Stator	72-51-04	CFM
CFM56-5A	X	X	1358M40P01	Shield, Nut	72-51-11	CFM
CFM56-5A	X		1358M62G02	Shield, HPT Nozzle Support Bolt	72-41-05	CFM
CFM56-5A	X	X	1359M18P02	Shield, HPT Shroud Support Mid	72-53-02	CFM
CFM56-5A	X		1386M56P01	Shaft, HPC Front	72-31-07	CFM
CFM56-5A	X	X	1386M85P01	Ring, Retainer HPT Rear	72-52-09	CFM
CFM56-5A	X		1443M41P001A	Bracket	72-09-04	CFM
CFM56-5A	X		1443M50P001A	Bracket	72-09-04	CFM
CFM56-5A	X		1443M51G01	Bracket	72-09-04	CFM
CFM56-5A	X		1443M52G01	Bracket	72-09-04	CFM
CFM56-5A	X		1443M53G01	Bracket	72-09-04	CFM
CFM56-5A	X		1443M66G01	Tube, Fuel Drain	72-09-03	CFM
CFM56-5A	X		1443M72G01	Tube, Air Signal	72-09-03	CFM
CFM56-5A	X		1443M72G02	Tube, Air Signal	72-09-03	CFM
CFM56-5A	X		1443M72G03	Tube, Air Signal	72-09-03	CFM
CFM56-5A	X		1443M74G01	Bracket	72-09-04	CFM
CFM56-5A	X		1443M77G01	Bracket	72-09-04	CFM
CFM56-5A	X		1443M83P001A	Bracket	72-09-04	CFM
CFM56-5A	X		1443M84P001A	Bracket	72-09-04	CFM
CFM56-5A	X		1443M85P001A	Bracket	72-09-04	CFM
CFM56-5A	X		1443M86P001A	Bracket	72-09-04	CFM
CFM56-5A	X		1443M95P001A	Bracket	72-09-04	CFM
CFM56-5A	X	X	1444M28G01	Tube, Drain	72-09-03	CFM
CFM56-5A	X		1444M33G01	Tube, Drain	72-09-03	CFM
CFM56-5A	X		1444M42G02	Tube, Air RACC Lower	72-09-03	CFM
CFM56-5A	X		1444M44G02	Tube, Air RACC Upper	72-09-03	CFM
CFM56-5A	X		1444M54G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5A	X		1444M56G02	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5A	X		1444M56G04	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5A	X		1444M56G05	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5A	X		1444M77G01	Bracket	72-09-04	CFM
CFM56-5A	X		1444M77G03	Bracket	72-09-04	CFM
CFM56-5A	X		1444M78G03	Bracket	72-09-04	CFM
CFM56-5A	X		1444M78P001B	Bracket	72-09-04	CFM
CFM56-5A	X		1467M10G01	Bracket	72-09-04	CFM
CFM56-5A	X		1467M11P001B	Bracket	72-09-04	CFM
CFM56-5A	X		1467M11P001C	Bracket	72-09-04	CFM
CFM56-5A	X	X	1467M12G01	Manifold, Drain VSV	72-41-04	CFM
CFM56-5A	X		1467M13G01	Bracket	72-09-04	CFM
CFM56-5A	X		1467M15P001A	Bracket	72-09-04	CFM
CFM56-5A	X		1467M15P001B	Bracket	72-09-04	CFM
CFM56-5A	X		1467M16P001B	Bracket	72-09-04	CFM
CFM56-5A	X		1467M19P001B	Bracket	72-09-04	CFM
CFM56-5A	X		1467M28G01	Bracket	72-09-04	CFM
CFM56-5A	X		1467M29G01	Bracket	72-09-04	CFM
CFM56-5A	X	X	1467M41G01	Manifold, Fuel	72-09-03	CFM
CFM56-5A	X	X	1467M41G02	Manifold, Fuel	72-09-03	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5A	X		1467M46G03	Bracket	72-09-04	CFM
CFM56-5A	X		1467M50P001A	Bracket	72-09-04	CFM
CFM56-5A	X		1467M72P001A	Bracket	72-09-04	CFM
CFM56-5A	X	X	1475M64G01	Shield, Heat Forward	72-53-12	CFM
CFM56-5A	X		1527M26G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5A	X		1527M46G01	Manifold, Drain TCC	72-09-03	CFM
CFM56-5A	X		1527M69G01	Tube, Fuel PC	72-09-03	CFM
CFM56-5A	X		1527M73P001A	Bracket	72-09-04	CFM
CFM56-5A	X	X	1527M77G04	Manifold, Fuel	72-09-03	CFM
CFM56-5A	X		1527M80P001B	Bracket	72-09-04	CFM
CFM56-5A	X	X	1616M93G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5A	X	X	1616M94G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5A	X		1616M95G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5A	X	X	1621M90G01	Tube, Air Stage 5	72-09-03	CFM
CFM56-5A	X		1621M92P001B	Bracket	72-09-04	CFM
CFM56-5A	X		1645M79G01	Tube, Air Static Press	72-09-03	CFM
CFM56-5A	X		1645M89G01	Tube, Air Total Press	72-09-03	CFM
CFM56-5A	X		1645M93G01	Tube, Air Total Press	72-09-03	CFM
CFM56-5A	X		1645M95G01	Tube, Air Static Press	72-09-03	CFM
CFM56-5A	X	X	1716M40G01	Manifold	72-09-03, 72-41-04	CFM
CFM56-5A	X		1752M61P01	Spacer	72-09-03	CFM
CFM56-5A	X		1817M29G01	Bracket	72-09-04	CFM
CFM56-5A	X		1817M29G02	Bracket	72-09-04	CFM
CFM56-5A	X		1868M18P001A	Bracket	72-09-04	CFM
CFM56-5A	X		1895M18G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5A	X		1895M18G02	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5A	X		1895M18G09	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5A	X		1895M18G10	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5A	X		1895M18G14	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5A	X		1895M18G16	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5A	X	X	1895M18G23	Tube, Air Start	72-09-03	CFM
CFM56-5A	X	X	1896M95G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5A	X		1896M95G05	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5A	X		1896M95G08	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5A	X		1971M56G01	Bracket	72-09-04	CFM
CFM56-5A	X		1971M60G01	Bracket	72-09-04	CFM
CFM56-5A	X		2002M94G02	Support, Seal Outer HPT Stator	72-51-04	CFM
CFM56-5A	X		2283M40G01	Manifold, Drain VSV	72-09-03	CFM
CFM56-5A	X		238-0519-501	Tube	71-00-17	ROHR
CFM56-5A	X		238-0557-503	Bracket	72-09-04	CFM
CFM56-5A	X		238-0612-503	Tube	71-00-17	ROHR
CFM56-5A	X		238-0612-505	Tube	71-00-17	ROHR
CFM56-5A	X		238-0651-3	Bracket, Null	72-09-04	ROHR
CFM56-5A	X		238-0701-509	Tube Assy	71-00-17	ROHR
CFM56-5A	X		238-0751-501	Tube	71-00-17	ROHR
CFM56-5A	X		238-0751-503	Tube	71-00-17	ROHR
CFM56-5A	X		238-0801-537	Tube, Assy 6	71-00-17	ROHR
CFM56-5A	X		238-0801-549	Tube	71-00-17	ROHR
CFM56-5A	X		301-472-422-0	Panel, Fan Duct	72-23-07	CFM
CFM56-5A	X		301-472-425-0	Panel, Fan Duct	72-23-07	CFM
CFM56-5A	X		301-473-732-0	Panel, Fan Duct	72-23-07	CFM
CFM56-5A	X		301-473-735-0	Panel, Fan Duct	72-23-07	CFM
CFM56-5A	X		305-050-003-0	Nipple Assy Restrictor	72-56-20	CFM
CFM56-5A	X		305-082-817-0	Panel, Fan Duct	72-23-07	CFM
CFM56-5A	X		305-082-819-0	Panel, Fan Duct	72-23-07	CFM
CFM56-5A	X		305-147-201-0	Plug, Nozzle	72-62-11	CFM
CFM56-5A	X	X	305-151-401-0	Clamp, Starter V	72-09-04	CFM
CFM56-5A	X		305-156-001-0	Bracket	72-09-04	CFM
CFM56-5A	X		305-156-201-0	Bracket	72-63-16	CFM
CFM56-5A	X		305-156-602-0	Bracket	72-62-12	CFM
CFM56-5A	X		305-156-701-0	Bracket	72-63-16	CFM
CFM56-5A	X		305-327-204-0	Bracket	72-09-04	CFM
CFM56-5A	X		305-372-307-0	Panel, Fan Duct	72-23-07	CFM
CFM56-5A	X		305-372-310-0	Panel, Fan Duct	72-23-07	CFM
CFM56-5A	X		305-372-312-0	Panel, Fan Duct	72-23-07	CFM
CFM56-5A	X		305-372-314-0	Panel, Fan Duct	72-23-07	CFM
CFM56-5A	X		334-007-213-0	Tube, Oil Supply	72-09-03	CFM
CFM56-5A	X		334-007-216-0	Tube, Oil Scavenge	72-09-03	CFM
CFM56-5A	X		334-007-217-0	Tube, Oil Supply	72-09-03	CFM
CFM56-5A	X		336-000-305-0	Support, Conical LPT	72-54-05	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5A	X		336-000-306-0	Support, Conical LPT	72-54-05	CFM
CFM56-5A	X		336-001-303-0	Vane, Fan Outlet	72-23-03	CFM
CFM56-5A	X		336-001-304-0	Vane, Fan Outlet	72-23-03	CFM
CFM56-5A	X		336-001-802-0	Disk, LPT	72-54-03	CFM
CFM56-5A	X		336-001-803-0	Disk, LPT	72-54-03	CFM
CFM56-5A	X		336-001-908-0	Disk, LPT	72-54-03	CFM
CFM56-5A	X		336-002-004-0	Disk, LPT	72-54-03	CFM
CFM56-5A	X		336-002-103-0	Disk, LPT	72-54-03	CFM
CFM56-5A	X		336-002-104-0	Disk, LPT	72-54-03	CFM
CFM56-5A	X		336-003-202-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5A	X		336-003-203-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5A	X		336-003-211-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5A	X	X	336-003-212-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5A	X		336-003-225-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5A	X		336-003-226-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5A	X		336-003-236-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5A	X	X	336-003-237-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5A	X		336-003-250-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5A	X		336-003-251-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5A	X		336-003-261-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5A	X		336-003-262-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5A	X		336-003-275-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5A	X		336-003-276-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5A	X		336-003-286-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5A	X		336-003-287-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5A	X		336-003-302-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5A	X		336-003-303-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5A	X		336-003-311-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5A	X	X	336-003-312-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5A	X		336-003-325-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5A	X		336-003-326-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5A	X		336-003-336-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5A	X	X	336-003-337-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5A	X		336-003-350-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5A	X		336-003-351-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5A	X		336-003-361-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5A	X		336-003-362-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5A	X		336-003-375-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5A	X		336-003-376-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5A	X		336-003-386-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5A	X		336-003-387-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5A	X		336-003-402-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5A	X		336-003-403-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5A	X		336-003-411-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5A	X	X	336-003-412-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-5A	X		336-003-425-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-5A	X		336-003-426-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-5A	X		336-003-436-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-5A	X	X	336-003-437-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-5A	X		336-003-450-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-5A	X		336-003-451-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-5A	X		336-003-461-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-5A	X		336-003-462-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-5A	X		336-003-475-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-5A	X		336-003-476-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-5A	X		336-003-486-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-5A	X		336-003-487-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-5A	X		336-009-502-0	Tube, Supply Oil	72-09-03	CFM
CFM56-5A	X		336-009-503-0	Tube, Supply Oil	72-09-03	CFM
CFM56-5A	X		336-011-201-0	Lock, Stage 2 Blade	72-21-07	CFM
CFM56-5A	X		336-011-301-0	Lock, Stage 3 Blade	72-21-07	CFM
CFM56-5A	X		336-011-401-0	Lock, Stage 4 Blade	72-21-07	CFM
CFM56-5A	X		336-014-804-0	Spool, Booster	72-21-04	CFM
CFM56-5A	X		336-014-806-0	Spool, Booster	72-21-04	CFM
CFM56-5A	X		336-014-807-0	Spool, Booster	72-21-04	CFM
CFM56-5A	X		336-014-808-0	Spool, Booster	72-21-04	CFM
CFM56-5A	X		336-015-001-0	Platform, Fan Blade	72-21-06	CFM
CFM56-5A	X		336-015-102-0	Spacer	72-21-10	CFM
CFM56-5A	X	X	336-018-202-0	Cone, Spinner Rear	72-21-05	CFM
CFM56-5A	X		336-018-402-0	Shroud, Support LPT	72-54-04	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5A	X		336-018-403-0	Shroud, Support LPT	72-54-04	CFM
CFM56-5A	X		336-018-904-0	Fairing, Outer	72-23-39	CFM
CFM56-5A	X		336-018-905-0	Fairing, Outer OGV	72-23-39	CFM
CFM56-5A	X	X	336-023-005-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-5A	X	X	336-023-008-0	Panel, Acoustical Assy	72-23-08	CFM
CFM56-5A	X		336-023-208-0	Panel, Acoustical	72-23-08	CFM
CFM56-5A	X	X	336-023-214-0	Panel, Acoustical	72-23-08	CFM
CFM56-5A	X		336-023-215-0	Panel, Acoustical	72-23-08	CFM
CFM56-5A	X		336-023-219-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-5A	X		336-023-220-0	Panel, Acoustical Assy	72-23-08	CFM
CFM56-5A	X		336-023-221-0	Panel, Acoustical	72-23-08	CFM
CFM56-5A	X		336-023-408-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-5A	X	X	336-023-413-0	Panel, Acoustical	72-23-08	CFM
CFM56-5A	X		336-028-902-0	Tube, Scavenge Oil	72-09-03	CFM
CFM56-5A	X		336-030-105-0	Panel, Acoustical	72-23-08	CFM
CFM56-5A	X	X	336-030-109-0	Panel, Acoustical Forward	72-23-08	CFM
CFM56-5A	X		336-030-110-0	Panel, Acoustical	72-23-08	CFM
CFM56-5A	X		336-030-404-0	Panel, Acoustical Mid	72-23-08	CFM
CFM56-5A	X	X	336-030-407-0	Panel, Acoustical Mid	72-23-08	CFM
CFM56-5A	X		336-030-408-0	Panel, Acoustical	72-23-08	CFM
CFM56-5A	X		336-030-602-0	Skin, Fillet Mid	72-23-09	CFM
CFM56-5A	X		336-043-802-0	Support, Assy No. 1 Bearing	72-22-02	CFM
CFM56-5A	X		336-044-303-0	Shield, LPT Stator Shroud Stage 3	72-54-20	CFM
CFM56-5A	X		336-049-701-0	Tube, Drain	72-09-03	CFM
CFM56-5A	X		336-054-002-0	Tube, Drain No. 3 Bearing	72-09-03	CFM
CFM56-5A	X		336-054-003-0	Tube, Drain No. 3 Bearing	72-09-03	CFM
CFM56-5A	X		336-054-101-0	Tube, Drain	72-09-03	CFM
CFM56-5A	X	X	336-056-402-0	Bracket	72-54-14	CFM
CFM56-5A	X		336-057-003-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-066-403-0	Manifold, Cooling	72-54-11	CFM
CFM56-5A	X		336-066-503-0	Manifold, Cooling	72-23-03	CFM
CFM56-5A	X		336-083-902-0	Panel, Fan Duct	72-23-07	CFM
CFM56-5A	X		336-084-102-0	Panel, Fan Duct	72-23-07	CFM
CFM56-5A	X		336-084-152-0	Panel, Fan Duct	72-23-07	CFM
CFM56-5A	X		336-084-601-0	Panel, Fan Duct	72-23-07	CFM
CFM56-5A	X		336-084-651-0	Panel, Fan Duct	72-23-07	CFM
CFM56-5A	X	X	336-085-114-0	Damper, Assembly	72-21-13	CFM
CFM56-5A	X		336-085-504-0	Retainer, Rear	72-21-14	CFM
CFM56-5A	X		336-086-401-0	Panel, Fan Duct	72-23-07	CFM
CFM56-5A	X		336-086-402-0	Panel, Fan Duct	72-23-07	CFM
CFM56-5A	X		336-086-406-0	Panel, Fan Duct	72-23-07	CFM
CFM56-5A	X		336-086-408-0	Panel, Fan Duct	72-23-07	CFM
CFM56-5A	X		336-086-451-0	Panel, Fan Duct	72-23-07	CFM
CFM56-5A	X		336-086-452-0	Panel, Fan Duct	72-23-07	CFM
CFM56-5A	X		336-086-453-0	Panel, Fan Duct	72-23-07	CFM
CFM56-5A	X		336-086-455-0	Panel, Fan Duct	72-23-07	CFM
CFM56-5A	X		336-400-501-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-400-601-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-400-901-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-400-902-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-401-401-0	Manifold	72-09-03	CFM
CFM56-5A	X		336-402-201-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-402-202-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-402-401-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-402-402-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-402-701-0	Clamp	72-09-04	CFM
CFM56-5A	X		336-404-906-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-405-702-0	Tube, Bleed Bias CDP	72-09-03	CFM
CFM56-5A	X	X	336-405-703-0	Tube, Bleed Bias CDP	72-09-03	CFM
CFM56-5A	X		336-405-802-0	Tube, Bleed Bias CDP	72-09-03	CFM
CFM56-5A	X		336-405-902-0	Tube, Bleed Bias CDP	72-09-03	CFM
CFM56-5A	X		336-406-002-0	Tube, Bleed Bias CDP	72-09-03	CFM
CFM56-5A	X		336-406-102-0	Tube, Bleed Bias CDP	72-09-03	CFM
CFM56-5A	X		336-406-202-0	Tube, Bleed Bias CDP	72-09-03	CFM
CFM56-5A	X		336-406-301-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-406-501-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-406-602-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-407-802-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-409-301-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-409-801-0	Bracket	72-09-04	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5A	X		336-410-001-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-410-201-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-410-301-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-410-501-0	Tube Assy, Air PS12	72-09-03	CFM
CFM56-5A	X		336-412-201-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-412-902-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-413-301-0	Hose, PS3	72-09-03	CFM
CFM56-5A	X		336-413-351-0	Hose, PS3	72-09-03	CFM
CFM56-5A	X		336-414-102-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-414-301-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-450-205-0	Tube, Fuel Injection Nozzle Supply	72-09-03	CFM
CFM56-5A	X		336-450-406-0	Tube, Fuel Inlet Exchanger IDG	72-09-03	CFM
CFM56-5A	X	X	336-450-605-0	Tube, Fuel Inlet Exchanger IDG	72-09-03	CFM
CFM56-5A	X		336-450-805-0	Tube, Fuel Outlet Exchanger IDG	72-09-03	CFM
CFM56-5A	X	X	336-450-807-0	Tube, Fuel Outlet Exchanger IDG	72-09-03	CFM
CFM56-5A	X	X	336-452-005-0	Tube, VSV Head	72-09-03	CFM
CFM56-5A	X	X	336-452-204-0	Tube, VSV Rod	72-09-03	CFM
CFM56-5A	X	X	336-452-406-0	Tube, PCR	72-09-03	CFM
CFM56-5A	X	X	336-452-605-0	Tube, HPT	72-09-03	CFM
CFM56-5A	X		336-452-807-0	Hose, Return Heater	72-09-03	CFM
CFM56-5A	X	X	336-453-603-0	Tube, Supply Oil Pump	72-09-03	CFM
CFM56-5A	X		336-453-802-0	Tube, Supply Oil Pump	72-09-03	CFM
CFM56-5A	X	X	336-454-003-0	Tube, Oil Supply TGB	72-09-03	CFM
CFM56-5A	X		336-454-403-0	Tube, Oil Rear Supply	72-09-03	CFM
CFM56-5A	X		336-454-605-0	Tube, Oil Supply Rear Sump	72-09-03	CFM
CFM56-5A	X		336-454-805-0	Tube, Oil Supply Rear Sump	72-09-03	CFM
CFM56-5A	X		336-455-005-0	Tube, AGB	72-09-03	CFM
CFM56-5A	X		336-455-207-0	Tube, Scavenge AGB	72-09-03	CFM
CFM56-5A	X	X	336-455-208-0	Tube, Scavenge AGB	72-09-03	CFM
CFM56-5A	X		336-455-602-0	Tube, Oil Scavenge Rear Sump	72-09-03	CFM
CFM56-5A	X	X	336-455-802-0	Tube, Oil Aft Sump Scavenge	72-09-03	CFM
CFM56-5A	X		336-456-002-0	Tube, Oil Forward Sump Scavenge	72-09-03	CFM
CFM56-5A	X		336-456-005-0	Tube, Oil Forward Sump Scavenge	72-09-03	CFM
CFM56-5A	X		336-456-206-0	Tube, Oil Heater (Supply Heater)	72-09-03	CFM
CFM56-5A	X		336-456-207-0	Tube, Oil Heater (Supply Heater)	72-09-03	CFM
CFM56-5A	X		336-456-402-0	Tube Assy, Return Fuel Oil Exchange Heater	72-09-03	CFM
CFM56-5A	X		336-456-602-0	Tube Assy, Return Fuel Oil Exchange Heater	72-09-03	CFM
CFM56-5A	X		336-457-208-0	Tube, PS13	72-09-03	CFM
CFM56-5A	X		336-457-406-0	Tube, Air P25	72-09-03	CFM
CFM56-5A	X		336-457-803-0	Tube, Oil Supply Heater	72-09-03	CFM
CFM56-5A	X		336-457-805-0	Tube, Oil Supply Heater	72-09-03	CFM
CFM56-5A	X		336-458-606-0	Tube, Air PS3	72-09-03	CFM
CFM56-5A	X		336-458-608-0	Tube, Air PS3	72-09-03	CFM
CFM56-5A	X		336-458-805-0	Tube, Air PS3	72-09-03	CFM
CFM56-5A	X	X	336-459-003-0	Tube, Drain VSV	72-09-03	CFM
CFM56-5A	X	X	336-459-203-0	Tube, Drain HP TC Valve	72-09-03	CFM
CFM56-5A	X		336-459-406-0	Tube Assy, Vent Oil Tank	72-09-03	CFM
CFM56-5A	X		336-459-610-0	Tube Assy, Air PS12	72-09-03	CFM
CFM56-5A	X		336-459-803-0	Tube, Air P25	72-09-03	CFM
CFM56-5A	X		336-460-007-0	Hose, Fuel Inj Noz Supply	72-09-03	CFM
CFM56-5A	X		336-460-051-0	Hose, Fuel Inj Noz Supply	72-09-03	CFM
CFM56-5A	X		336-460-106-0	Hose, VBV Open	72-09-03	CFM
CFM56-5A	X		336-460-205-0	Hose, VBV Close	72-09-03	CFM
CFM56-5A	X		336-460-302-0	Hose, Stage	72-09-03	CFM
CFM56-5A	X		336-460-402-0	Hose, Fuel SOV	72-09-03	CFM
CFM56-5A	X		336-460-603-0	Hose, VSV Head	72-09-03	CFM
CFM56-5A	X		336-460-703-0	Hose, VSV Rod	72-09-03	CFM
CFM56-5A	X		336-460-803-0	Hose, PCR	72-09-03	CFM
CFM56-5A	X		336-460-903-0	Hose, HPT Fuel	72-09-03	CFM
CFM56-5A	X		336-461-002-0	Hose, Supply Oil Pump	72-09-03	CFM
CFM56-5A	X		336-461-104-0	Tube Assy, Supply Oil Pump	72-09-03	CFM
CFM56-5A	X		336-461-203-0	Hose (Anti Siphon)	72-09-03	CFM
CFM56-5A	X		336-461-501-0	Hose, Return Fuel Oil Heater Exchange	72-09-03	CFM
CFM56-5A	X		336-462-102-0	Hose, Oil Forward Sump Scavenge	72-09-03	CFM
CFM56-5A	X		336-462-202-0	Hose, Nonmetallic	72-09-03	CFM
CFM56-5A	X		336-462-304-0	Hose, RACC	72-09-03	CFM
CFM56-5A	X		336-462-403-0	Hose, Nonmetallic PS13	72-09-03	CFM
CFM56-5A	X		336-462-502-0	Hose, Nonmetallic P25	72-09-03	CFM
CFM56-5A	X		336-462-603-0	Hose, LPT Fuel	72-09-03	CFM
CFM56-5A	X		336-462-802-0	Hose, PS3	72-09-03	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5A	X		336-463-005-0	Tube, Drain Fan Case Water	72-09-03	CFM
CFM56-5A	X		336-463-006-0	Tube, Drain Fan Case Water	72-09-03	CFM
CFM56-5A	X		336-463-203-0	Tube, Supply Heater	72-09-03	CFM
CFM56-5A	X		336-463-405-0	Tube, Drain VBV	72-09-03	CFM
CFM56-5A	X		336-468-206-0	Tube, Oil Supply Rear Sump	72-09-03	CFM
CFM56-5A	X		336-468-605-0	Tube, Oil Scavenge Rear Sump	72-09-03	CFM
CFM56-5A	X		336-469-003-0	Tube Assy, Air PS12	72-09-03	CFM
CFM56-5A	X		336-469-201-0	Tube Assy, Air PS12	72-00-23	CFM
CFM56-5A	X	X	336-469-401-0	Tube Assy, Air PS12	72-00-23	CFM
CFM56-5A	X		336-469-604-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-469-908-0	Tube, Manifold	72-23-21	CFM
CFM56-5A	X		336-469-910-0	Tube, Manifold	72-23-21	CFM
CFM56-5A	X		336-470-101-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-470-102-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-470-201-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-470-202-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-470-403-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-470-404-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-470-503-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-470-504-0	Bracket	72-09-04	CFM
CFM56-5A	X	X	336-470-702-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-470-804-0	Bracket	72-23-35	CFM
CFM56-5A	X		336-470-805-0	Bracket	72-23-35	CFM
CFM56-5A	X		336-470-806-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-472-702-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-475-201-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-475-301-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-476-702-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-476-703-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-476-802-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-476-803-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-476-903-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-477-003-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-477-405-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-477-407-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-477-502-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-477-601-0	Hose, Oil Forward Sump Supply	72-09-03	CFM
CFM56-5A	X		336-477-704-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-477-805-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-478-001-0	Tube Assy, Air PS12	72-09-03	CFM
CFM56-5A	X		336-478-803-0	Tube, HPT Fuel	72-09-03	CFM
CFM56-5A	X		336-479-001-0	Hose, Heat Exchange Oil	72-09-03	CFM
CFM56-5A	X		336-479-303-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-480-201-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-480-303-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-480-305-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-480-604-0	Tube, Drain Fan Case Water	72-09-03	CFM
CFM56-5A	X		336-480-605-0	Tube, Drain Fan Case Water	72-09-03	CFM
CFM56-5A	X		336-481-503-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-481-504-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-482-003-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-482-205-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-482-302-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-482-407-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-482-607-0	Tube, Supply Bearing Front	72-09-03	CFM
CFM56-5A	X		336-482-611-0	Tube, Supply Bearing Front	72-09-03	CFM
CFM56-5A	X		336-483-901-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-485-003-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-486-102-0	Bracket	72-63-16	CFM
CFM56-5A	X		336-486-203-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-486-303-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-488-908-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-490-407-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-490-502-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-490-602-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-490-702-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-490-802-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-493-603-0	Tube, Fuel PB PSF	72-09-03	CFM
CFM56-5A	X	X	336-493-802-0	Tube, Fuel CLP	72-09-03	CFM
CFM56-5A	X		336-494-004-0	Tube, Fuel PSF	72-09-03	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5A	X		336-494-202-0	Tube, Fuel HLP	72-09-03	CFM
CFM56-5A	X		336-495-003-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-495-204-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-495-705-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-496-001-0	Bracket	72-23-35	CFM
CFM56-5A	X		336-496-103-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-496-602-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-496-701-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-496-702-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-496-703-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-496-901-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-497-604-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-498-204-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-498-205-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-498-405-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-498-606-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-498-804-0	Bracket	72-09-04	CFM
CFM56-5A	X	X	336-504-602-0	Tube	72-09-03	CFM
CFM56-5A	X	X	336-504-603-0	Tube	72-09-03	CFM
CFM56-5A	X		336-506-704-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-512-402-0	Tube, Oil Supply Rear Sump	72-09-03	CFM
CFM56-5A	X	X	336-512-403-0	Tube, Oil Supply Rear Sump	72-09-03	CFM
CFM56-5A	X		336-512-601-0	Tube, Oil Scavenge Rear Sump	72-09-03	CFM
CFM56-5A	X	X	336-512-602-0	Tube, Oil Scavenge Rear Sump	72-09-03	CFM
CFM56-5A	X		336-512-901-0	Airscoop, Assy, Inlet	72-09-03	CFM
CFM56-5A	X		336-513-602-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-514-303-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-514-304-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-514-407-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-514-408-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-514-702-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-514-904-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-515-303-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-515-605-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-515-608-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-515-610-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-515-611-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-515-612-0	Bracket Assy	72-09-04	CFMI
CFM56-5A	X		336-515-613-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-515-702-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-516-104-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-516-502-0	Bracket	72-09-04	CFM
CFM56-5A	X	X	336-517-004-0	Tube, Stage	72-09-03	CFM
CFM56-5A	X		336-520-205-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-520-601-0	Tube, Fuel Sov	72-09-03	CFM
CFM56-5A	X		336-520-602-0	Tube, Fuel Sov	72-09-03	CFM
CFM56-5A	X		336-520-804-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-521-503-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-522-101-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-522-203-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-522-702-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-522-803-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-523-102-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-523-302-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-523-402-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-523-904-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-525-403-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-525-404-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-528-103-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-528-105-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-528-202-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-528-203-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-528-402-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-528-502-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-535-602-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-535-701-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-535-702-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-536-104-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-537-002-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-538-501-0	Bracket	72-09-04	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5A	X		336-539-202-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-539-402-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-539-502-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-539-904-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-540-705-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-540-902-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-541-301-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-542-602-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-543-001-0	Tube, Drain VBV	72-09-03	CFM
CFM56-5A	X		336-543-701-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-544-302-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-544-602-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-544-704-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-544-802-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-546-802-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-548-104-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-548-302-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-548-303-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-548-304-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-548-501-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-548-601-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-548-702-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-548-801-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-548-901-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-549-103-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-549-104-0	Bracket	72-09-04	CFM
CFM56-5A	X		336-549-303-0	Bracket	72-09-04	CFM
CFM56-5A	X	X	336-550-102-0	Shims	72-21-22	CFM
CFM56-5A	X		337-152-904-0	Tube, Oil Scavenge Rear Sump	72-09-03	CFM
CFM56-5A	X	X	337-153-303-0	Tube, Oil Heater (Supply Heater)	72-09-03	CFM
CFM56-5A	X		337-153-504-0	Tube, Oil Scavenge Rear Sump	72-09-03	CFM
CFM56-5A	X		337-153-703-0	Tube Assy, Return Fuel Oil Exchange Heater	72-09-03	CFM
CFM56-5A	X		338-022-701-0	Bracket	72-09-04	CFM
CFM56-5A	X		649-430-002-0	Hose, Nonmetallic	72-09-03	CFM
CFM56-5A	X		649-430-003-0	Hose, Nonmetallic P25	72-09-03	CFM
CFM56-5A	X		649-430-008-0	Hose, PS3	72-09-03	CFM
CFM56-5A	X		649-430-009-0	Hose, Return Fuel Oil Heater Exchange	72-09-03	CFM
CFM56-5A	X		649-430-032-0	Hose, Nonmetallic	72-09-03	CFM
CFM56-5A	X		649-430-033-0	Hose, Nonmetallic P25	72-09-03	CFM
CFM56-5A	X		649-430-038-0	Hose, PS3	72-09-03	CFM
CFM56-5A	X	X	649-430-039-0	Hose, Return Fuel Oil Heater Exchange	72-09-03	CFM
CFM56-5A	X	X	649-430-101-0	Hose, Heat Exchange Oil	72-09-03	CFM
CFM56-5A	X		649-430-102-0	Tube Assy, Supply Oil Pump	72-09-03	CFM
CFM56-5A	X		649-430-103-0	Hose, Supply Oil Pump	72-09-03	CFM
CFM56-5A	X		649-430-131-0	Hose, Heat Exchange Oil	72-09-03	CFM
CFM56-5A	X		649-430-132-0	Tube Assy, Supply Oil Pump	72-09-03	CFM
CFM56-5A	X		649-430-133-0	Hose, Supply Oil Pump	72-09-03	CFM
CFM56-5A	X		649-430-330-0	Hose, Oil Forward Sump Scavenge	72-09-03	CFM
CFM56-5A	X		649-430-400-0	Hose, Nonmetallic PS13	72-09-03	CFM
CFM56-5A	X		649-430-402-0	Hose, Oil Forward Sump Supply	72-09-03	CFM
CFM56-5A	X		649-430-430-0	Hose, Nonmetallic PS13	72-09-03	CFM
CFM56-5A	X		649-430-432-0	Hose, Oil Forward Sump Supply	72-09-03	CFM
CFM56-5A	X		649-432-009-0	Hose, Return Fuel Oil Heater Exchange	72-09-03	CFM
CFM56-5A	X		649-773-407-0	Plug	72-09-04	CFM
CFM56-5A	X		9393M42G01	Manifold, Fuel Rod End Var Stator	72-09-03	CFM
CFM56-5A	X		9393M46G05	Manifold, VSV Drain	72-09-03	CFM
CFM56-5A	X	X	9393M46G06	Manifold, VSV Drain	72-09-03	CFM
CFM56-5A	X		9394M25G01	Bracket	72-09-04	CFM
CFM56-5A	X		9394M50P001A	Bracket	72-09-04	CFM
CFM56-5A	X	X	9528M56G04	Nut, Shield	72-41-06	CFM
CFM56-5A	X	X	9529M85G07	Shield, Bolt	72-41-05	CFM
CFM56-5A	X		9909873-103	Duct, Interface Assy	72-09-03	ROHR
CFM56-5A	X		9909874-105	Duct, Assy	72-09-03	ROHR
CFM56-5A	X		9909874-107	Duct, Assy	72-09-03	ROHR
CFM56-5A	X		9966M73P01	Cover, Plate	72-09-03	CFM
CFM56-5A, 5B	X		108280-19	Hose	72-09-03	CFM
CFM56-5A, 5B	X		108280-211	Hose	72-09-03	ROHR
CFM56-5A, 5B	X		108280-215	Hose	72-09-03	ROHR
CFM56-5A, 5B	X		108280-51	Hose Assy	72-09-03	CFM
CFM56-5A, 5B	X		108280-53	Hose	72-09-03	ROHR

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5A, 5B	X		110551-503	Hose, Assy	72-09-03	ROHR
CFM56-5A, 5B	X		110560-1	Hose	72-09-03	ROHR
CFM56-5A, 5B	X		110560-17	Hose	72-09-03	ROHR
CFM56-5A, 5B	X		1-1-09-0782	Hose Assy	71-00-17	ROHR
CFM56-5A, 5B	X		112441-505	Tube	72-09-03	CFM
CFM56-5A, 5B	X		116854-507	Tube	71-00-17	ROHR
CFM56-5A, 5B	X		1443M55G01	Bracket	72-09-04	CFM
CFM56-5A, 5B	X	X	1443M57P01	Bracket	72-09-04	CFM
CFM56-5A, 5B	X	X	1467M30G01	Manifold, Fuel Drain	72-09-03	CFM
CFM56-5A, 5B	X	X	1527M36G01	Flange	72-09-04	CFM
CFM56-5A, 5B	X		238-0207-512	Support Assy	71-21-08, 71-21-06	ROHR
CFM56-5A, 5B	X		238-0244-509	Bracket	71-22-07	ROHR
CFM56-5A, 5B	X		238-0244-511	Bracket	71-22-07	ROHR
CFM56-5A, 5B	X	X	238-0251-515	Bracket	72-09-04	CFM
CFM56-5A, 5B	X		238-0252-505	Retainer	71-22-07	ROHR
CFM56-5A, 5B	X		238-0502-501	Duct Assy	71-00-17	CFM
CFM56-5A, 5B	X		238-0502-503	Duct Assy	71-00-17	ROHR
CFM56-5A, 5B	X		238-0505-505	Bracket	72-09-04	CFM
CFM56-5A, 5B	X		238-0508-503	Duct Assy	71-00-17	ROHR
CFM56-5A, 5B	X	X	238-0513-505	Bracket	72-09-04	CFM
CFM56-5A, 5B	X		238-0515-513	Tube	71-00-17	ROHR
CFM56-5A, 5B	X		238-0610-511	Firesield	72-09-04	CFM
CFM56-5A, 5B	X		238-0658-501	Tube Assy	71-00-17	ROHR
CFM56-5A, 5B	X		238-0658-505	Tube Assy	71-00-17	ROHR
CFM56-5A, 5B	X		238-0701-523	Tube	71-00-17	ROHR
CFM56-5A, 5B	X		238-0701-525	Tube	71-00-17	ROHR
CFM56-5A, 5B	X		238-0701-527	Tube	71-00-17	ROHR
CFM56-5A, 5B	X		238-0701-529	Tube	71-00-17	ROHR
CFM56-5A, 5B	X		238-0726-505	Tube Assy	71-00-17	ROHR
CFM56-5A, 5B	X		238-0751-513	Tube, Assy Tee To Oil Xmtr	71-00-17	ROHR
CFM56-5A, 5B	X		238-0801-513	Tube	71-00-17	ROHR
CFM56-5A, 5B	X		238-0801-541	Tube	71-00-17	ROHR
CFM56-5A, 5B	X		238-0801-543	Tube	71-00-17	ROHR
CFM56-5A, 5B	X		238-0801-551	Tube	71-00-17	ROHR
CFM56-5A, 5B	X		238-0801-557	Tube	71-00-17	ROHR
CFM56-5A, 5B	X		238-0801-561	Tube	71-00-17	ROHR
CFM56-5A, 5B	X		238-0804-503	Manifold	71-00-17	ROHR
CFM56-5A, 5B	X		238-0824-503	Tube Assy	71-00-17	ROHR
CFM56-5A, 5B	X	X	238-0856-173	Bracket	72-09-04	CFM
CFM56-5A, 5B	X		238D0551-509	Duct, Starter Lower Assy	71-00-17	ROHR
CFM56-5A, 5B	X		238D0551-513	Duct, Starter Upper Assy	71-00-17	ROHR
CFM56-5A, 5B	X		238D0551-517	Duct, Starter Upper Assy	71-00-17	ROHR
CFM56-5A, 5B	X		238D0561-503	Hose Assy	71-00-17	ROHR
CFM56-5A, 5B	X		238D0660-501	Tube, Hose	71-00-17	ROHR
CFM56-5A, 5B	X		238D0660-503	Hose/Tube	71-00-17	ROHR
CFM56-5A, 5B	X		238D0660-505	Tube	71-00-17	ROHR
CFM56-5A, 5B	X		238D0660-507	Hose/Tube	71-00-17	ROHR
CFM56-5A, 5B	X	X	301-348-412-0	Sleeve, Speed Sensor	72-22-17	CFM
CFM56-5A, 5B	X		305-150-701-0	Tube Assy	72-09-03	CFM
CFM56-5A, 5B	X		305-156-301-0	Bracket	72-63-16	CFM
CFM56-5A, 5B	X		305-156-603-0	Bracket	72-62-12	CFM
CFM56-5A, 5B	X		305-156-901-0	Bracket	72-63-16	CFM
CFM56-5A, 5B	X		305-157-001-0	Bracket	72-63-16	CFM
CFM56-5A, 5B	X		305-157-103-0	Bracket	72-63-16	CFM
CFM56-5A, 5B	X		305-157-201-0	Bracket	72-63-16	CFM
CFM56-5A, 5B	X	X	305-872-701-0	Tube, Air Ignition Lead Cooling	72-09-03	CFM
CFM56-5A, 5B	X	X	30659-200	Coupling	72-09-04	CFM
CFM56-5A, 5B	X	X	30679-300	Coupling	72-09-04	CFM
CFM56-5A, 5B	X	X	30680-400	Coupling	72-09-04	CFM
CFM56-5A, 5B	X		321-402-401-0	Pipe, Actuator Head Supply (RH)	71-00-17	ROHR
CFM56-5A, 5B	X		321-402-502-0	Pipe, Actuator Rod Supply (RH)	71-00-17	ROHR
CFM56-5A, 5B	X		321-403-002-0	Pipe, Actuator Rod Supply (LH)	71-00-17	ROHR
CFM56-5A, 5B	X		321-409-100-0	Pipe, LH	71-00-17	ROHR
CFM56-5A, 5B	X		321-409-300-0	Pipe, RH	71-00-17	ROHR
CFM56-5A, 5B	X		321-409-551-0	Pipe, RH	71-00-17	ROHR
CFM56-5A, 5B	X		321-409-800-0	Hose	71-00-17	ROHR
CFM56-5A, 5B	X		334-007-367-0	Tube, Oil Supply	72-09-03	CFM
CFM56-5A, 5B	X	X	336-009-505-0	Tube, Supply Oil	72-09-03	CFM
CFM56-5A, 5B	X	X	336-028-701-0	Tube, Scavenge Oil	72-09-03	CFM
CFM56-5A, 5B	X	X	336-031-201-0	Retainer, Blade LPT Rotor	72-54-20	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5A, 5B	X	X	336-031-301-0	Retainer, Blade LPT Rotor	72-54-20	CFM
CFM56-5A, 5B	X		336-044-102-0	Shield, LPT Stator Shroud Stage 1	72-54-20	CFM
CFM56-5A, 5B	X		336-044-202-0	Shield, LPT Stator Shroud Stage 2	72-54-20	CFM
CFM56-5A, 5B	X	X	336-049-702-0	Tube, Drain	72-09-03	CFM
CFM56-5A, 5B	X		336-052-111-0	Tube, Oil Supply	72-09-03	CFM
CFM56-5A, 5B	X		336-091-201-0	Tube, Spacer	72-09-03	CFM
CFM56-5A, 5B	X	X	336-098-601-0	Tube, Oil	72-09-03	CFM
CFM56-5A, 5B	X		336-403-201-0	Bracket	72-09-04	CFM
CFM56-5A, 5B	X		336-450-208-0	Tube, Fuel Injection Nozzle Supply	72-09-03	CFM
CFM56-5A, 5B	X	X	336-451-005-0	Tube, VBV Open	72-09-03	CFM
CFM56-5A, 5B	X	X	336-451-205-0	Tube, VBV Close	72-09-03	CFM
CFM56-5A, 5B	X	X	336-455-405-0	Tube, Oil Scavenge Rear Sump	72-09-03	CFM
CFM56-5A, 5B	X	X	336-457-407-0	Tube, Air P25	72-09-03	CFM
CFM56-5A, 5B	X	X	336-457-606-0	Tube, Air P25	72-09-03	CFM
CFM56-5A, 5B	X		336-459-804-0	Tube, Air P25	72-09-03	CFM
CFM56-5A, 5B	X	X	336-462-051-0	Hose, Oil Scavenge TGB	72-09-03	CFM
CFM56-5A, 5B	X	X	336-469-605-0	Bracket	72-09-04	CFM
CFM56-5A, 5B	X		336-477-701-0	Bracket	72-09-04	CFM
CFM56-5A, 5B	X		336-479-401-0	Bracket	72-09-04	CFM
CFM56-5A, 5B	X		336-480-401-0	Bracket	72-09-04	CFM
CFM56-5A, 5B	X		336-482-301-0	Bracket	72-09-04	CFM
CFM56-5A, 5B	X		336-483-601-0	Bracket	72-09-04	CFM
CFM56-5A, 5B	X		336-486-001-0	Bracket	72-09-04	CFM
CFM56-5A, 5B	X	X	336-489-402-0	Tube, LPT Fuel	72-09-03	CFM
CFM56-5A, 5B	X	X	336-489-604-0	Tube, RACC	72-09-03	CFM
CFM56-5A, 5B	X	X	336-493-204-0	Tube, Fuel Inlet	72-09-03	CFM
CFM56-5A, 5B	X		336-496-105-0	Bracket	72-09-04	CFM
CFM56-5A, 5B	X		336-497-203-0	Bracket	72-09-04	CFM
CFM56-5A, 5B	X	X	336-504-604-0	Tube	72-09-03	CFM
CFM56-5A, 5B	X	X	336-512-905-0	Airscoop, Assy, Inlet	72-09-03	CFM
CFM56-5A, 5B	X	X	336-512-906-0	Airscoop, Assy, Inlet	72-09-03	CFM
CFM56-5A, 5B	X		336-513-603-0	Bracket	72-09-04	CFM
CFM56-5A, 5B	X	X	336-515-803-0	Bracket	72-09-04	CFM
CFM56-5A, 5B	X		336-516-402-0	Bracket	72-09-04	CFM
CFM56-5A, 5B	X		336-516-801-0	Tube, LPT Fuel	72-09-03	CFM
CFM56-5A, 5B	X		336-522-703-0	Bracket	72-09-04	CFM
CFM56-5A, 5B	X		336-523-002-0	Bracket	72-09-04	CFM
CFM56-5A, 5B	X		336-527-202-0	Bracket	72-09-04	CFM
CFM56-5A, 5B	X		336-527-302-0	Bracket	72-09-04	CFM
CFM56-5A, 5B	X		336-544-202-0	Bracket	72-09-04	CFM
CFM56-5A, 5B	X		336-544-303-0	Bracket	72-09-04	CFM
CFM56-5A, 5B	X		336-544-406-0	Bracket	72-09-04	CFM
CFM56-5A, 5B	X		336-544-503-0	Bracket	72-09-04	CFM
CFM56-5A, 5B	X		336-544-603-0	Bracket	72-09-04	CFM
CFM56-5A, 5B	X		336-544-707-0	Bracket	72-09-04	CFM
CFM56-5A, 5B	X		336-544-803-0	Bracket	72-09-04	CFM
CFM56-5A, 5B	X		336-544-902-0	Bracket	72-09-04	CFM
CFM56-5A, 5B	X		336-545-002-0	Bracket	72-09-04	CFM
CFM56-5A, 5B	X		336-545-104-0	Bracket	72-09-04	CFM
CFM56-5A, 5B	X		336-547-902-0	Bracket	72-09-04	CFM
CFM56-5A, 5B	X		336-549-401-0	Bracket	72-09-04	CFM
CFM56-5A, 5B	X	X	338-048-204-0	Tube, Fuel HPT	72-09-03	CFM
CFM56-5A, 5B	X	X	338-056-502-0	Tube, Fuel Injection Nozzle Supply	72-09-03	CFM
CFM56-5A, 5B	X		338-058-601-0	Bracket	72-09-04	CFM
CFM56-5A, 5B	X		338-059-401-0	Bracket	72-09-04	CFM
CFM56-5A, 5B	X		338-069-901-0	Shield, LPT Stator Shroud Stage 3	72-54-20	CFM
CFM56-5A, 5B	X	X	338-070-102-0	Panel, Fan Duct	72-23-07	CFM
CFM56-5A, 5B	X	X	338-070-202-0	Panel, Fan Duct	72-23-07	CFM
CFM56-5A, 5B	X	X	338-070-302-0	Panel, Fan Duct	72-23-07	CFM
CFM56-5A, 5B	X	X	338-070-402-0	Panel, Fan Duct	72-23-07	CFM
CFM56-5A, 5B	X	X	338-070-502-0	Panel, Fan Duct	72-23-07	CFM
CFM56-5A, 5B	X	X	338-072-601-0	Bracket	72-09-04	CFM
CFM56-5A, 5B	X	X	338-125-003-0	Tube, LPT Fuel	72-09-03	CFM
CFM56-5A, 5B	X		338-125-803-0	Bracket	72-09-04	CFM
CFM56-5A, 5B	X		338-126-004-0	Hose, Fuel Inj Noz Supply	72-09-03	CFM
CFM56-5A, 5B	X		338-126-103-0	Hose, Fuel Tube	72-09-03	CFM
CFM56-5A, 5B	X	X	338-126-153-0	Hose, Fuel Tube	72-09-03	CFM
CFM56-5A, 5B	X		338-126-605-0	Bracket	72-09-04	CFM
CFM56-5A, 5B	X		338-129-201-0	Hose, Return Heater	72-09-03	CFM
CFM56-5A, 5B	X	X	338-129-251-0	Hose, Return Heater	72-09-03	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5A, 5B	X		642-5801-521	Tube	71-00-17	ROHR
CFM56-5A, 5B	X		642D5674-501	Hose/Tube Assy	71-00-17	ROHR
CFM56-5A, 5B	X		642D5713-501	Hose/Tube	71-00-17	ROHR
CFM56-5A, 5B	X		642D5752-501	Duct, Interface	71-00-17	ROHR
CFM56-5A, 5B	X		642K9001-211	CFM56-5B QEC Kit	72-09-03, 72-09-04, 71-00-01, 71-00-17	CFM
CFM56-5A, 5B	X		642K9001-91	CFM56-5B QEC Kit	72-09-03, 72-09-04, 71-00-01, 71-00-17	CFM
CFM56-5A, 5B	X		642M5001-501	Duct	71-00-17	ROHR
CFM56-5A, 5B	X		649-412-056-0	Bushing, Plastics	72-09-04	CFM
CFM56-5A, 5B	X		649-430-300-0	Hose, Oil Forward Sump Scavenge	72-09-03	CFM
CFM56-5A, 5B	X	X	649-432-300-0	Hose, Oil Forward Sump Scavenge	72-09-03	CFM
CFM56-5A, 5B	X		649-433-150-0	Hose, Return Heater	72-09-03	CFM
CFM56-5A, 5B	X		649-434-149-0	Hose, Return Heater	72-09-03	CFM
CFM56-5A, 5B	X		9909874-207	Duct, Starter Upper Assy	71-00-17	ROHR
CFM56-5A, 5B	X		AE705925-31	Hose Assy	71-00-17	ROHR
CFM56-5A, 5B	X		AE706058-10	Hose	71-00-17	ROHR
CFM56-5A, 5B	X		AE706058-63	Hose	71-00-17	ROHR
CFM56-5A, 5B	X		AE706058-65	Hose	71-00-17	ROHR
CFM56-5A, 5B	X		AE706058-8	Hose	71-00-17	ROHR
CFM56-5A, 5B	X		AE708821-1	Hose	71-00-17	ROHR
CFM56-5A, 5B	X		AE708821-2	Hose	71-00-17	ROHR
CFM56-5A, 5B	X		AE709459-3	Hose	71-00-17	ROHR
CFM56-5A, 5B	X		AE709461-1	Hose	71-00-17	ROHR
CFM56-5A, 5B	X		C10GT3-06	Clamp	72-09-04	CFM
CFM56-5A, 5B	X		C10GT3-20	Clamp	72-09-04	CFM
CFM56-5A, 5B ,5C	X	X	1895M81G06	Manifold, Fuel	72-41-04, 72-09-03	CFM
CFM56-5A, 5B ,5C	X		1895M81G09	Manifold, Fuel	72-41-04, 72-09-03	CFM
CFM56-5A, 5B ,5C	X		1895M82G06	Manifold, Fuel	72-41-04, 72-09-03	CFM
CFM56-5A, 5B ,5C, 7B	X	X	1276M85P05	Bellcrank, Upper Support	72-32-15	CFM
CFM56-5A, 5B ,5C, 7B	X	X	1386M56P03	Shaft, HPC Front	72-31-07	CFM
CFM56-5A, 5B ,5C, 7B	X	X	1476M79P02	Damper, Forward Sleeve	72-52-07	CFM
CFM56-5A, 5B ,5C, 7B	X		1522M47P01	Pin	72-09-04	CFM
CFM56-5A, 5B ,5C, 7B	X		1523M39P06	Bolt, Hook	72-31-20	CFM
CFM56-5A, 5B ,5C, 7B	X		1523M39P07	Bolt, Hook	72-31-20	CFM
CFM56-5A, 5B ,5C, 7B	X		1895M80G08	Manifold	72-41-04, 72-09-03	CFM
CFM56-5A, 5B ,5C, 7B	X		1895M81G11	Manifold, Fuel	72-41-04, 72-09-03	CFM
CFM56-5A, 5B ,5C, 7B	X		1895M82G08	Manifold, Fuel	72-41-04, 72-09-03	CFM
CFM56-5A, 5B ,5C, 7B	X		305-127-706-0	Mating Ring	72-63-07	CFM
CFM56-5A, 5B ,5C, 7B	X	X	336-026-101-0	Plug Assy, Borescope	72-53-09	CFM
CFM56-5A, 5B ,5C, 7B	X		9524M49P04	Weight, Balance	72-52-09	CFM
CFM56-5A, 5B ,5C, 7B	X		9524M50P07	Weight, Balance	72-52-09	CFM
CFM56-5A, 5B, 5C	X		1324M91G01	Tube, Drain VSV Rod Upper	72-09-03	CFM
CFM56-5A, 5B, 5C	X		1348M38P001A	Bracket	72-09-04	CFM
CFM56-5A, 5B, 5C	X		1348M59P01	Bracket	72-23-35	CFM
CFM56-5A, 5B, 5C	X		1386M56P02	Shaft, HPC Front	72-31-07	CFM
CFM56-5A, 5B, 5C	X		1443M34G03	Bracket	72-09-04	CFM
CFM56-5A, 5B, 5C	X	X	1443M68G01	Manifold, Fuel Drain	72-41-04	CFM
CFM56-5A, 5B, 5C	X		1443M74G02	Bracket	72-09-04	CFM
CFM56-5A, 5B, 5C	X		1443M77G02	Bracket	72-09-04	CFM
CFM56-5A, 5B, 5C	X	X	1443M92G01	Tube, Drain VSV HD Upper	72-09-03	CFM
CFM56-5A, 5B, 5C	X	X	1444M22G02	Tube, Fuel Supply	72-09-03	CFM
CFM56-5A, 5B, 5C	X		1444M50G11	Manifold, Fuel Outer	72-41-04, 72-09-03	CFM
CFM56-5A, 5B, 5C	X		1467M38G01	Bracket	72-09-04	CFM
CFM56-5A, 5B, 5C	X		1527M71G01	Bracket	72-09-04	CFM
CFM56-5A, 5B, 5C	X		1590M28G01	Shaft, HPC Front	72-31-07	CFM
CFM56-5A, 5B, 5C	X		1590M28G02	Shaft, HPC Front	72-31-07	CFM
CFM56-5A, 5B, 5C	X		1590M28G03	Shaft, HPC Front	72-31-07	CFM
CFM56-5A, 5B, 5C	X		1590M28G04	Shaft, HPC Front	72-31-07	CFM
CFM56-5A, 5B, 5C	X		1817M25G01	Bracket	72-09-04	CFM
CFM56-5A, 5B, 5C	X	X	1817M66G01	Manifold, Variable Stator Fuel	72-09-03	CFM
CFM56-5A, 5B, 5C	X	X	1867M25G01	Tube, Fuel Supply	72-09-03	CFM
CFM56-5A, 5B, 5C	X		1867M36G01	Bracket	72-09-04	CFM
CFM56-5A, 5B, 5C	X		1868M15P001A	Bracket	72-09-04	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5A, 5B, 5C	X	X	1895M80G06	Manifold, Fuel Outer	72-41-04, 72-09-03	CFM
CFM56-5A, 5B, 5C	X		1896M75G01	Bracket	72-09-04	CFM
CFM56-5A, 5B, 5C	X		1896M80G01	Bracket	72-09-04	CFM
CFM56-5A, 5B, 5C	X		1896M90G01	Bracket	72-09-04	CFM
CFM56-5A, 5B, 5C	X		1897M57G01	Bracket	72-09-04	CFM
CFM56-5A, 5B, 5C	X		1971M95G01	Manifold, Fuel Outer	72-41-04, 72-09-03	CFM
CFM56-5A, 5B, 5C	X		2046M63G01	Manifold, Fuel Inner	72-41-04, 72-09-03	CFM
CFM56-5A, 5B, 5C	X		2174M20P01	Bracket	72-09-04	CFM
CFM56-5A, 5B, 5C	X	X	2175M48G01	Manifold, Fuel Head End Var Stator	72-09-03	CFM
CFM56-5A, 5B, 5C	X	X	2283M26G01	Manifold, Drain VSV	72-09-03	CFM
CFM56-5A, 5B, 5C	X		2283M37G01	Manifold, Fuel Drain	72-09-03	CFM
CFM56-5A, 5B, 5C	X	X	305-138-501-0	Adapter	72-62-07	CFM
CFM56-5A, 5B, 5C	X	X	305-139-603-0	Pad, Assy Drive Starter	72-63-02	CFM
CFM56-5A, 5B, 5C	X	X	305-140-104-0	Housing, Horiz Drive Shaft, AGB	72-63-20	CFM
CFM56-5A, 5B, 5C	X		305-145-401-0	Shaft, Drive Hand Crank	72-63-11	CFM
CFM56-5A, 5B, 5C	X		305-145-502-0	Nut, Slotted	72-63-12	CFM
CFM56-5A, 5B, 5C	X		305-145-601-0	Cover, Handcranking Assy	72-63-09	CFM
CFM56-5A, 5B, 5C	X		305-146-302-0	Gearshaft, 70 Tooth	72-63-03	CFM
CFM56-5A, 5B, 5C	X		305-146-402-0	Gearshaft, Assy Spur 31 Tooth	72-63-03	CFMI
CFM56-5A, 5B, 5C	X		305-148-801-0	Housing Assy	72-62-04	CFM
CFM56-5A, 5B, 5C	X		305-151-601-0	Adapter, Starter	72-63-15	CFM
CFM56-5A, 5B, 5C	X		305-163-501-0	Gearshaft, 43 Tooth	72-63-03	CFM
CFM56-5A, 5B, 5C	X	X	305-165-301-0	Gearshaft, 71 Tooth	72-63-03	CFM
CFM56-5A, 5B, 5C	X		305-165-401-0	Gearshaft, 43 Tooth	72-63-03	CFM
CFM56-5A, 5B, 5C	X		305-165-501-0	Shaft Assy	72-63-05	CFM
CFM56-5A, 5B, 5C	X		305-165-601-0	Gearshaft Assy	72-63-03	CFM
CFM56-5A, 5B, 5C	X	X	336-030-701-0	Pin Assy, Straight	72-23-10	CFM
CFM56-5A, 5B, 5C	X		336-049-602-0	Plug, Borescope	72-54-20	CFM
CFM56-5A, 5B, 5C	X		336-055-106-0	Bracket	72-09-04	CFM
CFM56-5A, 5B, 5C	X		336-057-802-0	Clevis	72-23-16	CFM
CFM56-5A, 5B, 5C	X		336-081-001-0	Bracket	72-09-04	CFM
CFM56-5A, 5B, 5C	X		336-460-008-0	Hose, Fuel Inj Noz Supply	72-09-03	CFM
CFM56-5A, 5B, 5C	X	X	336-460-071-0	Hose, Fuel Inj Noz Supply	72-09-03	CFM
CFM56-5A, 5B, 5C	X	X	336-462-002-0	Hose, Oil Scavenge TGB	72-09-03	CFM
CFM56-5A, 5B, 5C	X	X	336-462-071-0	Hose, Oil Scavenge TGB	72-09-03	CFM
CFM56-5A, 5B, 5C	X	X	336-477-901-0	Anti Siphon Assy	72-09-04	CFM
CFM56-5A, 5B, 5C	X		336-494-702-0	Bracket	72-09-04	CFM
CFM56-5A, 5B, 5C	X		336-495-706-0	Bracket	72-09-04	CFM
CFM56-5A, 5B, 5C	X		336-499-001-0	Bracket	72-09-04	CFM
CFM56-5A, 5B, 5C	X		336-524-003-0	Bracket	72-09-04	CFM
CFM56-5A, 5B, 5C	X	X	337-152-702-0	Tube, Oil Supply TGB	72-09-03	CFM
CFM56-5A, 5B, 5C	X	X	337-153-101-0	Tube, Drain VBV	72-09-03	CFM
CFM56-5A, 5B, 5C	X	X	337-153-503-0	Tube, Oil Scavenge Rear Sump	72-09-03	CFM
CFM56-5A, 5B, 5C	X		337-153-702-0	Tube Assy, Return Fuel Oil Exchange Heater	72-09-03	CFM
CFM56-5A, 5B, 5C	X	X	337-153-901-0	Tube, Supply Heater	72-09-03	CFM
CFM56-5A, 5B, 5C	X	X	337-153-903-0	Tube, Supply Heater	72-09-03	CFM
CFM56-5A, 5B, 5C	X	X	337-154-101-0	Tube, Drain VBV	72-09-03	CFM
CFM56-5A, 5B, 5C	X	X	649-430-000-0	Hose, Fuel	72-09-03	CFM
CFM56-5A, 5B, 5C	X	X	649-430-004-0	Hose, RACC	72-09-03	CFM
CFM56-5A, 5B, 5C	X		649-430-005-0	Hose, Oil Supply AGB	72-09-03	CFM
CFM56-5A, 5B, 5C	X	X	649-430-006-0	Hose, VBV Open	72-09-03	CFM
CFM56-5A, 5B, 5C	X		649-430-030-0	Hose, Fuel	72-09-03	CFM
CFM56-5A, 5B, 5C	X		649-430-034-0	Hose, RACC	72-09-03	CFM
CFM56-5A, 5B, 5C	X		649-430-035-0	Hose, Oil Supply AGB	72-09-03	CFM
CFM56-5A, 5B, 5C	X		649-430-036-0	Hose, VBV Open	72-09-03	CFM
CFM56-5A, 5B, 5C	X		649-430-201-0	Hose, LPT Fuel	72-09-03	CFM
CFM56-5A, 5B, 5C	X	X	649-430-203-0	Hose, VBV Close	72-09-03	CFM
CFM56-5A, 5B, 5C	X		649-430-231-0	Hose, LPT Fuel	72-09-03	CFM
CFM56-5A, 5B, 5C	X		649-430-233-0	Hose, VBV Close	72-09-03	CFM
CFM56-5A, 5B, 5C	X	X	9393M42G03	Manifold, Fuel Rod End Var Stator	72-09-03	CFM
CFM56-5A, 5B, 5C	X	X	9393M48G01	Tube, Drain VSV Rod Upper	72-09-03	CFM
CFM56-5A, 5B, 5C	X		9393M60G07	Manifold, Fuel Drain (LH)	72-09-03	CFM
CFM56-5A, 5B, 5C	X		9394M20G03	Bracket	72-09-04	CFM
CFM56-5A, 5B, 5C	X		9394M21G01	Bracket	72-09-04	CFM
CFM56-5A, 5B, 5C	X		9394M22G01	Bracket	72-09-04	CFM
CFM56-5A, 5B, 5C	X		C10GT3-04	Clamp	72-09-04	CFM
CFM56-5A, 5B, 5C	X		C10GT3-12	Clamp	72-09-04	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5A, 5B, 5C, 7B	X	X	1276M86P05	Support, Lower Bellcrank	72-32-15	CFM
CFM56-5A, 5B, 5C, 7B	X		1499M47P02	Ring, Dampening	72-31-15	CFM
CFM56-5A, 5B, 5C, 7B	X	X	1873M95P01	Plate	72-09-04	CFM
CFM56-5A, 5B, 5C, 7B	X	X	1882M60G04	Manifold	72-41-04	CFM
CFM56-5A, 5B, 5C, 7B	X	X	1882M62G04	Manifold, Fuel	72-41-04	CFM
CFM56-5A, 5B, 5C, 7B	X		1882M63G04	Manifold, Fuel	72-41-04	CFM
CFM56-5A, 5B, 5C, 7B	X		1895M36G01	Bracket	72-09-04	CFM
CFM56-5A, 5B, 5C, 7B	X		1895M37G01	Bracket	72-09-04	CFM
CFM56-5A, 5B, 5C, 7B	X	X	336-044-801-0	Plug	72-23-35	CFM
CFM56-5A, 5B, 5C, 7B	X		336-049-301-0	Stop, Insert	72-54-20	CFM
CFM56-5A, 5B, 5C, 7B	X	X	336-049-603-0	Plug Assy	72-54-20	CFM
CFM56-5A, 5B, 5C, 7B	X	X	336-063-001-0	Duct, Air	72-54-20	CFM
CFM56-5A, 5B, 5C, 7B	X	X	9514M54G05	Duct, HPT Rotor Air	72-31-11	CFM
CFM56-5A, 5B, 5C, 7B	X	X	9542M62P02	Housing, Inner Support No 3	72-61-13	CFM
CFM56-5A, 5B, 5C, 7B	X	X	9542M62P03	Housing, Inner Support No 3	72-61-13	CFM
CFM56-5A, 5B, 7B	X	X	112441-507	Tube	72-09-03	CFM
CFM56-5A, 5B, 7B	X	X	336-001-804-0	Disk, LPT Stage 1	72-54-03	CFM
CFM56-5A, 5B, 7B	X	X	336-001-909-0	Disk, LPT Stage 2	72-54-03	CFM
CFM56-5A, 5B, 7B	X	X	336-002-006-0	Disk, LPT Stage 3	72-54-03	CFM
CFM56-5A, 5B, 7B	X	X	336-002-105-0	Disk, LPT Stage 4	72-54-03	CFM
CFM56-5A, 5B, 7B	X	X	336-003-102-0	Ring, LPT 4 Rotating	72-54-06	CFM
CFM56-5A, 5B, 7B	X		336-026-806-0	Support #5 Bearing	72-56-02	CFM
CFM56-5A, 5B, 7B	X	X	336-031-401-0	Retainer, Blade LPT Rotor	72-54-20	CFM
CFM56-5A, 5B, 7B	X	X	336-031-501-0	Retainer, Blade LPT Rotor	72-54-20	CFM
CFM56-5A, 5B, 7B	X	X	336-031-802-0	Shield, Heat	72-56-09	CFM
CFM56-5A, 5B, 7B	X	X	338-077-502-0	Support, LPT Rotor	72-54-05	CFM
CFM56-5A, 5B, 7B	X		338-103-405-0	Tube, Oil Supply	72-09-03	CFM
CFM56-5A, 5B, 7B	X		338-106-602-0	Tube, Oil	72-09-03	CFM
CFM56-5A, 5B, 7B	X	X	338-106-603-0	Tube, Oil	72-09-03	CFM
CFM56-5A, 5B, 7B	X	X	338-107-801-0	Tube, Drain Bearing 5	72-09-03	CFM
CFM56-5A, 5C	X		1348M87P001B	Bracket	72-09-04	CFM
CFM56-5A, 5C	X		1467M39G01	Manifold, Fuel Drain	72-09-03	CFM
CFM56-5A, 5C	X		1527M69G02	Tube, Fuel	72-09-03	CFM
CFM56-5A, 5C	X	X	1868M24G01	Manifold, Fuel Drain	72-09-03	CFM
CFM56-5A, 5C	X	X	30076-400	Coupling	72-09-04	CFM
CFM56-5A, 5C	X		336-016-203-0	Mount, Accessory Drive Clevis	72-23-15	CFM
CFM56-5A, 5C	X	X	336-042-801-0	Link Assy, Mount TGB	72-23-14	CFM
CFM56-5A, 5C	X		336-454-203-0	Tube, Oil Supply TGB	72-09-03	CFM
CFM56-5A, 5C	X		336-460-052-0	Hose, Fuel Inj Noz Supply	72-09-03	CFM
CFM56-5A, 5C	X		336-463-209-0	Tube, Supply Heater	72-09-03	CFM
CFM56-5A, 5C	X		336-463-406-0	Tube, Drain VBV	72-09-03	CFM
CFM56-5A, 5C	X		336-543-002-0	Tube, Drain VBV	72-09-03	CFM
CFM56-5A, 5C	X		337-152-701-0	Tube, Oil Supply TGB	72-09-03	CFM
CFM56-5A, 5C	X		337-152-903-0	Tube, Oil Scavenge Rear Sump	72-09-03	CFM
CFM56-5A, 5C	X	X	337-153-302-0	Tube, Oil Heater (Supply Heater)	72-09-03	CFM
CFM56-5A, 5C	X		649-430-001-0	Hose, Fuel SOV	72-09-03	CFM
CFM56-5A, 5C	X		649-430-007-0	Hose, PCR	72-09-03	CFM
CFM56-5A, 5C	X		649-430-031-0	Hose, Fuel SOV	72-09-03	CFM
CFM56-5A, 5C	X		649-430-037-0	Hose, PCR	72-09-03	CFM
CFM56-5A, 5C	X		649-430-100-0	Hose, Return Heater	72-09-03	CFM
CFM56-5A, 5C	X	X	649-430-130-0	Hose, Return Heater	72-09-03	CFM
CFM56-5A, 5C	X		649-430-200-0	Hose, Stage	72-09-03	CFM
CFM56-5A, 5C	X	X	649-430-202-0	Hose, VSV Head	72-09-03	CFM
CFM56-5A, 5C	X		649-430-230-0	Hose, Stage	72-09-03	CFM
CFM56-5A, 5C	X		649-430-232-0	Hose, VSV Head	72-09-03	CFM
CFM56-5A, 5C	X		649-430-401-0	Hose, VSV Rod	72-09-03	CFM
CFM56-5A, 5C	X		649-430-431-0	Hose, VSV Rod	72-09-03	CFM
CFM56-5A, 5C	X		649-432-005-0	Hose, Oil Supply AGB	72-09-03	CFM
CFM56-5A, 5C	X		649-432-100-0	Hose, Return Heater	72-09-03	CFM
CFM56-5A, 5C	X		9393M92P001A	Bracket	72-09-04	CFM
CFM56-5A, 5C	X		C10GT3-10	Clamp	72-09-04	CFM
CFM56-5A, 5C	X		P231P01	Vane, Comp Sstr Stage 1	72-32-02	CFM
CFM56-5A, 5C	X		P231P02	Vane, Comp Sstr Stage 1	72-32-02	CFM
CFM56-5A, 5C	X		P232P01	Vane, Comp Sstr Stage 2	72-32-02	CFM
CFM56-5A, 5C	X		P232P02	Vane, Comp Sstr Stage 2	72-32-02	CFM
CFM56-5A, 5C	X		P233P01	Vane, Comp Sstr Stage 2	72-32-02	CFM
CFM56-5A, 5C	X		P233P02	Vane, Comp Sstr Stage 2	72-32-02	CFM
CFM56-5A, 5C	X		P251P09	Vane, Comp Sstr Stg 1	72-32-02	CFM
CFM56-5A, 5C	X		P251P10	Vane, Comp Sstr Stg 1	72-32-02	CFM
CFM56-5A, 5C	X		P252P05	Vane, Comp Sstr Stg 2	72-32-02	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5A, 5C	X		P252P06	Vane, Comp Sstr Stg 2	72-32-02	CFM
CFM56-5A, 5C	X		P253P11	Vane, Comp Sstr Stg 3	72-32-02	CFM
CFM56-5A, 5C	X		P253P12	Vane, Comp Sstr Stg 3	72-32-02	CFM
CFM56-5B	X		108280-193	Hose	72-09-03	CFM
CFM56-5B	X		108280-219	Hose	72-09-03	CFM
CFM56-5B	X		110551-2	Hose Assy	72-09-03	CFM
CFM56-5B	X	X	110560-29	Hose	72-09-03	CFM
CFM56-5B	X		1-1-09-0786	Hose	71-00-17	ROHR
CFM56-5B	X		1645M33G03	Bracket	72-09-04	CFM
CFM56-5B	X		1677M83G02	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5B	X		1716M87G01	Manifold, Air TCC	72-09-03	CFM
CFM56-5B	X		1716M89G01	Manifold, Air TCC	72-09-03	CFM
CFM56-5B	X		1787M42G01	Tube, Air 5th Stage Upper	72-09-03	CFM
CFM56-5B	X		1787M79G01	Manifold, Drain LH	72-09-03	CFM
CFM56-5B	X		1787M85G01	Tube, Drain Fuel Nozzle	72-09-03	CFM
CFM56-5B	X		1787M87G01	Tube, Drain Fuel Nozzle	72-09-03	CFM
CFM56-5B	X		1788M20G01	Tube, Signal Lower	72-09-03	CFM
CFM56-5B	X		1788M24G01	Tube, Air RACC	72-09-03	CFM
CFM56-5B	X		1788M28P001A	Bracket	72-09-04	CFM
CFM56-5B	X		1788M40G01	Manifold	72-09-03	CFM
CFM56-5B	X		1788M44G01	Tube, Air Signal PS3	72-09-03	CFM
CFM56-5B	X		1788M82G01	Bracket	72-09-04	CFM
CFM56-5B	X		1788M85G03	Manifold, Fuel	72-09-03	CFM
CFM56-5B	X		1788M89G01	Bracket	72-09-04	CFM
CFM56-5B	X		1788M95G01	Manifold, Drain RH	72-09-03	CFM
CFM56-5B	X		1788M97G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5B	X		1813M13G01	Bracket	72-09-04	CFM
CFM56-5B	X		1813M14G01	Bracket	72-09-04	CFM
CFM56-5B	X		1813M15G01	Bracket	72-09-04	CFM
CFM56-5B	X		1813M16G01	Bracket	72-09-04	CFM
CFM56-5B	X		1813M24G01	Manifold, Drain VSV	72-09-03	CFM
CFM56-5B	X		1813M33G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5B	X		1813M50G01	Tube, Fuel Drain Rotor Clearance Control Valve	72-09-03	CFM
CFM56-5B	X		1813M52G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5B	X		1813M54G03	Bracket	72-09-04	CFM
CFM56-5B	X		1813M58G02	Manifold, Fuel Supply Drain	72-09-03	CFM
CFM56-5B	X		1813M60G01	Tube, Fuel PC	72-09-03	CFM
CFM56-5B	X		1813M78P01	Bracket	72-09-04	CFM
CFM56-5B	X		1813M89G01	Bracket	72-09-04	CFM
CFM56-5B	X		1813M91G01	Bracket	72-09-04	CFM
CFM56-5B	X		1813M94G01	Tube, Fuel PCR	72-09-03	CFM
CFM56-5B	X		1813M96G01	Tube, Fuel PCR	72-09-03	CFM
CFM56-5B	X		1817M43G01	Bracket	72-09-04	CFM
CFM56-5B	X		1867M14G01	Bracket	72-09-04	CFM
CFM56-5B	X		1867M23G01	Tube	72-09-03	CFM
CFM56-5B	X		1867M24G01	Bracket	72-09-04	CFM
CFM56-5B	X		1867M27G01	Bracket	72-09-04	CFM
CFM56-5B	X		1867M32G01	Bracket	72-09-04	CFM
CFM56-5B	X		1867M50G01	Tube, Air Signal PS3	72-09-03	CFM
CFM56-5B	X		1869M10G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5B	X		1869M26G01	Bracket	72-09-04	CFM
CFM56-5B	X		1869M28G01	Bracket	72-09-04	CFM
CFM56-5B	X		1869M29G01	Bracket	72-09-04	CFM
CFM56-5B	X		1869M30G01	Bracket	72-09-04	CFM
CFM56-5B	X		1869M31G01	Bracket	72-09-04	CFM
CFM56-5B	X		1869M33G01	Tube, Air Discharge	72-09-03	CFM
CFM56-5B	X		1869M34G01	Bracket	72-09-04	CFM
CFM56-5B	X		1869M45G01	Tube, Start Bleed Discharge	72-09-03	CFM
CFM56-5B	X		1869M46G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5B	X		1869M47G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5B	X		1869M48G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5B	X		1871M12G05	Bracket	72-09-04	CFM
CFM56-5B	X		1871M15G01	Tube	72-09-03	CFM
CFM56-5B	X		1871M18G01	Bracket	72-09-04	CFM
CFM56-5B	X		1871M19G01	Manifold, Fuel Supply Drain	72-09-03	CFM
CFM56-5B	X		1871M32G01	Bracket	72-09-04	CFM
CFM56-5B	X		1871M32G03	Bracket	72-09-04	CFM
CFM56-5B	X		1871M34G01	Bracket	72-09-04	CFM
CFM56-5B	X	X	1871M35G01	Manifold, Drain VSV	72-09-03	CFM
CFM56-5B	X		1871M40G01	Tube, Drain BMV	72-09-03	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5B	X		1871M43G05	Bracket	72-09-04	CFM
CFM56-5B	X		1871M46G01	Tube, Start Bleed Discharge	72-09-03	CFM
CFM56-5B	X		1871M48G01	Bracket	72-09-04	CFM
CFM56-5B	X		1871M48G03	Bracket	72-09-04	CFM
CFM56-5B	X		1871M49G03	Bracket	72-09-04	CFM
CFM56-5B	X		1871M49G05	Bracket	72-09-04	CFM
CFM56-5B	X		1871M60G03	Bracket	72-09-04	CFM
CFM56-5B	X		1871M72G01	Bracket	72-09-04	CFM
CFM56-5B	X		1871M73G01	Bracket	72-09-04	CFM
CFM56-5B	X		1871M73G03	Bracket	72-09-04	CFM
CFM56-5B	X		1871M74G01	Manifold, Fuel Supply Drain	72-09-03	CFM
CFM56-5B	X		1871M75G03	Bracket	72-09-04	CFM
CFM56-5B	X		1871M76G01	Bracket	72-09-04	CFM
CFM56-5B	X		1871M83G01	Bracket	72-09-04	CFM
CFM56-5B	X		1871M85P01	Bracket	72-09-04	CFM
CFM56-5B	X		1871M86G01	Bracket	72-09-04	CFM
CFM56-5B	X		1871M87G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5B	X		1873M50P05	Tube, Borescope	72-09-03	CFM
CFM56-5B	X		1892M16G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5B	X		1892M18G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5B	X		1892M27G01	Bracket	72-09-04	CFM
CFM56-5B	X		1892M36G01	Bracket	72-09-04	CFM
CFM56-5B	X		1892M37G01	Bracket	72-09-04	CFM
CFM56-5B	X		1892M40G02	Tube, Air Signal	72-09-03	CFM
CFM56-5B	X		1892M41G01	Bracket	72-09-04	CFM
CFM56-5B	X		1892M47G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5B	X		1892M54G01	Bracket	72-09-04	CFM
CFM56-5B	X		1892M56G01	Bracket	72-09-04	CFM
CFM56-5B	X		1892M59G01	Bracket	72-09-04	CFM
CFM56-5B	X		1892M62G01	Tube, Air Signal PS4	72-09-03	CFM
CFM56-5B	X		1892M70G01	Tube, Air Transient Bleed Valve Outlet	72-09-03	CFM
CFM56-5B	X		1892M75G01	Bracket	72-09-04	CFM
CFM56-5B	X		1892M77G01	Tube, Air Transient Bleed Valve Inlet	72-09-03	CFM
CFM56-5B	X		1892M80G01	Tube, Air Signal	72-09-03	CFM
CFM56-5B	X		1892M81G01	Bracket	72-09-04	CFM
CFM56-5B	X		1892M82G01	Bracket	72-09-04	CFM
CFM56-5B	X		1892M86G01	Bracket	72-09-04	CFM
CFM56-5B	X		1892M87G01	Bracket	72-09-04	CFM
CFM56-5B	X		1892M88G01	Bracket	72-09-04	CFM
CFM56-5B	X		1892M89G01	Tube, Air LPT Cooling Lower Left	72-09-03	CFM
CFM56-5B	X		1892M92G01	Tube, Air Transient Bleed Valve Outlet	72-09-03	CFM
CFM56-5B	X		1892M93G01	Bracket	72-09-04	CFM
CFM56-5B	X		1892M94G01	Bracket	72-09-04	CFM
CFM56-5B	X		1892M95G01	Manifold, Fuel Supply Drain	72-09-03	CFM
CFM56-5B	X		1892M97G01	Bracket	72-09-04	CFM
CFM56-5B	X		1892M98G01	Bracket	72-09-04	CFM
CFM56-5B	X		1895M13G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5B	X		1895M16G01	Bracket	72-09-04	CFM
CFM56-5B	X		1895M19G01	Manifold, Fuel Supply Drain	72-09-03	CFM
CFM56-5B	X		1895M20G01	Bracket	72-09-04	CFM
CFM56-5B	X		1895M23G01	Bracket	72-09-04	CFM
CFM56-5B	X		1895M60G01	Tube, Air Transient Bleed Valve Outlet	72-09-03	CFM
CFM56-5B	X		1895M76G01	Tube, Air Signal PS4	72-09-03	CFM
CFM56-5B	X		1897M24G01	Tube, Air 5th Stage Lower	72-09-03	CFM
CFM56-5B	X		1897M27G01	Tube, Air Start Bleed	72-09-03	CFM
CFM56-5B	X		1897M28G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5B	X		1897M39G01	Tube, Air 5th Stage Upper	72-09-03	CFM
CFM56-5B	X		1897M49G01	Bracket	72-09-04	CFM
CFM56-5B	X		1897M50G01	Bracket	72-09-04	CFM
CFM56-5B	X		1897M51G01	Tube, Air Start Bleed	72-09-03	CFM
CFM56-5B	X		1897M53G01	Bracket	72-09-04	CFM
CFM56-5B	X	X	1897M68G01	Tube, Air LPT Cooling Lower Left	72-09-03	CFM
CFM56-5B	X		1897M69G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5B	X		1897M72G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5B	X	X	1897M74G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5B	X		1897M75G01	Tube, Air Transient Bleed Valve Inlet	72-09-03	CFM
CFM56-5B	X		1897M76G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5B	X		1971M75G01	Tube, Air Signal PS3	72-09-03	CFM
CFM56-5B	X	X	2046M34G01	Bracket	72-09-04	CFM
CFM56-5B	X		2046M49G01	Bracket	72-09-04	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5B	X	X	2046M71G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5B	X		2046M73G01	Bracket	72-09-04	CFM
CFM56-5B	X		2046M76G01	Bracket	72-09-04	CFM
CFM56-5B	X	X	2046M77G01	Tube, Air LPT Cooling Lower Left	72-09-03	CFM
CFM56-5B	X	X	2046M79G01	Tube, Air Transient Bleed Valve Outlet	72-09-03	CFM
CFM56-5B	X	X	2124M14P01	Venturi	72-09-03	CFM
CFM56-5B	X		2174M22P01	Bracket	72-09-04	CFM
CFM56-5B	X		2174M27G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5B	X		2174M29G01	Bracket	72-09-04	CFM
CFM56-5B	X		2174M30G01	Bracket	72-09-04	CFM
CFM56-5B	X		2174M32G01	Bracket	72-09-04	CFM
CFM56-5B	X		2174M33P01	Bracket	72-09-04	CFM
CFM56-5B	X		2174M34G01	Bracket	72-09-04	CFM
CFM56-5B	X	X	2174M35G01	Bracket	72-09-04	CFM
CFM56-5B	X		2174M36G01	Bracket	72-09-04	CFM
CFM56-5B	X		2174M37G01	Bracket	72-09-04	CFM
CFM56-5B	X		2174M38G01	Bracket	72-09-04	CFM
CFM56-5B	X		2174M39G01	Bracket	72-09-04	CFM
CFM56-5B	X		2174M40G01	Bracket	72-09-04	CFM
CFM56-5B	X		2174M44G01	Bracket	72-09-04	CFM
CFM56-5B	X		2174M55G01	Tube, Air LPT Cooling Lower Left	72-09-03	CFM
CFM56-5B	X		2175M11G01	Bracket	72-09-04	CFM
CFM56-5B	X		2175M12G01	Bracket	72-09-04	CFM
CFM56-5B	X		2175M13G01	Bracket	72-09-04	CFM
CFM56-5B	X		2175M14G01	Bracket	72-09-04	CFM
CFM56-5B	X		2175M15G01	Bracket	72-09-04	CFM
CFM56-5B	X		2283M65G01	Bracket	72-09-04	CFM
CFM56-5B	X		238-0223-503	Retainer	71-21-08	ROHR
CFM56-5B	X		238-0244-517	Bracket	72-09-04	CFM
CFM56-5B	X		238-0244-519	Bracket	72-09-04	CFM
CFM56-5B	X		238-0504-507	Bracket	72-09-04	CFM
CFM56-5B	X		238-0504-509	Bracket	72-09-04	CFM
CFM56-5B	X	X	238-0505-503	Bracket	72-09-04	CFM
CFM56-5B	X		238-0553-501	Bracket	72-09-04	CFM
CFM56-5B	X		238-0554-501	Bracket	72-09-04	CFM
CFM56-5B	X		238-0556-501	Bracket	72-09-04	CFM
CFM56-5B	X		238-0556-503	Bracket	72-09-04	CFM
CFM56-5B	X		238-0557-501	Bracket	72-09-04	CFM
CFM56-5B	X		238-0602-503	Duct, Assy	71-00-17	ROHR
CFM56-5B	X		238-0607-503	Bracket	72-09-04	CFM
CFM56-5B	X		238-0608-503	Bracket	72-09-04	CFM
CFM56-5B	X		238-0654-503	Bracket	72-09-04	CFM
CFM56-5B	X		238-0655-503	Bracket	72-09-04	CFM
CFM56-5B	X		238-0660-501	Bracket	72-09-04	CFM
CFM56-5B	X		238-0704-505	Bracket	72-09-04	CFM
CFM56-5B	X		238-0706-503	Bracket	72-09-04	CFM
CFM56-5B	X		238-0708-507	Bracket	72-09-04	CFM
CFM56-5B	X		238-0801-512	Tube, Assy Reservoir To Manifold	71-00-17	ROHR
CFM56-5B	X		238-0801-539	Tube, Assy, EPU Pad To Reservoir	71-00-17	ROHR
CFM56-5B	X		238-0801-545	Tube, Assy, Manifold Air To Reservoir	71-00-17	ROHR
CFM56-5B	X		238-0801-547	Tube	71-00-17	ROHR
CFM56-5B	X		238-0823-503	Bracket	72-09-04	CFM
CFM56-5B	X		238-0825-503	Bracket	72-09-04	CFM
CFM56-5B	X		238-0856-115	Bracket	72-09-04	CFM
CFM56-5B	X		238-0856-121	Bracket	72-09-04	CFM
CFM56-5B	X		238-0856-127	Bracket	72-09-04	CFM
CFM56-5B	X		238-0856-131	Bracket	72-09-04	CFM
CFM56-5B	X		238-0856-135	Bracket	72-09-04	CFM
CFM56-5B	X		238-0856-139	Bracket	72-09-04	CFM
CFM56-5B	X	X	238-0856-143	Bracket	72-09-04	CFM
CFM56-5B	X		238-0856-147	Bracket	72-09-04	CFM
CFM56-5B	X		238-0856-151	Bracket	72-09-04	CFM
CFM56-5B	X		238-0856-157	Bracket	72-09-04	CFM
CFM56-5B	X		238-0856-159	Bracket	72-09-04	CFM
CFM56-5B	X		238-0856-3	Bracket	72-09-04	CFM
CFM56-5B	X		238-0910-19	Bracket	72-09-04	CFM
CFM56-5B	X		238-0910-35	Bracket	72-09-04	CFM
CFM56-5B	X		238-0910-37	Bracket	72-09-04	CFM
CFM56-5B	X		238-0910-5	Bracket	72-09-04	CFM
CFM56-5B	X		238-0914-503	Bracket	72-09-04	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5B	X		238-0950-15	Bracket	72-09-04	CFM
CFM56-5B	X		238-0950-223	Bracket	72-09-04	CFM
CFM56-5B	X		238-0950-237	Bracket	72-09-04	CFM
CFM56-5B	X		238-0950-309	Bracket	72-09-04	CFM
CFM56-5B	X		238-0950-311	Bracket	72-09-04	CFM
CFM56-5B	X		238-0950-351	Bracket	72-09-04	CFM
CFM56-5B	X		238-0950-63	Bracket	72-09-04	CFM
CFM56-5B	X		238-0950-69	Bracket	72-09-04	CFM
CFM56-5B	X		238-0950-73	Bracket	72-09-04	CFM
CFM56-5B	X		238-0950-75	Bracket	72-09-04	CFM
CFM56-5B	X		238-0950-77	Bracket	72-09-04	CFM
CFM56-5B	X		238-0951-505	Bracket	72-09-04	CFM
CFM56-5B	X		238-0951-507	Bracket	72-09-04	CFM
CFM56-5B	X		238D0561-507	Hose/Tube	71-00-17	ROHR
CFM56-5B	X	X	2406M74G01	Cone, Spinner	72-21-05	CFM
CFM56-5B	X	X	2406M75G01	Cone, Spinner	72-21-05	CFM
CFM56-5B	X		30398-200	Coupling	72-09-04	CFM
CFM56-5B	X	X	30679-175	Clamp	72-09-04	CFM
CFM56-5B	X	X	336-401-403-0	Manifold, Fuel LPTCC	72-09-03	CFM
CFM56-5B	X		336-462-003-0	Hose, Oil Scavenge TGB	72-09-03	CFM
CFM56-5B	X		336-462-052-0	Hose, Oil Scavenge TGB	72-09-03	CFM
CFM56-5B	X		336-544-204-0	Bracket	72-09-04	CFM
CFM56-5B	X	X	338-001-204-0	Cone, Spinner Rear	72-21-05	CFM
CFM56-5B	X		338-001-304-0	Cone, Spinner Rear	72-21-05	CFM
CFM56-5B	X	X	338-001-305-0	Cone, Spinner Rear	72-21-05	CFM
CFM56-5B	X	X	338-001-905-0	Spool, Booster	72-21-04	CFM
CFM56-5B	X	X	338-001-906-0	Spool, Booster	72-21-04	CFM
CFM56-5B	X		338-002-206-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5B	X		338-002-207-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5B	X		338-002-208-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5B	X		338-002-209-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5B	X	X	338-002-218-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5B	X	X	338-002-219-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5B	X	X	338-002-220-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5B	X	X	338-002-221-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5B	X		338-002-306-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5B	X		338-002-307-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5B	X	X	338-002-308-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5B	X	X	338-002-309-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5B	X	X	338-002-318-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5B	X	X	338-002-319-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5B	X	X	338-002-320-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5B	X	X	338-002-321-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5B	X		338-002-406-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-5B	X		338-002-407-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-5B	X	X	338-002-408-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-5B	X	X	338-002-409-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-5B	X	X	338-002-418-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-5B	X	X	338-002-419-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-5B	X	X	338-002-420-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-5B	X	X	338-002-421-0	Blade, Booster Stage 4	72-21-02	CFM
CFM56-5B	X		338-002-518-0	Blade, Booster Stg 5	72-21-02	CFM
CFM56-5B	X		338-002-519-0	Blade, Booster Stg 5	72-21-02	CFM
CFM56-5B	X		338-002-520-0	Blade, Booster Stg 5	72-21-02	CFM
CFM56-5B	X		338-002-521-0	Blade, Booster Stg 5	72-21-02	CFM
CFM56-5B	X		338-002-534-0	Blade, Booster Stg 5	72-21-02	CFM
CFM56-5B	X		338-002-535-0	Blade, Booster Stg 5	72-21-02	CFM
CFM56-5B	X		338-002-536-0	Blade, Booster Stg 5	72-21-02	CFM
CFM56-5B	X		338-002-537-0	Blade, Booster Stg 5	72-21-02	CFM
CFM56-5B	X	X	338-002-542-0	Blade, Booster Stg 5	72-21-02	CFM
CFM56-5B	X	X	338-002-543-0	Blade, Booster Stg 5	72-21-02	CFM
CFM56-5B	X	X	338-002-544-0	Blade, Booster Stg 5	72-21-02	CFM
CFM56-5B	X	X	338-002-545-0	Blade, Booster Stg 5	72-21-02	CFM
CFM56-5B	X	X	338-006-102-0	Spacer	72-21-10	CFM
CFM56-5B	X		338-007-205-0	Fairing	72-23-04	CFM
CFM56-5B	X		338-011-002-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-011-101-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-011-201-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-011-402-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-011-706-0	Tube, Fuel PB/PSF	72-09-03	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5B	X	X	338-011-809-0	Tube, Fuel CLP	72-09-03	CFM
CFM56-5B	X		338-011-906-0	Tube, Fuel PSF	72-09-03	CFM
CFM56-5B	X	X	338-011-908-0	Tube, Fuel PSF	72-09-03	CFM
CFM56-5B	X	X	338-012-006-0	Tube, Fuel HLP	72-09-03	CFM
CFM56-5B	X	X	338-012-104-0	Tube, Fuel Inlet Exchanger IDG	72-09-03	CFM
CFM56-5B	X		338-012-206-0	Tube, Fuel Outlet Exchanger IDG	72-09-03	CFM
CFM56-5B	X		338-012-303-0	Tube, Supply Bearing Front	72-09-03	CFM
CFM56-5B	X	X	338-012-403-0	Tube, Drain Fan Case Water	72-09-03	CFM
CFM56-5B	X		338-012-601-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-012-602-0	Bracket	72-23-35	CFM
CFM56-5B	X		338-012-701-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-012-702-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-012-902-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-013-101-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-013-302-0	Bracket	72-09-04	CFM
CFM56-5B	X	X	338-013-402-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-013-901-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-014-104-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-014-106-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-014-203-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-014-504-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-014-505-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-014-601-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-015-202-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-015-302-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-015-604-0	Tube Assy, Supply Oil Pump	72-09-03	CFM
CFM56-5B	X		338-015-803-0	Tube Assy, Supply Oil Pump	72-09-03	CFM
CFM56-5B	X		338-016-002-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-016-201-0	Bracket	72-23-35	CFM
CFM56-5B	X		338-016-403-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-016-603-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-016-902-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-017-301-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-017-502-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-018-302-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-018-502-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-019-505-0	Tube, Oil Vent Tank	72-09-03	CFM
CFM56-5B	X	X	338-019-703-0	Tube Assy, Return Fuel Oil Exchange Heater	72-09-03	CFM
CFM56-5B	X	X	338-020-603-0	Bracket	72-23-21	CFM
CFM56-5B	X		338-020-703-0	Bracket	72-23-21	CFM
CFM56-5B	X	X	338-020-704-0	Box, Junction Tube Bundle	72-23-21	CFM
CFM56-5B	X		338-020-705-0	Box, Junction Tube Bundle	72-23-21	CFM
CFM56-5B	X	X	338-020-706-0	Box, Junction Tube Bundle	72-23-21	CFM
CFM56-5B	X		338-021-004-0	Bracket	72-09-04	CFM
CFM56-5B	X	X	338-021-007-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-021-303-0	Bracket	72-23-35	CFM
CFM56-5B	X		338-021-402-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-021-604-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-021-605-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-021-702-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-021-804-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-022-101-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-022-301-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-023-003-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-023-203-0	Bracket	72-09-04	CFM
CFM56-5B	X	X	338-023-402-0	Tube, Oil Return Rear Sump	72-09-03	CFM
CFM56-5B	X		338-023-603-0	Tube, Oil Scavenge TGB	72-09-03	CFM
CFM56-5B	X	X	338-023-803-0	Tube, Oil Return Forward Sump	72-09-03	CFM
CFM56-5B	X	X	338-023-804-0	Tube	72-09-03	CFM
CFM56-5B	X		338-024-004-0	Tube, Oil Scavenge AGB	72-09-03	CFM
CFM56-5B	X		338-024-404-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-024-405-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-024-601-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-024-802-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-025-003-0	Tube Assy, Air PS12	72-09-03	CFM
CFM56-5B	X	X	338-025-104-0	Tube, Drain Fan Case Water	72-09-03	CFM
CFM56-5B	X		338-025-402-0	Bracket	72-09-04	CFM
CFM56-5B	X	X	338-026-403-0	Tube, Fuel CLP	72-09-03	CFM
CFM56-5B	X	X	338-026-607-0	Tube, Oil Heater	72-09-03	CFM
CFM56-5B	X		338-026-803-0	Bracket	72-09-04	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5B	X		338-027-201-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-027-302-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-027-402-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-027-801-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-028-001-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-028-301-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-028-601-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-028-704-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-028-802-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-029-204-0	Tube, Fuel PB/PSF	72-09-03	CFM
CFM56-5B	X		338-029-404-0	Tube, Fuel PSF	72-09-03	CFM
CFM56-5B	X	X	338-029-407-0	Tube, Fuel PSF	72-09-03	CFM
CFM56-5B	X		338-029-702-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-030-504-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-030-803-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-031-003-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-031-602-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-031-702-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-032-002-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-032-502-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-032-702-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-032-803-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-033-104-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-033-602-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-033-903-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-034-102-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-034-302-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-034-403-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-034-703-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-035-701-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-036-003-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-036-202-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-037-003-0	Bracket	72-09-04	CFM
CFM56-5B	X	X	338-037-202-0	Tube, Oil Tank Return	72-09-03	CFM
CFM56-5B	X		338-037-601-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-037-901-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-038-101-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-038-601-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-038-602-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-038-604-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-038-801-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-039-002-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-039-402-0	Bracket	72-09-04	CFM
CFM56-5B	X	X	338-039-603-0	Tube, PS3	72-09-03	CFM
CFM56-5B	X		338-039-802-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-040-003-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-040-201-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-040-702-0	Tube Assy, Supply Oil	72-09-03	CFM
CFM56-5B	X	X	338-040-751-0	Tube Assy, Supply Oil	72-09-03	CFM
CFM56-5B	X		338-040-752-0	Tube Assy, Supply Oil	72-09-03	CFM
CFM56-5B	X		338-040-801-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-041-002-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-041-201-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-041-402-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-041-602-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-041-802-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-042-001-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-042-202-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-042-401-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-042-602-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-042-802-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-043-202-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-043-401-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-043-601-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-043-801-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-044-001-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-045-001-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-045-401-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-045-601-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-045-801-0	Bracket	72-09-04	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5B	X		338-046-101-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-046-301-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-046-401-0	Bracket	72-09-04	CFM
CFM56-5B	X	X	338-047-002-0	Tube, Oil Supply AGB/TGB	72-09-03	CFM
CFM56-5B	X	X	338-047-202-0	Tube, PS3	72-09-03	CFM
CFM56-5B	X	X	338-047-204-0	Tube, PS3	72-09-03	CFM
CFM56-5B	X	X	338-047-402-0	Tube, Fuel Stage	72-09-03	CFM
CFM56-5B	X		338-047-602-0	Tube, Fuel Drain	72-09-03	CFM
CFM56-5B	X	X	338-047-802-0	Tube, Fuel	72-09-03	CFM
CFM56-5B	X		338-048-002-0	Tube, Fuel HPT	72-09-03	CFM
CFM56-5B	X		338-048-202-0	Tube, Fuel HPT	72-09-03	CFM
CFM56-5B	X	X	338-048-403-0	Tube, VSV Rod	72-09-03	CFM
CFM56-5B	X		338-048-604-0	Tube, VSV Head	72-09-03	CFM
CFM56-5B	X		338-048-802-0	Tube, Oil Supply Rear Sump	72-09-03	CFM
CFM56-5B	X		338-049-402-0	Tube, Fuel Stage	72-09-03	CFM
CFM56-5B	X		338-049-602-0	Tube, Fuel BMV PB	72-09-03	CFM
CFM56-5B	X		338-049-802-0	Tube, Fuel BMV PSF	72-09-03	CFM
CFM56-5B	X		338-050-202-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-050-301-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-050-801-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-050-902-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-051-001-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-051-401-0	Tube, Manifold	72-23-21	CFM
CFM56-5B	X		338-052-103-0	Hose, Fuel Inj Noz Supply	72-09-03	CFM
CFM56-5B	X		338-052-153-0	Hose, Fuel Inj Noz Supply	72-09-03	CFM
CFM56-5B	X	X	338-052-202-0	Tube, Oil Supply Rear Sump	72-09-03	CFM
CFM56-5B	X		338-052-203-0	Tube, Oil Supply Rear Sump	72-09-03	CFM
CFM56-5B	X		338-052-401-0	Bracket	72-09-04	CFM
CFM56-5B	X	X	338-052-602-0	Tube, Oil Supply Rear Sump	72-09-03	CFM
CFM56-5B	X	X	338-052-802-0	Tube, Oil Scavenge Rear Sump	72-09-03	CFM
CFM56-5B	X		338-052-803-0	Tube, Oil Scavenge Rear Sump	72-09-03	CFM
CFM56-5B	X	X	338-053-002-0	Tube, Oil Supply Rear Sump	72-09-03	CFM
CFM56-5B	X		338-053-204-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-053-602-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-053-803-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-054-001-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-054-303-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-054-501-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-054-802-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-055-004-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-055-005-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-055-202-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-055-401-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-055-601-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-056-201-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-056-701-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-056-901-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-057-001-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-057-301-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-057-401-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-057-601-0	Hose, Fuel HLP	72-09-03	CFM
CFM56-5B	X	X	338-057-651-0	Hose, Fuel HLP	72-09-03	CFM
CFM56-5B	X		338-057-701-0	Hose, Fuel CLP	72-09-03	CFM
CFM56-5B	X		338-057-751-0	Hose, Fuel CLP	72-09-03	CFM
CFM56-5B	X	X	338-057-753-0	Hose, Fuel CLP	72-09-03	CFM
CFM56-5B	X		338-057-802-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-057-803-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-058-401-0	Bracket	72-09-04	CFM
CFM56-5B	X	X	338-059-403-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-059-501-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-059-601-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-059-901-0	Hose, PS3	72-09-03	CFM
CFM56-5B	X	X	338-059-951-0	Hose, PS3	72-09-03	CFM
CFM56-5B	X		338-061-302-0	Manifold Assy, Cooling	72-09-03	CFM
CFM56-5B	X		338-061-352-0	Manifold Assy, Cooling	72-09-03	CFM
CFM56-5B	X		338-062-001-0	Tube, Air	72-22-08	CFM
CFM56-5B	X	X	338-062-003-0	Tube, Air	72-22-08	CFM
CFM56-5B	X		338-062-201-0	Tube, Drain	72-09-03	CFM
CFM56-5B	X	X	338-062-501-0	Tube Assy, Oil No.1 Bearing	72-22-07	CFM
CFM56-5B	X	X	338-062-701-0	Tube, Oil No. 1 Bearing Scavenge	72-09-03	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5B	X		338-067-703-0	Mount, Accessory Drive Clevis	72-23-15	CFM
CFM56-5B	X		338-067-704-0	Mount, Accessory Drive Clevis	72-23-15	CFM
CFM56-5B	X		338-068-007-0	Panel, Acoustical	72-23-08	CFM
CFM56-5B	X		338-068-008-0	Panel, Acoustical	72-23-08	CFM
CFM56-5B	X	X	338-068-010-0	Panel, Acoustical	72-23-08	CFM
CFM56-5B	X		338-068-108-0	Panel, Acoustical	72-23-08	CFM
CFM56-5B	X		338-068-109-0	Panel, Acoustical	72-23-08	CFM
CFM56-5B	X	X	338-068-111-0	Panel, Acoustical	72-23-08	CFM
CFM56-5B	X		338-068-208-0	Panel, Acoustical	72-23-08	CFM
CFM56-5B	X		338-068-209-0	Panel, Acoustical	72-23-08	CFM
CFM56-5B	X	X	338-068-211-0	Panel, Acoustical	72-23-08	CFM
CFM56-5B	X		338-068-307-0	Panel, Acoustical	72-23-08	CFM
CFM56-5B	X		338-068-308-0	Panel, Acoustical	72-23-08	CFM
CFM56-5B	X	X	338-068-310-0	Panel, Acoustical	72-23-08	CFM
CFM56-5B	X		338-068-408-0	Panel, Acoustical	72-23-08	CFM
CFM56-5B	X		338-068-409-0	Panel, Acoustical	72-23-08	CFM
CFM56-5B	X	X	338-068-411-0	Panel, Acoustical	72-23-08	CFM
CFM56-5B	X	X	338-072-801-0	Bracket	72-54-20	CFM
CFM56-5B	X		338-073-008-0	Panel, Acoustical	72-23-08	CFM
CFM56-5B	X		338-073-009-0	Panel, Acoustical	72-23-08	CFM
CFM56-5B	X		338-073-010-0	Panel, Acoustical	72-23-08	CFM
CFM56-5B	X	X	338-073-011-0	Panel, Acoustical	72-23-08	CFM
CFM56-5B	X	X	338-073-012-0	Panel, Acoustical	72-23-08	CFM
CFM56-5B	X	X	338-077-651-0	Link Assy, Mount TGB	72-23-14	CFM
CFM56-5B	X		338-078-804-0	Panel, Acoustical	72-23-08	CFM
CFM56-5B	X	X	338-078-806-0	Panel Assy, Acoustical Forward	72-23-08	CFM
CFM56-5B	X	X	338-078-808-0	Panel, Acoustical Fwd	72-23-08	CFM
CFM56-5B	X		338-079-301-0	Baffle, Rear	72-53-08	CFM
CFM56-5B	X		338-079-504-0	Panel, Acoustical	72-23-08	CFM
CFM56-5B	X	X	338-079-506-0	Panel, Acoustical Forward	72-23-08	CFM
CFM56-5B	X	X	338-079-507-0	Forward Panel	72-23-08	CFM
CFM56-5B	X		338-079-705-0	Panel, Acoustical	72-23-08	CFM
CFM56-5B	X	X	338-079-706-0	Panel, Acoustical Forward	72-23-08	CFM
CFM56-5B	X	X	338-079-708-0	Panel, Acoustical Fwd	72-23-08	CFM
CFM56-5B	X		338-079-901-0	Link	72-23-17	CFM
CFM56-5B	X		338-082-101-0	Tube, Drain No. 3 Bearing	72-23-18	CFM
CFM56-5B	X		338-082-201-0	Manifold, Oil Bearing Supply	72-23-18	CFM
CFM56-5B	X		338-085-202-0	Cone, Front Spinner	72-21-05	CFM
CFM56-5B	X		338-085-203-0	Cone, Spinner Front	72-21-05	CFM
CFM56-5B	X		338-085-204-0	Cone, Spinner Front	72-21-05	CFM
CFM56-5B	X		338-103-601-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-103-701-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-106-702-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-108-101-0	Bracket	72-09-04	CFM
CFM56-5B	X	X	338-118-602-0	Manifold, Air	72-54-18	CFM
CFM56-5B	X		338-122-902-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-122-903-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-125-503-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-125-603-0	Bracket	72-09-04	CFM
CFM56-5B	X	X	338-128-501-0	Hose, Fuel Inlet Exchanger IDG	72-09-03	CFM
CFM56-5B	X	X	338-129-101-0	Tube, Fuel PB/PSF	72-09-03	CFM
CFM56-5B	X		338-129-301-0	Hose, Oil Heater	72-09-03	CFM
CFM56-5B	X		338-130-102-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-163-304-0	Tube, Forward Left	72-09-03	CFM
CFM56-5B	X		338-163-505-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-163-603-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-165-603-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-165-802-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-166-604-0	Tube, Forward Right	72-09-03	CFM
CFM56-5B	X		338-166-804-0	Tube, Aft Right	72-09-03	CFM
CFM56-5B	X		338-166-904-0	Tube, Aft Left	72-09-03	CFM
CFM56-5B	X		338-167-004-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-167-103-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-167-204-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-167-401-0	Box	72-09-03	CFM
CFM56-5B	X		338-168-402-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-168-604-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-168-803-0	Bracket	72-09-04	CFM
CFM56-5B	X		338-169-302-0	Tube, Forward Upper	72-09-03	CFM
CFM56-5B	X	X	338-171-501-0	Tube, Air	72-23-26	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5B	X		338-171-902-0	Plate, Retaining	72-56-07	CFM
CFM56-5B	X	X	338-180-101-0	Tube, Vent Rear	72-55-10	CFM
CFM56-5B	X	X	34H40-400	Clamp	72-09-04	CFM
CFM56-5B	X		390-611-201-0	Plug, Identification	73-21-94	CFM
CFM56-5B	X	X	390-611-301-0	Plug, Identification	73-21-94	CFM
CFM56-5B	X		390-611-501-0	Plug, Identification	CMM 73-21-94	CFM
CFM56-5B	X	X	642-2007-501	Support-Brg, Eng Fwd Mt	71-21-08	CFM
CFM56-5B	X		642-3031-501	Bracket	72-09-04	CFM
CFM56-5B	X	X	642-3031-503	Bracket	72-09-04	CFM
CFM56-5B	X		642-5508-503	Duct Assy	71-00-17	ROHR
CFM56-5B	X		642-5508-505	Duct Assy	omers request to have on the next version a	CFM
CFM56-5B	X		642-5511-503	Duct, Assy	71-00-17	ROHR
CFM56-5B	X		642-5515-507	Tube	71-00-17	ROHR
CFM56-5B	X		642-5515-509	Hose/Tube	71-00-17	ROHR
CFM56-5B	X		642-5517-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-5520-501	Tube	71-00-17	ROHR
CFM56-5B	X		642-5520-503	Hose/Tube	71-00-17	ROHR
CFM56-5B	X		642-5520-505	Tube	71-00-17	ROHR
CFM56-5B	X		642-5520-507	Tube Assy	71-00-17	ROHR
CFM56-5B	X		642-5521-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-5522-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-5523-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-5524-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-5525-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-5612-501	Tube	71-00-17	ROHR
CFM56-5B	X		642-5612-503	Tube	71-00-17	ROHR
CFM56-5B	X		642-5613-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-5651-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-5652-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-5653-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-5656-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-5657-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-5657-503	Bracket	72-09-04	CFM
CFM56-5B	X		642-5658-501	Tube	71-00-17	ROHR
CFM56-5B	X		642-5658-503	Tube, Assy	72-09-03	ROHR
CFM56-5B	X		642-5658-505	Tube	71-00-17	ROHR
CFM56-5B	X		642-5663-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-5664-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-5664-503	Bracket	72-09-04	CFM
CFM56-5B	X		642-5665-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-5671-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-5672-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-5673-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-5676-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-5677-501	Channel, Assy	72-09-04	ROHR
CFM56-5B	X		642-5702-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-5703-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-5705-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-5715-503	Bracket	72-09-04	CFM
CFM56-5B	X		642-5715-507	Bracket	72-09-04	CFM
CFM56-5B	X		642-5752-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-5753-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-5754-501	Tube	71-00-17	ROHR
CFM56-5B	X		642-5754-503	Tube	71-00-17	ROHR
CFM56-5B	X		642-5754-505	Tube	71-00-17	ROHR
CFM56-5B	X		642-5754-507	Tube	71-00-17	ROHR
CFM56-5B	X		642-5801-507	Tube, Assy, Fuel Return Valve To Junction	72-09-03	ROHR
CFM56-5B	X		642-5801-509	Tube	71-00-17	ROHR
CFM56-5B	X		642-5801-511	Tube, Assy, Junction To Drain Mast	72-09-03	ROHR
CFM56-5B	X		642-5801-513	Tube, Assy, HMU to Heat Exchanger Drain Line	72-09-03	ROHR
CFM56-5B	X		642-5801-515	Tube	71-00-17	ROHR
CFM56-5B	X		642-5801-517	Tube, Assy, DF1A To Drain Manifold	72-09-03	ROHR
CFM56-5B	X		642-5826-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-5827-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-5828-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-5829-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-5830-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-5830-503	Bracket	72-09-04	CFM
CFM56-5B	X		642-5851-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-5856-501	Bracket	72-09-04	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5B	X		642-5862-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-5926-501	Tube	71-00-17	ROHR
CFM56-5B	X		642-5926-502	Tube	71-00-17	ROHR
CFM56-5B	X		642-5926-503	Tube	71-00-17	ROHR
CFM56-5B	X		642-5926-504	Tube	71-00-17	ROHR
CFM56-5B	X		642-5927-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-5927-502	Bracket	72-09-04	CFM
CFM56-5B	X		642-9801-1	Clip, Anti Rotation	72-09-04	CFM
CFM56-5B	X		642-9825-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9826-501	Bracket	72-09-04	CFM
CFM56-5B	X	X	642-9827-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9828-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9828-503	Bracket	72-09-04	CFM
CFM56-5B	X		642-9829-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9829-502	Bracket	72-09-04	CFM
CFM56-5B	X		642-9829-505	Bracket	72-09-04	CFM
CFM56-5B	X		642-9830-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9831-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9831-503	Bracket	72-09-04	CFM
CFM56-5B	X		642-9831-505	Bracket	72-09-04	CFM
CFM56-5B	X	X	642-9833-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9834-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9835-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9836-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9837-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9837-503	Bracket	72-09-04	CFM
CFM56-5B	X		642-9838-505	Bracket	72-09-04	CFM
CFM56-5B	X		642-9840-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9841-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9842-503	Bracket	72-09-04	CFM
CFM56-5B	X		642-9843-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9844-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9845-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9846-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9847-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9849-503	Bracket	72-09-04	CFM
CFM56-5B	X		642-9850-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9851-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9851-503	Bracket	72-09-04	CFM
CFM56-5B	X		642-9852-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9855-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9855-502	Bracket	72-09-04	CFM
CFM56-5B	X		642-9855-503	Bracket	72-09-04	CFM
CFM56-5B	X		642-9856-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9857-503	Bracket	72-09-04	CFM
CFM56-5B	X		642-9857-505	Bracket	72-09-04	CFM
CFM56-5B	X		642-9858-502	Bracket	72-09-04	CFM
CFM56-5B	X		642-9861-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9862-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9863-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9866-503	Bracket	72-09-04	CFM
CFM56-5B	X		642-9867-505	Bracket	72-09-04	CFM
CFM56-5B	X		642-9868-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9869-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9869-503	Bracket	72-09-04	CFM
CFM56-5B	X		642-9870-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9870-503	Bracket	72-09-04	CFM
CFM56-5B	X		642-9871-503	Bracket	72-09-04	CFM
CFM56-5B	X		642-9876-503	Bracket	72-09-04	CFM
CFM56-5B	X		642-9877-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9877-503	Bracket	72-09-04	CFM
CFM56-5B	X		642-9878-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9879-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9887-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9889-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9890-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9892-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9893-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9894-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9895-501	Bracket	72-09-04	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5B	X		642-9896-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9897-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9898-503	Bracket	72-09-04	CFM
CFM56-5B	X		642-9899-503	Bracket	72-09-04	CFM
CFM56-5B	X		642-9912-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9913-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9915-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9916-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9917-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9918-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9919-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9920-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9921-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9922-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9923-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9924-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9925-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9926-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9927-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9928-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9929-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9930-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9934-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9936-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9943-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9944-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9945-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9950-503	Bracket	72-09-04	CFM
CFM56-5B	X		642-9951-503	Bracket	72-09-04	CFM
CFM56-5B	X		642-9970-501	Bracket	72-09-04	CFM
CFM56-5B	X		642-9970-505	Bracket	72-09-04	CFM
CFM56-5B	X		642-9971-501	Bracket	72-09-04	CFM
CFM56-5B	X		642D5670-503	Hose	71-00-17	ROHR
CFM56-5B	X		642M5001-503	Duct	71-00-17, 72-09-03	CFM
CFM56-5B	X		649-400-055-0	Clamp	72-09-04	CFM
CFM56-5B	X		649-430-069-0	Hose, Nonmetallic P25	72-09-03	CFM
CFM56-5B	X		649-430-070-0	Hose, PS3	72-09-03	CFM
CFM56-5B	X		649-430-073-0	Hose, VSV Rod	72-09-03	CFM
CFM56-5B	X		649-430-090-0	Hose, PS3	72-09-03	CFM
CFM56-5B	X		649-430-113-0	Hose, Oil Vent Tank	72-09-03	CFM
CFM56-5B	X		649-430-115-0	Hose, Return Heater	72-09-03	CFM
CFM56-5B	X		649-430-221-0	Hose, VSV Head	72-09-03	CFM
CFM56-5B	X		649-430-502-0	Hose	72-09-03	CFM
CFM56-5B	X		649-433-051-0	Hose, Anti Siphon	72-09-03	CFM
CFM56-5B	X	X	649-433-087-0	Hose, Oil Forward Sump Supply	72-09-03	CFM
CFM56-5B	X		649-433-094-0	Hose	72-09-03	CFM
CFM56-5B	X		649-433-144	Hose, Fuel Inlet Exchanger IDG	72-09-03	CFM
CFM56-5B	X		649-433-220-0	Tube, Fuel CLP	72-09-03	CFM
CFM56-5B	X		649-433-234-0	Hose, Fuel Stage 9 BI V	72-09-03	CFM
CFM56-5B	X		649-433-253-0	Hose, Stage	72-09-03	CFM
CFM56-5B	X		649-433-404-0	Hose	72-09-03	CFM
CFM56-5B	X		649-434-051-0	Hose, Anti Siphon	72-09-03	CFM
CFM56-5B	X		649-434-086-0	Hose, Oil Supply AGB	72-09-03	CFM
CFM56-5B	X		649-434-087-0	Hose, Oil Forward Sump Supply	72-09-03	CFM
CFM56-5B	X		649-434-091-0	Hose, Return Fuel Oil Heater Exchange	72-09-03	CFM
CFM56-5B	X		649-434-094-0	Hose	72-09-03	CFM
CFM56-5B	X		649-434-144-0	Hose, Fuel Inlet Exchanger IDG	72-09-03	CFM
CFM56-5B	X		649-434-146-0	Hose, Oil Heater	72-09-03	CFM
CFM56-5B	X		649-434-147-0	Hose, Return Heater	72-09-03	CFM
CFM56-5B	X	X	649-434-219-0	Tube, Fuel Outlet Exchanger IDG	72-09-03	CFM
CFM56-5B	X		649-434-220-0	Tube, Fuel CLP	72-09-03	CFM
CFM56-5B	X		649-434-231-0	Hose, LPT Fuel	72-09-03	CFM
CFM56-5B	X		649-434-234-0	Hose, Fuel PSF	72-09-03	CFM
CFM56-5B	X		649-434-330-0	Hose, Oil Forward Sump Scavenge	72-09-03	CFM
CFM56-5B	X		649-434-404-0	Hose	72-09-03	CFM
CFM56-5B	X		649-434-532-0	Hose	72-09-03	CFM
CFM56-5B	X		649-436-144-0	Hose, Fuel Inlet Exchanger IDG	72-09-03	CFM
CFM56-5B	X		649-436-330-0	Hose, Oil Forward Sump Scavenge	72-09-03	CFM
CFM56-5B	X		751SS14-12SF	Clamp	72-09-04	CFM
CFM56-5B	X		751SS22-8BHTB	Clamp	72-09-04	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5B	X		751SS24-8SF	Clamp	72-09-04	CFM
CFM56-5B	X		754SS29-2-8SF	Clamp	72-09-04	CFM
CFM56-5B	X		9909875-103	Duct, Starter Lower Assy	72-09-03	ROHR
CFM56-5B	X		MS9592-014	Bracket	72-09-04	CFM
CFM56-5B	X		P2A0302	Race	71-21-08	ROHR
CFM56-5B	X		S700M1477-1	Clip, Anti Rotation	72-09-04	CFM
CFM56-5B	X		338-078-807-0	Panel, Acoustical Fwd	72-23-08	CFM
CFM56-5B ,5C, 7B	X	X	1498M46P01	Ring, Retainer HPT Rear	72-52-09	CFM
CFM56-5B ,5C, 7B	X		1522M71P01	Spacer, Manifold+D6937 Air HPT Stator	72-53-05	CFM
CFM56-5B ,5C, 7B	X	X	1523M37P02	Shield, Bolt HPT Nozzle Support	72-41-05	CFM
CFM56-5B ,5C, 7B	X	X	1523M43P01	Shield, Nut HPT Noz Support Rear	72-51-11	CFM
CFM56-5B ,5C, 7B	X	X	1667M72P01	Bushing, Air HPT Stator Manifold	72-53-05	CFM
CFM56-5B, 5A	X		S700H0387-57	Tube, Hose	71-00-17	ROHR
CFM56-5B, 5A	X		S700H0389-15	Hose	71-00-17	ROHR
CFM56-5B, 5A	X		S700H0389-55	Hose	71-00-17	ROHR
CFM56-5B, 5A	X		S700H0389-57	Hose	71-00-17	ROHR
CFM56-5B, 5A	X		S700H0389-63	Hose	71-00-17	ROHR
CFM56-5B, 5A	X		S700H0389-65	Hose	71-00-17	ROHR
CFM56-5B, 5A	X		S700H0391-193	Hose	71-00-17	ROHR
CFM56-5B, 5A	X		S700H0391-199	Hose	71-00-17	ROHR
CFM56-5B, 5A	X		S700H0391-211	Hose	71-00-17	ROHR
CFM56-5B, 5A	X		S700H0391-219	Tube	71-00-17	ROHR
CFM56-5B, 5A	X		S700H0391-53	Tube	71-00-17	ROHR
CFM56-5B, 5A	X		S700H0981-17	Hose	71-00-17	ROHR
CFM56-5B, 5A	X		S700H0981-29	Hose	71-00-17	ROHR
CFM56-5B, 5C	X	X	1444M33G02	Tube, Drain	72-09-03	CFM
CFM56-5B, 5C	X		1467M96G01	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		1523M72G01	Shield, Heat HPT Stator Aft	72-53-02	CFM
CFM56-5B, 5C	X		1605M10G02	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5B, 5C	X		1605M14G02	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5B, 5C	X		1605M38G02	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5B, 5C	X	X	1605M63G01	Tube, Air HPT 9th Stage	72-09-03	CFM
CFM56-5B, 5C	X		1605M65G01	Tube, Drain Fuel	72-09-03	CFM
CFM56-5B, 5C	X		1605M68P001A	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		1605M94G01	Tube, Air Discharge	72-09-03	CFM
CFM56-5B, 5C	X		1621M35G01	Bracket	72-09-04	CFM
CFM56-5B, 5C	X	X	1621M50G01	Manifold, Fuel Drain VSV	72-09-03	CFM
CFM56-5B, 5C	X		1621M52P001A	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		1645M11G01	Tube, Air Start Bleed	72-09-03	CFM
CFM56-5B, 5C	X		1645M19G01	Tube, Air 5th Stage Lower	72-09-03	CFM
CFM56-5B, 5C	X		1645M23P001A	Bracket	72-09-04	CFM
CFM56-5B, 5C	X	X	1645M25G03	Manifold, Air TCC	72-09-03	CFM
CFM56-5B, 5C	X		1645M28G05	Bracket	72-09-04	CFM
CFM56-5B, 5C	X	X	1645M31G03	Tube, Air HPT 9th Stage	72-09-03	CFM
CFM56-5B, 5C	X		1645M33G01	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		1645M43G02	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5B, 5C	X		1645M45P001B	Bracket	72-09-04	CFM
CFM56-5B, 5C	X	X	1677M12G02	Manifold, Fuel	72-09-03	CFM
CFM56-5B, 5C	X		1677M18G01	Manifold, Air Start Bleed 5th Stage	72-09-03	CFM
CFM56-5B, 5C	X		1677M18G02	Manifold, Air Start Bleed 5th Stage	72-09-03	CFM
CFM56-5B, 5C	X		1677M28G01	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		1677M31G01	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		1677M33G01	Manifold, Fuel Drain	72-09-03	CFM
CFM56-5B, 5C	X	X	1677M55G01	Manifold, Fuel Distribution	72-09-03	CFM
CFM56-5B, 5C	X	X	1677M61G01	Manifold	72-09-03	CFM
CFM56-5B, 5C	X		1677M63G01	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		1677M75G01	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		1677M76G01	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		1677M91G01	Tube, Start Bleed Discharge	72-09-03	CFM
CFM56-5B, 5C	X		1677M98G01	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		1677M99P001A	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		1716M12P001A	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		1716M29G01	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		1716M80P001A	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		1716M85P001A	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		1716M97G01	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		1787M40G01	Tube, Air Start Bleed	72-09-03	CFM
CFM56-5B, 5C	X		1787M42G02	Tube, Air 5th Stage Upper	72-09-03	CFM
CFM56-5B, 5C	X		1817M10G01	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		1817M21G01	Tube, Air Signal PS4	72-09-03	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5B, 5C	X		1817M21G02	Tube, Air Signal PS3	72-09-03	CFM
CFM56-5B, 5C	X		1817M35G01	Manifold, Fuel RACC	72-09-03	CFM
CFM56-5B, 5C	X		1817M37P001A	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		1817M38G01	Tube, Fuel Drain Rotor Clearance Control Valve	72-09-03	CFM
CFM56-5B, 5C	X		1817M45G01	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		1817M52G01	Tube, Adapter Air Start Bleed 5th Stage	72-09-03	CFM
CFM56-5B, 5C	X		1817M67G01	Tube, Start Bleed Discharge	72-09-03	CFM
CFM56-5B, 5C	X	X	1851M62P01	Venturi	72-09-03	CFM
CFM56-5B, 5C	X	X	1851M70P01	Spacer, Flow Bleed Bias	72-09-03	CFM
CFM56-5B, 5C	X		1867M19G01	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		1869M13G01	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		1869M14G01	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		1869M32G01	Bracket	72-09-04	CFM
CFM56-5B, 5C	X	X	1892M13G01	Tube, Fuel Drain TBV	72-09-03	CFM
CFM56-5B, 5C	X		1892M21G01	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		1892M23P001A	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		1892M42G01	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		1892M43G01	Bracket	72-09-04	CFM
CFM56-5B, 5C	X	X	1892M61G01	Manifold, Fuel Transient Bleed Valve	72-09-03	CFM
CFM56-5B, 5C	X		1895M17G01	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		1895M58G01	Tube, Air Transient Bleed Valve Inlet	72-09-03	CFM
CFM56-5B, 5C	X		1895M59G01	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		1896M66G01	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		1897M55P001A	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		1897M70G01	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		1971M10G01	Manifold, Fuel Supply	72-09-03	CFM
CFM56-5B, 5C	X		1971M14P01	Flange, Blank	72-09-04	CFM
CFM56-5B, 5C	X	X	1971M74G01	Tube, Air Signal PS3	72-09-03	CFM
CFM56-5B, 5C	X		1971M86G01	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		1971M98G01	Bracket	72-09-04	CFM
CFM56-5B, 5C	X	X	2046M12G01	Tube, Air Signal PS3	72-09-03	CFM
CFM56-5B, 5C	X		2046M13G01	Tube, Air Signal PS3	72-09-03	CFM
CFM56-5B, 5C	X	X	2046M30G01	Tube, Air Transient Bleed Valve Inlet	72-09-03	CFM
CFM56-5B, 5C	X		2046M41G01	Manifold, Drain VSV	72-09-03	CFM
CFM56-5B, 5C	X		2046M59G01	Manifold, TCC	72-09-03	CFM
CFM56-5B, 5C	X		2174M25G01	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		2174M26G01	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		2174M31G01	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		2174M41G01	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		2174M42P01	Bracket	72-09-04	CFM
CFM56-5B, 5C	X	X	2174M43G01	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		2175M16G01	Bracket	72-09-04	CFM
CFM56-5B, 5C	X	X	2283M20G01	Tube, Drain	72-09-03	CFM
CFM56-5B, 5C	X	X	2283M22G01	Manifold, Fuel Drain VSV	72-09-03	CFM
CFM56-5B, 5C	X	X	2283M23G01	Manifold, Drain VSV	72-09-03	CFM
CFM56-5B, 5C	X	X	2283M24G01	Manifold	72-09-03	CFM
CFM56-5B, 5C	X		2283M34G01	Bracket	72-09-04	CFM
CFM56-5B, 5C	X	X	2283M38G01	Manifold, Drain VSV	72-09-03	CFM
CFM56-5B, 5C	X	X	2283M69G01	Manifold, Fuel Drain VSV	72-09-03	CFM
CFM56-5B, 5C	X	X	2283M73G01	Manifold, Fuel Supply	72-09-03	CFM
CFM56-5B, 5C	X	X	2409M00G01	Tube, Fuel Drain TBV	72-09-03	CFM
CFM56-5B, 5C	X	X	2480M87G01	Manifold, Air	72-09-03	CFM
CFM56-5B, 5C	X	X	305-151-403-0	Clamp, Starter	72-09-04	CFM
CFM56-5B, 5C	X	X	337-026-804-0	Tube, Open VBV	72-09-03	CFM
CFM56-5B, 5C	X	X	337-027-203-0	Tube, Close VBV	72-09-03	CFM
CFM56-5B, 5C	X		337-029-705-0	Tube, Oil Rear Supply	72-09-03	CFM
CFM56-5B, 5C	X	X	337-029-902-0	Tube, Oil Supply Rear Sump	72-09-03	CFM
CFM56-5B, 5C	X		337-049-202-0	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		337-050-601-0	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		337-111-802-0	Support, Tube	72-55-20	CFM
CFM56-5B, 5C	X		337-111-903-0	Tube, Support Vent	72-55-20	CFM
CFM56-5B, 5C	X	X	337-123-301-0	Flange	72-23-27	CFM
CFM56-5B, 5C	X	X	337-124-620-0	Shaft, Plug LPT	72-55-16	CFM
CFM56-5B, 5C	X		337-154-601-0	Bracket	72-09-04	CFM
CFM56-5B, 5C	X		337-164-001-0	Tube, Fuel Outlet Exchanger IDG	72-09-03	CFM
CFM56-5B, 5C	X	X	649-430-017-0	Hose, Oil Rear Sump	72-09-03	CFM
CFM56-5B, 5C	X	X	649-430-021-0	Hose, Anti Siphon	72-09-03	CFM
CFM56-5B, 5C	X	X	649-430-047-0	Hose, Oil Rear Sump	72-09-03	CFM
CFM56-5B, 5C	X		649-430-051-0	Hose, Anti Siphon	72-09-03	CFM
CFM56-5B, 5C	X		649-430-067-0	Hose, Oil Forward Sump Supply	72-09-03	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5B, 5C	X	X	649-430-071-0	Hose, Return Fuel Oil Heater Exchange	72-09-03	CFM
CFM56-5B, 5C	X		649-430-114-0	Hose, Fuel Inlet Exchanger IDG	72-09-03	CFM
CFM56-5B, 5C	X	X	649-430-219-0	Tube, Fuel Outlet Exchanger IDG	72-09-03	CFM
CFM56-5B, 5C	X		649-430-220-0	Tube, Fuel CLP	72-09-03	CFM
CFM56-5B, 5C	X		649-430-242-0	Hose, Fuel	72-09-03	CFM
CFM56-5B, 5C	X		9393M46G08	Manifold, Drain VSV	72-09-03	CFM
CFM56-5B, 5C	X		P172G01	Vane, Comp Sstr Stage 2	72-32-02	CFM
CFM56-5B, 5C	X		P173G01	Vane, Comp Sstr Stage 3	72-32-02	CFM
CFM56-5B, 5C	X		P202P12	Vane, Comp Sstr Stage 2	72-32-02	CFM
CFM56-5B, 5C, 7B	X		1498M58P01	Nut, Self Locking Clinch	72-09-04	CFM
CFM56-5B, 5C, 7B	X		1523M37P01	Shield, Bolt	72-41-05	CFM
CFM56-5B, 5C, 7B	X		1523M68P02	Bushing	72-09-04	CFM
CFM56-5B, 5C, 7B	X		1523M70P05	Pin, Straight Threaded	72-09-04	CFM
CFM56-5B, 5C, 7B	X	X	1523M71G06	Shield, Heat HPT Stator Forward	72-53-02	CFM
CFM56-5B, 5C, 7B	X	X	1523M71G07	Shield, Heat HPT Stator Forward	72-53-02	CFM
CFM56-5B, 5C, 7B	X		1590M28G05	Shaft, HPC Front	72-31-07	CFM
CFM56-5B, 5C, 7B	X		1590M28G06	Shaft, HPC Front	72-31-07	CFM
CFM56-5B, 5C, 7B	X		1590M28G07	Shaft, HPC Front	72-31-07	CFM
CFM56-5B, 5C, 7B	X		1590M28G08	Shaft, HPC Front	72-31-07	CFM
CFM56-5B, 5C, 7B	X	X	1873M90P01	Adapter	72-41-11	CFM
CFM56-5B, 5C, 7B	X	X	1971M17G01	Manifold, Fuel (RH)	72-41-04	CFM
CFM56-5B, 5C, 7B	X	X	1971M18G01	Manifold, Fuel Left Side	72-41-04	CFM
CFM56-5B, 5C, 7B	X	X	1971M25G01	Bracket	72-09-04	CFM
CFM56-5B, 5C, 7B	X	X	2002M15P01	Retainer, Blade HPT	72-52-06	CFM
CFM56-5B, 5C, 7B	X	X	2071M15P01	Shield, Nut HPT Nozzle Support Rear	72-51-11	CFM
CFM56-5B, 5C, 7B	X	X	2410M52P01	Ring, Retainer HPT Rear	72-52-09	CFM
CFM56-5B, 5C, 7B	X	X	301-495-102-0	Clamp	72-63-14	CFM
CFM56-5B, 5C, 7B	X	X	305-126-601-0	Adapter	72-63-14	CFM
CFM56-5B, 5C, 7B	X	X	337-011-902-0	Nut	72-22-13	CFM
CFM56-5B, 5C, 7B	X	X	337-111-302-0	Ring, Retaining	72-55-13	CFM
CFM56-5B, 5C, 7B	X	X	649-051-001-0	Cap Assembly	72-54-20	CFM
CFM56-5B, 5C, 7B	X	X	P242P04	Vane, Comp Sstr Stage 2	72-32-02	CFM
CFM56-5B, 5C, 7B	X		P262G01	Vane, Comp Sstr Stg 2	72-32-02	CFM
CFM56-5B, 5C, 7B	X		P263G01	Vane, Comp Sstr Stg 3	72-32-02	CFM
CFM56-5B, 5C, 7B	X		P263G02	Vane, Comp Sstr Stg 3	72-32-02	CFM
CFM56-5B, 7B	X		1324M13P07	Bushing, Igniter	72-41-11	CFM
CFM56-5B, 7B	X	X	1476M79P03	Damper, Fwd Sleeve	72-52-07	CFM
CFM56-5B, 7B	X		1751M35P01	Tube, Igniter Plug	72-09-03	CFM
CFM56-5B, 7B	X		1751M35P02	Tube, Igniter Plug	72-09-03	CFM
CFM56-5B, 7B	X		1808M79P01	Plug, Mach Thread Borescope	72-41-11	CFM
CFM56-5B, 7B	X		1867M55G01	Bracket	72-09-04	CFM
CFM56-5B, 7B	X		1870M11G01	Manifold, Fuel Supply	72-09-03	CFM
CFM56-5B, 7B	X		1871M23G01	Bracket	72-09-04	CFM
CFM56-5B, 7B	X		1871M24G03	Bracket	72-09-04	CFM
CFM56-5B, 7B	X		1871M31P01	Clamp, Tube Lower Triple	72-09-04	CFM
CFM56-5B, 7B	X		1871M51G01	Bracket	72-09-04	CFM
CFM56-5B, 7B	X		1871M81P01	Clamp, Tube Lower Triple	72-09-04	CFM
CFM56-5B, 7B	X		1895M44G01	Manifold, Fuel Supply	72-09-03	CFM
CFM56-5B, 7B	X		1895M45G01	Manifold, Fuel Supply	72-09-03	CFM
CFM56-5B, 7B	X		1957M74G02	Hanger	72-53-04	CFM
CFM56-5B, 7B	X		1958M81G01	Manifold, Fuel Supply	72-09-03	CFM
CFM56-5B, 7B	X		1958M82G01	Manifold, Fuel Supply	72-09-03	CFM
CFM56-5B, 7B	X		1958M86G01	Manifold, Fuel Supply	72-09-03	CFM
CFM56-5B, 7B	X	X	2116M22P01	Bolt, Slab Head	72-31-20	CFM
CFM56-5B, 7B	X		338-011-603-0	Pin	72-23-17	CFM
CFM56-5B, 7B	X		338-014-801-0	Bushing	72-23-17	CFM
CFM56-5B, 7B	X		338-067-302-0	Bracket, Bearing 1	72-09-03	CFM
CFM56-5B, 7B	X	X	338-067-351-0	Bracket	72-22-07	CFM
CFM56-5B, 7B	No		338-067-502-0	Nozzle, Oil	72-09-02	CFM
CFM56-5B, 7B	X	X	338-111-502-0	Ring, LPT 1 Rotating	72-54-06	CFM
CFM56-5B, 7B	X	X	338-111-603-0	Ring, LPT 2 Rotating	72-54-06	CFM
CFM56-5B, 7B	X	X	338-111-701-0	Ring, LPT 3 Rotating	72-54-06	CFM
CFM56-5B, 7B	X	X	338-111-703-0	Ring, LPT3 Rotating	72-54-06	CFM
CFM56-5B, 7B	X	X	338-111-801-0	Retainer, Blade LPT Rotor, Stage 1	72-54-20	CFM
CFM56-5B, 7B	X	X	338-111-901-0	Retainer, Blade LPT Rotor, Stage 2	72-54-20	CFM
CFM56-5B, 7B	X		338-118-501-0	Bracket	72-09-04	CFM
CFM56-5B, 7B	X		338-121-701-0	Plate, Retaining	72-54-20	CFM
CFM56-5B, 7B	X		338-121-702-0	Plate, Retaining	72-54-20	CFM
CFM56-5B, 7B	X	X	338-122-202-0	Ring, Holding	72-54-04	CFM
CFM56-5B, 7B	X		338-122-301-0	Bracket	72-09-04	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5B, 7B	X		340-027-505-0	Manifold Assy, Cooling	72-09-03	CFM
CFM56-5B, 7B	X	X	340-027-506-0	Manifold Assy, Cooling	72-54-11	CFM
CFM56-5B, 7B	X	X	340-027-507-0	Manifold Assy, Cooling	72-54-11	CFM
CFM56-5B, 7B	X		340-027-555-0	Manifold Assy, Cooling	72-09-03	CFM
CFM56-5B, 7B	X	X	340-027-556-0	Manifold Assy, Cooling	72-54-11	CFM
CFM56-5B, 7B	X	X	340-027-557-0	Manifold Assy, Cooling	72-54-11	CFM
CFM56-5B, 7B	X	X	340-029-703-0	Bracket	72-54-14	CFM
CFM56-5B, 7B	X	X	340-029-706-0	Bracket	72-54-14	CFM
CFM56-5B, 7B	X	X	340-029-707-0	Bracket	72-54-14	CFM
CFM56-5B, 7B	X		340-078-315-0	Tube	72-54-11	CFM
CFM56-5B, 7B	X		340-078-341-0	Tube	72-54-11	CFM
CFM56-5B, 7B	X		340-078-350-0	Tube	72-54-11	CFM
CFM56-5B, 7B	X		340-078-503-0	Tube	72-54-11	CFM
CFM56-5B, 7B	X		340-078-521-0	Tube	72-54-11	CFM
CFM56-5B, 7B	X	X	340-165-503-0	Fairing, Flowpath	72-56-04	CFM
CFM56-5B, 7B	X	X	340-166-101-0	Tube, Oil Supply	72-56-01	CFM
CFM56-5B, 7B	X	X	340-177-801-0	Tube, Oil	72-09-03	CFM
CFM56-5B, 7B	X	X	340-178-001-0	Tube, Oil	72-09-03	CFM
CFM56-5B, 7B	X	X	340-180-401-0	Handling	72-56-01	CFM
CFM56-5B, 7B	X	X	340-180-601-0	Handling	72-56-01	CFM
CFM56-5B, 7B	X		340-186-101-0	Tube	72-54-11	CFM
CFM56-5B, 7B	X		340-186-201-0	Tube	72-54-11	CFM
CFM56-5B, 7B	X		340-186-301-0	Tube	72-54-11	CFM
CFM56-5B, 7B	X		340-186-401-0	Tube	72-54-11	CFM
CFM56-5B, 7B	X		340-186-501-0	Tube	72-54-11	CFM
CFM56-5B, 7B	X		340-186-601-0	Tube	72-54-11	CFM
CFM56-5B, 7B	X		340-186-701-0	Tube	72-54-11	CFM
CFM56-5B, 7B	X		340-186-801-0	Tube	72-54-11	CFM
CFM56-5B, 7B	X		340-186-901-0	Tube	72-54-11	CFM
CFM56-5B, 7B	X		340-187-001-0	Tube	72-54-11	CFM
CFM56-5B, 7B	X		340-187-101-0	Tube	72-54-11	CFM
CFM56-5B, 7B	X		340-187-201-0	Tube	72-54-11	CFM
CFM56-5B, 7B	X		340-187-301-0	Tube	72-54-11	CFM
CFM56-5B, 7B	X		340-187-401-0	Tube	72-54-11	CFM
CFM56-5B, 7B	X	X	340-311-401-0	Manifold, Cooling	72-09-03	CFM
CFM56-5B, 7B	X		2410M51P01	Retainer, HPT Blade	72-52-06	CFMI
CFM56-5C	X		1476M79P01	Damper, Forward Sleeve	72-52-07	CFM
CFM56-5C	X		1605M50G01	Bracket	72-09-04	CFM
CFM56-5C	X		1605M51G01	Bracket	72-09-04	CFM
CFM56-5C	X		1605M59G01	Bracket	72-09-04	CFM
CFM56-5C	X		1605M78G03	Tube, Air RACC	72-09-03	CFM
CFM56-5C	X		1605M80G01	Bracket	72-09-04	CFM
CFM56-5C	X		1645M36G03	Bracket	72-09-04	CFM
CFM56-5C	X		1645M47P001A	Bracket	72-09-04	CFM
CFM56-5C	X		1677M20G01	Tube, Air 5th Stage Upper	72-09-03	CFM
CFM56-5C	X		1677M37G01	Tube, Signal Lower	72-09-03	CFM
CFM56-5C	X		1677M49G01	Bracket	72-09-04	CFM
CFM56-5C	X		1677M50P001A	Bracket	72-09-04	CFM
CFM56-5C	X		1677M73G01	Tube, Fuel Drain Rotor Clearance Control Valve	72-09-03	CFM
CFM56-5C	X		1677M83G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5C	X		1677M85G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5C	X		1677M87G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5C	X		1677M89G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5C	X		1716M10G01	Manifold, Fuel Drain	72-09-03	CFM
CFM56-5C	X		1716M32G01	Tube, Air Start Bleed	72-09-03	CFM
CFM56-5C	X		1716M46G01	Bracket	72-09-04	CFM
CFM56-5C	X		1716M48G01	Bracket	72-09-04	CFM
CFM56-5C	X		1716M81G01	Bracket	72-09-04	CFM
CFM56-5C	X		1817M12G01	Tube, Air Total Press	72-09-03	CFM
CFM56-5C	X		1817M41G01	Tube, Air Static Press	72-09-03	CFM
CFM56-5C	X		1888M49G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5C	X		1888M50G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5C	X		1888M51G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5C	X		1888M52G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5C	X	X	1895M96G01	Tube, Air 5th Stage	72-09-03	CFM
CFM56-5C	X		1896M52P01	Bracket	72-09-04	CFM
CFM56-5C	X		1953M11G03	Panel Assy, Upper	72-54-17	CFM
CFM56-5C	X		1953M20P01	Bracket	72-09-04	CFM
CFM56-5C	X		1953M23G01	Bracket	72-09-04	CFM
CFM56-5C	X		1953M27G01	Strut	72-09-04	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5C	X		1953M28G01	Strut	72-09-04	CFM
CFM56-5C	X		1971M40G01	Bracket	72-09-04	CFM
CFM56-5C	X		1971M42G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5C	X		1971M43G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5C	X		1971M55G01	Tube, LPTACC Drain	72-09-03	CFM
CFM56-5C	X		1971M85G01	Bracket	72-09-04	CFM
CFM56-5C	X		2046M21G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5C	X	X	2046M38G01	Tube, Air Transient Bleed Valve Outlet	72-09-03	CFM
CFM56-5C	X		2046M58G01	Bracket	72-09-04	CFM
CFM56-5C	X		2046M60G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-5C	X		2046M75G01	Bracket	72-09-04	CFM
CFM56-5C	X		2046M78G01	Bracket	72-09-04	CFM
CFM56-5C	X		2046M82G01	Manifold, Air TCC	72-09-03	CFM
CFM56-5C	X		2046M83G01	Bracket	72-09-04	CFM
CFM56-5C	X		2046M84G01	Bracket	72-09-04	CFM
CFM56-5C	X		2046M86G01	Bracket	72-09-04	CFM
CFM56-5C	X		2046M90G01	Bracket	72-09-04	CFM
CFM56-5C	X		2046M91G01	Bracket	72-09-04	CFM
CFM56-5C	X		2046M93G01	Bracket	72-09-04	CFM
CFM56-5C	X		2175M17G01	Bracket	72-09-04	CFM
CFM56-5C	X		2175M18G01	Bracket	72-09-04	CFM
CFM56-5C	X		2175M19G01	Bracket	72-09-04	CFM
CFM56-5C	X		2175M20G01	Bracket	72-09-04	CFM
CFM56-5C	X		2175M21G01	Bracket	72-09-04	CFM
CFM56-5C	X		2175M22G01	Bracket	72-09-04	CFM
CFM56-5C	X		2175M23G01	Bracket	72-09-04	CFM
CFM56-5C	X		2175M24G01	Bracket	72-09-04	CFM
CFM56-5C	X		2175M25G01	Bracket	72-09-04	CFM
CFM56-5C	X		2175M26G01	Bracket	72-09-04	CFM
CFM56-5C	X		2175M27G01	Bracket	72-09-04	CFM
CFM56-5C	X		2175M28G01	Bracket	72-09-04	CFM
CFM56-5C	X		2175M29G01	Bracket	72-09-04	CFM
CFM56-5C	X		2175M30G01	Bracket	72-09-04	CFM
CFM56-5C	X		305-159-104-0	Shaft, Outer Radial Drive	72-23-05	CFM
CFM56-5C	X		305-159-502-0	Shaft, Lower Radial Drive	72-62-06	CFM
CFM56-5C	X		305-159-601-0	Shaft, Upper Radial Drive	72-23-38	CFM
CFM56-5C	X		305-161-602-0	Bracket	72-09-04	CFM
CFM56-5C	X		305-161-801-0	Bracket	72-09-04	CFM
CFM56-5C	X		305-162-002-0	Bracket	72-09-04	CFM
CFM56-5C	X		305-162-102-0	Bracket	72-09-04	CFM
CFM56-5C	X		334-007-382-0	Tube, Oil Supply	72-56-01	CFM
CFM56-5C	X		336-456-405-0	Tube Assy, Return Fuel Oil Exchange Heater	72-09-03	CFM
CFM56-5C	X		337-001-020-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5C	X		337-001-021-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5C	X		337-001-022-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5C	X		337-001-023-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5C	X		337-001-025-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5C	X		337-001-026-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5C	X		337-001-027-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5C	X		337-001-028-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5C	X		337-001-040-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5C	X		337-001-041-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5C	X		337-001-042-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5C	X		337-001-043-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-5C	X		337-001-115-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5C	X		337-001-116-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5C	X		337-001-117-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5C	X		337-001-118-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5C	X		337-001-119-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5C	X		337-001-120-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5C	X		337-001-121-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5C	X		337-001-122-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5C	X		337-001-135-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5C	X		337-001-136-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5C	X		337-001-137-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5C	X		337-001-138-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-5C	X		337-001-223-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-5C	X		337-001-224-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-5C	X		337-001-225-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-5C	X		337-001-226-0	Blade, Booster Stg 4	72-21-02	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5C	X		337-001-227-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-5C	X	X	337-001-228-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-5C	X		337-001-229-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-5C	X		337-001-230-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-5C	X		337-001-239-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-5C	X		337-001-240-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-5C	X		337-001-241-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-5C	X		337-001-242-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-5C	X		337-001-332-0	Blade, Booster Stg 5	72-21-02	CFM
CFM56-5C	X		337-001-333-0	Blade, Booster Stg 5	72-21-02	CFM
CFM56-5C	X		337-001-336-0	Blade, Booster Stg 5	72-21-02	CFM
CFM56-5C	X		337-001-337-0	Blade, Booster Stg 5	72-21-02	CFM
CFM56-5C	X		337-001-350-0	Blade, Booster Stg 5	72-21-02	CFM
CFM56-5C	X		337-001-351-0	Blade, Booster Stg 5	72-21-02	CFM
CFM56-5C	X		337-001-356-0	Blade, Booster Stg 5	72-21-02	CFM
CFM56-5C	X		337-001-357-0	Blade, Booster Stg 5	72-21-02	CFM
CFM56-5C	X		337-001-403-0	Disk, LPT	72-54-03	CFM
CFM56-5C	X	X	337-001-404-0	Disk, LPT	72-54-03	CFM
CFM56-5C	X		337-001-502-0	Disk, LPT	72-54-03	CFM
CFM56-5C	X	X	337-001-503-0	Disk, LPT	72-54-03	CFM
CFM56-5C	X		337-001-602-0	Disk, LPT	72-54-03	CFM
CFM56-5C	X	X	337-001-605-0	Disk, LPT	72-54-03	CFM
CFM56-5C	X	X	337-001-802-0	Disk, LPT Stage 5	72-54-03	CFM
CFM56-5C	X		337-002-203-0	Seal, LPT Stg 4 Rotating Air	72-54-06	CFM
CFM56-5C	X		337-002-407-0	Support, Rotor LPT	72-54-05	CFM
CFM56-5C	X		337-002-409-0	Support, Rotor LPT	72-54-05	CFM
CFM56-5C	X		337-002-410-0	Support, Rotor LPT	72-54-05	CFM
CFM56-5C	X		337-005-206-0	Spool, Booster	72-21-04	CFM
CFM56-5C	X		337-005-207-0	Spool, Booster	72-21-04	CFM
CFM56-5C	X		337-005-210-0	Spool, Booster	72-21-04	CFM
CFM56-5C	X		337-005-211-0	Spool, Booster	72-21-04	CFM
CFM56-5C	X		337-005-311-0	Cone, Spinner Rear	72-21-05	CFM
CFM56-5C	X		337-005-312-0	Cone, Spinner Rear	72-21-05	CFM
CFM56-5C	X		337-005-603-0	Spacer	72-21-10	CFM
CFM56-5C	X		337-010-901-0	Tube, Lube	72-09-03	CFM
CFM56-5C	X		337-010-902-0	Tube, Lube	72-09-03	CFM
CFM56-5C	X	X	337-011-105-0	Tube, Air Oil	72-09-03	CFM
CFM56-5C	X	X	337-011-107-0	Tube, Air	72-09-03	CFM
CFM56-5C	X		337-011-502-0	Tube, Drain	72-09-03	CFM
CFM56-5C	X	X	337-014-602-0	Sensor, No. 1 Speed	72-22-15	CFM
CFM56-5C	X		337-023-005-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-023-104-0	Tube, Oil Tank Return	72-09-03	CFM
CFM56-5C	X		337-023-306-0	Tube, Fuel CLP	72-09-03	CFM
CFM56-5C	X		337-023-402-0	Tube, Fuel LPT	72-09-03	CFM
CFM56-5C	X		337-023-505-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-023-603-0	Tube, Fuel PB/PSF	72-09-03	CFM
CFM56-5C	X		337-023-606-0	Tube, Fuel PB/PSF	72-09-03	CFM
CFM56-5C	X		337-024-004-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-024-050-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-024-504-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-024-550-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-024-803-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-024-804-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-025-403-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-025-411-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-025-503-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-025-511-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-025-802-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-025-811-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-026-401-0	Tube, VSV Head	72-09-03	CFM
CFM56-5C	X		337-026-601-0	Tube, VSV Rod	72-09-03	CFM
CFM56-5C	X		337-026-602-0	Tube, VSV Rod	72-09-03	CFM
CFM56-5C	X		337-026-801-0	Tube, Open VBV	72-09-03	CFM
CFM56-5C	X		337-026-803-0	Tube, Open VBV	72-09-03	CFM
CFM56-5C	X		337-027-003-0	Tube, VBV Open	72-09-03	CFM
CFM56-5C	X		337-027-004-0	Tube, VBV Open	72-09-03	CFM
CFM56-5C	X		337-027-201-0	Tube, Close VBV	72-09-03	CFM
CFM56-5C	X		337-027-401-0	Tube, VBV Close	72-09-03	CFM
CFM56-5C	X		337-027-601-0	Tube, Fuel RACC	72-09-03	CFM
CFM56-5C	X		337-027-801-0	Tube, Fuel LPT	72-09-03	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5C	X		337-028-001-0	Tube, Fuel Stage	72-09-03	CFM
CFM56-5C	X		337-028-501-0	Tube, Fuel	72-09-03	CFM
CFM56-5C	X		337-028-505-0	Tube, Fuel	72-09-03	CFM
CFM56-5C	X		337-028-702-0	Tube, Fuel HPT	72-09-03	CFM
CFM56-5C	X		337-028-703-0	Tube, Fuel HPT	72-09-03	CFM
CFM56-5C	X		337-028-902-0	Tube, Fuel HPT	72-09-03	CFM
CFM56-5C	X	X	337-028-903-0	Tube, Fuel HPT	72-09-03	CFM
CFM56-5C	X		337-029-704-0	Tube, Oil Rear Supply	72-09-03	CFM
CFM56-5C	X		337-029-901-0	Tube, Oil Supply Rear Sump	72-09-03	CFM
CFM56-5C	X		337-030-101-0	Tube, Oil Supply Rear Sump	72-09-03	CFM
CFM56-5C	X		337-030-303-0	Tube, Oil Supply Rear Sump	72-09-03	CFM
CFM56-5C	X		337-030-304-0	Tube, Oil Supply Rear Sump	72-09-03	CFM
CFM56-5C	X		337-030-705-0	Tube, Oil Supply AGB/TGB	72-09-03	CFM
CFM56-5C	X		337-031-103-0	Tube, Oil Return Forward Sump	72-09-03	CFM
CFM56-5C	X		337-031-303-0	Tube, Oil Return Rear Sump	72-09-03	CFM
CFM56-5C	X		337-031-306-0	Tube, Oil Return Rear Sump	72-09-03	CFM
CFM56-5C	X		337-031-704-0	Tube, Oil Scavenge Rear Sump	72-09-03	CFM
CFM56-5C	X		337-032-705-0	Tube, Oil Heater	72-09-03	CFM
CFM56-5C	X		337-032-707-0	Tube, Oil Heater	72-09-03	CFM
CFM56-5C	X		337-032-904-0	Tube Assy, Return Fuel Oil Exchange Heater	72-09-03	CFM
CFM56-5C	X		337-032-905-0	Tube Assy, Return Fuel Oil Exchange Heater	72-09-03	CFM
CFM56-5C	X		337-033-702-0	Tube, Air PS3	72-09-03	CFM
CFM56-5C	X		337-033-704-0	Tube, Air PS3	72-09-03	CFM
CFM56-5C	X		337-033-901-0	Tube, Air Ignition Lead Cooling	72-09-03	CFM
CFM56-5C	X		337-033-903-0	Tube, Air Ignition Lead Cooling	72-09-03	CFM
CFM56-5C	X		337-034-104-0	Tube, PS3	72-09-03	CFM
CFM56-5C	X		337-034-105-0	Tube, PS3	72-09-03	CFM
CFM56-5C	X		337-034-107-0	Tube, PS3	72-09-03	CFM
CFM56-5C	X		337-034-304-0	Tube, Drain Fan Case Water	72-09-03	CFM
CFM56-5C	X		337-034-305-0	Tube, Drain Fan Case Water	72-09-03	CFM
CFM56-5C	X	X	337-034-708-0	Tube, Fuel Outlet Exchanger IDG	72-09-03	CFM
CFM56-5C	X		337-034-906-0	Tube, Fuel Inlet Exchanger IDG	72-09-03	CFM
CFM56-5C	X		337-035-304-0	Tube, Fuel PSF	72-09-03	CFM
CFM56-5C	X		337-035-306-0	Tube, Fuel PSF	72-09-03	CFM
CFM56-5C	X		337-035-307-0	Tube, Fuel PSF	72-09-03	CFM
CFM56-5C	X		337-035-503-0	Tube, Fuel PSF	72-09-03	CFM
CFM56-5C	X		337-035-703-0	Tube, Fuel PB/PSF	72-09-03	CFM
CFM56-5C	X		337-035-905-0	Tube, Fuel HLP	72-09-03	CFM
CFM56-5C	X		337-036-109-0	Tube, Fuel CLP	72-09-03	CFM
CFM56-5C	X		337-036-112-0	Tube, Fuel CLP	72-09-03	CFM
CFM56-5C	X		337-036-505-0	Tube Assy, Supply Oil Pump	72-09-03	CFM
CFM56-5C	X		337-036-704-0	Tube Assy, Supply Oil Pump	72-09-03	CFM
CFM56-5C	X		337-036-917-0	Tube, Supply Bearing Front	72-09-03	CFM
CFM56-5C	X		337-037-102-0	Tube, Oil Vent Tank	72-09-03	CFM
CFM56-5C	X		337-037-103-0	Tube, Oil Vent Tank	72-09-03	CFM
CFM56-5C	X		337-037-506-0	Tube Assy, Air PS12	72-09-03	CFM
CFM56-5C	X		337-037-507-0	Tube Assy, Air PS12	72-09-03	CFM
CFM56-5C	X		337-038-102-0	Tube Assy, Air PS12	72-09-03	CFM
CFM56-5C	X		337-038-702-0	Tube, Air P25	72-09-03	CFM
CFM56-5C	X		337-039-602-0	Tube, Fuel	72-09-03	CFM
CFM56-5C	X		337-039-802-0	Tube, Fuel	72-09-03	CFM
CFM56-5C	X		337-039-803-0	Tube, Fuel	72-09-03	CFM
CFM56-5C	X		337-040-004-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-040-206-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-040-306-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-041-002-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-041-203-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-041-204-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-041-302-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-041-703-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-041-901-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-042-403-0	Clip, Assy	72-09-04	CFM
CFM56-5C	X		337-043-402-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-043-602-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-043-802-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-044-902-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-045-001-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-046-702-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-046-905-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-047-004-0	Bracket	72-09-04	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5C	X		337-047-104-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-047-204-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-047-304-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-047-305-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-047-702-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-047-803-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-048-101-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-048-201-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-048-401-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-048-506-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-048-704-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-049-103-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-049-508-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-049-702-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-049-809-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-049-904-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-050-001-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-050-202-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-050-302-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-050-401-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-050-505-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-050-701-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-051-704-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-051-902-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-052-001-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-052-408-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-052-409-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-052-410-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-052-802-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-053-401-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-053-402-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-053-503-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-053-505-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-053-804-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-053-901-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-053-902-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-056-002-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-057-001-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-057-103-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-057-603-0	Tube, PS13	72-09-03	CFM
CFM56-5C	X		337-058-603-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-058-802-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-058-803-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-059-501-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-059-602-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-059-902-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-060-102-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-060-202-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-060-301-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-060-603-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-060-904-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-061-102-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-061-403-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-062-101-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-062-502-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-062-601-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-063-103-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-063-301-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-063-801-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-063-802-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-063-903-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-063-904-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-064-004-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-064-104-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-064-905-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-065-002-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-065-102-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-066-805-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-066-901-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-066-902-0	Bracket	72-09-04	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5C	X		337-067-004-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-067-008-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-067-809-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-067-813-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-068-401-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-068-701-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-070-313-0	Panel, Acoustical	72-23-08	CFM
CFM56-5C	X		337-070-314-0	Panel, Accoustical	72-23-08	CFM
CFM56-5C	X		337-070-415-0	Panel	72-23-08	CFM
CFM56-5C	X		337-070-416-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-5C	X		337-070-515-0	Panel, Acoustical	72-23-08	CFM
CFM56-5C	X		337-070-517-0	Panel, Acoustical	72-23-08	CFM
CFM56-5C	X		337-070-615-0	Panel, Acoustical	72-23-08	CFM
CFM56-5C	X		337-070-617-0	Panel, Acoustical	72-23-08	CFM
CFM56-5C	X		337-070-707-0	Panel, Acoustical	72-23-08	CFM
CFM56-5C	X		337-070-708-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-5C	X		337-070-813-0	Panel, Acoustical	72-23-08	CFM
CFM56-5C	X		337-070-814-0	Panel, Accoustical	72-23-08	CFM
CFM56-5C	X		337-070-913-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-5C	X		337-070-914-0	Panel, Accoustical	72-23-08	CFM
CFM56-5C	X		337-071-007-0	Panel, Acoustical	72-23-08	CFM
CFM56-5C	X		337-071-008-0	Panel, Acoustical	72-23-08	CFM
CFM56-5C	X		337-071-121-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-5C	X		337-071-123-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-5C	X		337-071-215-0	Panel, Acoustical	72-23-08	CFM
CFM56-5C	X		337-071-216-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-5C	X		337-071-318-0	Panel, Acoustical	72-23-08	CFM
CFM56-5C	X		337-071-321-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-5C	X		337-071-419-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-5C	X		337-071-422-0	Panel, Accoustical	72-23-08	CFM
CFM56-5C	X		337-071-516-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-5C	X		337-071-518-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-5C	X		337-071-613-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-5C	X		337-071-614-0	Panel, Acoustical Aft	72-23-08	CFM
CFM56-5C	X		337-073-205-0	Panel, Acoustical	72-23-08	CFM
CFM56-5C	X	X	337-073-206-0	Panel, Accoustical Forward	72-23-08	CFM
CFM56-5C	X	X	337-073-207-0	Panel, Acoustical	72-23-08	CFM
CFM56-5C	X		337-087-302-0	Flange Assy	72-56-07	CFM
CFM56-5C	X		337-089-003-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-090-301-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-094-803-0	Shield, LPT Stator Shroud Stage 1	72-54-20	CFM
CFM56-5C	X		337-094-902-0	Shield, LPT Stator Shroud Stage 2	72-54-20	CFM
CFM56-5C	X		337-095-001-0	Shield, LPT Stator Shroud Stage 3	72-54-20	CFM
CFM56-5C	X		337-095-102-0	Shield, LPT Stator Shroud Stage 4	72-54-20	CFM
CFM56-5C	X		337-095-202-0	Shield, LPT Stator Shroud Stage 5	72-54-20	CFM
CFM56-5C	X		337-095-203-0	Shield, LPT Stator Shroud Stage 5	72-54-20	CFM
CFM56-5C	X		337-099-007-0	Manifold Assy, Cooling	72-09-03	CFM
CFM56-5C	X		337-099-008-0	Manifold Assy, Cooling	72-09-03	CFM
CFM56-5C	X		337-099-009-0	Manifold Assy, Cooling	72-09-03	CFM
CFM56-5C	X		337-099-010-0	Manifold Assy, Cooling	72-09-03	CFM
CFM56-5C	X		337-099-107-0	Manifold Assy, Cooling	72-09-03	CFM
CFM56-5C	X		337-099-108-0	Manifold Assy, Cooling	72-09-03	CFM
CFM56-5C	X		337-099-109-0	Manifold Assy, Cooling	72-09-03	CFM
CFM56-5C	X		337-099-110-0	Manifold Assy, Cooling	72-09-03	CFM
CFM56-5C	X		337-099-901-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-100-804-0	Mount, Accessory Drive Clevis	72-23-15	CFM
CFM56-5C	X	X	337-103-501-0	Retainer, Blade LPT Rtr Stage 1	72-54-19	CFM
CFM56-5C	X	X	337-103-521-0	Retainer, Blade LPT Stage 2	72-54-19	CFM
CFM56-5C	X	X	337-103-541-0	Retainer, Blade	72-54-19	CFM
CFM56-5C	X	X	337-103-561-0	Retainer, LPT Stage 4	72-54-19	CFM
CFM56-5C	X		337-107-401-0	Bracket	72-09-04	CFM
CFM56-5C	X	X	337-107-402-0	Shroud, Support Turbine	72-54-04	CFM
CFM56-5C	X		337-109-501-0	Support, Assy No. 2 Bearing	72-22-03	CFM
CFM56-5C	X		337-110-303-0	Manifold, Air	72-09-03	CFM
CFM56-5C	X		337-112-101-0	Mount Assy, Shock Top	72-23-17	CFM
CFM56-5C	X		337-112-201-0	Mount Assy, Shock Top	72-23-17	CFM
CFM56-5C	X		337-113-201-0	Tube, Guide Speed Sensor No. 1	72-09-03	CFM
CFM56-5C	X		337-113-601-0	Tube, Guide	72-09-03	CFM
CFM56-5C	X		337-114-602-0	Tube, Guide	72-09-03	CFM
CFM56-5C	X		337-115-002-0	Tube, Supply Oil	72-09-03	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5C	X		337-115-052-0	Tube, Supply Oil	72-09-03	CFM
CFM56-5C	X		337-116-101-0	Tube, Drain No. 3 Bearing	72-09-03	CFM
CFM56-5C	X		337-116-401-0	Tube, Oil to IGB	72-09-03	CFM
CFM56-5C	X		337-123-501-0	Tube, Oil	72-09-03	CFM
CFM56-5C	X		337-124-601-0	Shaft, Plug LPT	72-55-16	CFM
CFM56-5C	X		337-128-601-0	Tube, Manifold	72-23-21	CFM
CFM56-5C	X		337-128-801-0	Tube, Manifold	72-23-21	CFM
CFM56-5C	X		337-129-301-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-129-402-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-129-502-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-129-602-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-129-701-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-129-802-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-130-503-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-130-602-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-130-803-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-131-202-0	Tube, Stage 5 Bleed	72-09-03	CFM
CFM56-5C	X		337-131-501-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-131-502-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-131-701-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-131-805-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-132-203-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-132-204-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-133-504-0	Tube Assy, Air PS12	72-09-03	CFM
CFM56-5C	X		337-133-505-0	Tube Assy, Air PS12	72-09-03	CFM
CFM56-5C	X		337-133-602-0	Tube Assy, Air PS13	72-09-03	CFM
CFM56-5C	X		337-133-603-0	Tube Assy, Air PS13	72-09-03	CFM
CFM56-5C	X		337-133-702-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-133-703-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-138-401-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-138-605-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-138-801-0	Tube, Fuel Inlet	72-09-03	CFM
CFM56-5C	X		337-138-802-0	Tube, Fuel Inlet	72-09-03	CFM
CFM56-5C	X		337-149-201-0	Scoop Assy	72-23-36	CFM
CFM56-5C	X		337-149-301-0	Scoop Assy	72-23-36	CFM
CFM56-5C	X		337-150-302-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-152-001-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-152-201-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-152-503-0	Tube, Drain Fan Case Water	72-09-03	CFM
CFM56-5C	X		337-152-905-0	Tube, Oil Scavenge Rear Sump	72-09-03	CFM
CFM56-5C	X		337-154-401-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-154-403-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-155-001-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-155-104-0	Tube, Star Bleed Valve Stage 5	72-09-03	CFM
CFM56-5C	X		337-155-601-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-155-701-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-155-702-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-156-002-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-156-401-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-156-501-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-157-501-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-157-601-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-157-701-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-157-901-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-158-003-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-158-005-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-158-401-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-158-501-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-161-201-0	Slide	72-23-37	CFM
CFM56-5C	X		337-161-202-0	Slide	72-23-37	CFM
CFM56-5C	X		337-161-210-0	Slide	72-23-37	CFM
CFM56-5C	X		337-161-211-0	Slide	72-23-37	CFM
CFM56-5C	X		337-161-301-0	Slide	72-23-37	CFM
CFM56-5C	X		337-161-302-0	Slide	72-23-37	CFM
CFM56-5C	X		337-161-310-0	Slide	72-23-37	CFM
CFM56-5C	X		337-161-311-0	Slide	72-23-37	CFM
CFM56-5C	X		337-161-401-0	Slide	72-23-37	CFM
CFM56-5C	X		337-161-402-0	Slide	72-23-37	CFM
CFM56-5C	X		337-161-410-0	Slide	72-23-37	CFM
CFM56-5C	X		337-161-411-0	Slide	72-23-37	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5C	X		337-164-201-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-164-301-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-165-002-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-165-401-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-165-403-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-165-801-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-165-802-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-166-003-0	Fitting	72-09-04	CFM
CFM56-5C	X		337-166-701-0	Box	72-09-04	CFM
CFM56-5C	X	X	337-166-702-0	Box	72-09-04	CFM
CFM56-5C	X	X	337-167-801-0	Tube, Oil Scavenge Rear Sump	72-09-03	CFM
CFM56-5C	X		337-168-001-0	Tube, Oil Supply Rear Sump	72-09-03	CFM
CFM56-5C	X		337-168-201-0	Tube, Oil Supply Rear Sump	72-09-03	CFM
CFM56-5C	X	X	337-168-202-0	Tube, Oil Supply Rear Sump	72-09-03	CFM
CFM56-5C	X		337-168-402-0	Tube, Oil Supply Rear Sump	72-09-03	CFM
CFM56-5C	X		337-168-403-0	Tube, Oil Supply Rear Sump	72-09-03	CFM
CFM56-5C	X		337-169-102-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-169-202-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-169-302-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-169-402-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-170-305-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-170-310-0	Bracket	72-09-04	CFM
CFM56-5C	X	X	337-171-001-0	Tube, EGT Probe	72-09-03	CFM
CFM56-5C	X	X	337-171-201-0	Tube, EGT Probe	72-09-03	CFM
CFM56-5C	X	X	337-171-401-0	Tube, EGT Probe	72-09-03	CFM
CFM56-5C	X		337-171-806-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-171-810-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-176-101-0	Scoop Assy	72-23-36	CFM
CFM56-5C	X		337-176-201-0	Scoop Assy	72-23-36	CFM
CFM56-5C	X		337-178-810-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-179-301-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-179-501-0	Tube, Oil Drain Rear Sump	72-09-03	CFM
CFM56-5C	X		337-179-504-0	Tube, Oil Drain Rear Sump	72-09-03	CFM
CFM56-5C	X		337-179-505-0	Tube, Oil Drain Rear Sump	72-09-03	CFM
CFM56-5C	X		337-179-601-0	Tube, Oil Drain Rear Sump	72-09-03	CFM
CFM56-5C	X		337-179-603-0	Tube, Oil Drain Rear Sump	72-09-03	CFM
CFM56-5C	X		337-179-810-0	Box, Collector	72-09-04	CFM
CFM56-5C	X		337-180-701-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-182-001-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-182-201-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-185-603-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-185-604-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-185-702-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-186-003-0	Hose, Fuel	72-09-03	CFM
CFM56-5C	X	X	337-186-053-0	Hose, Fuel	72-09-03	CFM
CFM56-5C	X		337-186-202-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-186-801-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-187-304-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-187-504-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-187-701-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-187-805-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-188-101-0	Bracket	72-09-04	CFM
CFM56-5C	X	X	337-188-502-0	Hose, Fuel Inlet Exchanger IDG	72-09-03	CFM
CFM56-5C	X		337-189-001-0	Bracket	72-09-04	CFM
CFM56-5C	X		337-220-401-0	Shield, LPT Stator Shrd Stage 1	72-54-20	CFM
CFM56-5C	X		340-7005-504	Link Assy-Null	71-21-12	CFM
CFM56-5C	X		340-8511-503-0	Tube Assy, Drain	72-09-03	CFM
CFM56-5C	X		340-8511-505-0	Tube Assy, Drain	72-09-03	CFM
CFM56-5C	X		340-8515-503	Tube Assy, HP Sense	72-09-03	CFM
CFM56-5C	X		340-8515-505	Tube Assy, HP Sense	72-09-03	CFM
CFM56-5C	X		340-8612-504	Tube Assy	71-00-18, 72-09-03	CFM
CFM56-5C	X		340-8612-505	Tube Assy	72-09-03	CFM
CFM56-5C	X		340-8612-506	Tube Assy	72-09-03	CFM
CFM56-5C	X		340-8701-515	Tube Assy, (PPK)	71-00-18	ROHR
CFM56-5C	X		340-8701-517	Tube Assy, (PPK)	71-00-18	ROHR
CFM56-5C	X		340-8701-519	Tube Assy, (PPK)	71-00-18	ROHR
CFM56-5C	X		340-8701-521	Tube Assy, (PPK)	71-00-18	ROHR
CFM56-5C	X		340-8701-523	Tube Assy, (PPK)	71-00-18	ROHR
CFM56-5C	X		340-8701-525	Tube Assy, (PPK)	71-00-18	ROHR
CFM56-5C	X		340-8801-501	Tube	71-00-18	ROHR

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-5C	X		340-8801-505	Tube, Drain	71-00-18	ROHR
CFM56-5C	X		340-8801-507	Tube, Drain	71-00-18	ROHR
CFM56-5C	X		340-8801-509	Tube, Drain	71-00-18	ROHR
CFM56-5C	X		340-8801-513	Tube, Drain	71-00-18	ROHR
CFM56-5C	X		340-8801-515	Tube, Drain	71-00-18	ROHR
CFM56-5C	X		340-8801-525	Tube, Drain	71-00-18	ROHR
CFM56-5C	X		340-8801-533	Tube, Drain	71-00-18	ROHR
CFM56-5C	X		340-8801-535	Tube, Drain	71-00-18	ROHR
CFM56-5C	X		340-8801-537	Tube	71-00-18	ROHR
CFM56-5C	X		340-8801-539	Tube	71-00-18	ROHR
CFM56-5C	X		340-8801-541	Tube, Drain	71-00-18	ROHR
CFM56-5C	X		340-8801-543	Tube	71-00-18	ROHR
CFM56-5C	X		340-8801-547	Tube, Drain	71-00-18	ROHR
CFM56-5C	X		340-8801-549	Tube	71-00-18	ROHR
CFM56-5C	X		340-8801-551	Tube	71-00-18	ROHR
CFM56-5C	X		340-8801-553	Tube, Drain	71-00-18	ROHR
CFM56-5C	X		340-8801-555	Tube, Drain	71-00-18	ROHR
CFM56-5C	X		340-8801-557	Tube	71-00-18	ROHR
CFM56-5C	X		340-8801-559	Tube, Drain	71-00-18	ROHR
CFM56-5C	X		340-8801-561	Tube, Drain	71-00-18	ROHR
CFM56-5C	X		340-8801-563	Tube, Drain	71-00-18	ROHR
CFM56-5C	X		340-8801-565	Tube, Drain	71-00-18	ROHR
CFM56-5C	X		340-8801-567	Tube, Drain	71-00-18	ROHR
CFM56-5C	X		340-8801-569	Tube	71-00-18	ROHR
CFM56-5C	X		340-8801-571	Tube, Drain	71-00-18	ROHR
CFM56-5C	X		340-8801-573	Tube, Drain	71-00-18	ROHR
CFM56-5C	X		340-8801-575	Tube, Drain	71-00-18	ROHR
CFM56-5C	X		340-8801-577	Tube, Drain	71-00-18	ROHR
CFM56-5C	X		340-8801-579	Tube, Drain	71-00-18	ROHR
CFM56-5C	X		340-8926-503	Tube Assy, Null	72-09-03	CFM
CFM56-5C	X	X	649-410-040-0	Clamp	72-09-04	CFM
CFM56-5C	X	X	649-410-510-0	Clamp	72-09-04	CFM
CFM56-5C	X		649-430-029-0	Hose, PS13	72-09-03	CFM
CFM56-5C	X		649-430-059-0	Hose, PS13	72-09-03	CFM
CFM56-5C	X		649-430-060-0	Hose, PS3	72-09-03	CFM
CFM56-5C	X		649-430-061-0	Hose, Supply Oil Pump	72-09-03	CFM
CFM56-5C	X		649-430-080-0	Hose, PS3	72-09-03	CFM
CFM56-5C	X		649-430-081-0	Hose, Supply Oil Pump	72-09-03	CFM
CFM56-5C	X		649-430-110-0	Hose, Oil Vent Tank	72-09-03	CFM
CFM56-5C	X		649-430-140-0	Hose, Oil Vent Tank	72-09-03	CFM
CFM56-5C	X		649-430-215-0	Hose, Flexible PS12	72-09-03	CFM
CFM56-5C	X		649-430-245-0	Hose, Flexible PS12	72-09-03	CFM
CFM56-5C	X		649-430-501-0	Hose, Oil Exchange Heater	72-09-03	CFM
CFM56-5C	X		649-430-531-0	Hose, Oil Exchange Heater	72-09-03	CFM
CFM56-5C	X		649-432-017-0	Hose, Oil Rear Sump	72-09-03	CFM
CFM56-5C	X		649-432-060-0	Hose, PS3	72-09-03	CFM
CFM56-5C	X		649-432-061-0	Hose, Supply Oil Pump	72-09-03	CFM
CFM56-5C	X		649-432-067-0	Hose, Oil Forward Sump Supply	72-09-03	CFM
CFM56-5C	X		649-432-071-0	Hose, Return Fuel Oil Heater Exchange	72-09-03	CFM
CFM56-5C	X		649-432-114-0	Hose, Fuel Inlet Exchanger IDG	72-09-03	CFM
CFM56-5C	X		649-432-215-0	Hose, Flexible PS12	72-09-03	CFM
CFM56-5C	X		649-432-219-0	Tube, Fuel Outlet Exchanger IDG	72-09-03	CFM
CFM56-5C	X		649-432-220-0	Tube, Fuel CLP	72-09-03	CFM
CFM56-5C	X		649-432-501-0	Hose, Oil Exchange Heater	72-09-03	CFM
CFM56-5C	X	X	9393M46G07	Manifold, Drain VSV	72-09-03	CFM
CFM56-5C, 7B	X	X	337-005-118-0	Cone, Spinner Front	72-21-05	CFM
CFM56-5C, 7B	X		337-138-303-0	Bracket	72-09-04	CFM
CFM56-7B	X		16135-84	Hose	71-00-04	ROHR
CFM56-7B	X		1867M38G01	Tube, DR VSV Right Side	72-09-03	CFM
CFM56-7B	X		1867M39G01	Tube, DR VBV Left Side	72-09-03	CFM
CFM56-7B	X	X	1867M43G01	Manifold, Fuel	72-09-03	CFM
CFM56-7B	X		1867M44G01	Bracket	72-09-04	CFM
CFM56-7B	X	X	1867M45G01	Bracket	72-09-04	CFM
CFM56-7B	X	X	1867M49G01	Bracket	72-09-04	CFM
CFM56-7B	X	X	1867M57G01	Manifold, Drain VSV Right Side	72-41-04	CFM
CFM56-7B	X		1867M58G01	Bracket	72-09-04	CFM
CFM56-7B	X		1867M59G01	Bracket	72-09-04	CFM
CFM56-7B	X		1867M60G01	Bracket	72-09-04	CFM
CFM56-7B	X		1867M61G01	Bracket	72-09-04	CFM
CFM56-7B	X		1867M62G01	Bracket	72-09-04	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-7B	X	X	1867M63G01	Manifold, Fuel	72-41-04	CFM
CFM56-7B	X	X	1867M64G01	Manifold, Fuel	72-41-04	CFM
CFM56-7B	X	X	1867M67G01	Manifold	72-09-03	CFM
CFM56-7B	X	X	1867M68G01	Manifold, Fuel Supply	72-09-03	CFM
CFM56-7B	X		1867M71G01	Manifold, Drain Lower	72-09-03	CFM
CFM56-7B	X		1867M72G01	Bracket	72-09-04	CFM
CFM56-7B	X		1867M73G01	Bracket	72-09-04	CFM
CFM56-7B	X		1867M77G01	Bracket	72-09-04	CFM
CFM56-7B	X		1867M78G01	Bracket	72-09-04	CFM
CFM56-7B	X		1867M79G01	Bracket	72-09-04	CFM
CFM56-7B	X		1867M80G01	Bracket	72-09-04	CFM
CFM56-7B	X		1867M81G01	Bracket	72-09-04	CFM
CFM56-7B	X		1867M82G01	Bracket	72-09-04	CFM
CFM56-7B	X		1867M83G01	Bracket	72-09-04	CFM
CFM56-7B	X		1867M84G01	Bracket	72-09-04	CFM
CFM56-7B	X		1867M86G01	Bracket	72-09-04	CFM
CFM56-7B	X		1870M12G01	Bracket	72-09-04	CFM
CFM56-7B	X		1870M22G01	Bracket	72-09-04	CFM
CFM56-7B	X	X	1870M24G01	Tube, Oil Supply	72-09-03	CFM
CFM56-7B	X		1870M26P01	Shield, Spray	72-09-04	CFM
CFM56-7B	X		1870M27G01	Manifold, Fuel VBV	72-09-03	CFM
CFM56-7B	X	X	1870M28G01	Manifold, Variable Stator Fuel	72-09-03	CFM
CFM56-7B	X		1870M29G01	Bracket	72-09-04	CFM
CFM56-7B	X		1870M30G01	Bracket	72-09-04	CFM
CFM56-7B	X		1870M31P001A	Bracket	72-09-04	CFM
CFM56-7B	X		1870M32G01	Manifold, Fuel Rod End	72-09-03	CFM
CFM56-7B	X		1870M33G01	Bracket	72-09-04	CFM
CFM56-7B	X		1870M34G01	Bracket	72-09-04	CFM
CFM56-7B	X		1870M37G01	Bracket	72-09-04	CFM
CFM56-7B	X		1870M38G01	Manifold, Fuel Distribution	72-09-03	CFM
CFM56-7B	X		1870M44G01	Tube, Air Transient Bleed	72-09-03	CFM
CFM56-7B	X		1870M45G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-7B	X	X	1870M46G01	Manifold, Drain VSV Left Side	72-09-03	CFM
CFM56-7B	X		1870M48G01	Bracket	72-09-04	CFM
CFM56-7B	X		1870M49G01	Bracket	72-09-04	CFM
CFM56-7B	X	X	1870M53G01	Tube, Oil Scavenge	72-09-03	CFM
CFM56-7B	X		1870M57G01	Manifold, Fuel Transient Bleed Valve	72-09-03	CFM
CFM56-7B	X		1870M58G01	Bracket	72-09-04	CFM
CFM56-7B	X		1870M59P001A	Bracket	72-09-04	CFM
CFM56-7B	X		1870M60G01	Tube, Air Ignition Lead Cooling	72-09-03	CFM
CFM56-7B	X		1870M61G01	Tube, Drain Transient BI V	72-09-03	CFM
CFM56-7B	X		1870M63G01	Bracket	72-09-04	CFM
CFM56-7B	X		1870M64G01	Bracket	72-09-04	CFM
CFM56-7B	X		1870M65G01	Bracket	72-09-04	CFM
CFM56-7B	X		1870M69G01	Bracket	72-09-04	CFM
CFM56-7B	X	X	1870M70G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-7B	X	X	1870M71G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-7B	X	X	1870M72G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-7B	X	X	1870M73G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-7B	X		1870M75G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-7B	X		1870M77G01	Bracket	72-09-04	CFM
CFM56-7B	X		1870M78G01	Bracket	72-09-04	CFM
CFM56-7B	X	X	1870M83G01	Bracket	72-09-04	CFM
CFM56-7B	X		1870M84P01	Bracket	72-09-04	CFM
CFM56-7B	X		1870M85G01	Bracket	72-09-04	CFM
CFM56-7B	X		1870M86G01	Manifold, Fuel Supply	72-09-03	CFM
CFM56-7B	X		1870M87G01	Bracket	72-09-04	CFM
CFM56-7B	X		1870M87P01	Bracket	72-09-04	CFM
CFM56-7B	X	X	1870M89P01	Bracket	72-09-04	CFM
CFM56-7B	X	X	1870M90G01	Tube, Air Transient Bleed	72-09-03	CFM
CFM56-7B	X		1870M91G01	Bracket	72-09-04	CFM
CFM56-7B	X	X	1870M97G01	Manifold, Fuel Transient Bleed Valve	72-09-03	CFM
CFM56-7B	X	X	1870M98G01	Manifold, Fuel VBV	72-09-03	CFM
CFM56-7B	X		1882M61G03	Manifold, Fuel	72-41-04, 72-09-03	CFM
CFM56-7B	X	X	1882M61G04	Manifold	72-41-04	CFM
CFM56-7B	X		1882M68G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-7B	X		1882M70G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-7B	X		1882M72G01	Tube, Air LPT Cooling	72-09-03	CFM
CFM56-7B	X		1882M74G01	Tube, Air LPT Cooling	72-09-03	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-7B	X	X	1882M76G01	Manifold, Air TCC	72-09-03	CFM
CFM56-7B	X		1882M78G01	Tube, Air TCC 9th Stage	72-09-03	CFM
CFM56-7B	X		1882M83G01	Tube, Oil Supply	72-09-03	CFM
CFM56-7B	X		1882M86G01	Tube, P25	72-09-03	CFM
CFM56-7B	X		1882M88G01	Tube, Air Ignition Lead Cooling	72-09-03	CFM
CFM56-7B	X	X	1882M92G01	Manifold, Fuel	72-09-03	CFM
CFM56-7B	X	X	1882M94G01	Manifold, Fuel	72-09-03	CFM
CFM56-7B	X		1894M11G01	Bracket	72-09-04	CFM
CFM56-7B	X		1894M12G01	Bracket	72-09-04	CFM
CFM56-7B	X		1894M15G01	Bracket	72-09-04	CFM
CFM56-7B	X		1894M16G01	Bracket	72-09-04	CFM
CFM56-7B	X		1894M19G01	Bracket	72-09-04	CFM
CFM56-7B	X		1894M21G01	Bracket	72-09-04	CFM
CFM56-7B	X		1894M22G01	Bracket	72-09-04	CFM
CFM56-7B	X		1894M28G01	Bracket	72-09-04	CFM
CFM56-7B	X		1894M36G01	Bracket	72-09-04	CFM
CFM56-7B	X		1894M37G01	Bracket	72-09-04	CFM
CFM56-7B	X		1894M39G01	Bracket	72-09-04	CFM
CFM56-7B	X		1894M42G01	Bracket	72-09-04	CFM
CFM56-7B	X		1894M43G01	Bracket	72-09-04	CFM
CFM56-7B	X		1894M44G01	Bracket	72-09-04	CFM
CFM56-7B	X		1894M45G01	Bracket, Harness	72-09-04	CFM
CFM56-7B	X		1894M46G01	Bracket	72-09-04	CFM
CFM56-7B	X		1894M47P001A	Bracket	72-09-04	CFM
CFM56-7B	X		1894M50G01	Bracket	72-09-04	CFM
CFM56-7B	X		1894M54G01	Bracket	72-09-04	CFM
CFM56-7B	X		1894M55G01	Bracket	72-09-04	CFM
CFM56-7B	X		1894M56G01	Bracket	72-09-04	CFM
CFM56-7B	X		1894M60G01	Bracket	72-09-04	CFM
CFM56-7B	X		1894M63P001A	Bracket	72-09-04	CFM
CFM56-7B	X		1894M65G01	Bracket	72-09-04	CFM
CFM56-7B	X		1894M66G01	Bracket, Manifold	72-09-04	CFM
CFM56-7B	X		1894M67G01	Bracket	72-09-04	CFM
CFM56-7B	X		1894M72P001A	Bracket	72-09-04	CFM
CFM56-7B	X	X	1894M76G01	Bracket	72-09-04	CFM
CFM56-7B	X		1894M79G01	Bracket	72-09-04	CFM
CFM56-7B	X		1894M80G01	Bracket, Harness J10	72-09-04	CFM
CFM56-7B	X		1894M84G01	Bracket	72-09-04	CFM
CFM56-7B	X		1894M86G01	Bracket	72-09-04	CFM
CFM56-7B	X		1894M87G01	Bracket	72-09-04	CFM
CFM56-7B	X		1894M88G01	Bracket	72-09-04	CFM
CFM56-7B	X		1894M90G01	Bracket	72-09-04	CFM
CFM56-7B	X		1894M91G01	Bracket	72-09-04	CFM
CFM56-7B	X		1894M92G01	Bracket	72-09-04	CFM
CFM56-7B	X		1894M94G01	Bracket	72-09-04	CFM
CFM56-7B	X		1894M95G01	Bracket	72-09-04	CFM
CFM56-7B	X		1894M96G01	Bracket	72-09-04	CFM
CFM56-7B	X		1895M51G01	Bracket	72-09-04	CFM
CFM56-7B	X		1895M65G01	Manifold, Drain Lower	72-09-03	CFM
CFM56-7B	X		1895M74G01	Tube, Drain Transient BI V	72-09-03	CFM
CFM56-7B	X		1895M79G01	Bracket	72-09-04	CFM
CFM56-7B	X		1895M84G01	Bracket	72-09-04	CFM
CFM56-7B	X		1895M85G01	Bracket	72-09-04	CFM
CFM56-7B	X		1895M86G01	Bracket	72-09-04	CFM
CFM56-7B	X		1895M89G01	Bracket	72-09-04	CFM
CFM56-7B	X		1895M90G01	Bracket, Harness	72-09-04	CFM
CFM56-7B	X	X	1896M46G01	Manifold, Fuel	72-09-03	CFM
CFM56-7B	X		1896M47G01	Manifold, Fuel HPTCC Valve	72-09-03	CFM
CFM56-7B	X		1896M49G01	Bracket	72-09-04	CFM
CFM56-7B	X	X	1896M53G01	Bracket	72-09-04	CFM
CFM56-7B	X	X	1896M60G01	Tube, DR LPTACC V	72-09-03	CFM
CFM56-7B	X		1896M69G01	Manifold, Air 9th Stage	72-09-03	CFM
CFM56-7B	X		1898M12G01	Manifold, Drain VSV Right Side	72-09-03	CFM
CFM56-7B	X		1898M13G01	Tube, DR VSV Right Side Upper	72-09-03	CFM
CFM56-7B	X		1898M18G01	Manifold, BMV and LPTACC V Drain	72-09-03	CFM
CFM56-7B	X		1898M19G01	Tube, DR LPTACC V	72-09-03	CFM
CFM56-7B	X		1898M35G01	Tube	72-09-03	CFM
CFM56-7B	X		1898M38G01	Tube, Fuel PC	72-09-03	CFM
CFM56-7B	X		1898M57G01	Tube, Drain VBV Right Side	72-09-03	CFM
CFM56-7B	X	X	1898M58G01	Manifold, Drain Upper	72-09-03	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-7B	X		1898M59G01	Tube, Drain Transient BI V	72-09-03	CFM
CFM56-7B	X		1898M60P001A	Bracket	72-09-04	CFM
CFM56-7B	X		1898M61G01	Bracket	72-09-04	CFM
CFM56-7B	X		1898M62G01	Bracket	72-09-04	CFM
CFM56-7B	X		1898M64G01	Bracket	72-09-04	CFM
CFM56-7B	X		1898M66G01	Bracket	72-09-04	CFM
CFM56-7B	X		1898M68G01	Bracket	72-09-04	CFM
CFM56-7B	X		1898M69G01	Bracket	72-09-04	CFM
CFM56-7B	X		1898M80G01	Bracket	72-09-04	CFM
CFM56-7B	X		1898M82G01	Bracket	72-09-04	CFM
CFM56-7B	X		1898M86G01	Bracket	72-09-04	CFM
CFM56-7B	X		1898M98G01	Bracket, Harness	72-09-04	CFM
CFM56-7B	X		1958M12G01	Bracket	72-09-04	CFM
CFM56-7B	X		1958M13G01	Bracket	72-09-04	CFM
CFM56-7B	X	X	1958M20P01	Deflector	72-09-04	CFM
CFM56-7B	X		1958M24G01	Bracket	72-09-04	CFM
CFM56-7B	X		1958M25G01	Manifold, Drain Lower	72-09-03	CFM
CFM56-7B	X		1958M29G01	Tube, Oil Supply	72-09-03	CFM
CFM56-7B	X		1958M30G01	Bracket, Harness	72-09-04	CFM
CFM56-7B	X		1958M31G01	Bracket	72-09-04	CFM
CFM56-7B	X		1958M32G01	Bracket	72-09-04	CFM
CFM56-7B	X		1958M34G01	Bracket	72-09-04	CFM
CFM56-7B	X		1958M35G01	Tube, DR VBV Left Side	72-09-03	CFM
CFM56-7B	X		1958M37G01	Bracket	72-09-04	CFM
CFM56-7B	X		1958M40G01	Bracket	72-09-04	CFM
CFM56-7B	X		1958M44G01	Bracket	72-09-04	CFM
CFM56-7B	X		1958M50G01	Bracket	72-09-04	CFM
CFM56-7B	X		1958M51G01	Bracket	72-09-04	CFM
CFM56-7B	X		1958M52G01	Bracket	72-09-04	CFM
CFM56-7B	X		1958M53G01	Bracket	72-09-04	CFM
CFM56-7B	X		1958M55G01	Bracket	72-09-04	CFM
CFM56-7B	X	X	1958M57G01	Tube, Oil Scavenge	72-09-03	CFM
CFM56-7B	X	X	1958M58G01	Tube, Oil Scavenge	72-09-03	CFM
CFM56-7B	X		1958M59G01	Bracket	72-09-04	CFM
CFM56-7B	X		1958M60G01	Bracket	72-09-04	CFM
CFM56-7B	X		1958M64G01	Bracket	72-09-04	CFM
CFM56-7B	X		1958M69G01	Tube, Drain VBV Right Side	72-09-03	CFM
CFM56-7B	X		1958M70G01	Manifold, BMV and LPTACC V Drain	72-09-03	CFM
CFM56-7B	X		1958M71G01	Tube, DR LPTACC V	72-09-03	CFM
CFM56-7B	X		1958M76G01	Bracket	72-09-04	CFM
CFM56-7B	X		1958M77G01	Bracket	72-09-04	CFM
CFM56-7B	X		1969M13G01	Bracket	72-09-04	CFM
CFM56-7B	X		1969M14G01	Bracket	72-09-04	CFM
CFM56-7B	X		1969M15G01	Bracket	72-09-04	CFM
CFM56-7B	X		1969M24G01	Bracket	72-09-04	CFM
CFM56-7B	X		1969M26G01	Bracket	72-09-04	CFM
CFM56-7B	X		1969M27G01	Bracket, Tube LPT Cooling	72-09-04	CFM
CFM56-7B	X		1969M30G01	Bracket	72-09-04	CFM
CFM56-7B	X		1969M39G01	Bracket	72-09-04	CFM
CFM56-7B	X		1969M68G01	Manifold, Drain Upper	72-09-03	CFM
CFM56-7B	X		1969M74G01	Tube, Drain VBV Right Side	72-09-03	CFM
CFM56-7B	X		1969M77G01	Manifold, Burner Selection V Drain	72-09-03	CFM
CFM56-7B	X		1969M78G01	Tube, DR LPTACC V	72-09-03	CFM
CFM56-7B	X		1969M80G01	Manifold, Fuel Burner	72-09-03	CFM
CFM56-7B	X		1969M83G01	Tube, Air PS3 Signal	72-09-03	CFM
CFM56-7B	X		1969M85G01	Tube, Air Transient Bleed	72-09-03	CFM
CFM56-7B	X		1969M90G01	Bracket	72-09-04	CFM
CFM56-7B	X		1969M91G01	Bracket	72-09-04	CFM
CFM56-7B	X		1969M92G01	Bracket	72-09-04	CFM
CFM56-7B	X		1970M10G01	Bracket	72-09-04	CFM
CFM56-7B	X		1970M11P001A	Bracket	72-09-04	CFM
CFM56-7B	X		1970M13P01	Bracket	72-09-04	CFM
CFM56-7B	X		1970M17G01	Bracket	72-09-04	CFM
CFM56-7B	X		1970M21G01	Tube, Air PS3 Signal	72-09-03	CFM
CFM56-7B	X		1970M27G01	Bracket	72-09-04	CFM
CFM56-7B	X		1970M28G01	Bracket	72-09-04	CFM
CFM56-7B	X		1970M36G01	Manifold, Air 9th Stage	72-09-03	CFM
CFM56-7B	X		1970M37G01	Manifold, Drain VSV Left Side	72-09-03	CFM
CFM56-7B	X		1970M38G01	Bracket	72-09-04	CFM
CFM56-7B	X		1970M45G01	Bracket	72-09-04	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-7B	X		1970M50G01	Bracket	72-09-04	CFM
CFM56-7B	X		1970M51G01	Bracket	72-09-04	CFM
CFM56-7B	X		1970M52P001A	Bracket	72-09-04	CFM
CFM56-7B	X		1970M53P001A	Bracket	72-09-04	CFM
CFM56-7B	X		1970M57G01	Bracket	72-09-04	CFM
CFM56-7B	X		1970M63G01	Tube, Oil Supply	72-09-03	CFM
CFM56-7B	X		1970M68G01	Bracket	72-09-04	CFM
CFM56-7B	X		1970M70G01	Bracket	72-09-04	CFM
CFM56-7B	X		1970M71G01	Bracket	72-09-04	CFM
CFM56-7B	X		1970M76G01	Bracket	72-09-04	CFM
CFM56-7B	X		1970M84G01	Bracket	72-09-04	CFM
CFM56-7B	X		1970M85G01	Bracket	72-09-04	CFM
CFM56-7B	X		1970M88G01	Tube, DR HPTCC Valve	72-09-03	CFM
CFM56-7B	X	X	1970M89G01	Tube, DR VSV Right Side	72-09-03	CFM
CFM56-7B	X	X	1970M90G01	Bracket	72-09-04	CFM
CFM56-7B	X	X	1970M91G01	Shield	72-09-04	CFM
CFM56-7B	X		1970M93G01	Tube, DR HPTCC Valve	72-09-03	CFM
CFM56-7B	X		1970M94G01	Bracket	72-09-04	CFM
CFM56-7B	X		1970M95G01	Bracket	72-09-04	CFM
CFM56-7B	X		1970M98G01	Bracket	72-09-04	CFM
CFM56-7B	X		1970M99G01	Bracket	72-09-04	CFM
CFM56-7B	X		1971M27G01	Tube, Oil Supply	72-09-03	CFM
CFM56-7B	X		1971M28G01	Tube, Oil Supply	72-09-03	CFM
CFM56-7B	X		1971M47G01	Bracket	72-09-04	CFM
CFM56-7B	X		1971M49G01	Tube, Air PS3 Signal	72-09-03	CFM
CFM56-7B	X	X	1971M63G01	Manifold, Fuel Right Side	72-09-03, 72-41-04	CFM
CFM56-7B	X		1971M63G02	Manifold, Fuel Left Side	72-09-03, 72-41-04	CFM
CFM56-7B	X		1971M79G01	Bracket	72-09-04	CFM
CFM56-7B	X	X	1971M90G01	Manifold, Drain Lower	72-09-03	CFM
CFM56-7B	X	X	2046M11G01	Tube, Air PS3 Signal	72-09-03	CFM
CFM56-7B	X		2046M14G01	Manifold, Drain Upper	72-09-03	CFM
CFM56-7B	X		2046M15G01	Manifold, Drain Upper	72-09-03	CFM
CFM56-7B	X	X	2046M16G01	Tube, DR VBV Left Side	72-09-03	CFM
CFM56-7B	X	X	2046M17G01	Tube, Air PS3 Signal	72-09-03	CFM
CFM56-7B	X		2046M32G01	Tube, Air PS3 Signal	72-09-03	CFM
CFM56-7B	X	X	2046M55G01	Manifold, Air 9th Stage	72-09-03	CFM
CFM56-7B	X		2174M15G01	Bracket	72-09-04	CFM
CFM56-7B	X	X	2174M19G01	Manifold, Fuel VBV	72-09-03	CFM
CFM56-7B	X		2174M24P01	Bracket	72-09-04	CFM
CFM56-7B	X		2174M45G01	Bracket	72-09-04	CFM
CFM56-7B	X		2174M46G01	Bracket	72-09-04	CFM
CFM56-7B	X		2174M47G01	Bracket	72-09-04	CFM
CFM56-7B	X		2174M48G01	Bracket	72-09-04	CFM
CFM56-7B	X		2174M49G01	Bracket	72-09-04	CFM
CFM56-7B	X		2174M50G01	Bracket	72-09-04	CFM
CFM56-7B	X		2174M51G01	Bracket	72-09-04	CFM
CFM56-7B	X		2174M52G01	Bracket	72-09-04	CFM
CFM56-7B	X		2174M53G01	Bracket	72-09-04	CFM
CFM56-7B	X		2174M54G01	Bracket	72-09-04	CFM
CFM56-7B	X		2174M56G01	Bracket	72-09-04	CFM
CFM56-7B	X		2174M57G01	Bracket	72-09-04	CFM
CFM56-7B	X		2174M58G01	Bracket	72-09-04	CFM
CFM56-7B	X		2174M59G01	Bracket	72-09-04	CFM
CFM56-7B	X		2175M10G01	Bracket	72-09-04	CFM
CFM56-7B	X		2175M34G01	Bracket	72-09-04	CFM
CFM56-7B	X		2175M38G01	Bracket	72-09-04	CFM
CFM56-7B	X	X	2175M39G01	Manifold	72-09-03	GE
CFM56-7B	X	X	2175M40G01	Manifold	72-09-03	CFM
CFM56-7B	X	X	2175M42G01	Manifold, Fuel VBV	72-09-03	CFM
CFM56-7B	X		2175M63G01	Bracket	72-09-04	CFM
CFM56-7B	X		2175M84G01	Bracket	72-09-04	CFM
CFM56-7B	X		2283M10G01	Bracket	72-09-04	CFM
CFM56-7B	X		2283M75G01	Bracket	72-09-04	CFM
CFM56-7B	X		2418M80G01	Bracket	72-09-04	CFM
CFM56-7B	X	X	2557M30G01	Bracket	72-09-04	CFM
CFM56-7B	X	X	2557M32G01	Tube	72-09-03	CFM
CFM56-7B	X		332A2240-1	Tube Assy	71-00-04	Boeing
CFM56-7B	X		332A2240-10	Tube	71-00-04	Boeing
CFM56-7B	X		332A2240-11	Tube	71-00-04	Boeing
CFM56-7B	X		332A2240-2	Tube Assy	71-00-04	ROHR

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-7B	X		332A2240-4	Tube Assy	71-00-04	Boeing
CFM56-7B	X		332A2310-4	Duct, Assy	CMM 36-10-03	Boeing
CFM56-7B	X		332A2321-10	Duct	36-10-03	CFM
CFM56-7B	X		332A2350-1	Tube Assy	71-00-04	Boeing
CFM56-7B	X		332A2350-11	Tube	71-00-04	Boeing
CFM56-7B	X		332A2350-12	Tube	71-00-04	Boeing
CFM56-7B	X		332A2350-13	Tube	71-00-04	Boeing
CFM56-7B	X		332A2350-14	Tube Assy	71-00-04	Boeing
CFM56-7B	X		332A2350-4	Tube	71-00-04	Boeing
CFM56-7B	X		332A2350-5	Tube	71-00-04	Boeing
CFM56-7B	X		332A2350-7	Tube	71-00-04	Boeing
CFM56-7B	X		332A2350-9	Tube	71-00-04	Boeing
CFM56-7B	X		332A2371-3	Inlet Assy, 12 O'Clock Strut	CMM 36-12-07	Boeing
CFM56-7B	X		332A2390-3	Duct, Assembly	71-00-04	Boeing
CFM56-7B	X		332A2390-43	Duct, Assy	CMM 36-10-03	Boeing
CFM56-7B	X		332A2390-45	Duct Assy, CTAI	CMM 36-10-03	Boeing
CFM56-7B	X		332A2410-1	Tube Assy	71-00-04	Boeing
CFM56-7B	X		332A2710-1	Line, Drain	71-00-04	Boeing
CFM56-7B	X		332A2710-11	Tube Assy	71-00-04	CFM
CFM56-7B	X		332A2710-13	Tube	71-00-04	Boeing
CFM56-7B	X		332A2710-15	Tube	71-00-04	Boeing
CFM56-7B	X		332A2710-27	Tube	71-00-04	Boeing
CFM56-7B	X		332A2710-3	Tube Assy	71-00-04	CFM
CFM56-7B	X		332A2710-31	Tube Assy	71-00-04	Boeing
CFM56-7B	X		332A2710-32	Tube Assy	71-00-04	Boeing
CFM56-7B	X		332A2710-33	Tube Assy	71-00-04	Boeing
CFM56-7B	X		332A2710-36	Tube Assy	71-00-04	Boeing
CFM56-7B	X		332A2710-38	Tube Assy	71-00-04	Boeing
CFM56-7B	X		332A2710-5	Tube	71-00-04	Boeing
CFM56-7B	X		332A2910-1	Bracket	71-00-04	Boeing
CFM56-7B	X		332A2910-136	Bracket	71-00-04	Boeing
CFM56-7B	X		332A2910-24	Bracket	71-00-04	Boeing
CFM56-7B	X		332A2910-41	Bracket	71-00-04	Boeing
CFM56-7B	X		332A2911-5	Bracket	71-00-04	Boeing
CFM56-7B	X		332A2911-9	Bracket	71-00-04	Boeing
CFM56-7B	X		332A2920-122	Bracket	71-00-04	Boeing
CFM56-7B	X		332A2920-147	Bracket Assy	71-00-04	Boeing
CFM56-7B	X		332A2920-178	Bracket	71-00-04	Boeing
CFM56-7B	X		332A2920-179	Bracket	71-00-04	Boeing
CFM56-7B	X		332A2920-193	Bracket	71-00-04	Boeing
CFM56-7B	X		332A2920-197	Bracket	71-00-04	Boeing
CFM56-7B	X		332A2920-201	Bracket	71-00-04	Boeing
CFM56-7B	X		332A2920-223	Bracket Assy	71-00-04	Boeing
CFM56-7B	X		332A2920-26	Bracket	71-00-04	Boeing
CFM56-7B	X		332A2920-92	Bracket	71-00-04	Boeing
CFM56-7B	X		332A2930-1	Bracket	71-00-04	Boeing
CFM56-7B	X		332A2930-104	Bracket	71-00-02	Boeing
CFM56-7B	X		332A2930-11	Bracket	71-00-04	Boeing
CFM56-7B	X		332A2930-17	Bracket	71-00-04	Boeing
CFM56-7B	X		332A2930-61	Bracket	71-00-04	ROHR
CFM56-7B	X		332A2930-62	Bracket	71-00-04	Boeing
CFM56-7B	X		332A2930-7	Bracket	71-00-04	Boeing
CFM56-7B	X		332A2930-83	Bracket	71-00-04	Boeing
CFM56-7B	X		335-191-202-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-7B	X		335-191-203-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-7B	X		335-191-204-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-7B	X		335-191-205-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-7B	X		335-191-302-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-7B	X		335-191-303-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-7B	X		335-191-304-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-7B	X		335-191-305-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-7B	X		335-295-702-0	Spool, Outer Sealing	79-21-16, 79-21-59	CFM
CFM56-7B	X	X	340-000-205-0	Cone, Spinner Rear	72-21-05	CFM
CFM56-7B	X		340-000-815-0	Booster Spools	72-21-04	CFM
CFM56-7B	X	X	340-000-816-0	Spool, Booster	72-21-04	CFM
CFM56-7B	X		340-000-824-0	Spool, Booster	72-21-04	CFM
CFM56-7B	X		340-000-825-0	Spool, Booster	72-21-04	CFM
CFM56-7B	X	X	340-000-826-0	Spool, Booster	72-21-04	CFM
CFM56-7B	X		340-001-215-0	Spacer	72-21-10	CFM
CFM56-7B	X		340-001-216-0	Spacer	72-21-10	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-7B	X		340-001-217-0	Spacer	72-21-20	CFM
CFM56-7B	X	X	340-001-261-0	Spacer, Fan Blade	72-21-10	CFM
CFM56-7B	X	X	340-001-262-0	Spacer, Fan Blade	72-21-10	CFM
CFM56-7B	X		340-001-804-0	Platform, Fan Blade	72-21-20	CFM
CFM56-7B	X		340-001-805-0	Platform, Fan Blade	72-21-20	CFM
CFM56-7B	X		340-001-806-0	Platform, Fan Blade	72-21-20	CFM
CFM56-7B	X		340-001-814-0	Platform, Fan Blade	72-21-20	CFM
CFM56-7B	X	X	340-001-816-0	Platform, Fan Blade	72-21-20	CFM
CFM56-7B	X	X	340-001-817-0	Platform, Fan Blade	72-21-20	CFM
CFM56-7B	X	X	340-002-305-0	OGV	72-23-03	CFM
CFM56-7B	X		340-005-002-0	Tube, Air PT25	72-09-03	CFM
CFM56-7B	X		340-005-103-0	Tube, Air PS3	72-09-03	CFM
CFM56-7B	X		340-005-104-0	Tube, Air PS3	72-09-03	CFM
CFM56-7B	X		340-005-105-0	Tube, Air PS3	72-09-03	CFM
CFM56-7B	X		340-006-004-0	Tube, Air PT25	72-09-03	CFM
CFM56-7B	X	X	340-006-005-0	Tube, Air PT25	72-09-03	CFM
CFM56-7B	X		340-006-102-0	Tube, Air PS3	72-09-03	CFM
CFM56-7B	X		340-006-103-0	Tube, Air PS3	72-09-03	CFM
CFM56-7B	X		340-006-104-0	Tube, Air PS3	72-09-03	CFM
CFM56-7B	X	X	340-007-005-0	Tube, Oil Scavenge	72-09-03	CFM
CFM56-7B	X		340-007-007-0	Tube, Oil Scavenge	72-09-03	CFM
CFM56-7B	X		340-007-008-0	Tube, Oil	72-09-03	CFM
CFM56-7B	X	X	340-007-102-0	Tube, Fuel Return	72-09-03	CFM
CFM56-7B	X		340-007-107-0	Tube, Fuel Return	72-09-03	CFM
CFM56-7B	X		340-007-110-0	Tube, Fuel Return	72-09-03	CFM
CFM56-7B	X		340-007-114-0	Tube, Fuel Return	72-09-03	CFM
CFM56-7B	X	X	340-007-203-0	Tube, Fuel Supply	72-09-03	CFM
CFM56-7B	X		340-007-304-0	Bracket	72-23-35	CFM
CFM56-7B	X		340-007-404-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-008-302-0	Tube, Fuel (Servo)	72-09-03	CFM
CFM56-7B	X	X	340-008-504-0	Tube, Oil Return	72-09-03	CFM
CFM56-7B	X		340-008-703-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-008-704-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-008-801-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-008-904-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-009-003-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-009-004-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-009-202-0	Tube, Oil Return	72-09-03	CFM
CFM56-7B	X		340-009-204-0	Tube, Oil Return	72-09-03	CFM
CFM56-7B	X	X	340-009-303-0	Tube, Oil Return	72-09-03	CFM
CFM56-7B	X		340-009-305-0	Tube, Oil Return	72-09-03	CFM
CFM56-7B	X	X	340-009-401-0	Tube, Oil Return	72-09-03	CFM
CFM56-7B	X		340-009-502-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-009-503-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-009-602-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-009-604-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-009-701-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-009-702-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-010-201-0	Tube, Fuel VBV (Rod)	72-09-03	CFM
CFM56-7B	X		340-010-401-0	Tube, Fuel VSV (Head)	72-09-03	CFM
CFM56-7B	X	X	340-010-402-0	Tube, Fuel VSV	72-09-03	CFM
CFM56-7B	X	X	340-010-603-0	Tube, Fuel FSU (TBV)	72-09-03	CFM
CFM56-7B	X	X	340-010-801-0	Tube, Fuel VBV (Head)	72-09-03	CFM
CFM56-7B	X	X	340-011-001-0	Tube, Fuel VSV (Rod)	72-09-03	CFM
CFM56-7B	X	X	340-011-202-0	Tube, Fuel FSU (HPT)	72-09-03	CFM
CFM56-7B	X		340-011-401-0	Tube, Fuel VSV (PC Stage)	72-09-03	CFM
CFM56-7B	X		340-011-402-0	Tube, Fuel VSV (PC Stage)	72-09-03	CFM
CFM56-7B	X		340-011-601-0	Tube, Fuel FSU (PCR)	72-09-03	CFM
CFM56-7B	X		340-011-803-0	Tube, Fuel FSU (LPTACC)	72-09-03	CFM
CFM56-7B	X	X	340-011-804-0	Tube, Fuel FSU (LPTACC)	72-09-03	CFM
CFM56-7B	X		340-012-002-0	Tube, Fuel FSV	72-09-03	CFM
CFM56-7B	X		340-012-202-0	Tube, Fuel FSV	72-09-03	CFM
CFM56-7B	X		340-012-402-0	Tube, Fuel FSU (PCR)	72-09-03	CFM
CFM56-7B	X	X	340-012-602-0	Tube, Fuel (PC Stage)	72-09-03	CFM
CFM56-7B	X	X	340-012-802-0	Tube, Fuel Supply	72-09-03	CFM
CFM56-7B	X		340-012-807-0	Tube, Fuel Supply	72-09-03	CFM
CFM56-7B	X		340-013-004-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-013-005-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-013-402-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-013-703-0	Bracket	72-09-04	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-7B	X		340-014-006-0	Tube, Oil Supply	72-09-03	CFM
CFM56-7B	X	X	340-014-007-0	Tube, Oil Supply	72-09-03	CFM
CFM56-7B	X		340-014-202-0	Tube, Oil	72-09-03	CFM
CFM56-7B	X		340-014-203-0	Tube, Oil	72-09-03	CFM
CFM56-7B	X		340-014-405-0	Tube, Fuel FSV	72-09-03	CFM
CFM56-7B	X	X	340-014-406-0	Tube, Fuel FSV	72-09-03	CFM
CFM56-7B	X		340-014-407-0	Tube, Fuel FSV	72-09-03	CFM
CFM56-7B	X		340-014-457-0	Tube, Fuel FSV	72-09-03	CFM
CFM56-7B	X	X	340-014-602-0	Tube, Fuel FSV	72-09-03	CFM
CFM56-7B	X		340-015-004-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-015-103-0	Tube, Oil Supply	72-09-03	CFM
CFM56-7B	X	X	340-015-302-0	Tube, Oil Return	72-09-03	CFM
CFM56-7B	X		340-015-801-0	Hose, Oil Return	72-09-03	CFM
CFM56-7B	X		340-015-802-0	Hose, Oil Return	72-09-03	CFM
CFM56-7B	X		340-015-851-0	Hose, Oil Return	72-09-03	CFM
CFM56-7B	X		340-015-852-0	Hose, Oil Return	72-09-03	CFM
CFM56-7B	X		340-015-906-0	Tube, Hose Oil	72-09-03	CFM
CFM56-7B	X	X	340-015-956-0	Tube, Hose Oil	72-09-03	CFM
CFM56-7B	X		340-016-002-0	Hose, Oil Supply (Valve Anti Sphn)	72-09-03	CFM
CFM56-7B	X	X	340-016-003-0	Hose, Oil Supply	72-09-03	CFM
CFM56-7B	X		340-016-052-0	Hose, Oil Supply (Valve Anti Sphn)	72-09-03	CFM
CFM56-7B	X	X	340-016-053-0	Hose, Oil Supply	72-09-03	CFM
CFM56-7B	X		340-016-101-0	Tube, Hose Fuel (VBV, Rod)	72-09-03	CFM
CFM56-7B	X	X	340-016-151-0	Tube, Hose Fuel (VBV, Rod)	72-09-03	CFM
CFM56-7B	X	X	340-016-201-0	Tube, Hose Fuel	72-09-03	CFM
CFM56-7B	X	X	340-016-251-0	Tube, Hose Fuel	72-09-03	CFM
CFM56-7B	X		340-016-402-0	Tube, Hose Fuel	72-09-03	CFM
CFM56-7B	X	X	340-016-452-0	Tube, Hose Fuel	72-09-03	CFM
CFM56-7B	X		340-016-602-0	Tube, Hose FSV	72-09-03	CFM
CFM56-7B	X		340-016-603-0	Tube, Hose FSV	72-09-03	CFM
CFM56-7B	X	X	340-016-652-0	Tube, Hose FSV	72-09-03	CFM
CFM56-7B	X		340-016-653-0	Tube, Hose FSV	72-09-03	CFM
CFM56-7B	X		340-016-701-0	Tube, Hose Fuel (VBV, Head)	72-09-03	CFM
CFM56-7B	X	X	340-016-751-0	Tube, Hose Fuel (VBV, Head)	72-09-03	CFM
CFM56-7B	X	X	340-016-802-0	Tube, Hose Oil	72-09-03	CFM
CFM56-7B	X		340-016-803-0	Tube, Hose Oil	72-09-03	CFM
CFM56-7B	X		340-016-805-0	Tube, Hose Oil	72-09-03	CFM
CFM56-7B	X		340-016-806-0	Tube, Hose Oil	72-09-03	CFM
CFM56-7B	X	X	340-016-852-0	Tube, Hose Oil	72-09-03	CFM
CFM56-7B	X		340-016-853-0	Tube, Hose Oil	72-09-03	CFM
CFM56-7B	X		340-016-855-0	Tube, Hose Oil	72-09-03	CFM
CFM56-7B	X		340-016-856-0	Tube, Hose Oil	72-09-03	CFM
CFM56-7B	X		340-016-901-0	Tube, Hose Fuel FSV	72-09-03	CFM
CFM56-7B	X		340-016-951-0	Tube, Hose Fuel FSV	72-09-03	CFM
CFM56-7B	X		340-017-002-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-017-101-0	Tube, Hose FSV	72-09-03	CFM
CFM56-7B	X		340-017-201-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-017-306-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-017-307-0	Bracket	72-09-04	CFM
CFM56-7B	X	X	340-017-402-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-017-501-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-017-502-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-017-601-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-017-602-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-017-804-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-017-805-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-018-102-0	Tube, Hose FSV	72-09-03	CFM
CFM56-7B	X	X	340-018-103-0	Tube, Fuel FSV (Discharge)	72-09-03	CFM
CFM56-7B	X		340-018-104-0	Tube, Fuel FSV	72-09-03	CFM
CFM56-7B	X		340-018-905-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-018-906-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-019-002-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-019-003-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-019-106-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-019-702-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-019-802-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-019-903-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-019-905-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-020-001-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-020-002-0	Bracket	72-09-04	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-7B	X		340-020-105-0	Bracket	72-23-35	CFM
CFM56-7B	X		340-020-106-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-020-203-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-020-204-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-020-205-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-020-206-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-020-303-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-020-304-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-020-308-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-020-404-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-020-405-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-020-408-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-020-501-0	Tube, Air PT25	72-09-03	CFM
CFM56-7B	X		340-020-502-0	Tube, Air PT25	72-09-03	CFM
CFM56-7B	X		340-020-902-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-021-002-0	Tube, Fuel Supply	72-09-03	CFM
CFM56-7B	X		340-021-003-0	Tube, Fuel Supply	72-09-03	CFM
CFM56-7B	X	X	340-021-004-0	Tube, Fuel Supply	72-09-03	CFM
CFM56-7B	X		340-021-801-0	Tube, Air	72-09-03	CFM
CFM56-7B	X	X	340-021-802-0	Tube, Air	72-09-03	CFM
CFM56-7B	X	X	340-021-803-0	Tube, Air	72-09-03	CFM
CFM56-7B	X		340-021-852-0	Tube, Air	72-09-03	CFM
CFM56-7B	X		340-021-853-0	Tube, Air	72-09-03	CFM
CFM56-7B	X	X	340-022-003-0	Tube, Oil IGB	72-09-03	CFM
CFM56-7B	X	X	340-022-201-0	Tube, Oil Supply	72-09-03	CFM
CFM56-7B	X		340-022-501-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-022-502-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-022-503-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-022-901-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-023-102-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-023-202-0	Tube, Hose PS13	72-09-03	CFM
CFM56-7B	X		340-023-301-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-023-302-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-023-404-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-023-405-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-023-502-0	Tube, Oil Supply	72-09-03	CFM
CFM56-7B	X		340-023-503-0	Tube, Oil Supply	72-09-03	CFM
CFM56-7B	X		340-023-506-0	Tube, Oil Supply	72-09-03	CFM
CFM56-7B	X	X	340-023-507-0	Tube, Oil Supply	72-09-03	CFM
CFM56-7B	X		340-023-508-0	Tube, Oil Supply	72-09-03	CFM
CFM56-7B	X		340-025-402-0	Bracket	72-23-35	CFM
CFM56-7B	X		340-025-404-0	Bracket	72-09-04	CFM
CFM56-7B	X	X	340-025-405-0	Bracket	72-23-35	CFM
CFM56-7B	X		340-025-406-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-025-503-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-025-504-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-026-302-0	Tube, Oil Bearing 2	72-22-07	CFM
CFM56-7B	X	X	340-026-402-0	Tube, Oil Supply	72-23-18	CFM
CFM56-7B	X		340-026-502-0	Tube, Drain	72-09-03	CFM
CFM56-7B	X	X	340-026-602-0	Tube, Pressurizing Bearing 1	72-09-03	CFM
CFM56-7B	X	X	340-027-051-0	Sleeve, Sensor No. 1	72-22-17	CFM
CFM56-7B	X	X	340-027-602-0	Manifold, Air	72-54-18	CFM
CFM56-7B	X	X	340-027-603-0	Manifold, Air	72-54-18	CFM
CFM56-7B	X		340-027-604-0	Manifold, Air	72-09-03	CFM
CFM56-7B	X	X	340-030-601-0	Nozzle, Oil	72-23-18	CFM
CFM56-7B	X		340-031-802-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-032-102-0	Tube, Drain Bearing 3	72-09-03	CFM
CFM56-7B	X	X	340-032-401-0	Tube, Pressurizing Air	72-23-26	CFM
CFM56-7B	X	X	340-032-801-0	Link Assy, Mount AGB	72-23-14	CFM
CFM56-7B	No		340-034-102-0	Nozzle, Oil	72-09-02	CFM
CFM56-7B	X	X	340-034-202-0	Tube, Oil Return Bearing No.1	72-09-03	CFM
CFM56-7B	X	X	340-034-402-0	Tube, Oil IGB	72-09-03	CFM
CFM56-7B	X	X	340-034-701-0	Wheel, Speed Sensor	72-22-15	CFM
CFM56-7B	X		340-035-401-0	Support, Assy No. 2 Bearing	72-22-03	CFM
CFM56-7B	X		340-035-403-0	Support, Assy No. 1 Bearing	72-22-02	CFM
CFM56-7B	X		340-046-106-0	Pin, Threaded	72-21-19	CFM
CFM56-7B	X		340-047-802-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-048-602-0	Pad Assy, Filter Adapter	72-63-02	CFM
CFM56-7B	X	X	340-049-001-0	Fork	72-63-12	CFM
CFM56-7B	X	X	340-049-101-0	Fork	72-63-12	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-7B	X		340-050-004-0	Shaft, Support Guide Radial	72-23-05	CFM
CFM56-7B	X	X	340-050-102-0	Shaft, Radial Drive	72-62-06	CFM
CFM56-7B	X	X	340-050-103-0	Shaft, Outer Radial Drive	72-23-06	CFM
CFM56-7B	X		340-051-201-0	Tube	72-62-07	CFM
CFM56-7B	X		340-054-801-0	Shaft, Radial Drive	72-23-06	CFM
CFM56-7B	X		340-054-802-0	Shaft, Radial Drive	72-23-06	CFM
CFM56-7B	X		340-055-202-0	Gearshaft, 61X31 Tooth	72-63-03	CFM
CFM56-7B	X		340-055-602-0	Pad Assy, Drive Lubr Unit	72-63-02	CFM
CFM56-7B	X	X	340-057-201-0	Blade, Stage 2	72-21-02	CFM
CFM56-7B	X	X	340-057-202-0	Blade, Stage 2	72-21-02	CFM
CFM56-7B	X	X	340-057-203-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-7B	X	X	340-057-204-0	Blade, Booster Stg 2	72-21-02	CFM
CFM56-7B	X	X	340-057-301-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-7B	X	X	340-057-302-0	Blade, Stage 3	72-21-02	CFM
CFM56-7B	X	X	340-057-303-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-7B	X	X	340-057-304-0	Blade, Booster Stg 3	72-21-02	CFM
CFM56-7B	X	X	340-057-401-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-7B	X	X	340-057-402-0	Blade, Stage 4	72-21-02	CFM
CFM56-7B	X	X	340-057-403-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-7B	X	X	340-057-404-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-7B	X	X	340-057-409-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-7B	X	X	340-057-410-0	Blade, Booster Stg 4	72-21-02	CFM
CFM56-7B	X		340-064-303-0	Shroud, Pad 10	72-23-33	CFM
CFM56-7B	X	X	340-064-307-0	Pad, Shroud 10	72-23-32	CFM
CFM56-7B	X	X	340-064-701-0	Plate, FRS	72-23-21	CFM
CFM56-7B	X		340-065-604-0	Clamp Assy	72-23-33	CFM
CFM56-7B	X	X	340-065-605-0	Clamp Assy	72-23-33	CFM
CFM56-7B	X	X	340-065-803-0	Pad, Mating	72-23-33	CFM
CFM56-7B	X		340-066-105-0	Pad, Shroud	72-23-32	CFM
CFM56-7B	X	X	340-066-106-0	Pad, Shroud 4	72-23-32	CFM
CFM56-7B	X	X	340-066-604-0	Support, Harness	72-23-21	CFM
CFM56-7B	X	X	340-066-704-0	Support, Harness	72-23-21	CFM
CFM56-7B	X		340-067-405-0	Clamp Assy	72-23-33	CFM
CFM56-7B	X	X	340-067-406-0	Clamp Assy	72-23-33	CFM
CFM56-7B	X	X	340-067-702-0	Pad, Mating	72-23-33	CFM
CFM56-7B	X		340-067-806-0	Shroud, Pad 7	72-23-32	CFM
CFM56-7B	X		340-068-302-0	Plate, Fairing	72-23-33	CFM
CFM56-7B	X		340-068-402-0	Plate, Fairing	72-23-33	CFM
CFM56-7B	X	X	340-068-503-0	Plate, Fairing	72-23-33	CFM
CFM56-7B	X		340-068-603-0	Plate, Fairing	72-23-33	CFM
CFM56-7B	X	X	340-068-702-0	Pad, Mating	72-23-33	CFM
CFM56-7B	X	X	340-068-802-0	Pad, Mating	72-23-33	CFM
CFM56-7B	X	X	340-069-703-0	Clamp Assy	72-23-33	CFM
CFM56-7B	X	X	340-074-505-0	VBV, Hinge	72-23-16	CFM
CFM56-7B	X		340-075-702-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X		340-075-703-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X	X	340-075-705-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X		340-075-802-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X		340-075-803-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X	X	340-075-805-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X		340-075-902-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X		340-075-903-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X	X	340-075-905-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X		340-075-953-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X		340-076-002-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X		340-076-003-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X	X	340-076-005-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X		340-076-102-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X		340-076-103-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X	X	340-076-105-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X		340-076-153-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X		340-076-202-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X		340-076-203-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X	X	340-076-205-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X		340-076-253-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X		340-076-302-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X		340-076-303-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X	X	340-076-305-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X		340-076-402-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X		340-076-403-0	Panel, Strut	72-23-07	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-7B	X	X	340-076-405-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X		340-076-502-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X		340-076-503-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X	X	340-076-505-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X		340-076-553-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X		340-076-602-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X		340-076-603-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X	X	340-076-605-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X		340-076-702-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X		340-076-703-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X	X	340-076-705-0	Panel, Strut	72-23-07	CFM
CFM56-7B	X		340-077-601-0	Mount, Ax Load	72-23-15	CFM
CFM56-7B	X	X	340-077-702-0	Pin Assy, Straight	72-63-18	CFM
CFM56-7B	X		340-077-802-0	Pin Assy, Straight	72-63-18	CFM
CFM56-7B	X	X	340-077-903-0	Pin Assy, Straight	72-63-18	CFM
CFM56-7B	X		340-078-002-0	Pin Assy, Straight	72-63-18	CFM
CFM56-7B	X	X	340-079-204-0	Rod, Actuator	72-23-16	CFM
CFM56-7B	X	X	340-079-603-0	Pad Guide	72-21-23	CFM
CFM56-7B	X	X	340-079-604-0	Pad, Guide	72-21-23	CFM
CFM56-7B	X	X	340-082-501-0	Panel, Acoustical	72-23-08	CFM
CFM56-7B	X		340-082-503-0	Panel, Acoustical	72-23-08	CFM
CFM56-7B	X		340-082-504-0	Panel, Acoustical	72-23-08	CFM
CFM56-7B	X		340-082-505-0	Panel, Acoustical	72-23-08	CFM
CFM56-7B	X		340-082-506-0	Panel, Acoustical	72-23-08	CFM
CFM56-7B	X		340-082-507-0	Panel, Acoustical	72-23-08	CFM
CFM56-7B	X		340-082-602-0	Strut, Profile	72-23-09	CFM
CFM56-7B	X	X	340-082-702-0	Strut, Profile	72-23-09	CFM
CFM56-7B	X		340-082-802-0	Strut, Profile	72-23-09	CFM
CFM56-7B	X	X	340-082-902-0	Strut, Profile	72-23-09	CFM
CFM56-7B	X		340-083-002-0	Strut, Profile	72-23-09	CFM
CFM56-7B	X	X	340-083-102-0	Strut, Profile	72-23-09	CFM
CFM56-7B	X		340-083-203-0	Strut, Profile	72-23-09	CFM
CFM56-7B	X		340-083-302-0	Strut, Profile	72-23-09	CFM
CFM56-7B	X	X	340-083-402-0	Strut, Profile	72-23-09	CFM
CFM56-7B	X	X	340-084-201-0	Panel, Acoustical Assy	72-23-08	CFM
CFM56-7B	X	X	340-084-302-0	Panel, Acoustical	72-23-08	CFM
CFM56-7B	X	X	340-085-401-0	Turnbuckle, VBV	72-23-16	CFM
CFM56-7B	X	X	340-085-402-0	Turnbuckle	72-23-16	CFM
CFM56-7B	X	X	340-085-902-0	Pin Assy, Straight	72-63-18	CFM
CFM56-7B	X		340-086-003-0	Mount, Oil Tank	72-23-17	CFM
CFM56-7B	X		340-086-004-0	Mount, Oil Tank	72-23-17	CFM
CFM56-7B	X		340-086-102-0	Mount, Oil Tank	72-23-17	CFM
CFM56-7B	X		340-086-103-0	Mount, Oil Tank	72-23-17	CFM
CFM56-7B	X		340-086-201-0	Mount, Oil Tank	72-23-17	CFM
CFM56-7B	X		340-086-202-0	Mount, Oil Tank	72-23-17	CFM
CFM56-7B	X		340-086-302-0	Mount, Oil Tank	72-23-17	CFM
CFM56-7B	X		340-086-303-0	Mount, Oil Tank	72-23-17	CFM
CFM56-7B	X		340-087-804-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-087-904-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-087-905-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-087-907-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-087-909-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-088-503-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-088-602-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-088-802-0	Tube, Fuel FSV	72-09-03	CFM
CFM56-7B	X	X	340-088-803-0	Tube, Fuel FSV	72-09-03	CFM
CFM56-7B	X		340-088-804-0	Tube, Fuel FSV	72-09-03	CFM
CFM56-7B	X		340-088-901-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-088-903-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-089-001-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-089-106-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-089-107-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-090-301-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-090-303-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-090-304-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-090-306-0	Bracket	72-09-04	CFM
CFM56-7B	X	X	340-090-402-0	Bracket	72-23-35	CFM
CFM56-7B	X		340-090-403-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-090-501-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-090-502-0	Bracket	72-09-04	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-7B	X		340-090-601-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-090-602-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-090-603-0	Bracket	72-23-35	CFMI
CFM56-7B	X		340-090-701-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-090-702-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-090-802-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-090-803-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-090-804-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-090-902-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-091-001-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-091-106-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-091-107-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-091-109-0	Bracket	72-09-04	CFM
CFM56-7B	X	X	340-091-111-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-091-203-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-091-403-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-091-603-0	LPT Air Cool Duct and Manifold	72-54-18	CFM
CFM56-7B	X	X	340-091-604-0	Duct, Air Supply	72-09-03	CFM
CFM56-7B	X	X	340-091-605-0	Duct, Air Supply	72-09-03	CFM
CFM56-7B	X	X	340-091-805-0	Housing, Probe	72-23-35	CFM
CFM56-7B	X		340-091-806-0	Housing, Probe	72-23-35	CFM
CFM56-7B	X		340-091-901-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-092-102-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-093-301-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-093-701-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-094-002-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-095-501-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-095-602-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-095-704-0	Bracket	72-23-35	CFM
CFM56-7B	X		340-095-705-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-096-003-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-096-004-0	Bracket	72-23-35	CFM
CFM56-7B	X		340-096-301-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-097-002-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-097-102-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-097-202-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-097-203-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-097-304-0	Bracket	72-23-35	CFM
CFM56-7B	X		340-097-405-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-097-501-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-097-502-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-097-601-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-097-701-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-097-802-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-099-001-0	Spacer	72-23-35	CFM
CFM56-7B	X		340-099-101-0	Spacer	72-23-35	CFM
CFM56-7B	X		340-099-903-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-103-902-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-104-301-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-104-601-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-104-701-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-104-702-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-104-802-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-104-804-0	Bracket	72-09-04	CFM
CFM56-7B	X	X	340-104-805-0	Bracket	72-09-04	CFMI
CFM56-7B	X	X	340-105-302-0	Hose	72-09-03	CFM
CFM56-7B	X	X	340-105-352-0	Hose	72-09-03	CFM
CFM56-7B	X		340-105-605-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-105-606-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-105-607-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-105-608-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-105-609-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-105-701-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-105-702-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-105-802-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-105-803-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-105-903-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-106-005-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-106-006-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-106-007-0	Bracket	72-09-04	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-7B	X		340-106-203-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-106-204-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-106-302-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-106-402-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-106-403-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-106-504-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-106-602-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-106-603-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-106-704-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-109-305-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-109-601-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-109-602-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-110-801-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-110-902-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-112-113-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-112-114-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-112-117-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-114-301-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-115-303-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-116-001-0	Bracket	72-09-04	CFM
CFM56-7B	X	X	340-116-401-0	Panel, Acoustical	72-23-08	CFM
CFM56-7B	X		340-116-402-0	Panel, Acoustical	72-23-08	CFM
CFM56-7B	X		340-118-303-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-118-702-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-118-703-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-118-704-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-119-303-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-119-401-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-119-501-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-119-602-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-119-701-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-119-803-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-120-501-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-120-601-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-120-602-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-120-702-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-120-803-0	Bracket	72-09-04	CFM
CFM56-7B	X	X	340-120-901-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-120-902-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-121-001-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-121-101-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-121-201-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-121-202-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-121-401-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-121-502-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-121-602-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-121-702-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-121-802-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-122-501-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-122-502-0	Bracket	72-23-35	CFM
CFM56-7B	X		340-123-401-0	Spacer	72-23-35	CFM
CFM56-7B	X		340-123-703-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-123-704-0	Bracket	72-23-35	CFM
CFM56-7B	X		340-123-803-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-123-804-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-123-902-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-123-904-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-124-001-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-124-101-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-124-202-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-124-302-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-124-402-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-124-501-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-124-502-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-124-604-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-124-605-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-124-701-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-124-802-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-124-803-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-125-702-0	Bracket	72-09-04	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-7B	X		340-125-703-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-126-104-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-126-403-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-126-406-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-126-701-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-126-702-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-126-802-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-127-402-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-127-603-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-128-302-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-128-303-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-130-001-0	Bracket	72-09-04	CFM
CFM56-7B	X	X	340-130-401-0	Tube, Hose FADEC	72-09-03	CFM
CFM56-7B	X	X	340-130-501-0	Tube, Oil Suction	72-09-03	CFM
CFM56-7B	X		340-130-701-0	Spacer	72-23-35	CFM
CFM56-7B	X	X	340-130-902-0	Clamp, V Shaped	72-09-04	CFM
CFM56-7B	X		340-131-208-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-131-209-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-131-301-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-131-302-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-132-001-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-132-201-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-134-001-0	Tube, Hose Fuel (PCR)	72-09-03	CFM
CFM56-7B	X		340-134-002-0	Tube, Hose Fuel	72-09-03	CFM
CFM56-7B	X		340-134-051-0	Tube, Hose Fuel (PCR)	72-09-03	CFM
CFM56-7B	X	X	340-134-052-0	Tube, Hose Fuel	72-09-03	CFM
CFM56-7B	X		340-134-101-0	Tube, Hose Fuel (PC Stage)	72-09-03	CFM
CFM56-7B	X		340-134-102-0	Tube, Hose Fuel	72-09-03	CFM
CFM56-7B	X		340-134-151-0	Tube, Hose Fuel (PC Stage)	72-09-03	CFM
CFM56-7B	X		340-134-152-0	Tube, Hose Fuel	72-09-03	CFM
CFM56-7B	X		340-134-302-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-134-501-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-134-601-0	Spacer	72-23-35	CFM
CFM56-7B	X		340-134-702-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-135-302-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-135-303-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-135-701-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-138-201-0	Tube, Oil Drain	72-09-03	CFM
CFM56-7B	X	X	340-138-401-0	Tube, Fuel Supply	72-09-03	CFM
CFM56-7B	X		340-138-402-0	Tube	72-09-03	CFM
CFM56-7B	X	X	340-138-901-0	Tube, Hose	72-09-03	CFM
CFM56-7B	X	X	340-138-951-0	Tube, Hose	72-09-03	CFM
CFM56-7B	X		340-139-102-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-140-102-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-140-502-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-140-503-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-140-902-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-143-501-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-145-501-0	Tube, Oil Supply	72-09-03	CFM
CFM56-7B	X		340-145-701-0	Tube, Oil	72-09-03	CFM
CFM56-7B	X		340-146-401-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-147-601-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-148-601-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-148-702-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-148-802-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-156-901-0	Washer	72-09-04	CFM
CFM56-7B	X		340-157-501-0	Cover	72-56-07	CFM
CFM56-7B	X		340-159-301-0	Nipple	72-09-03	CFM
CFM56-7B	X	X	340-160-402-0	Ring, Retaining Fan	72-21-21	CFM
CFM56-7B	X		340-160-501-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-161-203-0	Support, Tube	72-55-20	CFM
CFM56-7B	X		340-168-101-0	Turnbuckle, AGB	72-23-14	CFM
CFM56-7B	X	X	340-168-701-0	Bellcrank, VBV	72-23-16	CFM
CFM56-7B	X		340-188-301-0	Bracket	72-09-04	CFM
CFM56-7B	X		340-199-701-0	Bracket	72-09-04	CFM
CFM56-7B	X	X	340-200-002-0	Tube, Drain Assy	72-09-03	CFM
CFM56-7B	X		340-251-201-0	Weight	72-21-24	CFM
CFM56-7B	X		340-251-202-0	Weight	72-21-24	CFM
CFM56-7B	X	X	340-304-002-0	Ring	72-54-06	CFM
CFM56-7B	X		340-404-502-0	Detector, DMS	79-21-54	CFM

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
CFM56-7B	X		340-404-503-0	Detector, DMS	79-21-54	CFM
CFM56-7B	X		340-404-601-0	Detector, DMS	79-21-54	CFM
CFM56-7B	X		340-404-602-0	Detector, DMS	79-21-54	CFM
CFM56-7B	X		390-660-201-0	Plug, Identification	73-24-06	CFM
CFM56-7B	X	X	390-660-301-0	Plug, Identification	73-24-06	CFM
CFM56-7B	X	X	390-660-401-0	Plug, Identification	73-24-06	CFM
CFM56-7B	X	X	390-660-501-0	Plug, Identification	73-24-06	CFM
CFM56-7B	X		390-661-301-0	PLUG	73-24-06	CFM
CFM56-7B	X		390-661-501-0	Plug, Identification	73-24-06	CFM
CFM56-7B	X		5024T14G04	Sector, Outlet Guide Vane	72-32-00	CFM
CFM56-7B	X		635E357G01	Turnbuckle Assy	79-11-02	CFM
CFM56-7B	X		649-411-981-0	Clamp	72-09-04	CFM
CFM56-7B	X		649-411-983-0	Clamp	72-09-04	CFM
CFM56-7B	X	X	649-431-650-0	Hose (Oil Vent Tank)	72-09-03	CFM
CFM56-7B	X		649-438-000-0	Hose	72-09-03	CFM
CFM56-7B	X		649-438-002-0	Hose (HPT)	72-09-03	CFM
CFM56-7B	X		649-438-003-0	Hose	72-09-03	CFM
CFM56-7B	X	X	649-438-004-0	Hose (LPTACC)	72-09-03	CFM
CFM56-7B	X	X	649-438-005-0	Hose (VSV, Head)	72-09-03	CFM
CFM56-7B	X	X	649-438-011-0	Hose	72-09-03	CFM
CFM56-7B	X	X	649-438-012-0	Hose	72-09-03	CFM
CFM56-7B	X		649-438-013-0	Hose	72-09-03	CFM
CFM56-7B	X	X	649-438-014-0	Hose	72-09-03	CFM
CFM56-7B	X		649-438-101-0	Hose	72-09-03	CFM
CFM56-7B	X	X	649-438-102-0	Hose	72-09-03	CFM
CFM56-7B	X	X	649-438-200-0	Hose (VSV, Rod)	72-09-03	CFM
CFM56-7B	X	X	649-438-201-0	Hose (TBV)	72-09-03	CFM
CFM56-7B	X	X	649-438-302-0	Hose	72-09-03	CFM
CFM56-7B	X		649-439-000-0	Hose	72-09-03	CFM
CFM56-7B	X		649-439-002-0	Hose (HPT)	72-09-03	CFM
CFM56-7B	X		649-439-003-0	Hose	72-09-03	CFM
CFM56-7B	X		649-439-004-0	Hose (LPTACC)	72-09-03	CFM
CFM56-7B	X	X	649-439-005-0	Hose (VSV, Head)	72-09-03	CFM
CFM56-7B	X		649-439-011-0	Hose	72-09-03	CFM
CFM56-7B	X		649-439-012-0	Hose	72-09-03	CFM
CFM56-7B	X		649-439-013-0	Hose	72-09-03	CFM
CFM56-7B	X		649-439-014-0	Hose	72-09-03	CFM
CFM56-7B	X		649-439-101-0	Hose	72-09-03	CFM
CFM56-7B	X		649-439-102-0	Hose	72-09-03	CFM
CFM56-7B	X		649-439-200-0	Hose (VSV, Rod)	72-09-03	CFM
CFM56-7B	X		649-439-201-0	Hose (TBV)	72-09-03	CFM
CFM56-7B	X	X	649-439-302-0	Hose	72-09-03	CFM
CFM56-7B	X	X	649-781-790-0	Pin, Threaded	72-21-19	CFM
CFM56-7B	X		649-781-791-0	Pin, Threaded	72-21-19	CFM
CFM56-7B	X		649-781-793-0	Pin, Threaded	72-21-19	CFM
CFM56-7B	X	X	649-791-260-0	Clamp	72-09-01	CFM
CFM56-7B	X		94028-30	Link, Left	72-23-14, 72-09-04	CFM
CFM56-7B	X		AE713733-1	Hose-Hydraulic Supply	71-00-04	Boeing
CFM56-7B	X		J952P22A	Screw, Mach Flush Torx Drive	72-55-11	CFM
CFM56-7B	X		2431M83G01	Tube	72-09-03	CFM
CFM56-7B	X		2497M72G01	Bracket	72-09-04	CFM
CFM56-7B	X		2557M31G01	Bracket	72-09-04	CFM
CFM56-7B	X		2557M43G01	Bracket	72-09-04	CFM
CFM56-7B	X		31428-6600	Clamp	72-09-04	CFM
CFM56-7B	X		340-077-602-0	Mount, Ax Load	72-23-15	CFM
CT7-2	X		6039T22G01	Ring, IGV Actuating	72-37-00	GE
CT7-5-7	X		6064T54G0X	Liner, Combustion	72-40-00	GE
GE90	X		1694M53G04	Separator	72-56-22	GE
GE90	X		1763M28G11	Adapter - Control Alternator	72-64-04	GE
GE90	X		1794M83P96	Coupling, V Band	72-09-04	GE
GE90	X		1840M11G01	Bracket Assy	72-09-04	GE
GE90	X		1840M13G01	Bracket, Clevis	72-09-04	GE
GE90	X		1843M27G01	Spacer, Fan Blade	72-21-12	GE
GE90	X		1844M92G01	Bracket Assy	72-09-04	GE
GE90	x		1861M46G01	Bracket, Heatshield	72-09-04	GE
GE90	x		1959M83G01	Manifold, Oil #4 Brg	72-09-03	GE
GE90	x		350-008-424-0	Ring, Actuation Stg 1	72-32-10	GE
GE90	x		350-008-623-0	Ring, Actuation Stg 2	72-32-10	GE
GE90	x		350-008-723-0	Ring, Actuation Stg 3	72-32-10	GE

Engine Model	FAA EASA UK CAA	CAAC	Part No	Description	ATA Chapter	OEM
GE90	X		350-112-654-0	Vane, IGV HPC	72-23-04	GE
GE90	X		350-345-968-0	Shroud, Vane Stg 4	72-32-06	GE
GE90	X		A5252-1	Manifold hose,Fuel VBV	72-09-03	GE
GE90, GE90-100	X		1847M48P01	Ring, Damper	72-53-11	GE
GE90, GE90-100	X		350-017-303-0	Ring, Retaining Stg 3	72-31-18	GE
GE90, GE90-100	X		350-017-405-0	Ring, Retaining Stg 4	72-31-18	GE
GE90, GE90-100	X		350-017-505-0	Ring, Retaining Stg 5	72-31-18	GE
GE90-100	X		1680M93P03	Tube Hose assy	72-09-03	GE
GE90-100	X		1709M15P02	Sleeve	72-53-10	GE
GE90-100	X		1709M18P02	Ring	72-53-11	GE
GE90-100	X		1763M28G13	Cover, Control Alternator Idler	72-62-04	GE
GE90-100	X		1805M22G01	Sleeve, Damper	72-56-19	GE
GE90-100	X		1847M10P01	Shield, Heat	72-53-11	GE
GE90-100	X		1963M10P02	Seal, Rotating Air/Oil No 1	72-26-07	GE
GE90-100	X		1963M23P01	Ring, Piston	72-22-10	GE
GE90-100	X		1995M13P01	Axe, Link Vertical	72-64-08	GE
GE90-100	X		2041M11P01	Clip-Spring	72-26-12	GE
GE90-100	X		2061M77P01	Retainer, nozzle	72-54-19	GE
GE90-100	X		2062M53P01	Retainer, HPT Stg 1 Nozzle	72-40-02	GE
GE90-100	X		2062M53P02	Retainer, HPT stg 1 Nozzle	72-40-02	GE
GE90-100	X		2082M11G01	Support	72-23-26	GE
GE90-100	X		2082M48P02	Retainer	72-54-19	GE
GE90-100	X		2090M35G01	Support	72-23-26	GE
GE90-100	X		2090M36G01	Support	72-23-26	GE
GE90-100	X		2165M23P01	Tube and Hose, Fuel Drain	72-09-03	GE
GE90-100	X		2726M86G01	Bracket, Support	72-09-04	GE
GE90-100	X		351-101-801-0	Ring	72-31-18	GE
GE90-100	X		351-102-001-0	Ring	72-31-18	GE
GE90-100	X		351-112-204-0	Ring, ACTG	72-32-10	GE
GE90-100	X		649-051-071-0	Plug	72-30-20	GE
GE90-100	X		A5408-1	Tube and Hose, Fuel Drain	72-09-03	GE